

PHILLIPS PETROLEUM CO.

MODEL 3-63A

MODEL 3-81A

MODEL 3-63A

Operation: The set operates on 105-125 volts 60 cycles, AC. The power drain is approximately 35 watts on radio operation and 17 watts additional on phonograph operation.

Range: This set has both a broadcast and shortwave range. The complete broadcast band is covered from 532 to 1700 kilocycles. Since the broadcast dial scale is calibrated from 55 to 160, the actual frequency of the station may be obtained by adding zero to the dial calibration. The shortwave band covers from 5.6 to 12.5-megacycles. The shortwave dial scale is calibrated directly in megacycles.

Alignment: No attempt should be made to re-align this receiver until it has been determined that poor tubes or some local condition is not responsible for faulty reception. The signal generator may be connected through 0.01 mfd capacitor used as a dummy antenna, to the lug on the RF section "B" of the tuning capacitor. Connect ground clip of generator directly to chassis. An output meter may be clipped across the voice coil lug on the speaker. Align IF trimmers to 455 kilocycles, using the least possible input in the signal generator. With tuning plates completely out of mesh (pointer at the extreme right end of travel) the set in broadcast position, adjust the

broadcast oscillator trimmer (A) to 1700 kilocycles. Then switch to shortwave and adjust the shortwave oscillator trimmer (D) to 12.5 megacycles. Replace the 01 mfd dummy by a 39 mmfd mica capacitor and connect to antenna terminal "A." Tune set and signal generator to 600 kilocycles and adjust broadcast antenna coil slug for maximum output. Then re-tune set and signal generator to 1550 kilocycles and adjust RF trimmer "B" on tuning capacitor for maximum response. Repeat these adjustments until no further adjustment is required, then switch receiver to shortwave. Tune set and signal generator to 6 megacycles and adjust shortwave antenna coil slug "E" for maximum response. Retune set and signal generator to 10.5 megacycles and tune shortwave antenna, trimmer "C" for maximum response. In these adjustments the tuning control should be rocked for best results. Repeat these adjustments until no further adjustment is needed.

For checking purposes, five marks are engraved on the dial plate. These represent, in order from left to right: the pointer position capacitor plates fully meshed and the pointer settings for 600 kc or 6 mc; 1000-kc, 10.5 mc and 1550 kc.

MODEL 3-81A

Operation: The set operates on 110 to 120 volts, 60 cycles A.C. Power drain is approximately 125 watts for radio and about 20 watts additional for the record changer

Ranges: This receiver has AM broadcast and short-wave and FM ranges:

FM—87.4 to 108.7 megacycles

AM Broadcast—535 to 1720 kilocycles

AM Short-Wave—5.6 to 18.5 megacycles

Instructions For Removing Radio From Cabinet

Main Chassis:

To remove main chassis from the cabinet it is first necessary to remove the four control knobs by pulling them gently until they come off. Remove all plugs from the rear of the main chassis and power pack chassis. Pull the 5U4G rectifier tube out of the power pack chassis. The four screws holding the chassis may now be removed. The chassis itself may now be taken out by sliding it straight back toward the rear of the cabinet.

Power Pack Chassis:

The power pack chassis may be removed from the cabinet by unscrewing the four large screws holding it to its support shelf. These are accessible from the under side of the cabinet.

Record Changer:

Most adjustments may be made to the record changer without removing it from its drawer. Before attempting to remove the record changer from the cabinet the motor plug and the phono pickup plug must first be removed from the main and power pack chassis. Loosen the cable clamps on the rear of the cabinet sufficiently to lift out cables.

Pull changer drawer forward until it hits its stop. Lift the turntable completely off. Be careful not to lose the spring and loose gear on the spindle of the record changer. Remove retaining washers from the mounting screws at the front and rear of the record changer. The mounting screws may now be removed from the bottom of record changer drawer and the record changer may be lifted out.