CIRCUIT CODE RADIOLA MODEL 437-P

Part No.	18621 27526	XA220	BH1
Description	0.05 μF paper 200V working 470 μμF padder ± 2½% 12-445 μμF Tuning 3-25 μμF Tuning 3-25 μμF Tuning 3-25 μμF mica 0.4 μF paper 200V working 47 μμF silvered mica 47 μμF silvered mica 0.05 μF paper 200V working 0.05 μF paper 200V working 47 μμF silvered mica 200 μμF mica 200 μμF mica 200 μμF mica 200 μμF mica 200.25 μF paper 400V working 0.025 μF paper 400V working 25 μF 40 P.V. Electrolytic 0.0025 μF paper 600V working 20 μF 200 P.V. Electrolytic 20 μF 200 P.V. Εlectrolytic 2	Loudspeaker Transformer LOUDSPEAKER	4 inch permanent magnet SWITCH ON/OFF Switch (on R8)
Code No.	22222222222222222222222222222222222222	F	51
Part No.	27534 25145 27324 27324 27530	18621	27526
Description	inductors ioop Aerial Coil Oscillator Coil 1st I.F. Transformer 2nd I.F. Transformer RESISTORS 0.1 megohms ½ " 2.5 megohms ½ " 2.5 megohms ½ " 2.0000 ohms ½ " 2.0000 ohms ¾ " 2.0000 ohms ¾ " 3.2 megohms ¼ " 4.0 megohm ¼ " 8.000 ohms ¾ " 9.25 megohm ¼ " 9.26 megohm ¼ " 9.27 megohm ¼ " 9.28 megohm ¾ " 9.29 megohm ¾ " 9.20 megohm ¾ " 9.40 megohm ¾ " 9.50 megohm ¾ " 9.50 megohm ¾ " 9.50 megohm ¾ "	CAPACITORS 12-445 μμΕ Tuning	3-25 μμF trimmer 70 μμF mica 0.05 μF paper 200V working
Code No.	L1 L2, L3 L4, L5 L6, L7 R1 R2 R3 R8 R8 R8 R8 R8 R8 R8 R8 R8 R8	ū	5882

* Junction of R12 and battery negative to earth.

TECHNICAL INFORMATION AND

SERVICE DATA



Portable Model 437-P

FOUR VALVE, BROADCAST, DRY-CELL BATTERY
OPERATED SUPERHETERODYNE

ISSUED BY

AMALGAMATED WIRELESS (A/SIA) LTD.



ELECTRICAL SPECIFICATIONS.

Frequency Range 540-1	600 Kc/s (555-187.5 metres)
Intermediate Frequency	455 Kc/s
Battery Complement One 7½V,	9V-90V Battery Pack No. 753
Battery Consumption	L.T. 50 mA H.T. 12 mA
Loudspeaker (Permanent Magnet)	4 inch — code No. BH1
Transformer	XA220
V.C. Impedance	3 ohms at 400 C.P.S.
Undistorted Power Output	200 milliwatts

Power Unit Operation:

The receiver may be operated on the following voltage ranges by altering the transformer tappings:

200-215 volts 216-230 volts

231-245 volts

246-260 volts


Power Unit Frequency Range 50-60 C.P.S. and 40 C.P.S.

Valve Complement:

- (1) 1R5 Converter
- (2) 1T4 I.F. Amplifier
- (3) 1S5 Detector, A.F. Amplifier, A.V.C.
- (4) 3V4 Output

Controls:

ON/OFF-Volume Control — left hand end of cabinet. Tuning Control — right hand end of cabinet.



Drive Cord Replacement:

The accompanying diagram shows the route of the cord and the method of attachment.

ALIGNMENT PROCEDURE.

Manufacturer's Setting of Adjustments.

The receiver is tested by the manufacturer with precision instruments and all adjusting screws are sealed. Re-alignment should be necessary only when components in tuned circuits are repaired or replaced, or when it is found that the seals over the adjusting screws are broken.

It is especially important that the adjustments should not be altered, unless in association with the correct testing instruments listed below.

Under no circumstances should the plates of the ganged tuning capacitor be bent, as the unit is accurately aligned

during manufacture and cannot be re-adjusted unless by skilled operators using special equipment.

For all alignment operations, keep the generator output as low as possible to avoid A.V.C. action, and set the volume control in the maximum clockwise position.

Testing Instruments.

- (1) A.W.A. Junior Signal Generator, type 2R3911, or,
- (2) A.W.A. Modulated Oscillator, type J6726. If the modulated oscillator is used, connect a 0.25 megohm non-inductive resistor across the output terminals.
- (3) A.W.A. Output Meter, type 2M8832.

ALIGNMENT TABLE.

Order	Connect "high" side of Generator to:	Tune Generator to:	Tune Receiver to:	Adjust for maximum peak output.
OTE: If loop	leads protruding from the chassi	s are disconnected, cor	nnect a 1 megohm resistor	across them.
. 1	Grid of 174 * (I.F. Amp.) Aerial Section of Gang *	455 Kc/s	Gang in full mesh	L7 and L6 Cores
-	(Drive End)	455 Kc/s	Gang in full mesh	L5 and L4 Cores
instabili The cha	veak valves greater sensitivity ty occurs, however, the alignm assis should now be fitted in th	nent procedure as abo one cabinet, the resistor	ve should be adhered to. r removed from the loop le	ads and the leads then
instabili The cha	ty occurs, however, the alignm assis should now be fitted in the ed to the aerial in the hinged	nent procedure as abo one cabinet, the resistor	ve should be adhered to. r removed from the loop le	ads and the leads then
instabili The cha connect	ty occurs, however, the alignm assis should now be fitted in the ed to the aerial in the hinged	nent procedure as abo one cabinet, the resistor	ve should be adhered to. r removed from the loop le	ads and the leads then
instabili The cha connect battery	ty occurs, however, the alignmassis should now be fitted in the do the aerial in the hinged fitted. Inductively coupled to	nent procedure as abo ne cabinet, the resistor back lid. The battery	ve should be adhered to. r removed from the loop le y must be in place in the 600 Kc/s (approx. 10	ads and the leads then e cabinet or a dummy

^{*} A 0.001 µF capacitor should be connected in series with the high side of the test instrument.

SOCKET VOLTAGES.

Valve	Bias Volts	Screen to Chassis Volts	Anode to Chassis Volts	Anode Current mA	Filament Volts *
5 Converter	0	45	45	0.4	1.3 - 1.4
4 I.F. Amp	0	35	90	1.0	1.3 - 1.4
55 Det., A.F. Amp., A.V.C	0	20†	30†	0.1	1.3 - 1.4
/4 Output	-5	90	88	6.0	2.6 - 2.8

^{*} These will rise to 1.5V and 3.0V with a new battery.


[†] A coil comprising 3 turns of 16 gauge D.C.C. wire and about 6 inches in diameter should be connected between the output terminals of the test instrument, placed co-axial with the loop and distant not less than 1 foot from it.


[§] Rock the tuning control back and forth through the signal.

[‡] These adjustments are accessible through 3 holes in the cabinet back.


[†] Calculated from measured current. An ordinary voltmeter will register a lower value.

Measured with no signal input. Volume Control maximum clockwise.





CHASSIS TOP VIEW MODEL 437-P



CHASSIS UNDERNEATH VIEW MODEL 437-P

NOTE: Owing to substitution, the position of some capacitors may be altered from the layout shown in these chassis views.