



To bypass input xfmr:  
 Disconnect wires at points  
 marked by "X".  
 Install jumpers where indicated  
 by arrows.

D-155846-0

MI-9377-A

MI-9377-A POWER AMPLIFIER  
 SCHEMATIC DIAGRAM