

WIRING INSTRUCTIONS FOR
SP10 POWER TRANSFORMER P/N 60005001

This new universal "all voltage" transformer replaces P/N 60005002, 60005003, 60005009 and 60005010

For 120V Units: Connect white and black/white together to center buss bar on receptacles (AC cord white).
Connect black and black/yellow together to AC switch.

Tie off unused violet and black/red wires.

For 100V Units: Connect white and black/white together to center buss bar on receptacles (AC cord white).
Connect violet and black/red together to AC switch.

Tie off unused black and black/yellow wires.

For 220V Units: Splice and sleeve black and black/white leads together.
Connect white to center buss bar on receptacles (AC cord white).
Connect black/red to AC switch.

Tie off unused black/yellow and violet wires.

For 240V Units: Splice and sleeve black and black/white leads together.
Connect white to center buss bar on receptacles (AC cord white).
Connect black/yellow to AC switch.

Tie off unused black/red and violet wires.