



PLAY-BACK		I	1-7	2-4	2-6	5-8	5-9	14-16	15-19	20-22
SK1										
RECORDING		II	1-3	5-10	11-13	12-14	17-19	18-20	19-21	

Conn	volt adapter
2-2	220 V
4-5	110 V

3104 108 51600

3104 108 51610

3104 106 04162