


**POSIZIONI STOP**

STOP	0	0
Q	↓	0
Δ	0	↓
	SK2	SK3
	24	40a
	26	42b
	25	43
	20b	40b
	20c	44
	22	46
	20d	29
	27	51
	28	21
		50
		53
		55
		57
		58



PHILIPS  
magnetofono EL 3516

