



- * Radio Tuner Section
(All Wave Superheterodyne)
- | | |
|----------------|--------------|
| R.F. | 6K7 |
| 1st Det | 6L7 |
| Oscillator | 6J7 (Triode) |
| Osci Cont. | 6J7 |
| 1st I.F. | 6K7 |
| 2nd I.F. | 6K7 |
| AVC - Det | 6H6 |
| Radio A.F. | 6C5 |
| Tun. Indicator | 6G5 |

R₁: Dynamic Amplifier Control
 R₈: Volume Control
 R₂₂: Fidelity Control
 R₁₂: Expander Bias Control