



- | | |
|-------------------------------|---------------------------|
| S₁ SELECTOR | S₂ MODE |
| (1) TUNER | (1) STEREO REV |
| (2) PHONO | (2) STEREO NORM |
| (3) TAPE | (3) MONO A |
| (4) MIC | (4) MONO B |
| (5) AUX | (5) MONO A+B |

S₃ ----- LOUDNESS
 S₄ ----- POWER