



Fil. Plate Switch  
 Pos. 1-Fil.- AB & DE Are Closed.  
 Pos. 2-Plate- ABC & DEF Are Closed.  
 Pos. 3-OFF- AB & DE Are Open.