



SCHEMATIC OF THE
HEATHKIT®
DIGITAL WIND SPEED/DIRECTION INDICATOR
MODEL ID-1590/ID-1590E

- NOTES:
1. ALL RESISTORS ARE 1/2 WATT, UNLESS MARKED OTHERWISE. VALUES ARE SHOWN IN OHMS (K-1000).
 2. CAPACITOR VALUES ARE SHOWN IN MICROFARADS.
 3. SYMBOLS:
 - - LETTERED CIRCUIT BOARD HOLE.
 - ▽ - CIRCUIT BOARD GROUND.
 4. COMPONENTS ARE NUMBERED ON THE SCHEMATIC IN THE FOLLOWING GROUPS:
 - 1- 10 PARTS ON THE DISPLAY CIRCUIT BOARD.
 - 101-110 PARTS ON THE WIND DIRECTION SENDER CIRCUIT BOARD.
 - 201-225 PARTS ON THE MAIN CIRCUIT BOARD.