



CONTATTI	1	1	4	6	8	9	11	12	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	
GAMMA	2	3	5	7	8	10	11	12	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	
MF																																			
OC																																			
OH																																			
PHONO																																			

SPENTO	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	
SPENTO																																								
FONO																																								
MEDIE																																								
CORTE																																								
MF																																								
HF																																								

Le tensioni riportate in verticale sono relative al funzionamento in MA quelle in corsivo a MF

