



Schalter	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	
K1	X																			
K2		X																		
K3			X																	
M				X																
L					X															
TA						X														



ECH11, EFT1, EL11, EM11 6H6, 6J5, 6SK7 524
Sockelschaltungen

