


1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97



**Wahlbereiche**  
 MAIN BANDS  
 GAMMES D'ONDES  
 GAMME D'ONDE

Band	Frequency Range	Component
LW / 00 / DL	165 - 300 kHz	Ferritkernantenne
MW / PD / DM	530 - 1620 kHz	FERRITE AERIAL
KW / SW / DC	5.95 - 10.0 MHz	ANTENNE FERRITE COMP.
SW / SW / DC	10.0 - 15.0 MHz	ANTENNA DI FERRITA COMP.
TS / FM	15.0 - 30.0 MHz	Wahltransistor
TF / AM	450 - 650 kHz	TRANS. SECTEUR
		TRANSF. DI RETE

**Wahltransistor**  
 MAINS TRANSFORMER  
 TRANS. SECTEUR  
 TRANSF. DI RETE

1 AA 112  
 2 AA 112  
 3 AA 112  
 4 AA 112  
 5 AA 112

1 P1 3...4,7  
 2 P2 3...5,8,10,11  
 3 08647 - 020 97  
 4 08647 - 022 97

**Voltages Measured Without Signal**  
 EN Ug = 7.5 V (BATTERY MINUS)  
 EN MAINS OPERATION 220 V AC

**TENSIONS MESUREES SANS SIGNAL**  
 EN Ug = 7.5 V (A MINUS)  
 EN IN FUSCT SW SECTEUR 220 V-

**TENSIONI MISURATE SENZA SEGNALE**  
 EN Ug = 7.5 V (A VERSO MINUS)  
 EN CON ALIMENTAZIONE DI RETE 220 V-

**Änderungen vorbehalten**  
 ALTERATIONS RESERVEES  
 MODIFICAZIONI RESERVEES  
 CON RISERVA DI MODIFICAZIONI

