



CONTATTI	a	b	c	d	e	f	g	h	k	i	j	l	m	n	o	p	q	r	s	t	u	v	w	x	y	z
FM																										
OM																										
OC1																										
OC2																										
FONDO																										
SPENTO																										

RADIOMARELLI
mod. RD 198

CONTATTI	α	β	γ	δ	θ	ε
MUSICA	•		•		•	
VOCE		•	•		•	
BASSI	•			•	•	
ALTI	•		•			•