



<p>"M" &amp; "I" BAND ANT. COIL SA-190</p> <p>BOTTOM VIEW</p>	<p>"M" &amp; "I" BAND OSC. COIL SA-191</p> <p>FRONT VIEW</p>	<p>"S" BAND ANT. COIL SA-192</p> <p>TOP VIEW</p>	<p>"S" BAND OSC. COIL SA-193</p> <p>TOP VIEW</p>	<p>I.F. FREQUENCY - 470 K.C.</p> <p>"M" BAND: 600 K.C. OR 500 METERS 1500 K.C. OR 200 METERS</p> <p>"I" BAND: 6 M.C. OR 50 METERS</p> <p>"S" BAND: 21.5 M.C. OR 13.95 METERS</p> <p>ALIGN "S" BAND FIRST, "I" BAND NEXT, THEN "M"</p>	<p>NOTE: BAND SELECTOR SWITCH SHOWN IN "S" BAND POSITION. SWITCH LUGS 4* AND 5* ARE ON FRONT OF REAR SECTION OF SWITCH</p> <p>REAR VIEW</p>
---	--	--	--	---	---

ANDREA RADIO CORP.  
 WOODSIDE, N. Y.  
 WIRING DIAGRAM "F6" REC.  
 MAT: 43F6