


WATT RADIO mod. WR 675 FD



Le tensioni riportate in verticale sono relative al funzionamento in MA, quelle in corsivo a MF

• contatti utili
○ contatti casuali

CONTATTI		GAMMA		MF		MA		OC		ON		OL		OF	
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16

CONTATTI		REGISTRO	
1	2	3	4
1	2	3	4
1	2	3	4
1	2	3	4

SPENTO	FONO	MA	MF
1	2	3	4
1	2	3	4
1	2	3	4
1	2	3	4

VOCE	ORCHESTRA	JAZZ
1	2	3
1	2	3
1	2	3
1	2	3

