Pr ce: 25¢

H648T
Westinghouse

1966 MASTER INDEX

to Supreme Publications

Most - Often - Needed

Television and RADIO

Servicing Information



SUPREME PUBLICATIONS

How to use this Index

A sample listing taken from Index



Names of manufacturers in alphabetical order

listed at left under each manufacturer in numerical order models and chassis included in various Supreme manuals.

Specific model or chassis

Directly across each listing, reference is made to manual and page where service material for such set begins,

This is manual reference

This is the first page in volume

Reference to proper manual and page number. First page applicable is at right of dash; manual number is at left of dash - see chart below.

Main Index section on pages 3 through 42, covers radio and TV sets through 1964 models. Use Index Supplement on pages 43 through 46 for 1965, 1966, and other additional sets.

REFERENCE AND VOLUME-YEAR CHART

Television Manuals

Reference	Year	Volume
TV25-	1966	TV-25
TV24-	Late 1965	TV-24
TV23-	Early 1965	TV-23
TV22-	1964	TV-22
TV21-	1963	TV-21
TV20-	Late 1962	TV-20
TV19-	Early 1962	TV-19
TV18-	1961	TV-18
TV17-	1960	TV-17
TV16-	Late 1959	TV-16
TV15-	Early 1959	TV-15
TV14-	1958	TV-14
TV13-	Late 1957	TV-13
TV12-	Early 1957	TV-12
TV11-	1956	TV-11
TV10-	Late 1955	TV-10
TV9-	Early 1955	TV-9
TV8-	1954	TV-8
TV7-	1953	TV-7
TV6-	1952	TV-6
TV5-	1951	TV-5

Radio Manuals

Reference	Year	Volume
1966-	1966	R-26
1965-	1965	25
1964-	1964	24
1963-	1963	23
1962-	1962	22
1961-	1961	21
1960-	1960	20
1959-	1959	19
1958-	1958	18
1957-	1957	17
1956-	1956	16
1955-	1955	15
1954-	1954	14

Reference	Year	Volume
1953 -	1953	13
Twelve-	1952	12
Eleven-	1951	11
Ten-	1950	10
Nine-	1949	9
Eight-	1948	8
Seven-	1947	7
Six-	1946	6
Five-	1942	5
Four-	1941	4
Three-	1940	3
One-	1926-38	1
AU1-	1964-65	AU-1

(Auto radio manual)

Refer to pages 42 and 47, for instructions on how to obtain needed SUPREME manuals.

Index

Use this Index for Radio and TV models prior to 1965.
For 1965 and 1966 models see Index on page 43.

This Master INDEX lists every television and radio set included in Supreme Publications manuals. For sets up to and including most 1964 models see Index starting below and continued through page 42. For 1966, 1965, and some older sets and additions, see separate Index on pages 43 through 47. Use both Indices. Manufacturers' names are listed alphabetically from Admiral to Zenith. Under each manufacturer, models and chassis of that make are listed numerically on the left side of the column. Corresponding to each model entry there is a reference at the right. In such right hand reference, words such as: One, Three, and up to Twelve, refer to volume number of RADIO Diagram manuals. Radio volumes 13 through 26 are listed by their corresponding years: 1953 through 1966. These numbers tell what volume is needed in each case. Reference to TV volumes is made by volume numbers, TV25 through TV5. In every reference entry, the figure following the volume number (-after the dash) tells you on what page in the volume stated, the material you need will be found. You will find the applicable year and volume number printed on the cover and backbone of every Supreme manual so they can be easily picked out. As a further aid, a cross-reference of volume numbers and years of manuals is given on the page at left (page 2).

ADMIRAL CORP.

1B1 1958-18
1B11 1958-18
1C1 1958-18
1C12 1958-18
1C14 1958-18
1D1 1958-18
1D11 1958-18
1D12 1958-18
1E13 1958-18
1E14 1958-18
1F1 1960-16
1F1B 1964-3
2E1 1960-16
2E1A 1960-16
3A1 Six-7
3A1-AN Seven-6
3C1 TV5-15
3C1 also in TV6-11
3G18 1955-7
3J1 1958-20
3J1A 1958-19
3J14 1958-20
3J16 1958-20
3K1 1958-21
3K1 1957-3
3N1A 1961-3
4A1 Six-8
4B1 Eight-6
4B2 1954-5
4B21 1954-5
4B22 1954-5
4B24 1954-5
4B28 1954-5
4B29 1954-5
4D Two-18
4D1 Nine-7
4D11 Nine-7
4D12 Nine-7
4D13 Nine-7
4D18D 1956-3
4D28D 1956-3
4E2 1957-4
4E3 1960-3
4E3A 1961-4
4F3A 1961-5
4E21 1957-4
4F22 1957-4
4F24 1957-4
4F26 1957-4
4F28 1957-4
4G2, -A 1956-3
4G3 TV16-13
4G22D 1956-3
4H1 TV3-5
4H2 1957-4
4H3 TV16-13
4H15S, -SN TV3-5
4H16S, -SN TV3-5
4H17S, -SN TV3-5
4H18S, -SN TV3-5
4H19S, -SN TV3-5
4H22 1957-4
4H24 1957-4
4H26 1957-4
4H28 1957-4
4L2 1960-17
4L2A 1960-17
4L2B 1961-6
4L20A 1960-17
4L21 1960-17
4L21A 1960-17

Admiral (Cont.)

4L24 1960-17
4L24A 1960-17
4L25, -A 1960-17
4L26, -A 1960-17
4L26B 1961-6
4L27B 1961-6
4L28, -A 1960-17
4L28B 1961-6
4L29B 1961-6
4M2 1957-6
4M22 1957-6
4M23 1957-6
4M25 1957-6
4M28 1957-6
4N2 1957-7
4N3 1961-4
4P2 1958-8
4P3 1961-7
4P3A 1961-7
4P21 1958-8
4P22 1958-8
4P24 1958-8
4P28 1958-8
4R1 Ten-6
4R2 TV13-19
4R3 1962-3
4R11, 4R12 Ten-6
4S2 1959-6
4S2 1958-16
4S2A TV14-14
4S3A 1964-3
4T1 Eleven-6
4T2 1958-21
4T11 Eleven-6
4V1 see 4T1
4V12, 4V18, 4V19, Use 4V1
4W1 Eleven-6
4W2 1958-4
4W18 Eleven-6
4W19 Eleven-6
4X1 1953-6
4X3, A 1964-4
4X11 1953-6
4X12 1953-6
4X18 1953-6
4X19 1953-6
4Y1 1953-5
4Y11 1953-5
4Y12 1953-5
4Y18 1953-5
4Y19 1953-5
4Z1 1955-6
4Z11 1955-6
4Z12 1955-6
4Z14 1955-6
4Z18 1955-6
4Z19 1955-6
5A1 Seven-7
5A3 Twelve-7
5A4 1956-4
5A5 1960-4
5A6 1963-6
5A32 Twelve-7
5A33 Twelve-7
5A42 1956-4
5A43 1956-4
5A44 1956-4
5A48 1956-4
5B1 Six-10
5B1A Seven-6

Admiral (Continued)

5B2 TV5-5
5B4 1958-6
5B5 1960-5
5B5B 1961-8
5B5C 1961-8
5B6 1963-6
5B42 1956-6
5B43 1956-6
5B48 1956-6
5C3 1953-7
5C4 1958-3
5C41, 5C45, 5C48, 5C49 — Use 5R3 Chassis, 1955-8
5D2 TV5-15
5D3 1953-8
5D4 1958-6
5D5 1960-4
5D6A 1964-5
5D6B, C 1964-5
5D9 TV22-8
5D31 1953-8
5D32 1953-8
5D33 1953-8
5D38 uses 5D3
5E2 Eleven-7
5E3 1953-9
5E4 1958-9
5E5 1960-6
5E5A 1960-6
5E5B 1960-7
5E21 Eleven-7
5E22 Eleven-7
5E23 Eleven-7
5E31 1953-9
5E32 1953-9
5E33 1953-9
5E38 1953-9
5E39 1953-9
5F1 Nine-6
5F4 1958-10
5F4A 1961-8
5F5 1960-8
5F6 1963-7
5F11 Nine-6
5F12 Nine-6
5F31, -A, -B 1954-6
5F32, -A, -B 1954-6
5F33, -A, -B 1954-6
5F34B 1954-6
5F38, -A, -B 1954-6
5G2 Eleven-8
5G3 1954-7
5G21 Eleven-8
5G21/15 Eleven-8
5G22 Eleven-8
5G22/15 Eleven-8
5G23 Eleven-8
5G23/15 Eleven-8
5G31 1954-7
5G32 1954-7
5G33 1954-7
5G44, 5G45, 5G46, 5G49 — Use 5S3 Chassis +Clock
5H1 Eight-7
5H44, 5H47, 5H49 — Use 5W3 Chassis

Admiral (Cont.)

5J2 Eleven-7
5J21 Eleven-7
5J22 Eleven-7
5J23 Eleven-7
5K1 Eight-8
5K3 1955-5
5K5A 1961-9
5K5B 1961-9
5K11, -12, -13, -14 see 5K1
5K31 1955-5
5K32 1955-5
5K34 1955-5
5K38 1955-5
5K39 1955-5
5L, 5LL Two-18
5L2 Twelve-9
5L5 1960-4
5L21 Twelve-9
5L22 Twelve-9
5L23 Twelve-9
5M2 Twelve-10
5M3A 1957-8
5M5 1961-10
5M21 Twelve-10
5M22 Twelve-10
5M36D 1956-5
5M37D 1956-5
5M56, -B 1957-8
5M56D 1956-5
5M57, -B 1957-8
5M57D 1956-5
5M66D 1956-7
5M67D 1956-7
5N1 Eight-9
5N3 1956-5
5P5 like 5L5
5R3 1955-8
5R5 1961-11
5R32 1955-8
5R33 1955-8
5R35 1955-8
5R36 1955-8
5R37 1955-8
5R38 1955-8
5RP4, -A 1958-11
5RP41 1958-11
5RP42 1958-11
5S2 see 5E2
5S3 1955-8
5S5 1961-12
5S21, 5S22, & 5S23 use 5S2
5S21AN 1953-7
5S22AN 1953-7
5S23AN 1953-7
5S32 1955-8
5S33 1955-8
5S34 1955-8
5S35 1955-8
5S38 1955-8
5T3 1955-8
5T4A 1959-9
5T5 1961-13
5T31 1955-8
5T32 1955-8
5T33 1955-8
5T34 1955-8
5T36, 5T37 — Same as above
5T38 1955-8

Admiral (Cont.)

5V5 1961-14
5W3 1956-6
5W4 1959-3
5W32 1956-6
5W33 1956-6
5W34 1956-6
5W38 1956-6
5W39 1956-6
5x2 1953-10
5x21 1953-10
5x22 1953-10
5x23 1953-10
5Y2 Twelve-10
5Y22 Twelve-10
5Z2 see 5E2
5Z22, and 5Z23 use 5Z2 see Eleven-7
F-5 Three-18
G-5 Four-18
M5-PH Four-18
UL5K1 Eight-8
XF-5 Three-18
XM5-PH Four-18
6A1 Six-12
6A2 Ten-7
6A21 Ten-7
6A22 Ten-7
6A23 Ten-7
6C1 Nine-8
6C2 Twelve-8
6C11 Nine-8
6C22 Twelve-8
6C23 Twelve-8
6C63 see 7C1
6C71 see 10A1
6E1 Six-6
6E1N Six-6
6J2 Eleven-9
6J21 Eleven-9
6J22 Eleven-9
6L1 Eight-10
6M2 Eleven-9
6M3A 1962-4
6M3C 1963-8
6M3D 1963-8
6M3E 1963-8
6M22 Eleven-9
6N3 1963-9
6Q1 Ten-8
6Q11 Ten-8
6Q12 Ten-8
6Q13 Ten-8
6Q14 Ten-8
6R1 Nine-11
6R2 1956-7
6R2B 1958-13
6R11 Nine-11
6RP48 see 3H1
6RP49 see 3H1
6RP50 see 3H1
6RT41 uses 5B1
6RT41A uses 5B1A
6RT42 uses 5B1
6RT42A uses 5B1A
6RT43 uses 5B1
6RT43A uses 5B1A
6S1 Ten-9
6S2 1958-14
6S11 Ten-9
6S12 Ten-9
6T01 Six-12

Admiral (Cont.)

6T02 Six-10
6T2 1959-4
6T04 see 5B1
6T05 see 6A1
6T06 see 4A1
6T07 see 4A1
6T11 see 5B1
6V3 1963-10
6W1 Ten-10
6W11 Ten-10
6W12 Ten-10
6Y1 Ten-11
6X3, A 1964-6
6Y18 Ten-11
6Y19 Ten-11
B6 Five-18
XB6 Five-18
7A2 1961-16
7B1 Seven-9
7B2 1962-5
7B2B 1962-6
7B2C 1962-7
7B2D 1962-7
7-C Three-18
7C1 Eight-11
7C63 Eight-11
7D2 1961-17
7K2 1963-11
7L1 1957-9
7L2 1964-7
7L12 1957-9
7L14 1957-9
7L16 1957-9
7L18 1957-9
7M1 1958-15
7M11 1958-15
7M12 1958-15
7M14 1958-15
7M15 1958-15
7M16 1958-15
7M18 1958-15
7N1 1959-6
7N1A 1959-6
7N2, A 1963-3
7P1 1960-9
7P32 Eight-7
7P33 Eight-7
7P34 Eight-7
7P35 Eight-7
7Q1 1960-12
7RT41 Eight-10
7RT42 Eight-10
7RT43 Eight-10
7T1 TV17-13
7TO1 Eight-9
7TO4 Eight-9
7TO6 Eight-6
7T10 Eight-8
7T12 Eight-6
7T14 Eight-8
7T15 Eight-8
7V1 1960-10
7V1A 1960-10
7V1B 1960-10
8A2 1962-8
8D2 1961-18
8F2 1963-12
8G2 1964-10
8H1 1958-16
8H1A TV14-12

Admiral (Cont.)

8K1 1958-17
8L1 like 8K1
8M1 1959-5
8P1 1964-8
8RP46 see 3A1
8S1 1959-8
8S1A 1959-8
8S1C 1960-13
8T1 1960-15
8T1A 1960-15
8T2A TV22-25
8V1 1960-14
8W1 TV17-18
9E1 Ten-12
9E15 Ten-12
9E16 Ten-12
9E17 Ten-12
9P1 1964-8
10A1 Seven-11
S11A TV16-13
12B1, -A 1959-9
14R12 uses 20T1
14R16 uses 20T1
14UY3B TV12-5
14UY3C TV12-5
14UY3D TV12-5
14YP3B TV12-5
14YP3BK TV12-5
14YP3C TV12-5
14YP3D TV12-5
P14D11 TV13-12
P14D12 TV13-12
P14D13 TV13-12
P14D14 TV13-12
PA14D11 TV13-12
PA14D12 TV13-12
PA14D13 TV13-12
PA14D14 TV13-12
15A2 TV16-13
15A2C Like above, but diff. tuner
15B2 TV16-13
15B3 TV16-13
15C1 TV15-5
15D1B TV16-24
15E1 TV18-27
15E1B TV18-27
15F1 TV18-27
15G1B TV18-3
15UA2 Like 15A2 diff. tuner
15UD1B Similar to 15B3
15EE1 TV18-27
15UG1B TV18-3
16A3B TV21-3
16A3U TV21-3
16A4C, D TV22-3
16A9, -U TV19-9
16AB1 TV13-14
16AE1 TV15-29
16AD1 TV15-29
16AF1 TV15-29
16AF1 TV13-10
16AG1 TV14-5
16AG1 TV15-29
16AH1 TV13-12
16AL1 TV14-5
16AL1 TV15-29
16AR1C TV16-5

Admiral (Continued)

16AS1C TV16-5
16AU1 TV15-29
16AW1 TV15-29
16AX1 TV15-15
16B1 TV15-29
16B3B TV21-3
16B3U TV21-3
16B4C, D TV22-3
16B9B TV19-9
16C9, -U TV19-9
16D1 TV15-29
16D9, -B TV19-15
16E1 TV15-29
16E1 TV13-14
16E4C, D TV22-3
16F1 TV13-10
16F4U TV22-3
16F9 TV19-15
16F3B TV20-10
16G1 TV14-5
16G1 TV15-29
16G3U TV20-10
16G4U TV22-3
16G9B TV19-9
16H1 TV13-12
16H3B TV21-3
16J1 TV15-29
16K1 TV15-29
16K3B TV21-7
16L1 TV15-29
16L1 TV14-5
16L3B TV21-7
16M3B TV21-7
16M12 uses 21X1
16R1C TV16-5
16R1CB TV16-5
16R11 TV5-15
16R12 TV5-15
16S1C TV16-5
16S1CB TV16-5
16U1 TV15-29
16UA3B TV21-3
16UA4C, D TV22-3
16UB3B TV21-3
16UB4C TV22-3
16UB9B TV19-9
16UD9, -F TV19-15
16UE4C, D TV22-3
16UF3B TV20-10
16UF9 TV19-15
16UG9B TV19-9
16UH3B TV21-3
16UK3B TV21-7
16UL3B TV21-7
16UM3B TV21-7
16W1 TV15-29
16X1 TV15-15
17AB1 TV13-19
17AC1 TV13-5
17AF1 TV13-23
17AG1 TV13-5
17AK1 TV14-16
17AL1 TV14-12
17B1 TV13-19
17C1 TV13-5
17DX10 TV7-5
17DX11 TV7-5
17DX12 TV7-5
17DX16 uses 21F1
17F1 TV13-23
17G1 TV13-5
17J1 TV14-8
17K1 TV14-16
17K1B TV14-16
17K21, 17K22 uses 21F1 or 21P1
17L1 TV14-12
17L1B TV14-12
17M15, 17M16, 17M17 use 21F1 or 21P1
17SX3 TV10-5
17SX3Z TV10-5
17UDX11, 17UDX12 use 19S1 Chassis
17X3Z TV10-5
17XP3 TV10-5
17Z3D TV12-16
17Z3DC TV12-16
17Z3DT TV12-16
P17D21 TV13-10
P17D22 TV13-10
P17D23 TV13-10
P17D24 TV13-10

Admiral (Cont.)

P17D46 TV15-15
P17D47 TV15-15
P17E31 TV15-5
P17E32 TV15-5
P17E33 TV15-5
P17E34 TV15-5
P17F35 TV15-5
P17E46 Uses 15C1
P17E59B Uses 15C1
P17F1 TV16-13
P17F2 TV16-13
P17F3 TV16-13
P17F1C, P17F2C, P17F3C } Use 15A2C Chassis
P17F4G, P17F5G, P17F6G } Use 15A2 TV16-13
P17UF1, P17UF2, P17UF3 } Use 15UA2 Chassis
PA17D21 TV12-10
PA17D22 TV13-10
PA17D23 TV13-10
PA17D24 TV13-10
PA17D41 TV15-15
PA17D42 TV15-15
PA17D43 TV15-15
PA17D44 TV15-15
PA17D45 TV15-15
PL17F31B TV16-24
PL17F32B TV16-24
PL17F33B TV16-24
PL17F41B TV16-24
PL17F42B TV16-24
PL17F43B TV16-24
PL17UF31B, PL17UF32B, PL17UF33B } Use Chassis 15UD1B
PL17UF41B, PL17UF42B, PL17UF43B } Use Chassis 15UD1B
PS17F12 TV16-13
PS17F13 TV16-13
PS17F22 TV16-13
PS17F23 TV16-13
18A6C, -CB TV15-21
18A6T, -TB TV15-21
18B6C, -CB TV15-21
18B6T, -TB TV15-21
18B7 TV17-19
18B7B TV17-19
18C6C TV15-21
18C6T TV15-21
18SX4BZ TV10-31
18SX4CZ TV10-31
18SX4EZ TV10-31
18SX4FZ TV10-31
18SX4GZ TV10-31
18UA6C, -CB TV15-21
18UA6T, -TB TV15-21
18UB6C, -CB TV15-21
18UB6T, -TB TV15-21
18UB7 TV17-19
18UB7B TV17-19
18X4CZ TV10-31
18X4FZ TV10-31
18X4FZ TV10-31
18X4GZ TV10-31
18XP4BZ TV10-31
18XP4HZ TV10-31
18Y4B TV12-13
18Y4BS TV12-13
18Y4BSA TV12-13
18Y4E TV12-13
18Y4EF TV12-13
18Y4EFA TV12-13
18Y4ESA TV12-13
18Y4L TV12-13
18Y4LS TV12-13
18Y4LSA TV12-13
18Y4PSA TV12-13
18Z4ES TV12-18
18Z4ESA TV12-18
18Z4FS TV12-18
18Z4FSA TV12-18
18Z4LSA TV12-18
18Z4PS TV12-18
18Z4PSA TV12-18
T18A1 TV10-5
T18A2 TV10-5
T18A3 TV10-5
T18A11 TV13-23
T18A12 TV13-23

Admiral (Cont.)

T18A13 TV13-23
TA18A11 TV13-23
TA18A12 TV13-23
TA18A13 TV13-23
TS18A1 TV10-5
TS18A2 TV10-5
TS18A3 TV10-5
19A2 TV8-15
19A2A, 19A2AZ, 19A2Z similar to 19A2
19A3+ TV22-15
19B1 TV7-5
19B2 TV8-15
19B2A, 19B2AZ, 19B2Z similar to 19B2
19B3+ TV22-15
19B8B TV19-5
19C1 TV7-5
19C3+ TV22-15
19C8B comb. set like 19B8B
19D2, -A TV8-15
19E1 TV7-5
19E2 TV8-15
19E2A like 19E2
19E8B TV20-3
19F1 TV7-5
19F1A TV7-5
19F1B like 19F1
19F2AZ, 19F2Z like 19E2+ Radio Tuner
19F8B TV20-3
19G1 TV7-5
19G2, 19G2A(24"tube) similar to 19E2
19G8B TV20-3
19H1 TV7-5
19H2, 19H2A see 19G2 plus UHF
19G3+ TV22-15
19H3+ TV22-15
19J1 TV8-15
19J8B TV20-3
19K1 TV7-5
19K2AZ, 19K2Z, Like 19E2, + tuner, UHF
19K3U TV22-15
19L1 TV8-15
19L2 TV9-11
19L2Z TV9-11
19M2 TV9-11
19M3U TV22-15
19N1 TV7-5
19N2Z TV9-11
19P1 TV8-15
19R2 TV9-11
19R3U TV22-15
19S1 TV8-15
19S2 TV9-11
19SZ4D TV12-20
19SZ4DF TV12-20
19SZ4DT TV12-20
19SZ4ES TV12-20
19SZ4FS TV12-20
19SZ4PS TV12-20
19T1, -C TV9-11
19T2, 19T2A similar to 19B1
19T3U TV22-15
19UA3+ TV22-15
19UB3+ TV22-15
19UB8B TV19-5
19UC3+ TV22-15
19UC8B comb. set like 19UB3B
19UE8B TV20-3
19UF8B TV20-3
19UG3+ TV22-15
19UG8B TV20-3
19UH3+ TV22-15
19UJ8B TV20-3
19W1 TV9-11
19W1A TV9-11
19W1B, -C TV9-11
19Y1A TV9-11
19Y4G TV12-13
19Y4GF TV12-13
19Y4PRS TV12-13
19Y4RF TV12-13
PL19J131 TV18-3
PL19J132 TV18-3
PL19J133 TV18-3
PL19J135 TV18-3
PL19J140 TV18-3

Admiral (Cont.)

PL19J141 TV18-3
PL19J149 TV18-3
PL19UJ131 TV18-3
PL19UJ133 TV18-3
PL19UJ135 TV18-3
PL19UJ140 TV18-3
PL19UJ141 TV18-3
PL19UJ149 TV18-3
20A2 TV9-5
20A2Z TV9-5
20A7 TV18-8
20A7B TV18-8
20A8 TV19-21
20AX5 TV10-39
20AX5A TV10-39
20AX5B TV10-39
20AX5D TV10-39
20AX5EZ TV10-39
20AX5F TV10-39
20AX5GZ TV10-39
20B6C, -CB TV15-9
20B6T, -TB TV15-9
20B8 TV19-21
20B7 TV18-8
20C6C TV15-9
20C7 TV18-8
20D2 TV9-5
20D8 TV19-21
20G6 TV17-6
20H6 TV17-5
20J6 TV17-5
20K7 TV18-19
20K7B TV18-19
20L2 TV9-11
20L7 TV18-19
20M6 TV17-5
20R6 TV17-19
20S6 TV17-19
20SY4B TV11-5
20SY4BF TV11-5
20SY4L TV11-5
20SY4EF TV11-5
20SY4ES As above
20SY4F TV11-5
20SY4FF TV11-5
20SY4H TV11-5
20SY4HF TV11-5
20SY4L TV11-5
20SY4LS TV11-5
20SZ4EF TV12-24
20SZ4FF TV12-24
20SZ4PS TV12-24
20T1 see TV5-15
20T6 TV17-19
20UA7 TV18-8
20UA7B TV18-8
20UA8 TV19-21
20UB6C, -CB TV15-9
20UB6T, -TB TV15-9
20UB3 TV19-21
20UD8 TV19-21
20UG6 TV17-5
20UK7 TV18-19
20UK7B TV18-19
20UR6 TV17-19
20US6 TV17-19
20V1 see TV5-15
20X5 TV9-10
20X5A, -B TV9-10
20X5C TV9-10
20X5CZ TV9-10
20X5EZ, 20X5GZ, similar to 20X5B
20XP5A TV9-10
20Y4B TV11-5
20Y4BF TV11-5
20Y4D TV11-5
20Y4E TV11-5
20Y4EF TV11-5
20Y4F TV11-5
20Y4FF TV11-5
20Y4H TV11-5
20Y4HF TV11-5
20Y4L TV11-5
20Y4LF TV11-5
20Y4LS TV11-5
20Y4MS TV11-5
20Y4NF TV11-5
20Z4EF TV12-22
20Z4FF TV12-22
20Z4PS TV12-22
21A3AZ TV10-12
21A3Z TV10-12

Admiral (Cont.)

21A4 TV21-19
21A5-11C, D TV22-20
21A5-12C, D TV22-20
21A5-51D TV22-20
21A5-71C, D TV22-20
21A5-91D TV22-20
21B1 TV5-15
21B3Z TV10-12
21B4 TV21-19
21B5-11C, D TV22-20
21B5-13C, D TV22-20
21B5-51D TV22-20
21B5-54D TV22-20
21C1 TV5-15
21C3Z TV10-12
21C4 TV21-19
21C5-14C, D TV22-20
21C5-15C, D TV22-20
21D1 TV5-15
21D3Z TV10-12
21D5-31C TV22-9
21D5-31D TV22-9
21D5-32C TV22-9
21D5-32D TV22-9
21D5-33C TV22-9
21D5-33D TV22-9
21D5-62D TV22-9
21D5-63D TV22-9
21E1 TV6-5
21E5-34C TV22-9
21E5-34D TV22-9
21E5-61D TV22-9
21F1 TV6-5
21F4 TV21-19
21G1 TV6-5
21G3Z TV10-12
21G4 TV21-19
21H1 TV5-15
21H3Z TV10-12
21J1 TV5-15
21K1 TV6-5
21K3U TV21-11
21L1 TV6-5
21L3U TV21-11
21M1 TV6-5
21M3U TV21-11
21N1 TV6-5
21P1 TV6-5
21Q1 TV6-5
21S3U TV21-15
21T1 TV6-5
21T3U TV21-15
21UA4 TV21-19
21UA5-21C TV22-20
21UB4 TV21-19
21UB5-21C TV22-20
21UB5-21D TV22-20
21UB5-23C TV22-20
21UB5-23D TV22-20
21UC4 TV21-19
21UC5-15C TV22-20
21UC5-15D TV22-20
21UC5-24C TV22-20
21UC5-24D TV22-20
21UD5-41C TV22-9
21UD5-41D TV22-9
21UD5-42C TV22-9
21UD5-42D TV22-9
21UD5-43C TV22-9
21UD5-43D TV22-9
21UE5-44C TV22-9
21UE5-44D TV22-9
21UF4 TV21-19
21UG4 TV21-19
21UK3 TV21-11
21UL3 TV21-11
21UM3 TV21-11
21V1 TV5-5
21W1 TV6-5
21X1, 21X2 similar to 21P1
21X3U TV21-15
21Y1 TV6-5
21Z1, 21Z1A same as 21W1
C21A1-1A TV22-27
C21A1-1E TV22-27
C21A10-1C TV22-27
C21E2 TV14-5
C21E2 TV15-29
C21E3 TV15-29
C21E3 TV14-5
C21E6 TV14-5
C21E6 TV15-29
C21E7 TV15-29

Admiral (Cont.)

C21E7 TV14-5
C21E11 TV13-14
C21E11E, F TV16-5
C21E12 TV15-29
C21E12 TV13-14
C21E12E, F TV16-5
C21E13 TV13-14
C21E13 TV15-29
C21E13E, F TV16-5
C21E14 TV13-14
C21F14 TV15-29
C21E16 TV15-29
C21E17 TV15-29
C21E22 TV15-29
C21E22 TV13-14
C21E23 TV13-14
C21F23 TV15-29
C21E24 TV15-29
C21E24 TV13-14
C21F25 TV13-14
C21F42 TV13-5
C21F43 TV13-5
C21F46 Use 17G1
C21F48 Use 17G1
C21G2 TV15-21
C21G3 TV15-21
C21G12 TV15-21
C21G13 TV15-21
C21G14 TV15-21
C21G22 TV15-21
C21G23 TV15-21
C21G24 TV15-21
C21UG2 TV15-21
C21UG3 TV15-21
C21UG12 TV15-21
C21UG13 TV15-21
C21UG14 TV15-21
C21UG22 TV15-21
C21UG23 TV15-21
C21UG24 TV15-21
CA21E2 TV15-29
CA21E2 TV14-5
CA21E3 TV14-5
CA21E3 TV15-29
CA21E6 TV15-29
CA21E6 TV14-5
CA21E7 TV14-5
CA21F7 TV15-29
CA21E11E TV16-5
CA21E12 TV15-29
CA21D12E TV16-5
CA21E13 TV15-29
CA21E13E TV16-5
CA21F14 TV15-29
CA21F16 TV15-29
CA21E17 TV15-29
CA21E22 TV15-29
CA21E23 TV15-29
CA21E24 TV15-29
CA21E25 TV13-14
CA21F42 TV13-5
CA21F43 TV13-5
CA21F46 Use 17AG1
CA21F48 Use 17AG1
CH21E26C TV15-29
CH21E27C TV15-29
CH21E29C TV15-29
CH21F52 TV13-19
CH21F53 TV13-19
CH21F54 TV13-19
CH21H32 TV15-9
CH21H33 TV15-9
CH21H34 TV15-9
CH21H41 TV15-9
CH21H43 TV15-9
CH21H44 TV15-9
CH21UH32 TV15-9
CH21UH33 TV15-9
CH21UH34 TV15-9
CH21UH41 TV15-9
CH21UH43 TV15-9
CH21UH44 TV15-9
CHA21E26C TV15-29
CHA21E27C TV15-29
CHA21E29C TV15-29
CHA21F52 TV13-19
CHA21F53 TV13-19
CHA21F54 TV13-19
CHS21H72 TV15-9
CHS21H77 TV15-9
CR21E12 TV15-29
CR21E13 TV15-29
CR21E14 TV15-29
GS21G62 TV15-21

Admiral (Cont.)

GS21G63 TV15-21
GS21G64 TV15-21
HF21F22 TV14-16
HF21F22B TV14-16
HF21F23 TV14-16
HF21F23B TV14-16
HF21F32 TV14-14
HF21F32B TV14-14
HF21F33 TV14-14
HF21F33B TV14-14
HF21F34 TV14-14
HF21F34B TV14-14
HFA21F22 TV14-16
HFA21F23 TV14-16
HFA21F32 TV14-14
HFA21F33 TV14-14
HFA21F34 TV14-14
L21E22 TV13-14
L21E22 TV15-29
L21E22E, F TV16-5
L21E23 TV15-29
L21E23 TV13-14
L21E23E, F TV16-5
L21E24 TV15-29
L21G12 TV15-21
L21G13 TV15-21
L21G14 TV15-21
L21UG12 TV15-21
L21UG13 TV15-21
L21UG14 TV15-21
LA21E22 TV15-29
LA21E22 TV13-14
LA21E23 TV13-14
LA21E23 TV15-29
LA21E24 TV15-29
LH21F32 TV13-19
LH21F33 TV13-19
LH21F34 TV13-19
LH21H22 TV15-9
LH21H23 TV15-9
LH21H24 TV15-9
LH21H32 TV15-9
LH21H35 TV15-9
LH21UH22 TV15-9
LH21UH23 TV15-9
LH21UH24 TV15-9
LH21UH32 TV15-9
LH21UH35 TV15-9
LHA21F32 TV13-19
LHA21F33 TV13-19
LHA21F34 TV13-19
LHR21F32 TV14-8
LHR21F33 TV14-8
LHR21F34 TV14-8
LHS21H51 TV15-9
LHS21H53 TV15-9
LHS21H54 TV15-9
LHS21H62 TV15-9
LHS21H69 TV15-9
LS21G42 TV15-21
LS21G43 TV15-21
S21A TV16-13
T21E1 TV14-5
T21E1 TV15-29
T21E2 TV15-29
T21E2 TV14-5
T21E3 TV14-5
T21E3 TV15-29
T21E11 TV13-14
T21E12 TV13-14
T21E13 TV13-14
T21E20E, F TV16-6
T21E21 TV13-14
T21E21 TV15-29
T21E21E, F TV16-5
T21E22 TV15-29
T21E22 TV13-14
T21E22E, F TV16-5
T21E23 TV13-14
T21E23 TV15-29
T21E23E TV16-5
T21ED2 Uses 16G1C
T21F32 TV13-5
T21F33 TV13-5
T21G1 TV15-21
T21G2 TV15-21
T21G11 TV15-21
T21G12 TV15-21
T21G13 TV15-21
T21UG1 TV15-21
T21UG2 TV15-21
T21UG11 TV15-21

Admiral (Cont.)

T21UG12 TV15-21
T21UG13 TV15-21
TA21E1 TV15-29
TA21E1 TV14-5
TA21E2 TV14-5
TA21E2 TV15-29
TA21E3 TV15-29
TA21E3 TV14-5
TA21E11 TV13-14
TA21E12 TV13-14
TA21E13 TV13-14
TA21E20E TV16-5
TA21E21 TV13-14
TA21E21 TV15-29
TA21E22 TV15-29
TA21E22 TV13-14
TA21E22E TV16-5
TA21E23 TV15-29
TA21E23 TV13-14
TA21E23E TV16-5
TA21F32 TV13-5
TA21F33 TV13-5
TH21E51C TV15-29
TH21E52C TV15-29
TH21E53C TV15-29
TH21H22 TV15-9
TH21H23 TV15-9
TH21UH22 TV15-9
TH21UH23 TV15-9
THA21E51C TV15-29
THA21E52C TV15-29
THA21E53C TV15-29
TR21E21 TV15-29
TR21E22 TV15-29
TR21E23 TV15-29
TS21G22 TV15-21
TS21G23 TV15-21
22A2 TV7-12
22A2A TV7-12
22A3, 22A3AZ, - Z, similar to 22F2
22B3, 22B3AZ, - Z, modified 22G2
22C2 TV7-12
22E2 TV7-12
22F2 TV8-5
22G2 TV8-5
22M1 TV7-12
22M2 TV8-5
22N2 TV8-5
22P2 TV8-5
22R2 TV8-5
22Y1 TV7-12
C22M1 TV17-19
C22M2 TV17-19
C22M3 TV17-19
C22M11 TV17-19
C22M12 TV17-19
C22M13 TV17-19
C22M22 TV17-19
C22M23 TV17-19
C22M24 TV17-19
C22UM1 TV17-19
C22UM2 TV17-19
C22UM3 TV17-19
C22UM11 TV17-19
C22UM12 TV17-19
C22UM13 TV17-19
C22UM22 TV17-19
C22UM23 TV17-19
C22UM24 TV17-19
CS22M41 TV17-19
CS22M42 TV17-19
CS22M43 TV17-19
CS22M44 TV17-19
L22M22 TV17-19
L22M23 TV17-19
L22M24 TV17-19
L22UM22 TV17-19
L22UM23 TV17-19
L22UM24 TV17-19
LS22M42 TV17-19
LS22M43 TV17-19
LS22M44 TV17-19
T22M1 TV17-19
T22M2 TV17-19
T22M3 TV17-19
T22M10 TV17-19
T22M11 TV17-19
T22M12 TV17-19
T22M13 TV17-19
T22UM1 TV17-19
T22UM2 TV17-19
T22UM3 TV17-19

Admiral (Cont.)

T22UM10 TV17-19
T22UM11 TV17-19
T22UM12 TV17-19
T22UM13 TV17-19
TS22M40 TV17-19
TS22M41 TV17-19
TS22M42 TV17-19
TS22M43 TV17-19
C23A1, -A TV12-13
C23A2, -A TV12-13
C23A3, -A TV12-13
C23A6 TV12-13
C23A7 TV12-13
C23A8, -A TV12-13
C23A11 TV12-16
C23A12 TV12-16
C23A13 TV12-16
C23A26 TV12-16
C23A27 TV12-16
C23B1 TV11-5
C23B2 TV11-5
C23B3 TV11-5
C23B16 TV11-5
C23B17 TV11-5
C23B18 TV11-5
C23B26 TV11-5
C23B27 TV11-5
CS23A1W, CS23A2W, CS23A3W } Use 20SY4ES Chassis
CS23A6 TV11-5
CS23A7 TV11-5
CS23A11 TV12-20
CS23A12 TV12-20
CS23A13 TV12-20
CS23A16C TV12-20
CS23A26 TV12-20
CS23A27 TV12-20
CS23B1 TV11-5
CS23B2 TV11-5
CS23B3 TV11-5
CS23B16 TV11-5
CS23B16C TV12-20
CS23B17 TV11-5
CS23B17C TV12-20
CS23B26 TV11-5
CS23B27 TV11-5
F23B6 TV11-5
F23B7 TV11-5
K23A6 TV12-13
K23A7 TV12-13
L23B6 TV11-5
L23B7 TV11-5
LS23B6 TV11-5
LS23B7 TV11-5
T23A1 TV12-16
T23A2 TV12-16
T23A3 TV12-16
T23A6 TV12-16
T23A7 TV12-16
T23B1 TV11-5
T23B2 TV11-5
T23B6 TV11-5
T23B7 TV11-5
T23B16 TV11-5
T23B17 TV11-5
T23B18 TV11-5
T23B26 TV11-5
T23B27 TV11-5
TS23A1 TV12-20
TS23A2 TV12-20
TS23A3 TV12-20
TS23A6 TV12-20
TS23A7 TV12-20
TS23B1 TV11-5
TS23B2 TV11-5
TS23B6 TV11-5
TS23B7 TV11-5
TS23B16 TV11-5
TS23B17 TV11-5
TS23B16 TV11-5
TS23B26 TV11-5
TS23B27 TV11-5
24D1 TV5-5
24E1 TV5-5
24F1 TV5-5
24G1 TV5-5
24H1 TV5-5
24R12 uses 20T1
C24M21 TV17-5
C24M22 TV17-5
C24M23 TV17-5
C24M32 TV17-5
C24M33 TV17-5
C24M34 TV17-5

Admiral (Cont.)

C24K111, B TV17-19
C24K112, B TV17-19
C24K113, B TV17-19
C24K142, B TV17-19
C24K145, B TV17-19
C24M121 TV18-9
C24M122 TV18-9
C24M123 TV18-9
C24M131 TV18-9
C24M132 TV18-9
C24M133 TV18-9
C24M142 TV18-9
C24M149 TV18-9
C24M171 TV18-9
C24M172 TV18-9
C24M189 TV18-9
C24UK111, B TV17-19
C24UK112, B TV17-19
C24UK113, B TV17-19
C24UK142, B TV17-19
C24UK145, B TV17-19
C24UM21 TV17-5
C24UM22 TV17-5
C24UM23 TV17-5
C24UM32 TV17-5
C24UM33 TV17-5
C24UM34 TV17-5
C24UM121 TV18-9
C24UM122 TV18-9
C24UM123 TV18-9
C24UM131 TV18-9
C24UM132 TV18-9
C24UM133 TV18-9
C24UM142 TV18-9
C24UM149 TV18-9
C24UM171 TV18-9
C24UM172 TV18-9
C24UM189 TV18-9
CG24K131 TV18-19
CG24K132 TV18-19
CG24K133 TV18-19
CG24UK131 TV18-19
CG24UK132 TV18-19
CG24UK133 TV18-19
CS24M52 TV17-5
CS24M57 TV17-5
CS24M131 TV18-9
CS24M132 TV18-9
CS24M133 TV18-9
CS24M142 TV18-9
CS24M149 TV18-9
L24K131, B TV17-19
L24K132, B TV17-19
L24K133, B TV17-19
L24K152, B TV17-19
L24K157, B TV17-19
L24M22 TV17-5
L24M27 TV17-5
L24M31 TV17-5
L24M34 TV17-5
L24M37 TV17-5
L24M151 TV18-9
L24M152 TV18-9
L24M153 TV18-9
L24M161 TV18-9
L24M169 TV18-9
L24UK131B TV17-19
L24UK132, B TV17-19
L24UK133, B TV17-19
L24UK152, B TV17-19
L24UK157, B TV17-19
L24UM22 TV17-5
L24UM27 TV17-5
L24UM31 TV17-5
L24UM34 TV17-5
L24UM37 TV17-5
L24UM151 TV18-9
L24UM152 TV18-9
L24UM153 TV18-9
L24UM161 TV18-9
L24UM169 TV18-9
LS24M52 TV17-5
LS24M53 TV17-5
LS24M54 TV17-5
LS24M152 TV18-9
LS24M159 TV18-9
LS24M161 TV18-9
LS24M169 TV18-9
ST24M61 TV17-5
ST24M62 TV17-5
ST24M63 TV17-5
ST24M72 TV17-5
ST24M77 TV17-5
STA24M120 TV18-9

Admiral (Cont.)

STA24M121 TV18-9
STA24M122 TV18-9
STA24M123 TV18-9
STF24M171 see 20C7
STF24M151 TV18-9
STF24M152 TV18-9
STF24M153 TV18-9
STF24M162 TV18-9
STF24M169 TV18-9
STG24K131 TV18-19
STG24K132 TV18-19
STG24K133 TV18-19
STR24M81 TV17-5
STR24M82 TV17-5
STR24M83 TV17-5
STR24M92 TV17-5
STR24M97 TV17-5
T24K110, B TV17-19
T24K111, B TV17-19
T24K112, B TV17-19
T24K113, B TV17-19
T24M21 TV17-5
T24M22 TV17-5
T24M23 TV17-5
T24M110 TV18-9
T24M111 TV18-9
T24M112 TV18-9
T24M113 TV18-9
T24UK110, B TV17-19
T24UK111, B TV17-19
T24UK112, B TV17-19
T24UK113, B TV17-19
T24UM21 TV17-5
T24UM22 TV17-5
T24UM23 TV17-5
T24UM110 TV18-9
T24UM111 TV18-9
T24UM112 TV18-9
T24UM113 TV18-9
TG24K120 TV18-19
TG24K122 TV18-19
TG24K123 TV18-19
TG24UK120 TV18-19
TG24UK122 TV18-19
TG24UK123 TV18-19
TS24M52 TV17-5
TS24M53 TV17-5
TS24M120 TV18-9
TS24M122 TV18-9
TS24M123 TV18-9
C25B6 TV11-5
C25B7 TV11-5
C25B8 TV11-5
C25B16 TV11-5
C25B17 TV11-5
C25B18 TV11-5
CS25B6 TV11-5
CS25B7 TV11-5
CS25B16 TV11-5
CS25B17 TV11-5
F25B6 TV11-5
F25B7 TV11-5
T25B26 TV11-5
T25B27 TV11-5
TS25B26 TV11-5
TS25B27 TV11-5
26R12 TV6-15
26R25 TV5-5
26R25A TV5-15
26R26 TV5-5
26R26A TV5-15
26R35 TV5-5
26R35A TV5-15
26R36 TV5-5
26R36A TV5-15
26R37 TV5-5
26R37A TV5-15
26X35, 26X36 TV5-5
26X37 TV5-5
26X45 TV5-5
26X46 TV5-5
26X55 TV5-5
26X55A TV5-15
26X56 TV5-5
26X56A TV5-15
26X57 TV5-5
26X57A TV5-15
26X65 TV5-5
26X65A TV5-15
26X66 TV5-5
26X66A TV5-15
26X67 TV5-5
26X67A TV5-15
26X75 TV5-5

Admiral (Cont.)

26X75A TV5-15
26X76 TV5-5
26X76A TV5-15
27DX15 uses 21F1
27K15, 27K16, 27K17, 27K25, 27K26, 27K27, 27K35, 27K36, 27K46, all use 21F1, 21P1
27K85, 27K86, 27K87, use 21F1 or 21P1
27M12 uses 21X2
27M25, 27M26, 27M27
27M35, 27M36 all use 21P1 or 21P1
C28B6 TV11-5
C28B7 TV11-5
29X15 TV5-5
29X16 TV5-5
29X17 TV5-5
29X25 TV5-5
29X25A TV5-15
29X26 TV5-5
29X26A TV5-15
29X27 TV5-5
C33K11 TV21-11
C33K12 TV21-11
C33K13 TV21-11
C33K21 TV21-11
C33K22 TV21-11
C33K23 TV21-11
C33K31 TV21-11
C33K32 TV21-11
C33K33 TV21-11
C33K41 TV21-11
C33K42 TV21-11
C33K43 TV21-11
C33K51 TV21-11
C33K52 TV21-11
C33K53 TV21-11
C33UK11 TV21-11
C33UK12 TV21-11
C33UK13 TV21-11
C33UK21 TV21-11
C33UK22 TV21-11
C33UK23 TV21-11
C33UK31 TV21-11
C33UK32 TV21-11
C33UK33 TV21-11
C33UK41 TV21-11
C33UK42 TV21-11
C33UK43 TV21-11
C33UK51 TV21-11
C33UK52 TV21-11
C33UK53 TV21-11
L33K11 TV21-11
L33K12 TV21-11
L33K13 TV21-11
L33K25 TV21-11
L33K39 TV21-11
L33L11 TV21-11
L33L12 TV21-11
L33L29 TV21-11
L33L31 TV21-11
L33L32 TV21-11
L33L33 TV21-11
L33L41 TV21-11
L33L42 TV21-11
L33M11 TV21-11
L33M12 TV21-11
L33M13 TV21-11
L33M29 TV21-11
L33M39 TV21-11
L33UK11 TV21-11
L33UK12 TV21-11
L33UK13 TV21-11
L33UK25 TV21-11
L33UK39 TV21-11
L33UL11 TV21-11
L33UL12 TV21-11
L33UL29 TV21-11
L33UL31 TV21-11
L33UL32 TV21-11
L33UL33 TV21-11
L33UL41 TV21-11
L33UL42 TV21-11
L33UM11 TV21-11
L33UM12 TV21-11
L33UM13 TV21-11
L33UM29 TV21-11
L33UM39 TV21-11
STF33S11 TV21-15
STF33S12 TV21-15
STF33S13 TV21-15
STF33T11 TV21-15
STF33T12 TV21-15
STF33T29 TV21-15
STF33T31 TV21-15

Admiral (Cont.)

STF33T41 TV21-15
STF33T49 TV21-15
STF33X11 TV21-15
STF33X12 TV21-15
STF33X13 TV21-15
STR33S11 TV21-15
STR33S12 TV21-15
STR33S13 TV21-15
T33K10, E TV21-11
T33K11 TV21-11
T33K12 TV21-11
T33K13 TV21-11
T33UK10 TV21-11
T33IK11 TV21-11
T33UK12 TV21-11
T33UK13 TV21-11
34R15 uses 20V1
34R16 uses 20V1
36R37 TV5-15
36R45 TV5-15
36R46 TV5-15
36X35 TV5-5
36X35A TV5-5
36X36 TV5-5
36X36A TV5-5
36X37 TV5-5
36X37A TV5-5
37F15, 37F16, 37F27, 37F28, 37F35, 37F36, all use 21G1, 21Q1
37F55, 37F56, 37F67 use 21G1 or 21Q1
37K15, 37K16, 37K27, 37K28, 37K35, 37K36, all use 21G1, 21Q1
37K55, 37K56, 37K67 use 21G1 or 21Q1
37M15, and 37M16 use 21G1 or 21Q1
37M25 uses 21Z1
37M26 uses 21Z1
37M27 uses 21Z1
39X16 TV5-5
39X16A TV5-5
39X16B TV5-5
39X17A TV5-5
39X17B TV5-5
39X17C TV5-15
39X25 TV5-5
39X25A TV5-15
39X26 TV5-5
39X26A TV5-15
39X35 TV5-15
39X36 TV5-15
47M15 uses 21W1
47M15A uses 21Z1
47M16 uses 21W1
47M17 uses 21W1
47M35 uses 21Z1
47M36 uses 21Z1
47M37 uses 21Z1
57M10 uses 21Z1A
57M11 uses 21Z1A
57M12 uses 21Z1A
57M16 uses 21Z1A
57M17 uses 21Z1
P93A11, U TV21-3
P93A13, U TV21-3
P93A16, U TV21-3
P93A28, U TV21-3
P93A31, U TV21-3
P93A48, U TV21-3
P93B11, U TV21-3
P93B13, U TV21-3
P93B16, U TV21-3
P93B28 TV21-3
P93B31, U TV21-3
P93B48, UM TV21-3
P93F10 TV20-10
P93K11, U TV21-3
P93UA11 TV21-3
P93UA13 TV21-3
P93UA16 TV21-3
P93UA28 TV21-3
P93UA31 TV21-3
P93UA48 TV21-3
P93UB11 TV21-3
P93UB13 TV21-3
P93UB16 TV21-3
P93UB28 TV21-3
P93UB31 TV21-3
P93UB48 TV21-3
P93UF10 TV20-10
P93F11 TV20-10
P93UF11 TV20-10
P93F16 TV20-10

Admiral (Cont.)

P93UF16 TV20-10
P93F19 TV20-10
P93UF19 TV20-10
P93UK11 TV21-3
PS93G11U TV20-10
PS93G19U TV20-10
T93F10 TV20-10
T93FU10 TV20-10
T101 through T107 use 14YP3B or-BK
TS101 to TS107AL all use 14UY3B
121DX10, -A TV7-5
121DX11 TV7-5
121DX12, -A TV7-5
121DX16, -A, -L TV7-5
121DX17, -A, -L TV7-5
121K15 uses 21M1
121K15A TV7-12
121K16 uses 21M1
121K16A TV7-12
121K17 uses 21M1
121K17A TV7-12
121M10 TV7-12
121M11 uses 21M1
121M11A TV7-12
121M12 uses 21M1
121M12A TV7-12
121UDX12 TV8-15
121UDX15L, 121UDX16L, 121UDX17L, 121UDX26L } use 19L1 chassis
122DX12 TV8-5
122UDX12 TV8-5
T140 TV12-5
TS140 TV12-5
T141 TV12-5
TS141 TV12-5
T142 TV12-5
TS142 TV12-5
T143 TV12-5
TS143 TV12-5
T144AL TV12-5
TS144AL TV12-5
T145AL TV12-5
TS145AL TV12-5
T171 TV12-5
TS171 TV12-5
T172AL TV12-5
TS172AL TV12-5
T173AL TV12-5
TS173AL TV12-5
200 1958-4
202 1958-4
215 1958-4
217 1958-4
218 1958-4
221 1958-14
221DX15, -A, -L TV7-5
221DX16, -A, -L TV7-5
221DX17, -A, -L TV7-5
221DX26, -A, -L TV7-5
221DX38, -A TV7-5
221K45 uses 21M1
221K45A TV7-12
221K46 uses 21M1
221K46A TV7-12
221K47 uses 21M1
221K47A TV7-12
221M26, 221M27 use 21K1
221UDX16L TV8-15
221UDX17L TV8-15
222DX15 TV7-5
222DX15B TV8-5
222DX15S TV7-12
222DX16 TV7-12
222DX16B TV8-5
222DX17 TV7-12
222DX17B TV8-5
222DX26 TV7-12
222DX27 TV7-12
222DX27B TV8-5
222DX48 TV7-12
222DX49 TV7-12
222UDX15 TV8-5
222UDX16 TV8-5
222UDX17 TV8-5
227 1958-14
228 1958-14
231 1958-17
237 1958-17
242 1958-6

Admiral (Cont.)

244 1958-6
245 1958-6
248 1958-6
251, -A Like 4M2
263 1958-3
264 1958-3
265 1958-3
268 1958-3
275 1958-6
278 1958-6
279 1958-6
284 1958-9
288 1958-9
289 1958-9
292 1958-10
296 1958-10
298 1958-10
299 1958-10
L301 TV20-3
LG301 TV19-5
LGU301 TV19-5
LU301 TV20-3
L302 TV20-3
LG302 TV19-5
LGU302 TV19-5
LU302 TV20-3
ST301, STU301, ST302, STU302, ST303, STU303 — Use Chassis 19C8B and 19UC8B
303 1958-12
L303 TV20-3
LG303 TV19-5
LGU303 TV19-5
LU303 TV20-3
304 1958-12
L309 TV20-3
LU309 TV20-3
TG310 TV19-5
TGU310 TV19-5
C311 TV19-21
CU311 TV19-21
L311 TV19-21
LG311 TV19-5
LGU311 TV19-5
LU311 TV19-21
ST311 TV19-21
STU311 TV19-21
TG311 TV19-5
TGU311 TV19-5
C312 TV19-21
CU312 TV19-21
L312 TV19-21
LG312 TV19-5
LGU312 TV19-5
LU312 TV19-21
ST312 TV19-21
STU312 TV19-21
TG312 TV19-5
TGU312 TV19-5
C313 TV19-21
CU313 TV19-21
L313 TV19-21
LG313 TV19-5
LGU313 TV19-5
LU313 TV19-21
ST313 TV19-21
STU313 TV19-21
TG313 TV19-5
TGU313 TV19-5
320R17 TV5-15
320R25 TV5-15
320R26 TV5-15
T320 TV20-3
TU320 TV20-3
321DX15, -A, -L TV7-5
321DX16, -A, -L TV7-5
321DX17, -A, -L TV7-5
321DX25A, -B TV7-5
321DX26, -A, B TV7-5
321DX27A, -B TV7-5
321F46, 321F47, & 321F49 use 21L1
321F65, 321F66, 321F67 use 21N1
321K15, 321K16, 321K18, 321K27, 321K35, 321K36, 321K46 to 321K48 all use 21L1
321K65, 321K66, 821K67 use 21N1

Admiral (Cont.)

321M25 uses 21Y1
321M25A TV7-12
321M26 uses 21Y1
321M26A TV7-12
321M27 uses 21Y1
321M27A TV7-12
321UDX15L TV8-15
321UDX16L TV8-15
C321 TV19-21
CU321 TV19-21
L321 TV20-3
LG321 TV19-5
LGU321 TV19-5
LU321 TV20-3
STF321 TV19-21
STFU321 TV19-21
T321 TV20-3
TU321 TV20-3
322DX16 TV7-12
322DX16A TV8-5
322UDX16 TV8-5
C322 TV19-21
CU322 TV19-21
L322 TV20-3
LG322 TV19-5
LGU322 TV19-5
LU322 TV20-3
STF322 TV19-21
STFU322 TV19-21
T322 TV20-3
TU322 TV20-3
C323 TV19-21
C323A6 TV12-19
C323A7 TV12-19
C323A16 TV12-19
C323A17 TV12-19
C828A19 TV12-19
C323B2 TV12-22
C828B3 TV12-22
C323B26 TV12-22
C323B27 TV12-22
CS323A6 TV12-20
CS323A7 TV12-20
CS323A16 TV12-20
CS323A17 TV12-20
CS323A19 TV12-20
CS323B2 TV12-24
CS323B3 TV12-24
CS323B26 TV12-24
CS323B27 TV12-24
CU323 TV19-21
L323 TV20-3
LG323 TV19-5
LGU323 TV19-5
LU323 TV20-3
STF323 TV19-21
STFU323 TV19-21
T323 TV20-3
T323A1, -A TV12-19
T323A2 TV12-19
T323A3, -A TV12-19
T823B1 TV12-22
T323B2 TV12-22
T323B3 TV12-22
TS323A1 TV12-20
TS323A2 TV12-20
TS323A3 TV12-20
TS323B1 TV12-24
TS323B2 TV12-24
TS323B3 TV12-24
TU323 TV20-3
C325A6, -A TV12-19
C325A7, -A TV12-19
C325B26 TV12-22
C325B27 TV12-22
CS325A6 TV12-20
CS325A7 TV12-20
CS325B26 TV12-24
CS825B27 TV12-24
329 1960-16
331 1958-19
C331 TV19-21
CU331 TV19-21
C332 TV19-21
CU332 TV19-21
C333 TV19-21
CU333 TV19-21
335 1958-19
338 1958-19
STF339 TV19-21
STFU339 TV19-21
341 1958-21
C341 TV20-3
C341G1 TV20-3

Admiral (Cont.)

C341G11 TV20-3
CU341 TV20-3
CU341G1 TV20-3
CU341G11 TV20-3
L341 TV19-21
LU341 TV19-21
STF341 TV19-21
STFU341 TV19-21
C342 TV20-3
C342G2 TV20-3
C342G12 TV20-3
CU342 TV20-3
CU342G2 TV20-3
CU342G12 TV20-3
L342 TV19-21
LU342 TV19-21
C343 TV20-3
C343G3 TV20-3
C343G13 TV20-3
CU343 TV20-3
CU343G3 TV20-3
CU343G13 TV20-3
L343 TV19-21
LU343 TV19-21
347 1958-21
C351 TV20-3
CU851 TV20-3
L351 TV19-21
LU351 TV19-21
C352 TV20-3
CU352 TV20-3
L352 TV19-21
LU352 TV19-21
C353 TV20-3
CU353 TV20-3
L353 TV19-21
LU353 TV19-21
STF351, STFU351, STF352, STFU352, STF353, STFU353 — Use Chassis 19C8B and 19UC8B
C360 TV20-3
CU360 TV20-3
361 1955-7
C361 TV20-3
CU361 TV20-8
L361 TV19-21
LU361 TV19-21
STF361 TV19-21
STFU361 TV19-21
362 1958-21
C362 TV20-3
CU362 TV20-3
L362 TV19-21
LU362 TV19-21
363 1958-21
364 1958-21
366 1958-21
STF371 TV19-21
STFU371 TV19-21
372 1958-21
373 1958-21
382 1958-13
L382 TV19-21
LU382 TV19-21
383 1958-13
384 1958-13
392 1959-6
STF392, A TV20-3
STFU392, A TV20-3
393 1959-6
STF393, A TV20-3
STFU393, A TV20-3
L389 TV19-21
LU389 TV19-21
STF389 TV19-21
STFU389 TV19-21
L391 TV19-21
LU391 TV19-21
STF391, A TV20-3
STFU391, A TV20-3
RC400 Ten-23
402 1958-16
403 1958-16
404 1958-16
421M15 uses 21Y1
421M15A TV7-12
421M16 uses 21Y1
421M16A TV7-12
421M35 TV7-12
421M36 TV7-12

Admiral (Cont.)

421M37 TV7-12
462 1959-6
463 1959-6
502, 511, 513, 515, 518 — Use Chassis 4W2 See 1958-4
520M11 TV7-12
520M12 TV7-12
520M15 TV7-12
520M16 TV7-12
520M17 TV7-12
521 1959-4
521M15, 521M16, 521M17 use 21Y1
528 1959-4
531 uses 8L1
537 uses 8L1
RC550, -A Twelve-11
RC550GA Twelve-11
561 1959-8
566 1959-8
581 1959-3
582 1959-3
RC600 1958-11
RC625, RC630, RC650 similar to RC600
632 1959-9
633 1959-9
634 1959-9
642 1959-9
643 1959-9
644 1959-9
649 1959-9
654 1959-9
662 1959-9
663 1959-9
664 1959-9
671 1959-9
691 1960-6
692 1960-6
703 1960-9
708 1960-9
711 1960-15
715 1960-15
739 1960-8
742 1960-12
743 1960-12
751 1960-14
757 1960-14
Y793 1960-7
Y797 1960-7
Y798 1960-7
801 1959-5
802 1959-5
808 1959-5
811 1959-8
811B 1960-13
816 1959-8
816B 1960-13
Y821 1960-15
Y822 1960-15
Y833 1960-4
Y837 1960-4
Y838 1960-4
Y839 1960-4
Y846 1960-4
Y847 1960-4
Y848 1960-4
Y849 1960-4
Y853 1960-5
Y853C 1961-8
Y858 1960-5
Y865 1960-5
Y865B 1961-8
Y866 1960-5
Y866B 1961-8
873 1960-4
875 1960-4
878 1960-4
P901 TV19-9
UP901 TV19-9
P902 TV19-9
UP902 TV19-9
P908M TV21-3
UP908M TV21-3
P909 TV19-9
UP909 TV19-9
P910 TV19-9
UP910 TV19-9
P911 TV19-9
UP911 TV19-9
P915 TV19-9

Admiral (Cont.)

UP915 TV19-9
P918 TV19-9
UP918 TV19-9
PS921, -U TV19-9
925 1960-16
PS925, -U TV19-9
PS928, -U TV19-9
929 1960-16
T930 TV19-15
TU930 TV19-15
P931 TV19-15
T931 TV19-15
TU931 TV19-15
UP931 TV19-15
P935 TV19-15
T935 TV19-15
TU935 TV19-15
UP935 TV19-15
938 1960-16
Y949 1960-16
C951 TV19-15
CU951 TV19-15
C952 TV19-15
CU952 TV19-15
C953 TV19-15
CU953 TV19-15
C969 TV19-15
CU969 TV19-15
C971 TV19-15
CU971 TV19-15
Y979 1961-9
Y1002 1961-9
Y1009 1961-9
T1010 TV12-5
TS1010 TV12-5
T1011AL TV12-5
TS1011AL TV12-5
T1012AL TV12-5
TS1012AL TV12-5
T1013AL TV12-5
TS1013 uses 14UY3B
Y1021 1961-9
Y1022 1961-9
Y1023 1961-9
T1023, T1024AL — Use 14YP3B
TS1023, TS1024AL — Use 14UY8B
P1104A, E TV22-27
UP1104C TV22-27
P1110A, E TV22-27
UP1110C TV22-27
P1112A, E TV22-27
UP1112C TV22-27
P1113A, E TV22-27
UP1113C TV22-27
P1119A, E TV22-27
UP1119C TV22-27
Y1189 1960-8
Y1189A 1961-4
T1410 uses 14YP3C
T1420 uses 14YP3C
TS1420 uses 14UY3C
T1710 uses 14YP3D
T1801 TV10-5
TS1801 TV10-5
T1802 TV10-5
TS1802 TV10-5
T1806 TV10-5
TS1806 TV10-5
T1807 TV10-5
TS1807 TV10-5
T1811, T1812, T1822 use 19B1 Chassis
TA1811 TV9-11
TU1811 TV8-15
T1812B uses 20XP5
TA1812 TV9-11
TA1812B TV10-39
TU1812 TV8-15
TA1822 TV9-11
TU1822 TV8-15
T1831 TV9-10
TA1831 TV10-39
T1832 TV9-10
TA1832 TV10-39
T1842 TV9-10
TA1842 TV10-39
Y2009 1960-10
Y2011 1960-10
Y2012 1960-10
Y2013 1960-10
Y2023 1960-10

Admiral (Cont.)

Y2027 1960-10
Y2028 1960-10
Y2056 Uses 5F4A
Y2061 1961-16
Y2063 1961-16
Y2067 1961-16
Y2068 1961-16
Y2081 1962-5
Y2081A 1962-7
Y2082 1962-5
Y2082A 1962-7
Y2083 1962-5
Y2083A 1962-7
Y2091 1962-8
Y2093 1962-8
Y2098 1962-8
Y2101 1962-6
Y2102 1962-6
Y2108 1962-6
Y2119 1961-17
Y2127 1961-18
TA2211 TV9-11
T2212 uses 19F1A
T2212B TV9-10
TA2212 TV9-11
TA2212B TV10-39
TU2212 TV8-15
C2215 TV8-15
CA2215Z TV9-11
CU2215 TV8-15
L2215Z, L2216Z, LA2215Z TV9-11
LU2215Z, -2216Z, -17Z use 19K2AZ 19K2Z
T2215 TV8-15
TA2215 TV9-11
TU2215 TV8-15
C2216 TV8-15
C2216AZ TV9-5
CA2216Z TV9-11
CU2216 TV8-15
F2216 see 22A3
FU2216 see 22B3
H2216 TV8-15
HA2216Z TV9-11
HU2216 TV8-15
K2216 TV8-16
K2216A TV9-5
KA2216 TV9-11
KU2216 TV8-15
LA2216Z TV9-11
T2216 TV8-15
T2216A TV9-5
TA2216, -A TV9-11
TU2216 TV8-15
C2217 TV8-15
CA2217Z TV9-11
CU2217 TV8-15
F2217 see 22A3
FU2217 see 22B3
H2217 TV8-15
HA2217Z TV9-11
HU2217 TV8-15
K2217 TV8-15
K2217A TV9-5
KA2217 TV9-11
KU2217 TV8-15
L2217Z use 19F2AZ
LA2217Z TV9-11
T2217 TV8-15
T2217A TV9-5
TA2217, -A TV9-11
TU2217 TV8-15
F2218 see 22A3
FU2218 see 22B3
T2218 TV8-16
TA2218 TV9-11
TU2218 TV6-15
Y2221 1962-4
T2222 uses 19F1
TA2222 TV9-11
TU2222 TV8-15
Y2223 1962-4
Y2223A 1963-8
C2225 see 22A3
CU2225 see 22B3
C2226 see 22A3
CU2226 see 22B3
F2226 TV9-5
FA2226 TV9-11
KA2226 TV9-11
TA2225 TV9-11
K2226, K2227 use 19G1A Chassis

Admiral (Cont.)

T2226 uses 19F1
TU2226 TV8-15
Y2226 1962-4
C2227 see 22A3
CU2227 see 22B3
KA2227 TV9-11
Y2229 1962-4
Y2231, + 1963-8
T2232 uses 22F2
TU2232 uses 22G2
Y2232, + 1963-8
C2236 TV8-15
C2236A TV9-5
CA2236, A TV9-11
CU2236 TV8-15
HT2235 1957-3
HT2236 1958-21
T2236 see 22A3
TU2236 see 22B3
C2237 TV8-15
CA2237 TV9-11
CU2237 TV8-15
HT2237 1957-3
HT2237 1958-21
T2237 see 22A3
TU2237 see 22B3
Y2238, + 1963-8
T2239 see 22A3
T2242 uses 19K1
T2242BZ TV9-10
TA2242 TV9-11
C2246 uses 19F1B
CA2246 TV9-11
Y2252 1962-7
Y2253 1962-7
C2256 TV9-10
CA2256 TV10-39
K2256 TV9-10
KA2256 TV10-39
Y2256 1962-7
K2257 TV9-10
KA2257 TV10-39
T2301D TV12-13
T2301DL TV12-13
T2301DR TV12-13
T2301DSA TV12-19
T2301SZ TV10-31
T2301Z TV10-31
TS2301DRW TV11-5
TS2301Z TV10-31
Y2301GP(S) 1963-8
T2302DR TV12-13
T2302DSA TV12-19
T2302Z TV10-31
TS2302DRW TV11-5
TS2302Z TV10-31
T2303D TV12-13
T2303DSA TV12-19
TS2303DRW TV11-5
Y2303GP(S) 1963-8
T2305D TV12-13
C2306+ TV10-39
C2306BZ see 20X5EZ
CA2306BZ TV10-39
CA2306Z TV10-39
T2306D TV12-13
C2307BZ see 20X5EZ
C2307+ TV10-39
CA2307BZ TV10-39
CA2307Z TV10-39
T2307D TV12-13
Y2307GP(S) 1963-8
T2311Z TV10-12
TA2311Z TV10-12
Y2311 1963-11
T2312Z TV10-12
TA2312Z TV10-12
Y2312 1963-11
C2316Z TV10-12
CA2316Z TV10-12
T2316Z TV10-12
TA2316Z TV10-12
C2317Z TV10-12
CA2317Z TV10-12
T2317Z TV10-12
TA2317Z TV10-12
T2318Z TV10-12
TA2318Z TV10-12
C2319Z TV10-12
T2319Z TV10-12
Y2319 1963-11
Y2321 1963-12
Y2323 1963-12
C2326Z TV10-12

Admiral (Cont.)

CA2326Z	TV10-12
F2326Z	TV10-12
FA2326Z	TV10-12
L2326Z	TV10-12
LA2326Z	TV10-12
T2326Z	TV10-31
TS2326Z	TV10-31
C2327Z	TV10-12
CA2327Z	TV10-12
F2327Z	TV10-12
FA2327Z	TV10-12
L2327Z	TV10-12
LA2327Z	TV10-12
T2327SZ	TV10-31
T2327Z	TV10-31
TS2327Z	TV10-31
Y2327	1963-12
F2328Z	TV10-12
FA2328Z	TV10-12
Y2332	1963-10
Y2333	1963-10
C2336Z	TV10-31
CS2336Z	TV10-31
T2336Z	TV10-31
TS2336Z	TV10-31
C2337Z	TV10-31
CS2337Z	TV10-31
T2337Z	TV10-31
TS2337Z	TV10-31
C2338Z	TV10-31
CS2338Z	TV10-31
Y2338	1963-10
Y2347	1964-7
Y2351	1964-10
C2356Z	TV10-31
CS2356Z	TV10-31
C2365Z	TV10-31
CS2365Z	TV10-31
C2366FZ	TV10-31
CS2366FZ	TV10-31
K2366Z see	20X5GZ
KA2366Z	TV10-39
C2367FZ	TV10-31
CS2367FZ	TV10-31
K2367Z see	20X5GZ
KA2367Z	TV10-39
T2501Z	TV10-31
TS2501Z	TV10-31
T2502Z	TV10-31
TS2502Z	TV10-31
T2506FZ	TV10-31
TS2506FZ	TV10-31
T2507FZ	TV10-31
TS2507FZ	TV10-31
C2526 uses	19G2
CA2526	TV9-11
CU2526 uses	19H2
C2566FZ	TV10-31
CS2566FZ	TV10-31
C2567FZ	TV10-31
CS2567FZ	TV10-31
C2826Z	TV10-12
C2827Z	TV10-12
CA2827Z	TV10-12
Y2993	1961-7
Y2996	1961-7
Y2998	1961-7
Y2999	1961-7
T3000	TV21-19
TU3000	TV21-19
T3001	TV21-19
TU3001	TV21-19
T3004	TV21-19
TU3004	TV21-19
Y3004, Y3006, Y3008	Use 5L5 1960-4
T3011	TV21-19
TU3011	TV21-19
T3012	TV21-19
TU3012	TV21-19
Y3012A	1963-6
Y3012, Y3016, Y3019	use 5P5, see 1960-4
Y3016A	1963-6
Y3019A	1963-6
T3021	TV21-19
TU3021	TV21-19
Y3021	1961-11
T3022	TV21-19
TU3022	TV21-19
Y3027	1961-11
Y3037	1961-4
Y3037A	1961-7
Y3038	1961-4

Admiral (Cont.)

Y3046	1961-12
Y3048	1961-12
Y3049	1961-12
Y3051	1961-13
Y3051A	1963-7
Y3053	1961-13
Y3053A	1963-7
Y3058	1961-13
Y3058A	1963-7
Y3083	1961-14
T3100C, D	TV22-20
TU3100C, D	TV22-20
Y3100	1963-6
C3101	TV21-19
CU3101	TV21-19
T3101C, D	TV22-20
TS3101D	TV22-20
TU3101C, D	TV22-20
C3102	TV21-19
CU3102	TV21-19
C3103	TV21-19
CU3103	TV21-19
T3104C, D	TV22-20
TS3104D	TV22-20
TU3104C, D	TV22-20
Y3104	1963-6
Y3107	1963-6
STF3109, A	TV20-3
Y3109	1963-6
C3111	TV21-19
CU3111	TV21-19
L3111	TV20-3
LU3111	TV20-3
STF3111, A	TV20-3
STFU3111, A	TV20-3
T3111C, D	TV22-20
TU3111C, D	TV22-20
C3112	TV21-19
CU3112	TV21-19
L3112	TV20-3
LU3112	TV20-3
T3112C, D	TV22-20
TU3112C, D	TV22-20
C3113	TV21-19
CU3113	TV21-19
C3121	TV21-19
CU3121	TV21-19
T3121C, D	TV22-20
TS3121D	TV22-20
TU3121C, D	TV22-20
C3122	TV21-19
CU3122	TV21-19
T3122C, D	TV22-20
TS3122D	TV22-20
TU3122C, D	TV22-20
C3125	TV21-19
CU3125	TV21-19
L3129	TV20-3
LU3129	TV20-3
Y3133	1962-3
Y3137	1962-3
Y3203	1963-9
L3211	TV21-19
LU3211	TV21-19
L3212	TV21-19
LU3212	TV21-19
L3213	TV21-19
LU3213	TV21-19
C3301C, D	TV22-20
CS3301D	TV22-20
CU3301C	TV22-20
CU3301D	TV22-20
L3301C, D	TV22-20
LU3301C, D	TV22-20
C3302C, D	TV22-20
CS3302D	TV22-20
CU3302C, D	TV22-20
L3302C, D	TV22-20
LU3302C, D	TV22-20
Y3303	1964-4
C3305C, D	TV22-20
CS3305D	TV22-20
CU3305C, D	TV22-20
Y3308	1964-4
Y3309	1964-4
C3311C, D	TV22-20
CS3311D	TV22-20
CU3311C, D	TV22-20
LS3311D	TV22-20
C3312C, D	TV22-20
CS3312D	TV22-20
CU3312C, D	TV22-20
LS3312D	TV22-20
C3313C, D	TV22-20
CS3313D	TV22-20
CU3313C, D	TV22-20

Admiral (Cont.)

L3313C, D	TV22-20
L53313D	TV22-20
LU3313C, D	TV22-20
Y3313 like	5A6
Y3318 like	5A6
Y3321	1964-5
C3321C, D	TV22-20
CS3321D	TV22-20
CU3321C, D	TV22-20
C3322C, D	TV22-20
CS3322D	TV22-20
CU3322C, D	TV22-20
Y3323	1964-5
Y3337	1964-4
Y3346	1964-5
Y3353	1964-5
Y3354	1964-5
Y3359	1964-5
Y3363	1964-5
Y3364	1964-5
Y3368	1964-5
HS3376	1957-7
Y3376	1964-5
HS3377	1957-7
Y3377	1964-5
Y3379	1964-5
Y3381	1964-5
Y3383	1964-5
T3400C, D	TV22-9
TS3400D	TV22-9
TU3400C, D	TV22-9
L3401C, D	TV22-9
LS3401D	TV22-9
LU3401C, D	TV22-9
T3401C, D	TV22-9
TS3401D	TV22-9
TU3401C, D	TV22-9
L3402C, D	TV22-9
LS3402D	TV22-9
LU3402C, D	TV22-9
L3403C, D	TV22-9
LS3403D	TV22-9
LU3403C, D	TV22-9
T3404C, D	TV22-9
TS3404D	TV22-9
TU3404C, D	TV22-9
L3411C, D	TV22-9
LS3411D	TV22-9
LU3411C, D	TV22-9
T3411C, D	TV22-9
TS3411D	TV22-9
TU3411C, D	TV22-9
L3412C, D	TV22-9
LS3412D	TV22-9
LU3412C, D	TV22-9
T3412C, D	TV22-9
TS3412D	TV22-9
TU3412C, D	TV22-9
L3421C, D	TV22-9
LS3421D	TV22-9
LU3421C, D	TV22-9
Y3421	1964-6
Y3426	1964-6
Y3431	1964-6
L3435C, D	TV22-9
LS3435D	TV22-9
LU3435C, D	TV22-9
Y3436	1964-6
L3441C, D	TV22-9
LU3441C, D	TV22-9
L3442C, D	TV22-9
LU3442C, D	TV22-9
Y3443	1964-4
L3445C, D	TV22-9
LU3445C, D	TV22-9
L3449C, D	TV22-9
LU3449C, D	TV22-9
L3451C, D	TV22-9
LU3451C, D	TV22-9
L3452C, D	TV22-9
LU3452C, D	TV22-9
L3455C, D	TV22-9
LU3455C, D	TV22-9
L3469C, D	TV22-9
LU3469C, D	TV22-9
SR3501	TV21-19
SRU3501	TV21-19
SR3502	TV21-19
SRU3502	TV21-19
SR3503	TV21-19
SRU3503	TV21-19
SR3511C, D	TV22-20
SRU3511C	TV22-20
SRU3511D	TV22-20
SR3512C, D	TV22-20
SRU3512+	TV22-20
SR3513C, D	TV22-20
SRU3513+	TV22-20

Admiral (Cont.)

T3600C, D	TV22-20
TU3600C, D	TV22-20
C3601C, D	TV22-20
CU3601C, D	TV22-20
T3601C, D	TV22-20
TU3601C, D	TV22-20
C3602C, D	TV22-20
CU3602C, D	TV22-20
T3604C, D	TV22-20
TU3604C, D	TV22-20
C3605C, D	TV22-20
CU3605C, D	TV22-20
T3611C, D	TV22-20
TU3611C, D	TV22-20
T3612C, D	TV22-20
TU3612C, D	TV22-20
SM3641C, D	TV22-20
SMU3641+	TV22-20
S3702	TV21-19
SU3702	TV21-19
SM3811	TV21-19
SMU3811	TV21-19
SM3812	TV21-19
SMU3812	TV21-19
SM3831	TV21-19
SMU3831	TV21-19
SM3841C, D	TV22-20
SMU3841+	TV22-20
SM3842C, D	TV22-20
SMU3842+	TV22-20
SM3843C, D	TV22-20
SMU3843+	TV22-20
SM3911C, D	TV22-20
SMU3911+	TV22-20
SM3921C, D	TV22-20
SMU3921+	TV22-20
SM3922C, D	TV22-20
SMU3922+	TV22-20
SM3925C, D	TV22-20
SMU3925+	TV22-20
SM3931C, D	TV22-20
SMU3931+	TV22-20
SM3932C, D	TV22-20
SMU3932+	TV22-20
Y4017	1961-10
Y4037 uses	2E1A
Y4049	1961-3
Y4057	1961-5
Y4067	1961-9
Y4071	1961-3
Y4072	1961-3
Y4073	1961-3
Y4081	1961-5
Y4082	1961-5
Y4083	1961-5
Y4131	1961-9
Y4132	1961-9
Y4159	1961-9
Y4461, A	1963-3
Y4462, A	1963-3
Y4463, A	1963-3
Y4482, A	1963-3
Y4483, A	1963-3
Y4499, A	1963-3
Y4659	1964-3
Y4677	1964-3
Y4851	1964-8
Y4852	1964-8
Y4871	1964-8
Y4872	1964-8
Y4885	1964-8
Y4918	1964-3
Y4941A	1964-8
P6000C, D	TV22-3
PS6000	TV22-3
UP6000C, D	TV22-3
P6001C, D	TV22-3
PS6001	TV22-3
UP6001C, D	TV22-3
P6009C, D	TV22-3
PS6009	TV22-3
UP6009C, D	TV22-3
P9002C, D	TV22-3
PS9002	TV22-3
UP9002C, D	TV22-3
P9004C, D	TV22-3
PS9004	TV22-3
UP9004C, D	TV22-3
P9005C, D	TV22-3
PS9005	TV22-3
UP9005C, D	TV22-3
P9009C, D	TV22-3
PS9009	TV22-3
UP9009C, D	TV22-3
P9010+	TV22-15
PS9010	TV22-15
UP9010+	TV22-15

Admiral (Continued)

P9014+	TV22-15
PS9014	TV22-15
UP9014+	TV22-15
P9015+	TV22-15
PS9015	TV22-15
UP9015+	TV22-15
P9020+	TV22-15
PS9020	TV22-15
UP9020	TV22-15
P9029+	TV22-15
PS9029	TV22-15
UP9029+	TV22-15
AA9100C	TV22-3
AAU9100C	TV22-3
P9100C	TV22-3
UP9100C	TV22-3
P9101C	TV22-3
UP9101C	TV22-3
P9102C	TV22-3
UP9102C	TV22-3
P9103C	TV22-3
UP9103C	TV22-3
P9109C	TV22-3
UP9190C	TV22-3
P9200+	TV22-15
PS9200	TV22-15
UP9200+	TV22-15
P9204+	TV22-15
PS9204	TV22-15
UP9204+	TV22-15
P9211+	TV22-15
PS9211	TV22-15
UP9211+	TV22-15
P9219+	TV22-15
PS9219	TV22-15
UP9219+	TV22-15
P9221+	TV22-15
UP9221+	TV22-15
P9229+	TV22-15
UP9229+	TV22-15
T9403+	TV22-15
TU9408+	TV22-15
P9509	TV21-7
UP9509	TV21-7
P9511	TV21-7
UP9511	TV21-7
P9513	TV21-7
UP9513	TV21-7
P9521	TV21-7
UP9521	TV21-7
P9523	TV21-7
UP9523	TV21-7
P9538	TV21-7
UP9538	TV21-7
P9548	TV21-7
UP9548	TV21-7
AA9900C, D	TV22-3
AAU9900C, D	TV22-3
SAA9900	TV22-3
AA9903C, D	TV22-3
AAU9903C, D	TV22-3
SAA9903	TV22-3
SAA9913	TV22-3
AA9913+	TV22-15
AAU9913+	TV22-15
SAA9913+	TV22-15
AA9998+	TV22-15
AAU9998+	TV22-15

AIR CHIEF
see Firestone

AIR KING PRODUCTS
also CBS-Columbia

17C5BC use	700-100
17C3C uses	700-100
17C9C uses	700-100
17C10C "	700-100
17K1C uses	700-100
17M1C uses	700-100
17M2C uses	700-100
17M3C uses	700-100
17T2C uses	700-100
20C1C uses	700-120
20C2C uses	700-120
20C3C uses	700-145
20C4B "	700-140
20C4C uses	700-140
20K1C usee	700-130
20M1C uses	700-140
20M3C uses	700-140
20T2C uses	700-140
257	Three-7
470-1	Eight-12
700-100 etc.	TV6-20

AIR KING (Cont.)

700-120	TV6-20
700-130, -134, -136	
Like 700-120	
700-137 +AM-FM	
Like 700-120	
700-140	TV6-20
700-144 focus dif.	
Like 700-140	
700-145 uses	20CP4
Similar to 700-120	
700-150 uses	21EP4
Like 700-100	
3905	Three-7
4012	Four-7
4016	Four-7
4112	Four-7
4136	Four-7
4257	Three-7
4604-A	Seven-14
4608	Seven-15
4625	Seven-16

AIRLINE
see Montgomery

ALLIED RADIO CORP.

5A-150	Six-16
5A-152	Six-16
5A-154	Six-16
5A-163	Six-16
5B175	Eight-12
5B176	Eight-12
5C175	Eight-12
5C176	Eight-12
5E250	Eleven-133
5F565 see	Ten-162
5G563	Eleven-59
5N, 5NL	Three-9
6A-122	Six-14
6A-127	Six-15
6B-122	Eight-14
6B-127	Eight-13
6C-122	Eight-14
6C-127	Eight-13
SG-8	One-6
AU-10	Three-8
D-100	Five-8
D-101	Five-8
D-109	Five-8
D-170	Five-9
A9710	One-7
A9711	One-7
A9712	One-7
B-10596	Four-8
B-10598	Four-8
B-10600	Four-8
B-10606	Four-8
E10725	Three-8
A10760	Three-8
A10806	Three-9
A10807	Three-9
A10822	Three-8
E10855	Three-9
B-17103	Four-3
B-17104	Four-8
B-17107	Four-8
B-17109	Five-8
B-17113	Four-8
B-17114	Four-8
B-17165	Four-9
B-17180	Four-9
B-17187	Four-9
B-17188	Five-7

AMERICAN MOTORS

8990377	1957-66
8990378	1956-73
another type	1956-84
8990455	1957-66
8990494	1958-94
8990543	1958-92
8990576	1959-69
8990582	1959-68

AMERICAN MOTORS (Continued)

8990706	1960-74
8990705, 8990810	Similar to 8990582
8990811	1960-75
8990831	1961-67
8990832	1961-66
8990833	1961-70
3990981	1962-50
8991142	1964-66

ANDREA RADIO CORP.

UF-6	Three-11
P-163	Twelve-27

ANSLEY RADIO CORP.

D1	Three-10
D16	Three-10
D20	Three-10
41A	Seven-17
51	Five-10

APEX

10	One-213
46, 47	One-214

ARVIN

5R65	1961-22
5R67	1961-22
10R16	1961-19
10R18	1961-19
10R22, 10R27	like 5591 less clock
10R32	1961-20
10R38	1961-20
10R39	1961-20
12R23, 12R25, 12R29	Like 5594 less clock
13R35	1964-11
13R37	1964-11
21-550	TV9-25
21-551	TV9-25
21-552	TV9-25
21-553	TV9-25
21-554	TV9-23
21-555	TV9-23
21-557	TV9-23
RE-29	One-112
30R12	1961-21
30R18	1961-21
31R25	1962-10
31R26	1962-10
33R28	1964-15
33R29	1964-15
RE-35	One-112
42R25	1963-13
42R29	1963-13
42R53 like	10R32
42R63	1963-13
42R77	1963-13
43R25, 43R29	Same as 42R25
43R43	1964-15
RE-48	Three-66
51R17, 51R23, 51R27	Like 10R16 plus clock
51R35, 51R37	Like 5594
51R43, 51R45	like 10R32
51R52, 51R56	like 10R32
52R35, 52R37	like 5594
52R43, 52R47, 52R55, 52R57	like 10R32 see 1961-20
53R05	1964-11

HOW TO USE THIS INDEX

This Master INDEX will tell you in which SUPREME volume and on what page the material you need is listed. Please refer to the easy-to-follow charts on page 2, and to the explanation at top of page 3, for guidance.

Arvin (Cont.)

53R07 1964-11
53R17 1964-11
53R19 1964-11
53R27 1964-11
53R28 1964-11
RE-55 Three-67
58, 58A One-112
RE-58 Three-67
59 Same as 2581
60 see 2581
60R19 see 7595
60R23 1961-23
60R28 1961-23
60R29 1961-23
60R33, 60R35, 60R38 like 9595 1960-23
60R47 1961-23
60R49 1961-23
60R58 1961-24
60R68 1961-24
60R69 1961-24
60R73 1961-24
60R79 1961-24
RE-60 Three-68
61R13 1962-9
61R16 1962-9
61R19 1962-9
61R23 1962-9
61R26 1962-9
61R29 1962-9
61R35 1962-9
61R39 1962-9
61R48 1962-11
61R49 1962-11
61R58 1962-14
62R09 1963-14
62R13, 62R16, 62R19, 62R23, 62R26, 62R29 like 61R13 etc. 1962-9
62R35, 62R39 like 61R48
62R48 1963-15
62R49 1963-15
62R65 1963-17
62R69 1963-17
63R38 1964-13
63R58 1964-12
71P19 radio like Model 5594
72P03 1963-19
72P25 1963-18
72P33 1963-19
72P59 1963-20
72P68 1963-20
73P93 like 72P33
73P16 like 72P33
73P59 like 72P59
73P98 like 72P25
RE-78 Four-87
RE-78 Four-88
80P78 1962-12
81P68 1962-12
81P75 1962-18
81P78 1962-13
RE-82 Four-86
83P15 1964-14
83P43 1964-14
83P53 1964-14
83P55 1964-14
83P68 like 81P68
83P76 like 81P75
RE-84 Four-89
RE-86 Four-89
88 One-112
90P53 1961-25
90P58 1961-25
RE-91 Five-80
92 Two-86
92P48 1963-21
92P58 like 81P75
RE-92 Five-80
93P38 like 81P75
RE-98 Five-82
RE-99 Five-82
140P Eight-123
150-TC Eight-128
151-TC Eight-128
152T Nine-72
153T Nine-72
160T Nine-76
161T Nine-76

Arvin (Continued)

182TFM Eight-127
RE-200 Six-87
RE-201 Six-86
RE-202 Eight-124
RE-204 Seven-111
RE-206-1 Seven-112
RE-206-2 Eight-125
RE-209 Eight-123
RE-228 Eight-128
RE-229 Eight-126
RE-231 Eight-124
RE-232 Nine-76
RE-233 Nine-72
RE-237 Eight-127
240P Nine-78
241P Nine-73
242T Nine-78
RE-242 Nine-77
243T Nine-78
RE-243 Nine-73
244P Nine-73
RE-244 Nine-73
RE-248 Nine-75
250P Nine-75
RE-251 Nine-78
RE-253 Nine-74
RE-254 Nine-78
RE-255 Nine-73
RE-256 Nine-73
RE-259 Nine-73
RE-260 Ten-97
RE-273 Ten-99
RE-274 Ten-96
RE-277 Eleven-13
RE-277-1 Eleven-13
RE-278 Ten-100
RE-278-1 1955-11
280TFM Nine-74
RE-280 Eleven-11
281TFM Nine-74
RE-281 Eleven-10
RE-284 Eleven-12
TE286 TV6-22
TE290 TV5-19
RE-292 Twelve-19
RE-297 Twelve-20
TE300 TV6-22
TE302 TV6-22
RE-306 Twelve-30
RE-307 Twelve-22
RE-308 Twelve-21
RE-310 Twelve-23
RE-313 Twelve-23
TE315 TV6-22
TE319 TV7-19
TE320-1 like TE315
RE-323 1953-19
RE-327 1953-20
TE330 TV7-19
TE330-1 TV7-19
TE330-2 to -7 minor differences from TE330-1
TE331 TV7-19
TE332 TV7-19
RE-333 1954-14
TE334 like TE315
TE337 TV7-23
TE340-2 similar to TE341
341T Ten-96
TE341 TV7-23
TE341-3 TV7-24
RE-342 1954-9
RE-343 1953-22
RE-347 1954-11
RE-348 1954-12
RE-350 1954-10
RE-352 1954-13
TE355 like TE359
356T Ten-99
357T Ten-99
TE358-1 TV8-19
TE359 TV8-19
360TFM Ten-97
361TFM Ten-97
TE362 like TE359
TE363-1 TV8-19
TE364 TV8-19
RE-369 1955-12
RE-372 1955-15
TE373 like 9240
RE-374 1955-16
RE-375 1955-13

Arvin (Continued)

RE-377 1955-14
RE-378 1955-16
D-379 TV9-25
RE-381 1955-15
D-382 TV9-25
D-382-1, D-382-2 video amp. changes
E-383 TV9-23
TE386 see E-383
RE-389 like RE-372
RE-391 1956-8
RE-392 1956-9
RE-393 1956-10
RE-397 1956-11
422 see RE-91
440T Ten-100
441T uses RE-278
444 Six-87
444-A Six-87
446P Eleven-11
450T Eleven-10
451T Eleven-10
460T Eleven-12
461T Eleven-12
480TFM Eleven-13
481TFM Eleven-13
520 Four-89
522 Four-87
540T uses RE-278
544 Six-86
544-A Six-86
547 Nine-77
547A Nine-77
551T Twelve-20
552AN Eight-124
552N Eight-124
553 Twelve-21
554CCB Twelve-20
554CCM Twelve-20
555 Eight-124
555A Eight-124
558 Seven-111
580TFM Twelve-23
581 1954-14
582CFB Twelve-23
582CFM Twelve-23
622 Four-88
650-P Twelve-19
651T 1953-19
652-P uses RE-202
654-P uses RE-202
655SWT 1953-20
657T Twelve-22
664, -A Seven-112
665 Eight-125
720 Four-89
740T uses RE-278
741T 1954-13
746P 1954-11
747P 1954-11
751TM, -TB 1953-22
753T 1954-12
758T 1954-10
760T 1954-9
780TFM 1954-14
822 Four-86
840T 1955-11
842T 1955-11
848T 1955-12
849T 1955-12
850T 1955-13
851T 1955-14
852P 1955-15
853T 1955-13
854P 1955-15
855T 1955-14
857T 1955-16
858T 1955-16
859T 1955-16
950T 1956-8
950T2 Like above
951T 1956-8
952P, 954P similar to 852P
956T 1956-9
956T1 Like above
957T 1956-10
958T 1956-11
1581 1958-22
1586 1960-18
2094 1960-26
2160 TV5-19
2161 TV5-19
2182 TV5-19
2164 TV5-19

Arvin (Continued)

2410P Nine-73
2563 1957-11
2564 1957-11
2572, 2573 Similar to 950T
2581 1959-13
2584 1959-15
2585 1959-12
2598 1960-21
3561 1957-12
3582 1960-19
3588 1959-14
4126 TV6-22
5170-5173 TV6-22
5176CM use TE320-1
5204 TV6-22
5206 TV6-22
5210 TV6-22
5211 TV6-22
5212 TV6-22
5213TM uses TE334
5561 1957-13
5571, 5572 see 2572 + clock
5578 1958-23
5583 1959-15
5591 1960-24
5592 1960-24
5594 1960-25
6000 Series TV7-19
6173 TV7-19
6175TM TV7-19
6179TM TV7-19
6213TB TV7-19
6213TM TV7-19
6215CB TV7-19
6215CM TV7-19
6640 Eight-125
7200 Series TV7-23
7210CB TV7-23
7210CM TV7-23
7210CR TV7-23
7212CFP TV7-23
7212MEA TV7-23
7214CM TV7-23
7216CB TV7-23
7218CB TV7-23
7218CM TV7-23
7219CM TV7-23
7595 1960-20
8092 1960-26
8093 1960-26
8171, 8179, 8211, 8213, 8215, 8218 Use later version TE319 and TE330
8565 1957-13
8571 1958-24
8572 1958-24
8578 1958-24
8576 1958-25
8581 1959-17
8583 1959-17
8584 1959-16
9210 TV8-19
9211 uses TE355
9212 TV8-19
9213 uses TE355
9215 uses TE355
9216 TV8-19
9218 TV8-19
9219 TV8-19
9240 TV8-19
9245 uses TE378
9562 1957-14
9574 1958-26
9594 1960-22
9595 1960-23
1.40300 1957-11
1.40400 1957-11
1.40600 1957-12
1.40800 1957-13
1.40900 1957-14
1.41100 1958-24
1.41200 1957-13
1.41300 1958-24
1.41400 1958-25
1.41900 see 5571
1.42200 see 2572
1.42202 1961-19
1.43000 1958-26

Arvin (Continued)

1.43400 see 950T2
1.43500 1958-23
1.43700 1959-17
1.43800 1959-13
1.43900 1959-17
1.44000 1958-22
1.44100 1959-15
1.44200 1959-15
1.44600 1959-16
1.44700 1960-19
1.45000 1959-12
1.45200 1959-14
1.46500 1960-18
1.46700 1960-24
1.46800 1960-24
1.46900 1960-25
1.47001 1961-22
1.47200 1960-20
1.47201 see 7595
1.47500 1960-22
1.47600 1960-23
1.47601 like 9595
1.47900 1960-21
1.48101 1961-21
1.48102 1961-21
1.48300 1960-26
1.48600 1960-26
1.49201 1961-23
1.49400 1960-26
1.49501 1961-25
1.49701 see 10R22
1.49801 1961-20
1.50000 See 1.43800
1.50002 see 2581
1.50101 1961-24
1.50300 1961-24
1.50401 1961-23
1.61601 1962-9
1.61701 1962-9
1.62001 1962-12
1.62201 1962-11
1.62402 1962-14
1.63601 see 10R16
1.63801 like 10R16
1.64701 like 5594
1.64901 1962-10
1.65301 1962-12
1.65401 like 71P19
1.65501 1962-13
1.65901 like 10R32
1.66001 like 1.49801
1.66102 1963-17
1.66401 1963-15
1.66402 1963-16
1.66501, 1.66502 like 1.61701
1.66601 1963-14
1.66801 like 61R48
1.67201 1964-14
1.68301 1963-19
1.69201 see 5594
1.69701 1963-18
1.70401 like 81P75
1.70601 1963-21
1.72101 like 5594
1.72401 1963-19
1.72801 like 10R32
1.73201 like 10R32
1.73301 like 10R32
1.74301 1964-15
1.74401 1964-11
1.74501 1964-11
1.75001 1964-13
1.75101 1964-12
1.75401 1964-11
1.76001 1964-11
1.77001 1964-14
1.77401 like 1.72401
1.78001 1964-15

ATWATER KENT

Chassis F One-16
30 One-8
32 One-8
35 One-8
37 One-9
38 One-11
40 One-10
42 One-10
43 One-12
44, 45 One-10

ATWATER KENT (Continued)

46 One-12
47 One-12
48 One-8
52 One-10
53 One-12
55, 55C One-14
56 One-10
57 One-10
60, 60C One-15
70 One-16
81 One-17
82 One-18
84 early One-19
84 late One-20
84F early One-19
84F late One-20
85 One-18
145 One-21
155 One-22
165 One-23
317 One-24
325 One-21
328 One-25
337 One-24
856 One-26
975 One-26

AUTOMATIC RADIO

501 Six-17
502 Six-17
611 Six-17
612X Six-18
640 Six-17
660 Six-18
670 Six-18

BALDWIN RADIO

80 One-27

BELMONT RADIO CORP

4B16 Five-11
4B17 Six-19
5D110 Seven-19
5P19 Seven-18
A-5D118 Nine-12
6D111 Six-20
6D120 Seven-21
6D121 Nine-13
11A25 Five-12
460 Three-12
507 Three-13
513 Three-13
518 Four-10
525 One-29
533 Three-14
533 Four-11
536 Four-12
579 Five-13
681 Four-13
1100 Four-14
5240 Nine-14

BENDIX RADIO

M-4 1954-16
M-4A, -B 1954-16
5BF 1955-17
5BH 1955-18
5BM 1955-18
R5BF 1955-17
R5BLA 1955-18
R5BLB 1955-18
R5BM 1955-18
T5 like 2051
T9 like 17K2
17K2 like T171
T18-1 TV10-43
T18-2 TV10-43
T19 TV11-19
20K2 like C200
20L2 like C200
T20 TV12-27
T20-1 TV12-27
KS21E TV10-43
KS21EU TV10-43
KST21E, EU TV10-43
TS21E, EU TV10-43
TSF21E, EU TV10-43
55X4 Nine-16
65P4 Nine-15
T170 TV6-28
T171 TV6-27
C172 TV6-27

BENDIX (Continued)

T173 TV6-28
C174 TV6-28
C176 TV6-28
C182 TV6-27
T190 TV6-28
C200 TV6-27
416A Eight-15
526A to E Seven-23
R526M Eight-17
626-A Seven-23
636A, C, D Seven-20
676B, C, D Seven-22
697A Eight-16
736-B Seven-24
753F, -M, -W 1954-18
853A to -D 1954-17
951 Eleven-14
951W Eleven-14
953A to -D 1954-17
2025 like 2051
2051 TV5-22
2060 TV6-28
2070 TV6-28
T2100E TV11-19
T2100M TV11-19
T2101M TV11-19
K2250 TV12-27
T2250 TV12-27
K2251 TV12-27
T2251 TV12-27
3051 TV5-22
6001 TV5-22
6003 TV5-22
6100 TV5-22
7001 TV6-28

BOSCH

60, 01 One-204

BRANDES RADIO

B15, B16 One-28

BUCKINGHAM RADIO

80 One-29

BUICK

BKA6A 1957-63
980051 1961-28
980052 1961-29
980132 1961-31
980134 1961-32
980135 1961-29
980296 1963-23
980297 1963-28
980316 1963-26
980462 1964-24
980463 1964-18
980464 1964-24
980626 1964-21
980635 1964-21
980655 1964-26
980690 Seven-166
980733 Seven-166
980744 Eight-175
980745 Eight-175
980782 Ten-163
980797 Nine-141
980798 Nine-141
980899 Ten-164
980980 similar to 980899
981320 1953-141
981321 1953-142
981550 1954-127
981551 1954-129
981651 similar to 981550
981652 similar to 981551
981707 1956-153
981708 1956-154
981813 1958-32
981814 1958-34
981902 1958-34
981903 1958-36
981968 1959-18
981969 1959-30
981970 1959-20

BULOVA WATCH

see Next Page

BULOVA WATCH

100	1953-27
110	1958-27
160	1960-27
170	1960-27
180	1960-27
190 like 180	
200	1958-27
220	1958-27
230	1958-27
240	1958-27
260	1958-27
270	1958-27
310	1958-27
320	1958-27
330	1960-27
660	1960-28
680	1960-29
890	1962-15

CADILLAC

7253207	Seven-170
7260405	Eleven-135
7260905	Eleven-135
7264165	1954-135
7264185	1954-135
7264195	1954-135
7265825	1955-106
7265845	1955-106
7282315	1964-18
7283295	1964-21

CAPEHART-FARNSWORTH

1C-213M uses CX-37	
1P55	1955-20
1T174+	TV9-27
1T175	TV10-47
2C56	1956-12
2F-213F uses CX-37	
2P56	1956-13
2T55	1955-21
2T214+	TV9-27
2T215	TV10-47
3T55	1955-21
3T215	TV10-47
3T216++	TV12-29
4C174+	TV9-27
4PH55B, -M	1955-22
4T-213M uses CX-37	
5C214+	TV9-27
5H-213M uses CX-37	
6TP4oM	1955-22
6T216++	TV12-29
7C215	TV10-47
8C215	TV10-47
9C215	TV10-47
9F214+	TV9-27
10	Twelve-25
11C216++	TV12-29
12F215	TV10-47
C-14	1955-19
15	Twelve-26
15W214+	TV9-27
16C216++	TV12-29
16PH55B, -F	1955-22
16PH55M	1955-22
16T244+	TV9-27
18C215	TV10-47
18W214	TV9-27
TC-20	Eleven-15
21T215	TV10-47
22C215	TV10-47
23T215	TV10-47
24T215	TV10-47
T-30	Eleven-16
CX-33	TV5-23
CX-33A	TV5-23
CX-33F	TV5-23
CX-33K	TV5-23
CX-33L	TV5-23
CX-33M	TV5-23
CX-33X see	CX33
CR-36	Eleven-15
CX-37	TV7-33
CX-37	TV9-27
CX-37-1	TV9-27
CX-38	TV10-47
CX-38C	TV10-47
CX-38S	TV12-29
CX-43	TV11-23
46TP56B, M	1956-15
CR-48	Twelve-26
52PH56B, M	1956-16
53PH56B, F	1956-16
53PH56M	1956-16

CAPEHART (Cont.)

T-54	1954-19
TC-62	1953-24
CR-70	1953-23
CR-71	1953-24
75C56	1956-14
CT-75	TV7-33
CR-76	1953-20
CT-77	TV7-33
CR-79	1954-20
CT-81	TV7-33
CT89	TV9-27
CT90	TV9-27
CR-93	1955-19
CT95	TV9-27
CT-100	Eleven-15
CT-101	Eleven-15
CT108	TV9-27
CT-109	TV10-47
CT110	TV9-27
CT112	TV9-27
CT115	TV9-27
CT116	TV9-27
CT-125	TV10-47
CR-130	1954-19
CT130	TV9-27
CT131	TV9-27
CT133	TV9-27
CT134	TV9-27
CT-139	TV10-47
CT-140	TV10-47
CR-147	1954-20
CR-148	1955-20
CR-150	1955-21
RP-152	1953-23
RP-153	1954-20
CR-154	1955-21
CA-156	1955-22
CT-157	TV10-47
CT-158	TV10-47
CA-161	1955-22
CT-171	TV10-47
CT-172	TV10-47
CR-202	1956-12
213	1953-25
CR-218	1956-13
CA-239	1956-15
CA-241	1956-16
CR-242	1956-14
CA-251	1956-16
RP-254	1954-20
C-297	Eleven-15
C-300	Eleven-16
C-312	Twelve-25
320	TV5-23
321	TV5-23
322	TV5-23
323	TV5-23
324	TV6-23
325	TV5-23
327	TV5-23
328	TV5-23
332	TV6-23
335 see	CX-33
337	TV5-23
T-522	1953-26
3011	TV5-23
3012	TV5-23

CAPITOL PHONOGRAPH

U-24	Seven-114
C-1461	Seven-114

CHANCELLOR

6W	Seven-125

CHANNEL MASTER

6532	1963-22
6533	1963-22
6535	1964-16

CHEVROLET, (G.M.)

CTA5	1956-72
CT6	Eight-113
CTA6T	1956-80
CTM6	1956-77
C-181	Four-15
364441	One-208
600565	One-209
601574	One-210
985100	One-211

CHEVROLET, (Cont.)

985158	1963-32
985159	1963-32
985189	1963-32
985264	1963-23
985315	1963-32
985431	1964-22
985432	1964-24
985453	1964-22
985455	1964-24
985471	1964-24
985536	Three-15
985537	Three-16
985538	Three-17
985694	Four-15
985695	Four-16
985697	Four-17
985793	Seven-169
985794	Five-17
986240	Ten-24
936241	Ten-24
986388	Ten-24
986389	Ten-24
986515	Eleven-140
986516	Twelve-28
986668	1953-30
986669	1953-29
987086	1956-159
987087	1955-100
987088	1955-102
987187	1956-164
987364	1956-159
987366 like	987088
987368	1956-160
987573	1957-155
987575	1957-157
987698	1957-159
987724	1958-28
987727	1958-30
937730	1958-42
987888	1959-22
987891	1959-24
987893	1959-30
988062	1961-26
988275	1961-26
988276	1961-30
988413	1961-33
988414	1961-34
988460	1961-26
988468	1961-35
3748611	1958-42

CHRYSLER, (PHILCO)

CT-11	One-116
333	1964-21
802	Nine-82
C4608	Nine-82

CLARION (OLD)

51, 53	One-202
55	One-202
480	One-203

CBS-COLUMBIA

also see Air King

3C627	TV11-27
3C623	TV11-27
3C631	TV11-27
3C632	TV11-27
3C633	TV11-27
3C634	TV11-27
3C635	TV11-27
3C636	TV11-27
3T602	TV11-27
3T615	TV11-27
3T616	TV11-27
3T621	TV11-27
3T622	TV11-27
3T623	TV11-27
3T624	TV11-27
U3C627	TV11-27
U3C628	TV11-27
U3C631	TV11-27
U3C632	TV11-27
U3C633	TV11-27
U3C634	TV11-27
U3C635	TV11-27
U3C636	TV11-27
U3T602	TV11-27
U3T615	TV11-27
U3T616	TV11-27
U3T621	TV11-27
U3T622	TV11-27
U3T623	TV11-27
U3T624	TV11-27
4P1	1954-22

CBS-COLUMBIA (Cont)

4P1	1956-19
4P2	1956-18
5C1	1954-21
5C4	1956-20
5T3	1955-23
6K321, -U	TV12-33
6K322, -U	TV12-33
6K327U	TV12-33
6K328U	TV12-33
6KR323	TV12-33
6KR324	TV12-33
6KR327	TV12-33
6KR328	TV12-33
6T101	TV12-33
6T103	TV12-33
6T104	TV12-33
6T301, -U	TV12-33
6T303, -U	TV12-33
6T304, -U	TV12-33
6TR305	TV12-33
6TR306	TV12-33
17C18	TV7-27
17M18	TV7-27
17T18	TV7-27
18M28, 18M38, 18T28, similar to 817	
20M18	TV7-27
20M28	TV7-27
20T18	TV7-27
21C11	TV7-30
21C11B	TV7-30
21C18	TV7-27
21C21	TV7-30
21C31B	TV7-30
21C41	TV7-30
21T11	TV7-30
22C05	TV9-31
22C07, -B	TV9-31
22C09, -B	TV9-31
22CK009	TV10-55
22CK010	TV10-55
22CX1	TV10-55
22CX2	TV10-55
22CX3	TV10-55
22CX4	TV10-55
22T09	TV9-31
22T19, -B	TV9-31
22C38, 22C48, 22C58, 22C68, 22C78, 22K38, 22L18, 22M28, 22M38, 22T28	All sets listed use later version of 821 type Chassis
22TK301	TV10-55
22TK321	TV10-55
22TX1	TV10-55
22TX2	TV10-55
U22C05	TV9-31
U22C07	TV9-31
U22T09	TV9-31
U22T19	TV9-31
U22TK301	TV10-55
U22TK321	TV10-55
23C39 uses	921-94
23C49	TV9-31
23C59	TV9-31
23CK011	TV10-55
23CK012	TV10-55
23CS013	TV10-55
23CS014	TV10-55
23T15 uses	922-8
23T19 uses	921-94
23TK001	TV10-55
23TK002	TV10-55
23TK003	TV10-55
23TK004	TV10-55
23TS005	TV10-55
23TS006	TV10-55
23TS007	TV10-55
23TS008	TV10-55
U23C39 uses	921-93
U23C49 uses	921-93
U23C59 uses	922-7
U23CS013	TV10-55
U23CS014	TV10-55
U23T15 uses	922-7
U23T19 uses	921-93
U23TK001	TV10-55
U23TK002	TV10-55
U23TK003	TV10-55
U23TK004	TV10-55

CBS-COLUMBIA (Cont)

U23TS005	TV10-55
U23TS006	TV10-55
U23TS007	TV10-55
U23TS008	TV10-55
T200	1956-17
T201	1956-17
T202	1956-17
T203	1956-17
T204	1956-17
216	1956-17
C220	1957-15
C230	1957-15
C231	1957-15
C232	1957-15
C240	1957-15
400	1960-30
511	1953-27
512	1953-27
515	1953-27
515A	1953-27
515-1	1954-21
516A	1953-27
517A	1953-27
525	1953-28
526	1953-28
535	1954-22
540	1953-28
600	1960-31
616	1957-15
636	1957-15
656	1957-15
750 and 751 similar to 817	
817, -1	TV7-27
820, -1	TV7-27
821	TV7-27
822 similar to 821	
921-11	TV9-31
921-12	TV9-31
921-13	TV9-31
921-14	TV9-31
921-93 Like	921-11
921-94	TV9-31
922-7, 922-8	similar to 921-11
C1010	1960-32
C1012	1960-32
1021	TV7-30
C1148	1960-32
C1152	1960-33
C1154	1960-33
C1156	1960-33
C1160	1960-33
1601	TV10-55
1602	TV10-55
1603	TV10-55
1604	TV10-55
1605	TV10-55
1606	TV10-55
1607	TV10-55
1608	TV10-55
1610	TV11-27
1611	TV11-27
2001	TV12-33
2002	TV12-33
2003	TV12-33
2017	TV12-33
5110	1956-18
5155	1955-23
5156	1955-23
5165	1954-21
5220	1954-22
5220	1956-19
5330	1954-21
5440	1956-20

COLUMBIA RADIO

SG-8	One-6

CONTINENTAL RADIO

see Admiral Radio

CORONA RADIO

127	One-187

CORONADO

see Gamble-Skogmo

CORVAIR

985443	1964-22
985447	1964-22
985449	1964-24

CORVETTE

985396	1964-13
985686	1964-21

CROSLEY CORP.

02CB	Five-21
02CP	Five-23
02CQ	Five-23
JT3BK	1956-23
JT3GN	1956-23
JT3IY	1956-23
JT3RD	1956-23
JT4BK	1956-23
JT4GN	1956-23
JT4IY	1956-23
JT4RD	1956-23
5B3	One-31
5F	1953-31
F-5CE	1953-31
F-5IY	1953-31
F-5MY	1953-31
F-5RD	1953-31
6H2	One-35
JC-6BK	1956-24
JC-6BN	1956-24
JC-6TN	1956-24
JC-6WE	1956-24
JC-8BK	1956-26
JC-8BN	1956-26
JC-8TN	1956-26
JC-8WE	1956-26
JM-8BG	1956-27
JM-8BK	1956-27
JM-8BN	1956-27
JM-8GN	1956-27
JM-8MN	1956-27
JM-8WE	1956-27
9-101	Nine-19
9-102	Nine-21
9-103	Nine-18
9-104W	Nine-18
9-113	Nine-20
9-114W	Nine-20
9-118W	Nine-21
9-119	Nine-23
9-120W	Nine-23
9-209	Nine-22
9-209L	Nine-24
9-212M	Nine-22
9-212ML	Nine-24
9-218B	Nine-24
9-214M	Nine-25
9-214ML	Nine-25
9-302	Nine-26
10	Three-19
10D	Eleven-17
10D-1	Eleven-17
10E	1953-32
10E-1	1953-32
10-102L	Ten-26
10-103	Ten-26
10-104W	Ten-26
10-135	Ten-28
10-136E	Ten-28
10-137	Ten-28
10-138	Ten-28
10-139	Ten-28
10-140	Ten-28
10-145M	Ten-29
10-307M	Ten-30
10-310	Ten-27
10-311	Ten-27
10-313	Ten-27
10-401	TV5-29
10-421	TV5-29
10-428	TV5-29
10-430	TV5-29
AC-10B, -M	TV12-43
AH-10B	TV12-43
AT-10B, -M	TV12-43
D10BE	Eleven-17
D10CE	Eleven-17
D10GN	Eleven-17
D10RD	Eleven-17
D10TN	Eleven-17
D10WE	Eleven-17
DC-10B	TV13-31
DC-10M	TV13-31
E10BE	1953-32
E10CE	1953-32
E10RD	1953-32
E10WE	1953-32
11-100U	Eleven-17
11-101U	Eleven-17
11-102U	Eleven-17
11-103U	Eleven-17
11-104U	Eleven-17
11-105U	Eleven-17
11-106U	Eleven-19

Crosley (Continued)

11-107U	Eleven-19
11-108U	Eleven-19
11-109U	Eleven-19
11-110U	Eleven-19
11-111U	Eleven-19
11-112U	Eleven-19
11-113U	Eleven-19
11-114U	Eleven-18
11-115U	Eleven-18
11-116U	Eleven-18
11-117U	Eleven-18
11-118U	Eleven-18
11-119U	Eleven-18
11-120U	Eleven-21
11-121U	Eleven-21
11-122U	Eleven-21
11-123U	Eleven-21
11-124U	Eleven-21
11-126U	Eleven-21
11-126U	Eleven-20
11-127U	Eleven-20
11-128U	Eleven-20
11-129U	Eleven-20
11-130U	Eleven-19
11-132U	Eleven-19
11-301U	Eleven-22
11-302U	Eleven-22
11-303U	Eleven-22
11-304U	Eleven-22
11-305U	Eleven-22
11-441to447	TV5-33
11-444MU	Eleven-23
11-453	TV5-33
11-459	TV6-33
11-460	TV5-33
11-461	TV5-33
11-470to477	TV5-33
11-474BU	Eleven-23
11-483	TV5-33
11-550MU	Eleven-24
11-560BU	Eleven-24
AC-11B	TV13-27
AC-11M	TV13-27
AH-11B	TV13-27
AT-11B	TV13-27
AT-11M	TV13-27
DC-11B	TV13-81
DC-11M	TV13-31
S11-442M1U	TV6-29
S11-444MU	TV6-29
S11-447MU	TV6-29
S11-453MU	TV6-29
S11-459MU	TV6-29
S11-472B1U	TV6-29
S11-474BU	TV6-29
BC-12BZ	TV13-31
BC-12M	TV13-31
BC-12MZ	TV13-31
BT-12BZ	TV13-31
BT-12M	TV13-31
BT-12MZ	TV13-31
CA-12	Four-28
DC-12M	TV13-31
DT-12B	TV13-31
DT-12M	TV13-31
BC-13B	TV13-31
BC-13M	TV13-31
BT-13B	TV13-31
BT-13M	TV13-31
DC-13M	TV13-31
DT-13B	TV13-31
DT-13M	TV13-31
BC-14M	TV13-31
DC-14M	TV13-31
15-20E	Twelve-30
BC-15M	TV13-31
DC-15M	TV13-31
E15BE	Twelve-30
E15CE	Twelve-30
E15SL	Twelve-30
E15TN	Twelve-30
E15WE	Twelve-30
DC-16B	TV13-31
17-CDC1	TV6-29
17-CDC2	TV6-29
17-CDC3	TV6-29
17-CDC4	TV6-29
17-COC1	TV6-29
17-COC2	TV6-29
17-COC3	TV6-29
DC-17B	TV13-31
DU-17CDB uses 356-1	

Crosley (Continued)

DU-17CDM TV6-29
DU-17CHB TV6-29
DU-17CHM TV6-29
DU-17CHN TV6-29
DU-17COB TV6-29
DU-17COL uses 356-1
DU-17COM TV6-29
DU-17PDB TV6-29
DU-17PDM TV6-29
DU-17PHB TV6-29
DU-17PHM TV6-29
DU-17PHN, -1 TV6-29
DU-17TOB TV6-29
DU-17TOL TV6-29
DU-17TOM TV6-29
EU-17COL TV7-37
EU-17COLB TV7-37
EU-17COLBU TV7-37
EU-17COLU TV7-37
EU-17COM uses 380
EU-17TOB uses 380
EU-17TOLa TV7-37
EU-17TOLB TV7-37
EU-17TOLBU TV7-37
EU-17TOLU TV7-37
EU-17TOM uses 380
F-17COBH TV8-23
F-17COBU TV8-23
F-17COMH TV8-23
F-17COMU TV8-23
F-17TOBH TV8-23
F-17TOBU TV8-23
F-17TOLBH TV8-23
F-17TOLBU TV8-23
F-17TOLH TV8-23
F-17TOLU TV8-23
F-17TOMH TV8-23
F-17TOMU TV8-23
F-17TOSBH uses 402-4
F-17TOSBU } both use
F-17TOSU } 402-5
F-17TOSH uses 402-4
G-17TOB TV9-35
G-17TOBK TV9-35
G-17TOBU TV9-35
G-17TOMH TV9-35
G-17TOMU TV9-35
G-17TOWEH TV9-35
G-17TOWH TV9-35
G-17TOWU TV9-35
H-17TOBH TV9-35
H-17TOBH TV10-61
H-17TOBU TV10-65
H-17TOBU TV9-35
H-17TOMH TV9-35
H-17TOMH TV10-61
H-17TOMU TV10-65
H-17TOMU TV9-35
H-17TOWH TV9-35
H-17TOWH TV10-61
H-17TOWU TV10-65
H-17TOWU TV9-35
J-17TABH TV12-43
J-17TABU TV12-43
J-17TAMH TV12-43
J-17TAMU TV12-43
J-17TAWH TV12-43
J-17TAWU TV12-43
J-17TJBH } All use
J-17TJMH } Chassis
J-17TOWH } 432-3
J-17TJBU } All use
J-17TJMU } Chassis
J-17TOWU } 441
S17-CDC1 TV6-29
S17-CDC2 TV6-29
S17-CDC3 TV6-29
S17-CDC4 TV6-29
S17-COC1 TV6-29
S17-COC2 TV6-29
S17-COC3 TV6-29
DC-18N TV13-31
DC-19N TV13-31
20-CDC1 TV6-29
20-CDC2 TV6-29
20-CDC3 TV6-29
DU-20CDM TV6-29
DU-20CHB TV6-29
DU-20CHM TV6-29
DU-20COB TV6-29
DU-20COM TV6-29
DU-20PDM TV6-29
E20GN Twelve-30

Crosley (Continued)

E20GY Twelve-30
E20MN Twelve-30
E20TN Twelve-30
S20-CDC1 TV6-29
S20-CDC2 TV6-29
S20-CDC3 TV6-29
DU-21CDM1 TV6-29
DU-21CDN TV6-29
DU-21CHM1 TV6-29
DU-21COB1 TV6-29
DU-21COL TV6-29
DU-21COLB TV6-29
DU-21COM1 TV6-29
EU-21CDB uses 381
EU-21CDBU uses 390
EU-21CDLB uses 387
EU-21CDLBU uses 394
EU-21CDLU uses 394
EU-21CDM uses 381
EU-21CDMU uses 390
EU-21CDN uses 381
EU-21CDNU uses 390
EU-21CLD uses 387
EU-21COBa uses 381
EU-21COBUa uses 390
EU-21COLBd TV7-37
EU-21COLBe TV7-37
EU-21COLBU uses 394
EU-21COLd TV7-37
EU-21COLe TV7-37
EU-21COLU uses 394
EU-21COMa uses 381
EU-21COMUa uses 390
EU-21COS uses 387
EU-21COSB uses 387
EU-21COSBU use 394
EU-21COSU uses 394
EU-21PDBU uses 392
EU-21PDMU uses 392
EU-21TOL TV7-37
EU-21TOLB TV7-37
EU-21TOLU uses 293
F-21CDBH TV8-23
F-21CDBU TV8-23
F-21CDLBH TV8-23
F-21CDLBU TV8-23
F-21CDLH TV8-23
F-21CDLU TV8-23
F-21CDMH TV8-23
F-21CDMU TV8-23
F-21CGBH TV8-23
F-21COBU TV8-23
F-21COLBH TV8-23
F-21COLBU TV8-28
F-21COLH TV8-23
F-21COLU TV8-23
F-21COMH TV8-23
F-21COMU TV8-23
F-21PDBH, F-21PDBU, F-21PDMH, and F-21PDMU use 406
F-21TOBH TV8-23
F-21TOBU TV8-23
F-21TOLBH TV8-23
F-21TOLBU TV8-23
F-21TOLH TV8-23
F-21TOLU TV8-23
F-21TOMH TV8-23
F-21TOMU TV8-23
F-21TOSBH } both use
F-21TOSH } 404-4
F-21TOSBU, F-21TOSU use 404-5 Chassis
G-21TOBH TV9-35
G-21TOMH TV9-35
G-21TOWH TV9-35
GF-21+ use 404-4
H-21CCOBH TV10-61
H-21CCOMH TV10-61
H-21CCOWH TV10-61
H-21CKBF TV10-71
H-21CKBU TV10-71
H-21CKMF TV10-71
H-21CKMU TV10-71
H-21COBH TV9-35
H-21COBHd TV10-61
H-21COBU TV9-35
H-21COBUc TV10-65
H-21COMH TV9-35
H-21COMHd TV10-61
H-21COMU TV9-35
H-21COMUc TV10-65
H-21COSBH TV9-35
H-21COSH TV9-35
H-21COWH TV9-35

Crosley (Continued)

H-21COWHd TV10-61
H-21COWU TV9-35
H-21COWUc TV10-65
H-21COSBHa, d TV10-61
H-21COSBUc TV10-65
H-21COSHa, d TV10-61
H-21COSUc TV10-65
H-21COWHa, d TV10-61
H-21HCBH TV9-35
H-21HCBHa, d TV10-61
H-21HCBHb TV10-65
H-21HCBU TV9-35
H-21HCBUc TV10-65
H-21HCMHa, d TV10-61
H-21HCMHb TV10-65
H-21HCMU TV9-35
H-21HCMUc TV10-65
H-21HCWH TV9-35
H-21HCWHa, d TV10-61
H-21HCWHb TV10-65
H-21HCWUc TV10-65
H-21HKBF TV10-71
H-21HKBU TV10-71
H-21HKMF TV10-71
H-21HKMU TV10-71
H-21HPBHa, d TV9-35
H-21HPWHa, d TV9-35
H-21LPKBF TV10-71
H-21LPKBU TV10-71
H-21LPKMF TV10-71
H-21LPKMU TV10-71
H-21TCOBH TV10-61
H-21TCOMH TV10-61
H-21TCOWH TV10-61
H-21TKBF TV10-71
H-21TKBU TV10-71
H-21TKMF TV10-71
H-21TKMU TV10-71
H-21TOBHd TV10-61
H-21TOBUc TV10-65
H-21TOBUf TV10-61
H-21TOMHd TV10-61
H-21TOMUc TV10-65
H-21TOMUf TV10-61
H-21TOWHd TV10-61
H-21TOWHUc TV10-65
H-21TOWUf TV10-61
J-21CABH TV12-43
J-21CABU TV12-43
J-21CAMH TV12-43
J-21CAMU TV12-43
J-21CKBF TV11-31
J-21CKBU TV11-31
J-21CKMF TV11-31
J-21CKMU TV11-31
J-21LKBF TV11-31
J-21LKBU TV11-31
J-21LPKBF TV11-31
J-21LPKBU TV11-31
J-21LPKMF TV11-31
J-21LPKMU TV11-31
J-21RABH TV12-43
J-21RABU TV12-43
J-21RAMH TV12-43
J-21RAMU TV12-43
J-21TABH TV12-43
J-21TABU TV12-43
J-21TAMH TV12-43
J-21TAMU TV12-43
J-21TAWH TV12-43
J-21TAWU TV12-43
J-21TKBF TV11-31
J-21TKBU TV11-31
J-21TKLBF TV11-31
J-21TKLBU TV11-31
J-21TKLMF TV11-31
J-21TKLMU TV11-31
J-21TKMF TV11-31
J-21TKMU TV11-31
J-21TJBH } All use
J-21TJMH } Chassis
J-21TOWH } 431-3
J-21TJBU } All
J-21TJMU } use
J-21TOWU } 431-5
JR-21CDBF TV12-37
JR-21CDBU TV12-37
JR-21CDTMF TV12-37
JR-21CDTMU TV12-37
JR-21CGDBF TV12-37
JR-21CGDBU TV12-37
22 Four-19
22-AS Four-19
25F 1954-23

Crosley (Continued)

D-25BE Eleven-21
D-25CE Eleven-21
D-25GN Eleven-21
D-25MN Eleven-21
D-25TN Eleven-21
D-25WE Eleven-21
F-25BE 1954-23
F-25BK 1954-23
F-25GN 1954-23
F-25MN 1954-23
CR-26 Four-20
27 Four-20
28 Four-21
Chassis 28 Four-38
29 Four-22
30 Four-23
30E Twelve-31
30E1 Twelve-31
30-S One-30
E30BE Twelve-31
E30GN Twelve-31
E30MN Twelve-31
E30TN Twelve-31
J30-BC Four-23
31-S One-30
31T 1956-22
T-31BK 1956-22
T-31CU 1956-22
T-31GN 1956-22
T-31GY 1956-22
T-31IY 1956-22
T-31RD 1956-22
33, 33-BG Four-25
33-S One-30
34, 34-BH Four-26
34-S One-30
C-35-AK Four-24
37 Five-19
40-S One-30
41-S One-30
41T 1957-18
T-41BK 1957-18
T-41GN 1957-18
T-41GY 1957-18
T-41IY 1957-18
T-41RD 1957-18
42-S One-30
46FA Six-21
46FB Six-21
48 One-33
P-50BG 1957-17
P-50BK 1957-17
P-50WE 1957-17
52-PA Five-20
52-TD Five-30
52-TE Five-30
52-TF Five-30
52-TG Five-27
52-TG-U Five-27
52-TP Five-25
52-TQ Five-33
TK-52 Four-31
53-TF Five-26
54 One-33
55 Five-21
56FA Six-22
56FB Six-22
56FC Seven-26
56PA, 56PB Seven-27
56TA Six-24
56TA-L Six-26
56TC Six-24
56TC-L Six-26
56TD Eight-19
56TG Seven-29
56TG-M Seven-30
56TG-O Seven-29
56TH Seven-29
56TH-M Seven-30
56TH-O Seven-29
56TJ Seven-29
56TJ-M Seven-30
56TJ-O Seven-29
56TN Eight-20
56TP Seven-31
56TQ Eight-21
56TW Six-24
56TW-L Six-26
56TX-L Seven-32
56TY Eight-22
56TZ Eight-21
57 One-33
57TK Eight-23
57TL Eight-23

Crosley (Continued)

57TQ Eight-21
58TC Eight-18
58TW Eight-18
58XTA Ten-25
58XTW Ten-25
60 Four-28
60T 1957-20
P-60BE 1957-17
P-60GY 1957-17
P-60PK 1957-17
P-60RD 1957-17
T-60CL 1957-20
T-60GN 1957-20
T-60GY 1957-20
T-60IY 1957-20
T-60RD 1957-20
61 One-35
62-PA, -PB Five-22
62-TA, -TC Five-19
62-TD Five-19
TA-62 Four-29
63 Four-29
64 Four-31
66CA Six-28
66CP Six-28
66CQ Six-28
66TA, 66TC Six-30
66TW Six-30
67 Five-20
68 Five-22
70 Five-23
AT-70B TV12-43
AT-70M, -W TV12-43
AT-71B TV12-43
AT-71M, -W TV12-43
72 Five-25
72-CA Five-31
74 Five-27
75 Five-28
75E 1953-33
E-75CE 1953-33
E-75GN 1953-33
E-75RD 1953-33
E-75TN 1953-33
77 Five-30
30 Five-31
82-CP Five-28
82-CQ Five-28
82-S One-30
CB-82-R Four-33
63 Five-33
85E 1953-33
E-35CE 1953-33
E-85GN 1953-33
E-85RD 1953-33
E-85TN 1953-33
88TA Nine-17
88TC Nine-17
90E 1953-33
E-90BK 1953-33
E-90CE 1953-33
E-90GY 1953-33
E-90RD 1953-33
E-90WE 1953-33
100F 1953-34
F-100BE 1953-34
F-100BK 1953-34
F-100CE 1953-34
F-100GN 1953-34
F-100RD 1953-34
R100 1956-23
R101 1956-23
R102 1956-27
R102-1 like above
R103 1956-24
R104 1956-26
106CP Seven-33
110F 1953-34
F-110BE 1953-34
F-110BK 1953-34
F-110CE 1953-34
F-110GN 1953-34
F-110RD 1953-34
115F 1954-25
F-115GN 1954-25
F-115MN 1954-25
F-115TN 1954-25
120F 1954-24
F-120BN 1954-24
124 One-36
125 One-32
147, 148 One-37
158 One-38
160 One-39
167 One-40

Crosley (Continued)

168 One-41
169 One-42
170 One-43
171 One-44
172 One-32
285 Twelve-29
285-1 Twelve-29
299 Eleven-19
301 Eleven-17
302 Eleven-19
303 Eleven-22
311 Eleven-21
311-1 Eleven-21
312 Eleven-20
320, 321 TV6-33
321-4 TV6-29
323 TV5-33
323-3 TV6-29
323-6 TV6-29
325 TV5-33
330 Eleven-17
330-1 Eleven-18
331 TV5-33
331, -1, -2 TV6-29
331-4 TV6-29
332 Eleven-23
337 Eleven-24
356 TV6-29
356-1 TV6-39
357, -1 TV6-29
359 TV6-29
363 TV6-29
380 and 381 similar to 356-1
385 TV7-37
386 TV7-37
387 TV7-37
390 similar 356-1
392 combination similar to 356-1
393 similar to 386
394 similar to 386
396 TV7-37
402 TV3-23
402-1 TV8-23
402-4 like 402
402-5 revised 402
403 TV8-23
403-1 TV8-23
404 TV8-23
404-1 TV8-23
404-4 revised 404
404-5 revised 404
405 TV8-23
405-1 TV8-23
406 like 405
410 TV8-23
410-1 TV8-23
426 TV9-35
431 TV9-35
431-1 TV10-61
431-2 TV9-35
431-3 TV10-61
431-4 TV10-61
431-5 Like above
432 TV9-35
432-1 TV10-61
432-3 TV10-61
434 TV10-65
441 TV10-65
442 TV10-65
443 TV9-35
443-3 TV9-35
445 TV9-35
466 TV10-71
467 TV10-71
468 TV10-71
469 TV10-71
472 TV11-31
473 TV11-31
474 TV12-37
475 TV12-37
476 TV11-31
477 TV11-31
478 TV12-37
479 TV12-37
481 TV12-43
482 TV12-43
483 TV12-43
484 TV12-43
487 TV12-43
438 TV13-27
489 TV13-31
490 TV13-31

Crosley (Continued)

493 TV13-31
494 TV13-31
515 One-45
517 One-46
536 One-34
547 One-46
548 Two-29
555 One-47
A-559 Three-21
666 One-48
706 One-49
716 One-51
726 One-50
5060P 1957-17
5515 One-45
5536 One-34
5549 Three-24
5555 One-47
5666 One-48

DAY-PAN

5091 One-78

DELCO

see United Motors

300 1964-21
331 1964-21
AC-2905 1958-28
AC-2906 1958-30
AC-2977 1961-26
AC-2978 1961-27
AC-3084 1961-26
AC-3085 1961-27
AC-3086 1961-26
AC-3087 1961-27
AC-3216 1963-23
AC-3247 1963-23
AC-3256 1963-23
AC-3351 1964-22
AC-3352 1964-24
AC-3353 1964-22
AC-3354 1964-24
AC-3377 1964-24
980051 1961-28
980052 1961-29
980132 1961-31
980134 1961-32
980135 1961-29
980296 1963-23
980297 1963-28
980316 1963-26
980462 1964-24
980463 1964-18
980464 1964-24
980626 1964-21
980635 1964-21
980655 1964-26
981813 1958-32
981814 1058-34
981902 1958-34
981903 1958-36
981968 1959-18
981969 1959-30
981970 1959-20
982029 1963-27
982030 1963-30
982136 1964-24
982137 1964-18
982149 1964-22
982212 1964-21
983578 1963-28
983579 1963-28
983687 1963-23
983873 1964-24
983874 1964-22
983875 1964-24
985158 1963-32
985159 1963-32
985189 1963-32
985264 1963-23
985315 1963-32
985332 1963-32
985396 1964-18
985431 1964-22
985432 1964-24
985443 1964-22
985447 1964-22
985449 1964-24
985453 1964-22
985455 1964-24
985471 1964-24
985686 1964-21
987724 1958-28
987727 1958-30
987730 1958-42
987888 1959-22

DELCO
(Continued)

987891	1959-24
987893	1959-30
988062	1961-26
988275	1961-26
988276	1961-30
988413	1961-33
988414	1961-34
988460	1961-26
988468	1961-35
988671	1958-38
988672	1958-40
988822	1958-44
988823	1958-42
988837	1958-46
988976	1959-26
988977	1959-30
988978	1959-20
989001	1958-48
989002	1958-50
989127	1958-52
989129	1958-42
989131	1958-46
989170	1959-28
989171	1959-30
989172	1959-20
989387	1961-31
989392	1961-36
989393	1962-17
989692	1962-18
989693	1961-37
989792	1961-26
989831	1962-16
2234003	1964-24
3748611	1958-42
7282315	1964-18
7283295	1964-21

DELMONICO

8B-2	1964-17
PTV-19	TV20-15

DESOTO

843	1956-91
846	1957-72
911	1956-92
919	1957-75

DETROLA RADIO

5W, 5X	One-52
100A	One-53
N-100	Five-35
106	One-53
134	One-53
N-200	Five-35
274	Three-20
280	Three-20
283	Three-20
288	Three-20
295	Four-35
295-1	Four-35
297	Four-35
304	Four-36
305	Four-36
310	Four-36
320	Four-37
360	Four-37
389	Five-36
390	Five-37
392	Four-37
417	Five-34
419	Five-34
427	Five-34
428	Five-34
441	Five-36
554	Six-56
558	Seven-65
568	Six-58
571A	Six-60
571B	Six-60
571X	Six-59
572	Six-62
576	Six-63
579	Six-64
626A	Six-65
626B	Six-65
2741	Four-37
2742	Four-37
3041	Four-36
3051	Four-36
3101	Four-36

Detrola (Cont.)

3201	Four-37
3202	Four-37
3601	Four-37
3602	Four-37
3782	Five-36

DE WALD RADIO MFG.

ET-140R	TV6-35
ET-141R	TV6-35
DT-162R	TV6-35
DT-163A, -R	TV6-35
DT-163R	TV6-35
ET-170	TV6-35
ET-171	TV6-35
ET-171R uses D-616	
ET-172	TV6-35
G-174 like ET-140R	
DT-190D	TV6-35
ET-191 see ET-140R	
FT-200 like ET-140R	
G-201 like ET-140R	
G-210 like ET-140R	
G-211 like ET-140R	
B-400	Nine-27
406R	Three-22
G-408	1954-27
A500	Six-32
A500	Nine-27
A501	Six-32
A-501	Nine-27
A-502	Six-32
A-502	Nine-27
A-503	Six-32
A-503	Nine-27
A504	Six-33
A505	Six-33
D-508	Ten-32
DE-517A	Twelve-33
E-520	Eleven-25
E-522	Eleven-26
F-523	Twelve-34
H-527	1954-27
H-528	1954-28
H-533	1954-28
J-540	1955-23
J-541	1955-23
K-544A	1957-21
564	Five-38
A602	Six-32
A603	Six-32
A-608 (see A-602)	
D-616	Ten-32
663	Three-22
666	Three-22
K-701B	1957-22
K-702B	1957-22
C-800	Ten-31

DODGE

PD1 through	
PD4	1960-83
331	1964-21
332	1964-21
624	1957-67
842	1956-91
845	1957-72
910	1956-92

DU MONT LABS.

17T350	TV7-41
21T327	TV7-41
21T328	TV7-41
21T328	TV7-41
21T359	TV7-41
21T366	TV7-41
21T376, -U	TV7-41
21T377, -U	TV7-41
21T378, -U	TV7-41
RA-109A	TV5-39
RA-111A	TV6-39
RA-112A	TV6-39
RA-113	TV6-39
B-148A	TV22-34
B-149A	TV22-34
B-158A	TV22-34
B-159A	TV22-34
RA-166	TV7-41
RA-167	TV7-41
RA-168 like RA-171	
RA-169 like RA-171	
RA-170	TV7-41
RA-171	TV7-41

DU MONT (Cont.)

B-173	TV22-34
B-174	TV22-34
B-176	TV22-34
B-177	TV22-34
B-178	TV22-34
B-179	TV22-34
RA-306	TV8-31
RA-307	TV8-31
RA-312	TV9-43
RA-313	TV9-43
RA-346	1956-28
RA-349	1956-29
RA-350	TV11-37
RA-351	TV11-37
RA-354	1957-23
RA-356	TV12-51
RA-357	TV12-51
RA-378	1957-26
RA-379	1957-26
RA-380	TV13-39
RA-381	TV13-39
RA-902	1958-54
800-B148	TV21-23
800-B149	TV21-23
800-B150	TV21-23
800-B151	TV21-23
800-B158	TV21-23
800-B159	TV21-23
800-B160	TV21-23
800-B161	TV21-23
1110	1957-24
1120	1957-24
1130	1957-24
1140	1957-24
1150	1957-24
1210	1958-54
120591A	TV21-23
120592B	TV21-23
120593A	TV21-23
120622A	TV22-34
120623A	TV22-34
120644A	TV22-34
120650C	TV21-23
120657A	TV21-23
120688A	TV22-34

ECHOPHONE

EC-306	Eight-66
EX-306	Eight-66

ELECTRONIC CORP.

101	Eight-25
102W	Eight-25
104	Eight-25
106	Eight-25
108	Eight-24
133	Eight-25

EMERSON RADIO

UV4	One-56
U6A	One-54
19	One-56
107	One-54
AD-108	One-57
AD-110	One-57
111	One-54
AD-125	One-57
AL-130	One-56
AL-132	One-56
AL-149	One-56
AL-168	One-56
EC-242	Five-39
CV-289	Three-23
CV-290	Three-23
CV1-290	Three-23
CG-293	Three-25
CG1-293	Three-25
CG-294	Three-25
CG1-294	Three-25
DB-296	Four-38
EC-296	Five-39
DB-301	Four-38
EC-301	Five-39
EC-314	Five-39
DB-315	Four-38
EC-315	Five-39
DB-327	Four-38
EC-327	Five-39
DL-330	Four-38
DW-330A	Four-38
DW-330B	Four-38
FG-330	Four-44
DM-331	Three-27
DM1-331	Three-27
DP-332	Three-28

Emerson (Cont.)

DP1-332	Three-28
DQ-333	Three-26
DQ1-333	Three-26
DQ-334	Three-26
DQ1-334	Three-26
EC-336	Five-39
DY-337	Four-43
DY1-337	Four-43
DR-343	Four-39
DR1-343	Four-39
EC-347	Five-39
DR1-348	Four-39
DY-349	Four-43
DY1-349	Four-43
DR-350	Four-39
DY-351	Four-43
DY1-351	Four-43
DR-352	Four-39
EC-353	Five-39
DW-358	Four-38
DS-365	Four-40
DS-372	Four-40
EC-376	Five-39
DU-379	Four-42
DU-380	Four-42
FC-400	Four-44
FH-413	Five-40
FL-415	Five-41
FL-416	Five-41
FL-417	Five-41
FL-418 -419	Five-41
FP-421	Four-45
FP-422	Four-45
FU-424	Five-42
EC-426	Five-39
FU-427	Five-42
FU-428	Five-42
FY-434	Five-44
GH-437	Five-45
GA-439	Five-46
FH-440	Five-40
GA-441	Five-46
GH-447	Five-45
GC-448	Five-43
501	Six-34
502	Six-34
503	Six-34
504	Six-34
505	Six-35
506	Six-36
507	Six-37
508	Six-39
509	Six-37
510	Six-34
511	Eight-27
512	Eight-28
514	Eight-29
515	Eight-28
516	Eight-28
517	Eight-27
518	Six-37
519	Six-34
520	Six-34
522	Six-37
523	Six-35
525	Eight-31
528	Seven-35
530	Eight-28
531	Eight-30
532	Eight-30
533	Eight-30
534	Eight-29
535	Six-37
536A	Eight-32
539	Six-34
540A	Eight-26
541	Eight-27
543	Eight-33
544	Eight-33
547A	Eight-35
548	Eight-37
549	Eight-37
550	Eight-28
551A	Eight-32
552	Eight-31
553A	Eight-32
557	Nine-28
558	Eight-36
559	Nine-29
560	Eight-39
565	Nine-28
567	Eight-39
570	Nine-30
573	Nine-32

Emerson (Cont.)

574	Nine-30
577	Nine-31
577	Ten-34
578	Eight-35
579	Ten-33
580	Nine-30
581	Ten-35
583	Nine-32
586	Ten-36
590	Ten-38
591	Ten-39
594	Ten-35
595	Ten-35
596	Ten-33
599	Ten-40
600	Ten-41
601	Ten-40
602	Ten-41
605	Ten-42
613	Ten-46
616	Ten-41
622B uses 120127B	
623	Ten-38
625	Eleven-28
634B	Eleven-27
636	Ten-47
640	Ten-48
641B	Eleven-29
642	Ten-45
645	Ten-49
646A	Eleven-30
646B	Eleven-30
652	Ten-44
653	Ten-44
653B	Twelve-35
656B, 657B	Ten-50
659B	Eleven-31
662B	TV5-43
663B	TV5-43
666B	TV5-47
669B	TV5-51
671D	Eleven-32
672B	Eleven-27
675B	TV5-51
676F uses 120143B	
679B	Eleven-33
681F uses 120143B	
686F uses 120143B	
686L	TV6-43
687F uses 120143B	
687L	TV6-43
688B	TV5-51
689B	TV5-51
690B	TV5-51
691B	Twelve-37
692B	TV5-51
693B	TV5-51
694B	TV5-51
695B	Twelve-36
696F uses 120143B	
696L	TV6-43
698B uses 120127B	
699B	TV6-47
699D uses 120160B	
700B, -D	TV6-47
700L uses chassis 120153D	
701B, -D	TV6-47
701F uses 120143B	
702B	Twelve-35
703B	Twelve-38
704	Twelve-39
705A, -B	1953-35
706B	Twelve-40
707	1962-21
707B	Twelve-40
708B uses 120165B	
709A uses 120162B	
710B	Twelve-36
711B	TV7-47
711F	TV7-47
712B	TV7-47
712F	TV7-47
713B uses 120156B	
714B uses 120153B	
714D and 715D use 120153D	
716D	TV7-47
716F	TV7-47
717D	TV7-47
717F	TV7-47
718B	1953-36
719D	TV7-47

Emerson (Cont.)

719F	TV7-47
720B	TV7-47
720D	TV7-47
720F uses 120169D	
721D	TV7-47
722D	TV7-47
724B	1953-37
725A	1953-38
727D	TV7-47
728D	TV7-47
729B	1953-39
731D	TV7-47
732B	TV7-47
732G	TV8-37
733F uses 120169F	
734B	TV7-47
736B uses 120171B	
737A, -B	1953-40
738B	1953-36
740D uses 120173D	
741D uses 120168D	
741F	TV8-45
742B uses 120169B	
742E	TV8-37
743A uses 120171B	
744B	1953-41
745B	1954-29
746B	1954-30
747	1954-32
748B, -C	TV9-47
750D uses 120166D	
751D uses 120168D	
752A	TV8-37
753D, F	TV8-37
754D	1954-29
756B uses 120125B	
757D	TV8-45
757F uses 120194D	
757J uses 120168D	
758F uses 120182D	
759C uses 120195D	
760D	TV8-37
760F uses 120194D	
760H	TV8-37
760J uses 120168D	
760M uses 120182D	
761C	TV8-37
762D	TV8-37
764F uses 120166D	
765D uses 120173D	
766D uses 120210D	
767A	TV8-37
767C uses 120169B	
768A	TV8-37
769F uses 120173D	
771A	TV8-37
771C uses 120169B	
771D	TV8-37
772A	TV8-37
773A	TV8-37
774A	TV8-37
775A, -B combinat. but like 120192B	
777B	TV9-47
778B	1954-34
779 uses 120170B	
780A uses 120171B	
781A, -B	TV8-45
781E uses 120206D	
782D uses 120166D	
783B	1954-33
784A	TV8-37
784E, -G	TV8-45
784K uses 120197B	
784M uses 120211D	
785C	TV8-37
785K	TV8-45
787A, -B	TV9-47
788B	1954-36
789B	1954-35
790B	1954-37
791D uses 120210D	
792D uses 120206D	
793E uses 120211F	
795C uses 120192B	
796C	TV9-47
797B, -C	TV9-47
798B	TV9-47
801 uses 120154B	
805B	1954-38
806	1954-35
807	1954-35
808 like 707	
808B	1955-24

Emerson (Cont.)

810B	1955-24
811B	1955-25
812B	1955-25
813B	1955-25
814B	1955-27
814D as above	
816 uses 120201B	
818F	1956-30
819F	1955-28
820B	1955-28
822B	1955-25
823F uses 120250F	
824F, D use 120243D	
824F, D like 825F	
825F	1955-29
826F	1955-29
826D as above	
828B uses 120207B	
830B	1955-30
832F	1956-31
833F uses 120267B	
834B	1956-34
834X	1959-33
835A	1956-32
836B	1956-36
837A like 830B	
838	1956-33
839B	1956-34
840F uses 120267B	
841A	1956-34
842	1956-35
843	1956-36
844	1957-27
846B uses 120243D	
847	1957-27
848B like 830B	
849	1957-28
850 uses 120154B	
851B	1957-30
851B	1958-57
852B	1957-30
853B	1957-30
855	1957-29
856 uses 120274	
858B	1957-32
860B	1957-33
861B	1957-33
865B uses 120243B	
866B	1957-33
867B	1958-58
870B	1958-57
871B	1958-56
874B	1958-57
875B	1958-62
876B	1958-63
876B	1960-41
877	1959-32
878B } Electrically	
879B } Like 830B	
880	1960-36
881B	1960-41
881B	1958-63
882B	1958-63
883B	1958-63
8838	1960-41
884B	1958-63
885B	1958-60
886B	1958-60
887B see 120371B	
888	1959-34
888	1953-33
888	1958-59
888	1960-35
890	1959-33
891B	1959-33
892A	1959-33
893B	1959-33
894B	1959-33
895B	1959-35
896B	1959-37
898B	1959-38
901-B	1960-40
902	1959-37
902-B	1960-40
903	1959-38
903-B	1960-40
904-B	1960-40
905-B	1960-40
906-B	1960-40
907B	1961-39
908-B	1960-37
909-B	1960-37
911	1964-28
912-B	1960-37

Emerson (Cont.)

914B 1961-44
915B 1960-41
916-B 1960-41
917B 1960-41
918B 1960-41
920 1961-40
921-D 1960-37
924B 1960-41
985 1964-40
926B 1961-39
927B like 876B
929B like 903B
929B like 903B
932B like 876B
932B 1961-41
935B 1961-41
937B 1961-41
938B 1961-42
941B 1962-22
943B 1962-22
944B 1961-44
945B uses 120467B
970 1959-37
also 1959-38
971, A 1959-37
also 1959-28
977 1961-43
988 uses 120485
990 1964-28
991 1964-28
999 1959-26
999R 1959-26
1000C uses 120206D
1000H uses 120235D
1001E uses 120208D
1001G uses 120211F
1002 Eight-28
1002C uses 120206D
1002H uses 120235D
1003 Eight-38
1003E uses 120208D
1003G uses 120211F
1004C uses 120206D
1004H uses 120235D
1005E uses 120208D
1006C uses 120206D
1006H uses 120235D
1007E uses 120208D
1008C uses 120206D
1008H uses 120235D
1009E uses 120208D
1009J uses 120236D
1010C uses 120206D
1010H uses 120235D
1011E uses 120208D
1011G uses 120211F
1011J uses 120236D
1012D uses 120182D
1012F uses 120233D
1012C uses 120195D
1014D uses 120182D
1015C uses 120195D
1018C uses 120206D
1018H uses 120235D
1022C uses 120206D
1022H uses 120235D
1023E uses 120211D
1024C uses 120206D
1025E uses 120211D
1026C uses 120206D
1027E uses 120211D
1028C uses 120206D
1028H uses 120235D
1029E uses 120211D
1030D uses 120220D
1032D uses 120220D
1036F uses 120225D
1040F uses 120206D
1040H uses 120235D
1041F uses 120211D
1042H uses 120235D
1043F uses 120238D
1044D uses 120235D
1044F uses 120225F
1045F uses 120238F
1045H uses 120238D
1046D uses 120235D
1047D uses 120236D
1047F uses 120238F
1048D uses 120235D
1049D uses 120236D
1050D uses 120241D
1052D uses 120241D
1054D uses 120235D

Emerson (Cont.)

1057D uses 120236D
1058D uses 120239D
1060D uses 120239D
1062D uses 120239D
1062L uses 120345N
1064D uses 120229D
1066D uses 120223D
1067D uses 120234D
1067F uses 120237D
1068D uses 120232D
1069D uses 120234D
1070D uses 120222D
1071D uses 120234D
1071F uses 120237F
1072D uses 120222D
1073D uses 120234D
1074D uses 120225D
1074F uses 120225F
1075D uses 120236D
1075F uses 120228H
1084D uses 120225D
1085F uses 120238H
1086D uses 120235D
1087D uses 120236D
1088D uses 120235D
1089D uses 120226D
1089F uses 120298D
1090D uses 120225D
1091D uses 120236D
1091F uses 120238D
1092D uses 120235D
1093D uses 120236D
1093F uses 120288D
1098D uses 120241F
1099D uses 120240F
1101D uses 120228D
1102D, F TV10-79
1102H see 120245H
1103 uses 120289R
1104D uses 120251D
1104H see 120256H
1104F, J, L TV10-79
1104N see 120256P
1105D see 120275L
1106D uses 120254D
1106F uses 120254D
1106H, J, L, N TV10-79
1106P, R 120255H
1106T see 120255P
1106V as above
1107D, F TV10-79
1108D TV11-41
1108F TV11-41
1109D TV11-41
1110D TV11-41
1111D TV11-41
1112D TV11-41
1113D TV11-41
1114D, F, H TV10-79
1114J see 120259P
1115D see 120276L
1116D TV11-41
1117D TV11-41
1118D see 120255P
1119D see 120269L
1120D TV11-41
1121D TV11-41
1122D TV11-41
1123D TV11-41
1124 TV12-55
1124D, F TV11-41
1125 TV12-55
1125D TV11-41
1126D, F TV11-41
1127D TV11-41
1128F TV10-79
1128H see 120272P
1130D TV10-79
1130F uses 120245N
1132F see 120256F
1132H see 120256P
1128 TV12-55
1138D, F TV11-41
1139D TV11-41
1140D, F TV11-41
1141D TV11-41
1142D see 120259F
1142F see 120259P
1142H see 120259D
1143D see 120276L
1144D TV11-41
1145D TV11-41
1146 uses 120333Z
1146D see 120244P

Emerson (Cont.)

1148D see 120259P
1148F see 120259P
1149D see 120276L
1150 TV12-55
1150D, F TV11-41
1151 TV12-55
1151D TV11-41
1152 TV12-55
1152D, F TV11-41
1153 TV12-55
1153D TV11-41
1154 TV12-55
1154D, F TV11-41
1155 TV12-55
1155D TV11-41
1156 TV12-55
1156D, F TV11-41
1157 TV12-55
1157D TV11-41
1158A TV11-41
1159C TV12-55
1160D TV11-41
1161D TV11-41
1162D, F TV11-41
1163D TV11-41
1164 TV12-55
1164D TV11-41
1165 TV12-55
1165D TV11-41
1166 uses 120259P
1168A see 120283N
1170 uses 120255P
1172 uses 139259P
1174 TV12-55
1175 TV12-55
1176 TV12-59
1177 TV12-59
1178 TV12-59
1179 TV12-59
1180 TV12-59
1181 TV12-59
1182 uses 120259P
1183 uses 120276R
1184 uses 120259P
1185 uses 120276R
1186 TV12-59
1187 TV12-59
1188 TV12-59
1189 TV12-59
1190 TV12-59
1192 TV13-59
1194 TV12-59
1196 uses 120259P
1198 uses 120259V
1199 uses 120276R
1200 thru 1211 use 120206C,E, 120207R
1212 TV12-61
1213 TV13-61
1214 TV13-43
1215 TV13-43
1216 TV13-43
1217 TV13-42
1218 TV12-42
1219 TV13-42
1220 uses 120325E
1221 uses 120326R
1224 TV12-43
1225 TV13-43
1226 TV13-43
1227 TV13-43
1228 TV13-61
1229 TV13-61
1232 TV12-47
1233 TV13-47
1234 uses 120333Z
1236 see 1102D
1238 TV13-61
1239 TV13-61
1244 TV13-61
1245 TV13-61
1246 TV13-61
1247 TV13-61
1254 TV13-51
1255 TV13-51
1258 TV13-51
1259 TV13-51
1264 TV13-51
1265 TV13-51
1266 Like 1254
1268 TV13-51
1269 TV13-51
1272 TV13-61
1273 TV13-61
1274 TV13-61

Emerson (Cont.)

1275 TV13-61
1276 TV14-29
1277 TV14-29
1280 TV13-66
1281 TV13-66
1282 TV14-23
1283, -X TV15-41
1283, -X TV15-41
1283 TV14-23
1284 TV14-23
1284, -X TV15-41
1285 TV15-41
1285 TV14-22
1286 TV15-41
1286 TV14-23
1287 TV14-23
1288 TV14-29
1289 TV14-29
1290 TV14-29
1291 TV14-29
1400 uses 120375S
1401 uses 120376U
1402 Uses 120424W
1402 Uses 120425Y
1406 } Use
1407 } 120367S
1408 } 120368U
1409 } 120375S
1410 } 120376U
1411 } all
1412 } Like
1413 } 120351E
1414 TV15-35
1415 TV15-35
1416 Uses 120434N
1417 Uses 120435P
1420 TV14-10
1421 TV14-19
1422 TV17-27
1423 TV17-27
1424 TV14-19
1425 TV14-19
1426 TV14-19
1428 TV14-19
1432 TV16-25
1433 TV15-35
1434 TV15-35
1435 TV15-35
1436 Uses 120434N
1437 Uses 120435P
1438 TV15-35
1439 TV15-35
1440 TV15-35
1441 TV15-35
1442 TV17-27
1443 TV17-27
1444 Uses 120434N
1445 Uses 120425N
1446 TV17-27
1447 TV17-27
1448 TV17-27
1449 TV17-27
1452 TV15-45
1453 TV15-45
1454 TV17-27
1455 TV17-27
1456 TV17-27
1457 TV17-27
1458 TV17-27
1460A TV17-27
1464 TV17-27
1465 TV17-27
1466 TV15-45
1467 TV15-45
1468 Uses 120434N
1469 Uses 120435P
1470 TV15-45
1471 TV15-45
1472 TV17-27
1473 TV17-27
1474 Uses 120434N
1475 Uses 120435P
1476 Uses 120434N
1478 Uses 120434W
1479 Uses 120435Y
1480 TV17-27
1482 TV17-27
1484 TV17-27
1485 TV17-27
1486 TV17-27
1488 TV17-27
1489 TV17-27
1490 TV17-27

Emerson (Cont.)

1492 TV17-27
1493 TV17-27
1494 TV17-27
1496 TV17-27
1497 TV17-27
1498 TV17-27
1500 TV16-25
1502 TV16-25
1503 TV16-25
1504 TV16-25
1505 TV16-25
1506 TV16-25
1524 TV19-27
1525 TV19-27
1526 TV19-27
1528 TV19-27
1529 TV19-27
1530 TV19-27
1531 TV19-27
1532 TV19-27
1533 TV19-27
1534 TV19-27
1534A, B TV19-27
1535A, B TV19-27
1536 TV19-27
1537 TV19-27
1538 TV19-27
1539 TV19-27
1540 TV19-27
1541 TV19-27
1542 TV19-27
1543 TV19-27
1544 TV19-27
1545 TV19-27
1546 TV19-27
1547 TV19-27
1548 TV19-27
1549 TV19-27
1550 TV19-27
1551 TV19-27
1552 TV19-27
1553 TV19-27
1554 TV20-18
1555 TV20-18
1601 TV18-35
1602 TV18-25
1604 TV18-35
1605 TV18-35
1608 TV18-25
1609 TV18-35
1610 TV18-35
1612 TV18-35
1613 TV18-35
1614 TV18-35
1620 TV17-27
1621 TV17-27
1622 TV18-35
1623 TV18-35
1624 TV18-25
1626 TV19-37
1628 TV19-37
1629 TV19-37
1630 TV19-37
1632 TV19-37
1633 TV19-37
1634 TV19-37
1636 TV19-37
1637 TV19-37
1638 TV19-37
1640 TV19-27
1641 TV19-27
1642 TV19-37
1644 TV19-37
1645 TV19-37
1646 TV19-37
1648 TV19-37
1649 TV19-37
1650 TV19-37
1656 TV19-37
1657 TV19-37
1658 TV19-37
1660 TV19-37
1661 TV19-37
1662 TV19-37
1668 TV19-37
1669 TV19-37
1670 TV19-37
1672 TV19-37
1673 TV19-37
1674 TV19-37
1676 TV19-37
1677 TV19-37
1678 TV19-37

Emerson (Cont.)

1660 TV19-37
1631 TV19-37
1664 TV19-37
1685 TV19-37
G-1700 1964-29
G-1701 1962-19
G-1702 1962-19
G-1703 like G-1704
G-1794 1962-20
G-1705 1962-20
G-1706 1962-20
G-1707 1964-20
G-1708 1964-32
G-1709 1964-29
G-1710 1964-41
G-1711 1964-41
G-1712 1964-29
T-1890B, G TV22-34
T-1800 } See
U-1000 } 120556F
T1000A TV21-22
U1800A TV21-23
T1801 TV21-23
T1802 TV21-23
U1802 TV21-23
R1803 TV21-23
T1803 TV21-23
U1803 TV21-23
T1804 TV21-22
U1804 TV21-23
T1805 TV21-22
T1805G TV22-34
U1805 TV21-22
R1806 TV21-23
T1806 TV21-22
U1806A TV22-34
T1807 TV21-23
U1807 TV21-22
T1808 TV21-23
U1808 TV21-23
T1809 TV22-34
U1809 TV22-34
T1810 A TV21-23
U1810A TV21-23
T-1810 } Use
U-1810 } 120549C
T-1811 } or
U-1811 } 120550D
T1811A TV21-23
U1811A TV21-23
T-1814 TV22-34
U-1814 TV22-34
T-1815 TV21-23
T-1816 TV22-34
U-1816 TV22-24
T-1817, A TV21-23
T-1817B TV22-34
T-1818 TV21-23
R-1819 TV22-34
T-1820, A TV21-23
T-1820B TV22-34
U-1820 TV21-22
U-1820B TV22-34
T-1822 TV22-34
U-1822 TV22-34
T-1823 TV22-34
U-1823 TV22-34
T-1824 TV22-34
U-1824 TV22-34
T-1825 TV22-34
U-1825 TV22-34
T-1826 TV22-34
T-1827 TV22-34
U-1827 TV22-34
T-1828 TV22-34
U-1828 TV22-34
T-1829 TV22-34
U-1829 TV22-34
T-1830 TV22-34
U-1830 TV22-34
T-1831 TV22-34
U-1831 TV22-34
T-1832 TV22-34
U-1832 TV22-34
T-1833 TV22-34
T-1834 TV22-34
U-1834 TV22-34
T-1835 TV22-34
T-1836 TV22-34
U-1836 TV22-34
T-1837 TV22-34
P-1900 use 120558B
P-1900A like 937B
P-1901 see 120547R
P-1904 1963-34
P-1905 1963-34

Emerson (Cont.)

P-1907 like 932B
P-1907A 1962-36
P-1908 1962-36
P-1910 1962-36
P1911 } Use
P1912 } 120547B
P-1912 1962-36
P-1912 1964-34
P-1914 1964-36
P-1915 1964-39
P-1916 1962-36
P-1917 1962-36
P-1918 1962-36
P-1919 1964-42
P-1920 1964-42
P-1921 1964-42
P-1922 1964-43
P-1926 1964-37
P-1926 1964-38
P-1927 1964-38
C-2000 TV21-22
C-2001, A TV21-23
C-2002, A TV21-23
D-2002, A TV21-23
E-2002, A TV21-23
C-2003 TV22-34
C-2004 TV22-24
D-2004 TV22-24
C-2005 TV22-34
D-2005 TV22-34
2034S TV13-57
2023S TV13-57
2040S TV13-57
2042S TV13-57
2056 TV13-57
2057 TV13-57
2053 TV13-57
2059 TV19-57
2060 TV13-57
2061 TV13-57
2062 TV13-57
2063 TV13-57
2064 TV12-51
2065 TV13-51
120000 Six-34
120002 Six-35
120003 Six-36
120004 Six-37
120005 Six-37
120006 Eight-30
120007 Eight-29
120008 Six-39
120010 Eight-27
120012B Nine-21
120012E Ten-34
120016 Eight-39
120020 Six-34
120023E Ten-36
120029 Six-34
120030 Six-24
120032B Ten-44
120034A Ten-33
120036 Eight-22
120027 Eight-21
120038 Seven-35
120039B Nine-32
120040 Eight-30
120041 Six-34
120042A Eight-26
120044 Six-24
120045 Six-37
120046 Eight-33
120048B Nine-28
120050A Eight-35
120051 Eight-37
120052 Eight-34
120055A Ten-39
120056 Eight-28
120058 Eight-26
120059 Nine-29
120064 Nine-30
120071A Ten-35
120072A Ten-41
120075B Ten-40
120076B Ten-42
120080B Ten-44
120082A Ten-41
120083B Ten-36
120085A Ten-46
120097-B Eleven-27
also Twelve-38
120101A, -B Ten-28
120105B Eleven-28
120106A Ten-47
120112 Ten-48

Emerson (Cont.)

120115 Ten-49
120116B Eleven-33
120117A Ten-45
129121A Eleven-30
120121B Eleven-30
120122B Ten-50
120125B Eleven-29
120126B Eleven-31
120127B TV5-43
120128B TV5-43
120129B TV5-51
120132B TV5-47
120135B TV5-47
120135G diff. tuner
120135H diff. tuner similar to 120135B
120138B Twelve-35
120127D Eleven-32
120142B TV6-43
120143B, -H similar to 120142B
120145B Twelve-37
120146B Twelve-36
120147B 1954-37
120148B TV6-47
120149A 1953-38
120150B 1953-36
120151B 1953-37
120152B TV6-47
120153D uses 17LF4 same as 120153B
120154B Twelve-29
120155A, -B 1953-35
129156B Twelve-40
120156B TV6-47
120159B 1956-30
120160B combinat. similar to 120153B
120162B uses 20CP4 similar to 120153B
120163B TV7-47
120163D TV7-47
120164B TV7-47
120165B very similar to 120156B
120166D TV7-47
120167D TV7-47
120168D TV7-47
120169B TV7-47
120169D uses 21FP4A similar to 120169B
120169F combination like 120169B
120170B 1953-39
120171B minor differences from 120166D
120172A, -B 1953-40
120173D almost like 120166D
120174B TV8-37
120175B 1953-41
120176B 1954-29
120177B 1954-30
120178 1954-22
120179B TV9-47
120180D TV8-37
120182D TV8-45
120185B TV8-37
120189B 1955-24
120190D TV8-37
120191D TV8-37
120192B TV8-27
120192D TV8-37
120193B TV8-37
120194D circuit same as 120168D
120195D TV8-45
120196B TV8-45
120197B TV8-45
120197D TV8-45
120198D TV8-37
120199B 1954-34
120200B 1954-33
120201B 1954-36
120202D 1954-38
120203B TV9-47
120204B TV9-47
120205B TV9-47
120206D like 120182D
120207B 1954-35
120208D like 120182D

Emerson (Cont.)

120210D like 120192D
120211D like 120132D
120211F like 120132D
120220D uses 14HP4 similar to 120132D
120222B 1955-24
120222D, 120225D, 120225F: Physically diff. from 120132D
120228B 1955-25
120229B 1955-25
120230B 1955-25
120231B 1955-27
120232B 1955-25
120233D, 120234D, 120235D, 120236D, 120237D, 120238D, 120238H: All like 120132D tuner & alignment differ.
120240B 1955-28
120239D, 120241D, 120241F, 120249D: All like 120182D with minor differences
120243B 1955-29
120243D as above
120244P like 1102D
120245D, H, N TV10-79
120245Z tuner diff. like above
120250B see 120125
120251D, 120254D: Late type of 120182D
120252B 1955-30
120255D, F TV10-79
120255H as above
120255P as above
120255V diff. tuner like 120255D
120256D, P TV10-79
120256F, N TV10-79
120256H as above
120256P as above
120257D TV11-41
120257P TV11-41
120258D TV10-82
120258D TV11-41
120259D, P TV10-79
120259F, N TV10-79
120259H as above
120259P as above
120259V diff. tuner like 120239D
120263D TV10-82
120263D TV11-41
120263P TV11-41
120265D TV10-82
120265D TV11-41
120266B 1956-31
120267B see 120252
120269L TV10-79
120269R like above
120270B 1956-34
120271A 1956-32
120273F TV10-79
120275L, 120276L: similar to above
120274 1956-33
120276R another tuner, as above
120277D TV11-41
120278D TV11-41
120281B see 830B
120282P TV11-41
120288N as above
120284P TV12-55
120285T TV12-55
120286F TV12-55
120287T TV12-55
120289R diff. tuner like 120245D
120290F TV12-55
120291A 1956-34
120292P TV12-59
120292V TV12-59
120293T TV12-59
120298 1956-36
120299V TV12-59
120300X TV12-59

Emerson (Cont.)

120301B see 311B
120302V TV12-59
120303V TV12-50
120306C, 120306E, 120307R: Similar to 120245D
120309 1957-27
120314 1957-29
120322V TV13-43
120323T TV13-43
120324 1957-23
120325B, 120326R: Same as 120306E
120327B 1957-30
120329 1957-27
120329V TV13-43
120330T TV13-43
120331H TV13-47
120332R TV12-47
120333Z almost same as 120245Z
120334B 1957-30
120335B 1957-30
120326B 1957-32
120340B 1957-32
120341H TV13-51
120342R TV13-51
120343E TV13-57
120344G TV13-57
120345E, -V TV13-57
120346V TV13-57
120347H TV13-51
120348R TV13-51
120349B 1958-53
120351E TV13-61
120352G TV13-61
120353E TV13-65
120354G TV13-65
120355B 1958-56
120358H TV13-51
120359R TV13-51
120360E TV13-66
120361G TV13-66
120363A 1958-57
120365B 1958-62
120366B 1958-58
120367S, 120368U: Like 120352G
120369C TV14-19
120370G TV14-19
120371B 1958-60
120372B 1958-63
120373B 1958-63
120374 1958-59
120374 1960-35
120375S, 120376U: Like 120351E
120377C TV14-19
120380H TV14-23
120381M TV14-23
120382H, HC TV14-29
120383M, MC TV14-29
120384H see 1254
120386H, HC TV14-29
120387M, MC TV14-29
120388H TV14-23
120389M TV14-23
120390H, HC TV14-29
120391M, MC TV14-29
120392B 1959-32
120393B like 120371B
120394B 1959-33
120397B TV15-40
120398B 1958-63
120399B 1959-33
120407S TV15-35
120408U TV15-35
120412H TV15-41
120413N TV15-41
120414H TV15-41
120416 1959-34
120417S TV15-35
120418U TV15-35
120420S TV15-35
120421U TV15-35
120422S TV15-35
120423U TV15-35
120424N TV17-27
120424W TV15-45
120425F TV17-27
120425Y TV15-45
120428+, 120429+ like 120382H

Emerson (Cont.)

120430B 1959-33
120431B 1959-35
120432B 1959-33
120433B 1959-36
120433R 1959-36
120434N TV17-27
120434N TV15-45
120434W TV15-45
120435F TV15-45
120435P TV17-27
120425Y TV15-45
120437HC TV15-41
120438MC TV15-41
120445W TV15-45
120446Y TV15-45
120451H TV16-25
120451HC TV16-25
120452N TV16-25
120452MC TV16-25
120455B 1959-37
120456B 1959-33
120458B 1960-40
120459B 1959-37
120462B 1959-33
120462B 1960-40
120466B 1960-37
120467B 1960-40
120468B 1960-37
120471B 1960-40
120472 1960-34
120473B 1960-40
120474B 1960-41
120475B 1960-41
120476B TV17-34
120477B TV17-25
120478B 1961-39
120479B 1960-41
120480B 1960-37
120482B 1961-44
120483B 1961-44
120484B 1960-41
120485 1960-36
120486 1964-23
120487B 1960-41
120488A TV17-27
120489A TV17-27
120494B 1961-40
120495B 1960-37
120496A TV17-27
120497B TV17-27
120498A TV17-27
120499B TV17-27
120505B 1961-39
120507A TV19-27
120508B TV19-27
120515C TV19-27
120516D TV19-27
120517B TV13-35
120518F TV18-35
120519C TV18-35
120520D TV18-35
120522B 1961-44
120523B 1961-44
120525E TV18-35
120526C TV18-35
120527B see 903B
120528 1961-43

Emerson (Cont.)

120530C TV19-37
120533B TV19-27
120534B TV18-43
120535B TV18-43
120536B TV18-43
120536B TV19-27
120541C TV19-27
120542D TV10-27
120542D TV18-43
120544B, 120546B: like 120479B
120547B 1961-41
120547B 1963-36
120548B 1963-36
120543B 1961-41
120549C TV19-37
120550D TV19-37
120551C TV19-37
120552E TV19-37
120553F TV19-37
120554E TV19-37
120555E TV19-37
120556F TV19-37
120557E TV19-37
120558B 1963-36
120558B 1961-41
120559B 1961-42
120564C TV19-27
120565D TV19-27
120566B TV19-37
120567B 1964-42
120569B 1962-22
120569D 1962-22
120572C TV20-18
120573C TV20-18
120574B TV20-18
120577 like 120405
120578 1962-19
120579 1962-19
120580 1962-20
120581 1962-20
120582E similar to 120530C
120583 1962-20
120584 like 120580
120587A TV21-23
120588B TV21-23
120589C TV21-23
120591A TV21-23
120592B TV21-23
120593A TV21-23
120598 1962-21
120599B 1963-34
120619A TV22-34
120620B TV22-34
120622A TV22-34
120624A TV22-34
120625C TV22-34
120626D TV22-34
120628C TV22-34
120637 1964-38
120638 1964-39
120639 1964-35
120640 1964-24
120646 1964-40
120647 1964-35
120649 1964-26
120650C TV21-23

Emerson (Cont.)

120651C, D TV21-23
120655 1963-33
120656C TV21-23
120653A TV22-34
120659B TV22-24
120662C TV22-34
120666 1964-28
120663 1964-42
120670 1964-43
120685 1964-29
120686 1964-41
120693 1964-37
and 1964-42
120700 1964-29
120701 1964-41
120713 1964-23
129003 Eight-33
319003 Six-40

ESPEY MFG. CO.

7-C Twelve-43
FJ-91 Six-42
FJ-91A Six-42
97-A Eight-40
FJ-97 Six-43
511 Twelve-41
511-C Twelve-41
621 Six-42
641 Six-42
642 Six-42
651 Six-43
652 Six-43
653 Six-43
2162 Five-47
6511 Six-43
6514 Six-43
6516 Six-43
6520 Six-43
6521 Six-43
6522 Six-43
6531 Six-43
6532 Six-43
6533 Six-43
6547 Eight-40
10536A Eight-41
20516A Eight-40
20626-A Eight-40

Esquire Radio Corp.

511 Twelve-44

EVEREADY

50 One-113
52-54 One-113

FADA RADIO & ELECT.

S6C55 TV6-51
S6T65 TV6-51
S7C20 TV6-51
S7C30 TV6-51
S7T65 TV6-51
S20C10 TV6-51
S20T20 TV6-51
F-25 Three-29
42.64 Tuner TV6-51
C-34 Five-48
P-41 Five-49
53 Three-30
P-58 Three-31
FL-58 Three-31
63 Three-33
F-82 Eight-42
L-96 Three-32
F-100 Eight-42
WP-101 Five-50
WP-102 Five-50
AP-104 Five-50
AF-105 Five-50
F-111 Eleven-35
F-130 Eleven-36
148 Four-47
153 Four-40
194 Four-46
256 Five-51
360 One-59
602 Seven-36
605 Six-44
609 Six-44
637 Seven-36
652 Six-45
711 Eight-43
740 Eight-43

Fada (Continued)

777 Twelve-46
790 Twelve-48
also is Nine-34
795 Nine-33
845 Twelve-45
855 Twelve-47
1000 Six-46
1001 Seven-37
S1955, -x TV6-51
S1060 TV6-51

FAIRBANKS MORSE

9A One-53

FARNSWORTH TELEV.

also see Capehart
CX-32 TV5-23
ET-060 Seven-39
ET-061 Seven-39
ET-033 Seven-39
ET-064 Six-47
CC-90 Five-52
CK-91 Five-52
CK-92 Five-52
CK-93 Five-52
GK-100 Eight-44
GK-102 Eight-44
GK-103 Eight-44
GK-104 Eight-44
C-105 Seven-39
150 Seven-39
C-152 Six-48
C-153 Six-43
C-153 Six-47
C-159 Six-47
C-162 Six-48
C-170 Eight-44
C-194 Eight-44
C-196 Eight-45
C-201 Eight-44
C-216 Eight-44
EC-260 Six-48
EK-262 Six-48
EK-263 Six-40
EK-264 Six-48
EK-265 Six-48
320 to 328 TV5-23
332 TV5-23
337 TV5-23
EF-451 Eight-45
K-669 see EC-260
3011 TV5-23
3012 TV5-23

FEDERAL RECORDER

101 Three-34

FEDERAL TELEPHONE

1030T Seven-41
1540T Seven-41

FIRESTONE TIRE

4-A-70 Eleven-39
4-A-35 Eleven-40
4-A-36 Twelve-49
4-A-39 Eleven-40
4-A-92 Twelve-50
4-A-95 Twelve-49
4-A-101 Twelve-51
4-A-102 Twelve-51
4-A-153 uses Arvin 3561
4-A-154 uses Arvin 058T
4-A-159 uses Arvin 2563
4-A-162 uses Arvin 857T
4-B-31 Ten-51
4-B-56 Eleven-38
4-B-57 Eleven-38
4-B-58 Eleven-37
4-B-60 Eleven-38
4-B-61 Eleven-37
4-B-62 Eleven-38
4-B-63 Eleven-30
4-B-64 Eleven-37
4-B-65 Eleven-37
4-B-82 1957-34
4-B-83 1957-34
4-C-13 Eleven-29
4-C-19 Twelve-51
4-C-20 Twelve-51
4-C-21 Twelve-52
4-C-29 1957-35

HOW TO OBTAIN DIAGRAMS

The most economical way to secure diagrams and service material you need is to buy SUPREME manuals. This INDEX will permit you to select the volume where any particular material is included. As an extra service, Supreme Publications also will sell service data and diagrams on any Radio or TV model listed in this Index. The charge for material for each radio model is $1, and for any TV model listed $1.50. All material will be sent Airmail. Send orders to:

Supreme Publications

1760 Balsam Road, Highland Park, Illinois

(Warehouse and Branch Office in Chicago, Illinois)

FORD

C1AF-18805+1961-68
C1KF-18805-G see Motorola 04MF
2TMF 1963-73
2TMX 1962-73
2TMY 1962-73
C2AA-18806+1983-73
C2AZ-18805 1982-51
C2GA-18806-D see 1963-72
C2GY-18805 1982-51
C2YA-18806E1983-73
C2YY-18805 1982-51
3MF see Motorola
C3AA-18806 1964-64
C3GA-18806 1964-64
C3YA-18806 1964-64
5BF 1955-17
5MF 1955-51
5MF8 1955-53
R5BF 1955-17
6MF080 Seven-183
B7A-18805-A1 1958-90
B7A-18805-B1 1958-91
B8A-18805-A 1958-91
B8A-13805-B 1958-90
B9FA-18805E 1959-70
B9FA-18806B 1959-71
B9FA-18806C 1959-70
C0AF-18805D1961-68
C0AF-18805T1960-76
C0AF-18805U1960-76
C0DF-18805D1960-76
FAC-18895-A Twelve-90
FAD-18805-C like FAC-18805-A
FDH-18805-A2 1955-53
FDH-18805-B1 1955-17
FDH-18805-B2 1955-51
FDR-18805-B1 1956-94
FEF-18805-B 1956-95
FDR-18806-F 1956-96
FEG-18806G 1957-70
FEG-18806H 1957-68
FEV-18805F 1958-96

GALVIN MFG. CO.

see Motorola

GAMBLE-SKOGMO

05RA1-43-7755A Ten-52
05RA4-43-9876A Eleven-43
05RA4-43-9876B Eleven-43
05RA33-43-5016A Eleven-41
05RA33-43-3120A Eleven-42
05RA33-43-8126A Eleven-44
05RA33-43-8127A Eleven-44
5D2 Three-35
15RA1-43-7654A,-B Similar to Ten-52
15RA2-43-8230A Twelve-54
15RA33-43-8245A Eleven-44
15RA33-43-8246A,-B Eleven-44
15RA33-43-8365 Twelve-53
15RA38-43-8225A & 15RA28-43-8226A Eleven-43
15TV1-43-8957A TV6-57

Gamble (Continued)

15TV1-43-8958A TV6-57
15TV1-43-9015A TV6-57
15TV1-43-9016A TV6-57
15TV1-43-9020A TV6-57
15TV1-43-9021A TV6-67
25TV2-42-9045A TV7-55
25TV2-42-9045B TV7-55
25TV2-42-9045C TV7-55
26TV2-42-9060A TV7-55
25TV2-42-9060B TV7-55
RA33-8115A 1956-37
RA33-9856D 1954-142
35RA2-43-5101A 1952-42
35RA27-43-8255 1954-29
35RA40-43-8247A 1954-40
RA37-43-9855 1954-141
RA42-9850A 1954-141
43-5005 Eight-46
43-8177 Eight-47
43-8173 Eight-47
43-8179 Eight-47
43-8190 Eight-48
43-3201 Eight-49
43-8351 Six-50
43-8352 Six-50
43-8353 Eight-50
42-8254 Eight-50
43-9903 1960-42
43-9905 1960-42
43-9906 Uses GE Model P770A
RA44-8140A } Arvin
RA44-8141A } RE-375
RA44-8254A similar to ARVIN 50R55
RA44-9915A see ARVIN 60R47
RA48-8158A 1958-64
RA48-8182A 1961-46
RA48-8260A 1962-24
RA48-8261A 1962-24
RA48-8266A 1962-24
RA48-8342A 1957-36
RA48-9903A 1960-42
RA48-9905A 1960-42
RA50-8231 1961-47
RA50-3232 1961-47
RA50-9908A 1962-25
RA50-9909A 1962-25
RA60-9899A uses Arvin 60R63
RA60-9921A 1964-44
RA60-9922A 1964-44
RA60-9924A 1964-44
T-64 Eleven-42
66 1960-42
88 1960-42
94RA1-43-8510B Ten-52
94RA1-42-8511B Ten-52
94RA2-43-8220A Twelve-54
579 Five-12
940 Three-36
951 Three-36
961 Three-36
1682-A Five-53
RAI-9245B 1956-38
RAI-9246B 1956-38

GAROD RADIO CORP.

also see MAJESTIC
4A-1 Eight-52
4A-2 Eight-52
5A1 Eight-52
5A2 Six-51
5A3 Nine-35

Garod Radio (Cont)

5A4 Nine-35
5AP1-Y Eight-51
5D Six-52
5D-5 Eight-61
6AU1 Six-52
6BU-1A Seven-43
6DPS Seven-44
10TZ1, etc. TV8-85A
11FMP Eight-53
12TZ1, etc. TV8-65A
15TZ6 TV8-65A
BP-36A Four-49
45APA Seven-43
99 TV5-71
100 to 105 TV5-71
120 TV5-71
121 TV5-71
141 TV5-71
142 TV5-71
160 TV5-71
162 TV5-71
902 TV5-71
910 TV5-71
011 TV5-71
1400 TV5-71
1401 TV5-71
1600 TV5-71
1605 TV5-71
1610 TV5-71
1710 TV5-71

GENERAL ELECTRIC

AY TV22-51
EE TV8-47
F TV9-57
G TV9-62
H TV10-85
J TV9-63
K TV9-63
LW Series TV19-45
LX TV21-51
LY TV21-45
M TV10-91
MW TV20-27
MX TV21-29
MXT TV21-29
MY TV22-44
N TV10-95
O TV10-99
Q Line TV14-33
QX TV21-37
S TV11-47
ST Line TV12-65
SY TV22-57
T Line TV13-79
U Line TV14-45
UHF (see numbers)
AS2 1959-56
Q2 Line TV13-75
U2 Line TV13-85
U2 Line TV14-41
M3 Line TV13-67
Q-3 TV15-59
U3 TV15-67
4SJ2A1 Ten-53
4SJ3A1 Ten-53
4SJ4A1 Ten-53
M4 TV15-51
U4 TV17-37
M5 Series TV16-31
U5 TV19-53
M6 Chassis TV18-47
9T001 TV13-79
9T002 TV13-79
10C101 TV5-55
10C102 TV5-55
10T1 TV5-55
10T4 TV5-55
10T5 TV5-55
10T6 TV5-55
12C101 TV5-55
12C102 TV5-55
12C105 TV5-55
12C107 TV5-55
12C108 TV5-55
12C109 TV5-55
12K1 TV5-55
12T1 TV5-55
12T3 TV5-55
12T4 TV5-55
12T7 TV5-55
14 Nine-39

General El. (Cont)

14C102 TV5-59
14C103 as above
14P1208 TV15-59
14P1209 TV13-75
14P1210 TV13-75
14P1211 TV13-75
14P1212 TV13-75
14P1215 TV15-59
14P1216 TV15-50
14T2 TV5-59
14T2 TV5-59
14T007 TV10-91
14T008 TV10-91
14T009 TV10-91
14T010 TV10-91
14T011 } Use
14T012 } modified
14T014 } M Chassis
14T016 TV14-33
14T017 TV14-23
14T018 TV14-33
14T020 TV14-38
15 Eight-68
AS15A 1959-59
16C110 TV5-59
16C111 TV5-59
16C113 TV5-59
10C115 TV5-59
16C116 TV5-59
16C117 TV6-61
16K1 TV5-59
16K2 TV5-59
16T1 TV5-59
16T2 TV5-59
16T3 TV5-59
16T4 TV5-59
16T5 TV6-61
16T6 as above
AS16A 1959-59
17C101 TV5-59
17C102 TV5-59
17C102 TV6-61
17C104 TV6-61
17C105 TV6-61
17C107 TV6-61
17C108 TV6-61
17C109 TV6-61
17C110 and 17C111 similar to 17C113
17C112 TV6-61
17C113 TV6-61
17C114 TV6-61
17C115 TV6-61
17C120 TV6-61
17C127 TV9-57
17P1325 } Use
17P1326 } M3 Line
17P1327 } TV13-67
17P1328 uses "M3"
17P1329 TV13-67
17P1330 TV13-67
17P1331 TV13-67
17P1332 uses "M3"
17P1333 } Use
17P1334 } M3 Line
17P1335 } TV13-67
17T1 to 17T6 TV6-61
17T7 see 17C115
17T10, 17T11, 17T12, similar to 21T4
17T14 TV9-63
17T15 TV9-63
17T16 TV9-63
17T17 see 17C127
17T20 TV9-63
17T21 TV10-95
17T22 TV10-95
17T115 TV9-57
17T117 TV9-57
17T2405 TV15-51
17T2406 TV15-51
17T2407 TV15-51
17T2408 TV15-51
17T2410 TV15-51
17T2411 TV15-51
17T2412 TV15-51
17T2414 TV15-51
17T2415 TV15-51
17T2430 TV15-51
17T2431 TV15-51
17T2432 TV15-51
17T2433 TV15-51
17T3304 TV16-31

General El. (Cont)

17T3305 TV16-31
17T2306 TV16-31
17T3207 Uses M5
17T3308 Uses M5
17T3310 TV16-31
17T3311 TV16-31
17T3312 } use
17T3313 } M5
17T3214 } TV16-21
17T3315 TV16-31
17T3316 TV16-31
17T3317 TV16-31
17T3318 TV16-31
17T2319 Uses M5
17T3220 TV16-31
17T3321U TV16-31
17T3322 } Use
17T3324 } M5
17T3381U } TV16-31
17T3332 } Use M5
17T3332 } TV16-31
17T3334 Uses M5
20C105 TV7-57
20C106 TV7-57
20C150 TV6-67
20C151 TV6-67
20T2 TV7-57
TU20,+ 1963-56
21C40 TV10-99
21C102 uses K set
21C103 TV9-63
21C104 TV9-63
21C105 as above
21C106 TV10-95
21C107 TV10-95
21C108 TV10-95
21C109 TV10-95
21C110 TV11-47
21C111 TV11-47
21C112 TV11-47
21C112 TV11-47
21C114 TV9-57
21C115 TV9-57
21C116 TV9-57
21C117 TV9-57
21C119 TV9-57
21C120 TV9-57
21C121 TV9-57
21C123 TV11-47
21C124 TV11-47
21C125 TV11-47
21C126 TV11-47
21C127 uses "S"
21C128 } both use
21C129 } "O" Line
21C130 TV10-99
21C131 TV10-99
21C123 TV12-65
21C134 TV12-65
21C135 TV12-65
21C136 TV12-65
21C137 TV14-45
21C138 TV14-45
21C140 uses "ST"
21C141 TV12-65
21C142 TV12-65
21C143 TV14-45
21C152 TV10-99
21C156 TV10-99
21C157 TV10-99
21C159 TV14-45
21C160 TV14-45
21C161 TV14-45
21C162 TV14-45
21C172 TV14-45
21C200 TV7-57
21C225 TV8-47
21C226 to 21C233 use "EE" Chassis
21C238 uses K set
21C240 TV10-85
21C241 TV10-86
21C242 TV10-85
21C243 TV10-85
21C244 TV10-85
21C245 TV10-85
21C333 TV8-47
21C348 } same as
21C349 } 21C350
21C350 TV9-63
21C351 TV9-63
21C1449 } use "M3"
21C1450 }
21C1540 TV13-85

General El. (Cont.)

21C1541 TV13-85
21C1542 TV13-85
21C1548 TV14-41
21C1549 TV14-41
21C1550 TV14-41
21C1551 TV13-85
21C1551 TV14-41
21C1552 TV14-41
21C1553 TV14-41
21C1554 TV14-41
21C1555 TV14-41
21C1556 TV14-41
21C1557 } All
21C1558 } use
21C1559 } "U2"
21C1560 } TV14-41
21C1562 TV14-41
21C1563 } Use
21C1564 } modified
21C1566 } "U2"
21C1567 } Line
21C1570 } Chassis
21C1572 } See
21C1573 } TV14-41
21C1574 }
21C1585 } All Use
21C1586 } "U2"
21C1587 } See
21C1588 } TV14-41
21C2437 } Use M4
21C2438 } See
21C2439 } TV15-51
21C2440 TV15-51
21C2441 TV15-51
21C2442 TV15-51
21C2443 TV15-51
21C2444 TV15-51
21C2445 TV15-51
21C2446 TV15-51
21C2447 TV15-51
21C2448 TV15-51
21C2449 TV15-51
21C2460 TV15-51
21C2461 TV15-51
21C2465 TV15-51
21C2470 TV15-51
21C2471 TV15-51
21C2478 TV15-51
21C2479 TV15-51
21C2525 TV15-67
21C2536 TV15-67
21C2550 TV15-67
21C2551 TV15-67
21C2560 TV15-67
21C2561 TV15-67
21C2574 } through
21C2578 } use "U3"
21C3438 use M5
21C3439 TV16-31
21C3440 TV16-31
21C3441 TV16-31
21C3442 TV16-81
21C3443 TV16-31
21C3445 TV16-31
21C3446 TV16-31
21C3448 uses M5
21C3450 TV16-31
21C3451 TV16-31
21C3457 uses M5
21C2458 TV16-31
21C3459 TV16-31
21C3460 TV16-31
21C3461 TV16-31
21C3477 uses M5
21C3478 TV16-31
21C3479 TV16-31
21C3480 } use M5
21C3481 } TV16-31
21C3482 TV16-31
21C3483 TV16-31
21C3488 } Use M5
21C3489 } ≠ power
21C3490 } tuning
21C3491 } See
21C3492 } TV16-31
21C3567 TV17-37
21C3568 Uses U4
21C3569 Uses U4
21C3570 TV17-37
21C3571 TV17-37
21C3573 TV17-37
21C3575 TV17-37
21C3576 TV17-37

General El. (Cont)

21C3580 TV17-37
21C3581 TV17-37
21C3585 TV17-37
21C3586 TV17-37
21L2555 TV15-67
21L2556 TV15-67
21L2557 TV15-67
21L3455 TV16-31
21L3456 TV16-21
21T2 like 21T4
21T4 TV7-57
21T5 TV7-57
21T7 TV8-47
21T8 TV8-47
21T10 TV9-57
21T11 TV9-57
21T12 TV9-57
21T14 TV9-57
21T15 TV9-57
21T17 TV9-63
21T18 TV9-63
21T19 TV9-57
21T20 TV8-47
21T21 TV8-47
21T22 TV9-63
21T23 TV9-63
21T24 TV9-63
21T25 TV9-63
21T26 TV10-85
21T27 TV10-85
21T029 } both use
21T020 } "O" Line
21T30 TV9-63
21T31 TV9-63
21T32 TV10-95
21T33 TV10-95
21T34 as above
21T36 TV10-95
21T37 TV10-95
21T038 TV11-47
21T029 TV11-47
21T041 TV11-47
21T042 TV11-47
21T043 TV11-47
21T045 TV11-47
21T048 uses "S"
21T050 TV14-45
21T054 TV14-45
21T055 TV14-45
21T056 TV14-45
21T057 TV14-45
21T060 TV14-45
21T061 TV14-45
21T1438 uses M3
21T1439 } Like
21T1449 } 17P1329
21T1450 } TV13-67
21T1536 } use
21T1537 } "U2"
21T1538 } Line
21T1540 TV14-41
21T1541 TV14-41
21T1542 TV14-41
21T1543 TV14-41
21T1544 TV14-41
21T1580 } All use
21T1581 } "U2"
21T1582 } Chassis
21T1583 } TV14-41
21T2417 TV15-51
21T2418 TV15-51
21T2419 TV15-51
21T2420 TV15-51
21T2421 TV15-51
21T2422 TV15-51
21T2424 TV15-51
21T2425 TV15-51
21T2426 TV15-51
21T2427 TV15-51
21T2429 TV15-51
21T2580 } Use
21T2581 } "U3"
21T3414 } Use
21T3415 } M5
21T3416 } TV16-31
21T3417 TV16-31
21T3418 TV16-31
21T3419 TV16-31
21T3420 TV16-31
21T3421 TV16-31
21T3422 Uses M5
21T3425 TV16-31
21T3427 Uses M5
21T3428 Uses M5

General El. (Cont)

21T3429 TV16-31
21T3430 TV16-31
21T3431 TV16-31
21T3432 TV16-31
21T3434 Uses M5
21T3435 TV16-31
21T3436 TV16-31
21T3437 Uses M5
21T3438 Uses M5
21T3559 TV17-37
21TC3437 uses M5
HM-21 Three-41
S-22 One-159
S-22A One-160
23C3484, 23C3485, 23C3486, 23C3493 thru 23C3499 } Use M5 TV16-31
24C101 TV5-67
24C180 TV11-47
24C181 TV11-47
24C182 TV14-45
24C183 TV14-45
24C1661 TV14-41
24C1670 TV14-41
24C1671 TV14-41
24T070 TV11-47
24T071 TV11-47
H-31 One-177
H-32 One-175
B-40 One-169
F-40 One-62
41 Eight-54
T-41 One-174
42 Eight-54
S-42 One-159
S-42B One-171
43 Eight-54
K-43 One-179
44 Eight-54
45 Eight-54
50 Seven-46
K-50-P One-169
H-51 One-177
J-51 Four-50
K-51-P One-169
K-52 One-179
J-53 Four-50
K-53 One-179
L-53 One-180
J-54 Four-50
60 Nine-40
YRB 60-1 Seven-47
YRB 60-2 Seven-47
E-61 One-64
62 Nine-40
E-62 One-64
K-62 One-163
A-63 One-63
F-63 One-67
K-63 One-181
64 Ten-61
65 Ten-61
A-65 One-63
F-65 One-67
66 Ten-61
F-66 One-67
67 Ten-61
E-68 One-64
J-70 One-157
H-71 One-177
J-71 Four-51
H-73 Three-37
J-75 One-157
H-77 Three-37
H-78 Three-37
H-79 Three-37
YRB 79-1 Eight-56
YRB 79-2 Eight-56
J-80 One-161
E-81 One-69
A-82 One-68
A-83 One-70
YRB 83-1 Eight-56
A-85 One-70
A-86 like A-82
E-86 One-69
A-87 One-68
H-87 Three-38
100 Six-53
T100A 1961-48
101 Six-53

General El. (Cont)

E-101 One-71
102 Nine-39
102W Nine-39
103 Six-53
105 Six-53
E-105 One-71
J-105 Four-52
T105 1958-65
T105A 1960-43
106 Seven-49
E-106 One-71
T106 1958-65
T106A, B 1960-43
107 Nine-39
107W Nine-39
T107B 1960-43
110 Seven-48
M110YBG TV22-57
111 Seven-48
M111YBG TV22-57
M112Y++ TV22-57
113 Nine-42
M113Y++ TV22-57
114 Nine-39
114W Nine-39
115 Nine-39
115W Nine-39
LF-115 Five-57
T115 1958-66
T115A 1959-40
LF-116 Five-57
M116Y++ TV22-57
T116 1958-66
T116A 1959-40
M117Y++ TV22-57
118 Nine-41
119M Nine-41
119W Nine-41
T120A, B 1959-41
123 Ten-55
124 Ten-55
125 Ten-55
T125A 1959-42
T126A 1959-42
T127A 1959-42
E-126 One-66
129 Ten-54
T130A, B 1959-43
131 Ten-54
T131A, E 1959-43
S-132 One-162
T132A, B 1959-43
135 Ten-55
T135A 1959-44
136 Ten-55
140 Eight-57
T140A 1960-44
T141A 1960-44
143 Ten-62
145 Ten-56
T145A 1961-49
T146A 1961-49
150 Nine-44
T150A 1960-45
T150B 1961-50
T151A 1960-45
T151B 1961-50
T155A 1960-46
T156A 1960-46
T160A 1963-37
165 Ten-57
T165A 1961-51
T166A 1961-51
T170A 1962-27
T171A 1962-27
180 Eight-58
M180Y++ TV22-57
M181Y++ TV22-57
186-3A Ten-53
T190 like T165A
T195C like T125A
M200XGN TV21-51
M200YBN TV21-45
SAM200XBN TV21-51
200 Seven-50
201, 202 as above
M201XGN TV21-51
M201YBN TV21-45
M202 TV19-45
M202X++ TV21-51
T200A, T201A, T202A } Similar to T170A

General El. (Cont)

PAM202XVY TV21-45
SAM202XVY TV21-51
203 Seven-50
M203 TV19-45
M203X++ TV21-51
PAM203YVY TV21-45
SAM203XVY TV21-51
M204 TV19-45
M204X++ TV21-51
M204Y++ TV21-45
SAM204X++ TV21-51
205 Seven-60
M205 TV19-45
M205X++ TV21-51
M205Y++ TV21-45
SAM205XVY TV21-51
SBM205XBG TV21-51
M206X++ TV21-51
SAM206XGL TV21-51
M207X++ TV21-51
SAM206+, SAM207+, SAM208+, SAM209+ } Use Chassis LW TV19-45
M208+++, SAM208++ } Use LY
M209Y++, SAM209Y++, M210Y++, SAM210Y++, M211Y++, SAM211Y++ } All Use LY
210 Nine-43
T210A 1959-45
T210B 1961-52
211 Nine-43
212 Nine-43
SAM212YVY TV21-45
SAM213YVY TV21-45
SAM214YGL TV21-45
SAM215YGL TV21-45
T215A 1964-52
T216A 1964-52
SAM215YGL, SAM217YGL } Use LY
218 Ten-58
218-H Ten-59
219 Seven-51
220 Seven-51
H220A 1964-45
TU220, + 1963-52
221 Seven-51
H221A 1964-45
226 Ten-60
T230A 1962-28
T245A 1963-42
T246A 1963-42
250 Seven-53
T250A 1963-42
254 Eight-59
T255A 1963-42
T256A 1963-42
T260A, T261A } Like T245A
T265A 1964-52
T266A 1964-52
T270A like T245A
280 Eight-61
M300T, M301T, M302T, M303T } Use M5 Series TV16-31
303 Seven-54
M304 TV18-47
M305 TV18-47
M306 TV18-47
R306 TV18-47
M307 TV18-47
M308 TV18-47
M310 TV18-47
R310 TV18-47
R310A 1963-38
M311 TV18-47
R315A 1963-38
321 Six-49
356 Nine-45
357 Nine-45
358 Nine-45
376 Nine-36
377 Nine-36
378 Nine-36
C399 1958-67
400 Eleven-45
C400A 1959-46

General El. (Cont)

H-400 Three-39
401 Eleven-45
C401A 1959-46
C-402 See above
403 Eleven-45
C403A 1961-48
404 Eleven-46
405 Eleven-46
C405, C406 } Similar to 935
C405A, B 1959-47
C406A, B 1959-47
C407C, D Like above
408 Eleven-47
409 Twelve-55
410 Eleven-46
C410A 1963-39
JB-410 Four-53
411 Eleven-45
C411A 1963-39
412 1953-44
HB-412 Three-41
LB-412 Five-54
414 Twelve-58
415 Twelve-58
C415, -A, -B 1958-68
C415A, C 1960-47
416 Twelve-58
C416, -A, -B 1958-68
C416A, C 1960-47
C417 1958-68
C417A, C 1960-47
M418V uses M6
C420 1958-69
C420A 1960-48
M420 TV18-47
R420 TV18-47
C421 1958-69
C421A, B, C 1960-48
M421 TV18-47
422 Twelve-57
C422B, C 1960-48
423 Twelve-57
424 1954-42
M424 TV18-47
425 1954-42
C425A, C426A, C427A } like C450A 1960-50
M426+ Uses MW
M427 TV18-47
430 Twelve-58
C430A 1960-49
M430 TV18-47
431, -A 1954-43
431B, -BH 1954-43
C431A 1960-49
M431 TV18-47
432, -A, -B 1954-43
M432 TV18-47
R432 TV18-47
433B 1954-43
M433 TV18-47
C435A 1959-48
440 1954-44
C440A 1959-49
C441A 1959-49
442 1954-43
443 1954-43
444 1954-43
C445A, C446A } like C450A
446 1955-31
447 1955-31
448 1955-31
450 1954-42
C450A, B 1960-50
451 1954-42
C451A, B 1960-50
452 1954-42
C452A, B 1960-50
453 1956-39
455S 1957-41
CT455 1960-51
455 1955-32
456, 457 as above
456S 1957-41
457S 1957-41
C460A 1960-52
465 1956-40

General El. (Cont)

C465A 1963-40
466 1956-40
C466A 1963-40
467 1956-40
C467A 1953-40
470 1956-41
C470A 1953-41
471 1956-41
472 1956-41
475 1956-42
476 1956-42
477 1955-42
480 1956-43
C490, C491 } Like C405A
495 like 455
C495A 1962-26
C496A 1962-26
500 Ten-61
C500A 1962-26
L-500 Five-55
501 Ten-51
M500X++ TV21-37
M501X++ TV21-37
M502X++ TV21-37
M503X++ TV21-37
505 Clock Ten-61
506 Ten-61
507 Ten-61
508 Ten-61
509 Clock Ten-61
510F Eleven-48
C510 1962-27
L-510 Five-55
511F Eleven-48
512F Eleven-48
513F Eleven-48
514 1953-46
515F Eleven-48
516F Eleven-48
C516A 1962-27
517F Eleven-48
C517A 1962-27
518F Eleven-48
C520A like T230A
521F Eleven-48
522F Eleven-48
C525A 1963-42
530 Ten-61
LB-530 Four-55
C540A 1964-52
C541A 1964-52
542 1953-46
543 1953-46
546 1953-43
547 1953-43
548 1953-43
549 1953-43
L-550 Five-55
555 1954-46
556 1954-46
557 1954-48
558 1954-48
559 1954-48
560 1954-48
L-560 Five-55
561 1954-48
564 1954-48
565 1954-48
566 1954-48
572 1954-49
573 1954-49
574 1954-49
575 1954-49
577 1955-33
578 1955-33
580 1955-34
581 1955-34
582 1955-34
590 1955-35
600 Ten-62
H-600 Three-40
601 Ten-62
H-601 Three-40
J-602 Four-54
M602W TV20-27
603 Ten-62
J-603 Four-54
604 Ten-62
CAM602XVY' TV21-29
CBM602XVY TV21-29
CFM602XVY TV21-29
CAM604WTS Uses MW
CBM604XVY See MXT

General El. (Cont)

M602V, M603V, M604V, R504V, M605V, M606V, R606V, M607V } Use Chassis M6 see TV18-47
M604W TV20-27
SAM604+++ TV22-44
SBM604+++ TV22-44
505 Eleven-49
CAM505WTS Uses MW
M505W TV20-27
R604, R605, R610 } Use M6 T18-47
SAM605+++ TV22-44
SBM605+++ TV22-44
605 Eleven-49
M605W TV20-27
SAM606WVY Uses MW
607 Twelve-59
M607W TV20-27
608 Twelve-59
M608W TV20-27
M608+++ TV22-44
R608W TV20-27
R608+++ TV22-44
SAM608+, SBM608+ } Use MW
M609+++ TV22-44
M609W TV20-27
SAM609WGR Uses MW
810 Eleven-50
H-610 Three-40
M610V, R610V, M611V } Use M6 TV18-47
M610W TV20-27
R610W TV20-27
R610WVY Uses MW
611 Eleven-50
H-611 Three-40
M611W TV20-27
HJ-612 Three-43
614 1953-45
M614V, M615V, M620V } Use M6 TV18-47
M614W TV20-27
M614X++ TV21-29
615 1953-45
M615W TV20-27
M615X++ TV21-29
M616X++ TV21-29
M616Y++ TV22-44
M617X++ TV21-29
M617Y++ TV22-44
C++618XVY Use Chassis MXT
620 1954-51
C++620++ Use MW
M620W TV20-27
621 1954-51
CAM621WVY Uses MW
622 1954-51
625 1954-50
626 1954-50
630 1954-54
631 1954-54
632 1954-54
H-634 Three-42
635 1955-36
636 1955-36
637 1955-36
H-638 Three-42
640 1954-52
H-640 Three-42
641 1954-52
645 1955-37
646 1955-37
647 1955-37
648 1955-37
650 Ten-57
660 1956-38
L-660 Five-56
661 1955-38
665 1956-44
666 1956-44
667 1956-44
670 1956-45
671 1956-45

General El. (Cont)

P671A, B 1960-53
672 1956-45
P672A, B 1960-53
673 1956-45
P673A, B 1960-53
P674B 1960-53
675 1956-46
676 1956-46
680, 681, 682 } Similar to 660
M684X++ TV21-29
M685X++ TV21-29
P710A, -B 1958-70
P710C, -C1 1958-70
P711A, -B 1958-70
P711C, -C1 1958-70
P715, B, D 1959-50
P716, B, D 1959-50
PAM718Y++ TV22-52
PAM719Y++ TV22-52
C++720++ Use MW
M720W TV20-27
M720X++ TV21-29
M720YEB TV22-52
P720 1957-37
SAM720++ Uses MW
SBM720WGN Uses MW
M721W TV20-27
P721 1957-37
M721X++ TV21-29
M721YEB TV22-52
SAM721++ Use MW
CAM722Y++ TV22-52
M722Y++ TV22-52
PAM722YWD TV22-52
M723Y++ TV22-52
CAM723Y++ TV22-52
PAM723YWD TV22-52
CAM724+ TV20-27
P725 1958-72
P725B 1959-51
CAM726+ TV20-27
M724V, M725V, M730V, M731V, M732V, R732V, M733V } Use Chassis M6 in TV18-47
P726 1958-72
P726B 1959-51
M780W TV20-27
M730X++ TV21-29
M730Y++ TV22-52
M731W TV20-27
M731XMD TV21-29
M731XWD TV21-29
M731Y++ TV22-52
M732W TV20-27
M732X++ TV21-29
M782Y++ TV22-52
R732W TV20-27
SAM732+ Uses MW
M733W TV20-27
M733X++ TV21-29
M733Y++ TV22-52
SAM733+ Uses MW
M734W TV20-27
M734X++ TV21-29
M734Y++ TV22-52
R734X++ TV21-29
R734Y++ TV22-52
SAM734+ Uses MW
SBM734+ Use MW
M735W TV20-27
M735X++ TV21-30
M735Y++ TV22-52
P735A 1959-52
P735, P736 } Similar to 670
SAM735+ Uses MW
SBM735+ Use MW
M736 TV18-47
M736+ TV20-27
M736Y++ TV22-52
P736A 1959-52
M737+ TV20-27
M737Y++ TV22-52
M738+ TV20-27
M738X++ TV21-30
R738WMD, R738WWD } Use MW

General El. (Cont)

R738	TV13-47
SAM723+	TV20-27
M739+	TV20-27
M739	TV13-47
M739X++	TV21-30
740	Eleven-51
M740	TV13-47
M740+	TV20-27
R740	TV13-47
741	Twelve-62
M741	TV16-47
M741+	TV20-27
R741	TV13-47
M742X++	TV21-30
M742Y++	TV22-52
SAM742+	TV20-27
M743X++	TV21-30
SAM742+	TV20-27
M743Y++	TV22-52
P745A, B	1960-56
P746A, B	1960-56
M750	TV13-47
P750A	1953-74
R750	TV13-47
M751	TV16-47
752	Eleven-52
M752	Use M6
753	Eleven-52
M753	Use M6
754	Twelve-60
P755A	1959-53
756	Twelve-60
M758X++	TV21-30
M758Y++	TV22-52
M759X++	TV21-30
M759Y++	TV22-52
M760+	TV20-27
M760X++	TV21-30
M760Y++	TV22-52
P760A	1953-74
M761+	TV20-27
M761X++	TV21-30
M761Y++	TV22-52
P761A	1956-74
M762X++	TV21-30
M762Y++	TV22-52
PAM762Y++	TV22-52
R762X++	TV21-30
R762Y++	TV22-52
M763X++	TV21-30
M763Y++	TV22-52
PAM763Y++	TV22-52
P765A, -B	1953-75
M766X++	TV21-30
M766Y++	TV22-52
P766A, -B	1958-75
M767X++	TV21-30
M767Y++	TV22-52
M770X++	TV21-30
M770+	TV20-27
P770A	1960-55
R770+	Use MW
M771+	TV20-27
M771X++	TV21-30
P771A	1960-55
SAM774+	TV20-27
P776A, B	1960-55
SAM776WMD	Uses MW
M780+	TV20-27
P780A	1960-58
M781+	TV20-27
M782, M783	Use M6
M782Y++	TV22-52
M783Y++	TV22-52
M784Y++	TV22-52
M785Y++	TV22-52
P785A	1960-57
M786X++	TV21-30
M786Y++	TV22-52
P785A	1960-57
M787X++	TV21-30
M787Y++	TV22-52
P787A	1960-57
M788X++	TV21-30
M788Y++	TV22-52
M789X++	TV21-30
M789Y++	TV22-52
P790A, B	1961-53
P791A, B	1961-53
P795	1960-59
P795A, B	1962-29
P796A, B	1962-29

General El. (Cont)

P796	1960-59
P797	1960-59
P797A, B	1962-29
P800A	1060-60
P805	1959-53
P805A	1961-54
P806	1959-53
P806A	1961-54
P807A	1961-54
P807B	1961-55
P807G, H	1964-48
P807S, T	1964-48
P808A	1961-54
P808B	1961-55
P808G, H	1964-48
P808S, T	1964-48
P810A	1963-46
P811A	1963-46
P815A	1961-56
P816A	1061-56
P820A	1962-30
P820C	1963-45
P821A	1962-30
P821C	1963-45
P822C	1963-45
P825A	1962-32
P826A	1962-32
P830A	1060-61
P830C	1961-57
P830E	1961-58
P831A	1960-61
P831C	1961-57
P831E	1961-58
P835A	1962-31
P845A	1963-44
850	1957-36
P850B, C	1962-32
P851C	1962-32
P852A	1963-47
P853A	1963-47
070	1957-39
M870VWD	TV19-53
R870VML	TV19-53
R870VWD	TV10-53
871	1957-39
M871VWD	TV19-53
P871A	1963-48
875	1957-41
876	1957-41
877	1957-41
P885B	1963-49
895	1956-39
P895A-M	1964-46
900	1956-47
900D	1956-48
902	1956-47
902D	1956-48
903	1956-47
903D	1956-48
905	1956-48
906	1956-48
907	1956-48
P910A-M	1964-46
911	1956-49
911H	1956-49
P911	1964-46
P911A-M	1964-46
912	1956-49
P912A-M	1964-46
913	1956-49
P913A-M	1964-46
915	1956-48
P915A, B	1964-49
916	1956-48
P916A, B	1964-49
P917A, B	1964-49
920	1956-50
921	1956-50
P925A	1964-50
930	1957-41
935	1957-41
936	1957-41
C937A	1963-51
940	1957-42
941	1957-42
942	1957-42
P945A	like P910A
955	1957-40
P955A	1964-51
956	1957-40
RP1100A	1961-59
RP1110A	1959-55
RP1112A	1961-50

General El. (Cont.)

RP1115A	1960-62
RP1116A	1960-62
LFC-1113	Five-57
LFC-1123	Five-57
RP1120A, B	1959-56
RP1127A	1961-59
RP1128A	1961-59
RP1130A	1960-63
RP1130B	1960-63
RP1135A	1962-34
RP1150A	1900-64
RP1155A, C	1962-36
RP1160A	1959-57
RP1170	1962-36
RC1190A, +	1963-55
RC1191A, +	1963-55
RC1192A, +	1963-55
RC1193A, +	1963-55
RC1195A, +	1963-55
RC1196A, +	1963-55
RC1197A, +	1963-55
RC1198A, +	1963-55
RC1200	1962-36
RC1201	1962-36
RC1202	1962-36
RC1203	1962-36
RC1210	1962-36
RC1211	1962-36
RC1212	1962-36
RC1213	1962-36
LFC-1228	Five-57
RT1230A	1959-56
RT1221A	1959-53
RC1240/50A	1960-65
RC1241/51A	1960-65
RC1242/52A	1960-65
RP1530	1964-56
RP1550A, D	1962-35
RP1551A, D	1962-35
RP1560	1963-57
RP1561	1963-57
RP1570	1963-57
RP1590A	1962-36
RP-1590A, C	1964-53
RC1611A	1963-58
RC1616A, B	1963-58
RC1641	1964-54
RC1642	1964-54
RC1651	1964-54
RC1652	1964-54
RC1660	1964-55
RC1661	1964-55
RC1662	1964-55
RC1663	1964-55
RC1664	1964-55
RC1670	1964-55
RC1671	1964-55
RC1672	1964-55
RC1673	1964-55
RC1674	1964-55
RC1680A	1963-60
RC1690A, +	1963-60
RC1691A, +	1963-60
RC1692A, +	1963-60
RC1694A, +	1963-60
RC1970, RC1971, RC1972, RC1975	Similar to RC3210 1963-54
RC1990, RC1991, RC1992, RC1995	Similar to RC3210 1968-54
RP2050A	1963-57
RP2051A	1963-57
RP2080	1964-54
RP2081	1964-54
RP2085	1964-54
RP2090	1964-54
RP2091	1964-54
RP2095	1964-54
RP2110	1964-56
RP2111	1964-56
RP2113	1964-56
RP2130	1964-56
RP2131A	1964-56
RP2138A	1964-56
RC3200	1963-54
RC3201	1963-54
RC3202	1963-54
RC3205	1963-54
RC3210	1963-54
RC3211	1963-54
RC3212	1963-54
RC3215	1963-54
RC3230	1963-54

General El. (Cont)

RC3221	1963-54
RC3222	1963-54
RC3225	1962-54
RC3430, RC3431	Like RC1690
RC3432, RC3435	See 1963-60
RC4231, RC4232, RC4235, RC4233	Like RC3200 Series 1963-54
RC4670	1964-55
RC4671	1964-55
RC4672	1964-55
RC4675	1964-55
RC4679	1964-55
P8522A	1963-47
P8523A	1963-47
P9001A	1962-33
P9011A	1962-33
P9151A, B	1964-49
P9161A, B	1964-49
P0171A, B	1964-49

GENERAL HOUSEHOLD

5B	One-73
7B	One-76
8A	One-74
11G	One-75
12B, 12W	One-72
501	One-73
520, 530	One-73
550	One-73
750-753	One-76
801	One-74
1191, 1191B	One-75
1291	One-72
1297	One-72

GENERAL MOTORS

see United Motors	
120	One-77
130	One-77
140	One-77
A5003	One-78
A5004	One-78
A5010	One-78
5091	One-78

GENERAL TELEVISION

21A4	Seven-55
22A5C	Seven-55
23A6	Eight-62

GILFILLAN

56	Eight-64
66B	Eight-62
66PM	Eight-64

GOODRICH (B. F.) CO.

R662	Eight-63
R662N	Eight-63
92505	Nine-46
92506	Nine-46

GRANCO PRODUCTS

601	1959-60
701	1959-61
750	1957-43

W. T. GRANT CO.

500	Seven-56
501	Seven-56

GRISBY-GRUNOW

see Majestic (old)

GRUNOW

see General House.

HALLICRAFTERS CO.

AT-1	1953-47
AT-2	1953-47
3HFP-1	1956-55
3HFP-2	1956-55
AT-3	1953-47
5R10	Eleven-53
5R11	Eleven-44
5R12	Eleven-44
5R13	Eleven-44
5R14	Eleven-44
5R18 to 5R22	all like 5R13
5R24	1955-41

Hallicrafters, Cont.

5R30A	Twelve-63
5R31A	Twelve-63
5R32A	Twelve-63
5R33A	Twelve-63
5R34A	Twelve-63
5R35 to 5R39	similar to 5R20A
5R40	1955-42
5R41	1955-42
5R42	1955-42
5R50	Twelve-64
5R51	Twelve-64
5R52	Twelve-64
5R60	1955-40
5R61	1956-40
5R70	1956-51
5R71	1956-51
5R72CL	1956-51
5R73CL	1956-51
5T	One-101
ATCL-5	1953-48
ATCL-6	1953-48
ATCL-7	1953-48
ATCL-8	1953-48
ATCL-9, -10, -11	all like ATCL-5
ATX-11	1953-40
ATX-12	1953-49
ATX-13	1953-49
17K110 uses	C1300D
17K111 uses	D1300D
17T100 uses	A1300D
17T101 uses	B1300D
17T310	TV9-69
17TS700M	TV11-57
17TS700MA	TV11-57
17TS710A, T	TV11-57
17TS720T	TV11-57
17TS720TA	TV11-57
17TS730TA	TV11-57
17TT700E	TV12-71
17TT700M	TV12-71
17TT701E	TV12-71
17TT701M	TV12-71
17TT710	TV12-71
17TT711	TV12-71
17TT760T	TV12-71
17TT761T	TV12-71
21K200B	TV8-53
21K201B	TV8-53
21K210M	TV8-53
21K211M	TV8-53
21K220B	TV8-53
21K221B	TV8-53
21K230M	TV8-53
21K231M	TV8-53
21T320	TV9-69
21K330	TV9-69
21K330BA, MA	TV10-107
21K331B, M	TV10-104
21K341B, M	TV10-104
21K340	see E1600D
21K340BA	TV10-107
21K340MA	TV10-107
21K520B, M	TV11-53
21K521B, M	TV11-53
21KF520B, -M	use A2000D
21KF521B, -M	use B2000D
21KS850B, -M	use C2003D
21KT540B	TV11-53
21KT540M	TV11-53
21KT850B	TV12-71
21KT850M	TV12-71
21KT851B	TV12-71
21KT851M	TV12-71
21T120 uses	E1300D
21T121 uses	F1300D
21T321B, M, W	TV10-104
21T420B, M	TV10-107
21T421B, M	TV10-107
21TS750B, BA, M, MA	all use C2003
21TT500B, M	TV11-53
21TT501B, M	TV11-53
21TT750M	TV12-71
21TT751M	TV12-71
24K240B	TV8-53
24K240M	TV8-53
24K241B	TV8-53

Hallicrafters, Cont.

24K241M	TV8-53
24K242 uses	D1400D
24K243 uses	D1400D
24K245B uses	C1400D
24KT550B, M	TV11-53
24KT551B, M	TV11-53
24T430B, M	TV10-107
24T431B, M	TV10-107
24TT510B, M	TV11-53
24TT511B, M	TV11-53
SX-25	Three-44
TW-25	1954-55
27K250B	TV3-53
27K250M	TV3-53
27K251B	TV3-53
27K251M	TV3-53
S-27	Four-56
S-38	Eight-65
S-40A	Nine-47
51C1, -A	1954-56
51C1B	1956-52
51C2, -A	1954-56
51C2B	1956-52
E-55	1955-39
TW-55	1955-39
S-32	Twelve-66
TR-83	1957-44
TW-100	1956-53
TW-101	1956-53
TW-102	1956-53
TW-200	1956-54
EC-306	Eight-66
EX-306	Eight-66
611	1954-57
612	1954-57
Series 800	TV6-69
E800D	see 811
J800D	like 860
K800D	see 818
L800D	TV6-60
810A	TV5-63
811	TV5-63
815	TV5-63
818	TV5-63
820	TV5-63
821	TV5-63
822	TV5-63
860	TV5-63
861	TV5-63
870	TV5-63
871	TV5-63
880	TV5-63
890	TV5-63
890A	TV5-63
894	TV5-63
Series 900,	similar to 800
1000 uses	W1000D
C1000D	like 800
E1000D	like 17824
K1000D	like 20823
M1000D	like 17B15
N1000D	like 17816
P1000D	like 17824
Q1000D	like 20823
R1000D	like 30823
W1000D, X1000D, Z1000D, A1100D, F1100D, G1100D	Except for tuner and pict. tubes basically similar to 800 chassis
1001 uses	F1100D
1002 uses	F1100D
1003 uses	F1100D
1004 uses	F1100D
1005 uses	G1100D
1006 uses	G1100D
1007 uses	F1100D
1008 uses	X1000D
1010P	TV7-72
1012P	TV7-72
1013C	TV7-72
1015 uses	A1100D
1017 uses	A1100D
1018 uses	G1100D
1019 uses	Z1000D
1021P	TV7-72
1022C	TV7-72
1025 uses	C1000D
1026P	TV7-72
1027C	TV7-72
1050	see AL1200D
1051P, 1052P	TV7-72

Hallicrafters, Cont.

1053P	TV7-72
1054P	TV7-72
1055C	TV7-72
1056C	TV7-72
1057B uses	BZ1200D
1057U uses	Z1200D
1058U uses	Y1200D
1059	see AM1200D
1060C	TV7-72
1061C	TV7-72
1062C	TV7-72
1063C	TV7-72
1871AV	see BQ1200D
1872	see AG1200D
1073A	see AQ1200D
1074	see AG 1200D
1075	TV7-71
1876A	see AQ1200D
1877	see AH1200D
1070	see AG1200D
1079AV	see BQ1200D
1081	see AJ1200D
1082	see AK1200D
1005	see AJ1200D
1886	see AK1200D
1003	see AJ1200D
1009	see AP1200D
1092	see AX1200D
A1100D	see W1000D
F1100D, G1100D	similar to W1000D
1200 Series	TV7-71
A1200D	TV7-71
AG1200D, AH1200D, AK1200D, AJ1200D, AL1200D, AM1200D, AP1200D, AQ1200D, AR1200D, AX1200D, AY1200D, AZ1200D	All these sets are similar to T1200D, TV7-71, with minor circuit changes
BA1200D, BH1200D, BQ1200D	Similar to T1200D
D1200D	TV7-71
F1200D	TV7-71
G1200D	TV7-71
J1200D	TV7-71
K1200D	TV7-71
L1200D	TV7-71
P1200D	TV7-71
R1200D	TV7-71
T1200D	TV7-71
W1200D	TV7-71
X1200D	TV7-71
Y1200D, Z1200D, HZ1200D	Has UHF similar to T1200D
A1300D	TV7-71
B1300D, C1300D, D1300D, E1300D, F1300D	All are similar to T1200D some with UHF tuners
A1400D	TV8-53
B1400D	TV8-53
C1400D	TV8-53
D1400D	TV8-53
A1600D	TV9-69
B1600D	TV9-69
E1600D	like above
A1700D	TV10-104
A1850D	TV10-107
B1850D	TV10-107
C1850D	TV10-107
D1850D	TV10-107
A2000D	TV11-53
B2000D	TV11-53
C2000D	TV11-53
D2000D	TV11-53
A2003D	TV11-57
B2003D	TV11-57
C2003D, D2003D	Like above 21'' tube
A2005	TV12-71
B2005	TV12-71
C2005	TV12-71
D2005	TV12-71
14808, -A	TV6-69
17804C	TV6-69
17310C	TV6-73

Hallicrafters Cont.

17810M, -MG	TV6-70
17811-H	TV0-60
17813	TV6-69
17313	TV6-69
17815-H	TV6-69
17816	TV0-69
17817	TV6-69
17819	TV6-69
17824	TV8-69
17824A like 17824	
17825	TV6-69
17338	TV0-39
17343	TV6-69
17849	TV6-69
17350	TV6-69
17860-H	TV6-69
17801-H	TV6-69
17906 like 17324	
17903 like 17824	
17922 tuner diff. similar to 17824	
17930 to 17934 similar to 17815-H	
20823, -B	TV6-69
20823C like 20823	
20372	TV6-73
20990, 20990S similar to 860	
20994 similar to 860	
21923 like 20923	
21920 like 20923	
21940 like 20923	

HITACHI, LTD.

TH-621	1960-66
TH-627R	1961-61
TH-650	1964-57
TH-660	1962-40
TH-661	1962-40
TH-666R	1960-67
T-728	1963-62
TH-759	1962-40
WH-761	1962-39
WH-822M	1962-38
WH-829	1963-64
TH-862R	1960-68
XH-1500	1963-66

HOFFMAN RADIO CORP

MARK 5	TV13-93
MARK 7	TV16-39
7B125 uses 195	
7B141	TV8-59
7B182	TV10-111
7M124 uses 195	
7M140	TV8-59
7M181	TV10-111
7W181	TV10-111
MARK 10	TV12-79
21B116	TV7-78
21B144, -U	TV8-59
21B176S	TV10-111
21B179S	TV11-61
21B184P	TV10-111
21B185P	TV10-111
21B188	TV10-111
21B189	TV10-111
21B191	TV10-111
21B194	TV11-61
21B309	TV7-78
21B318, -U	TV8-59
21B352	TV11-61
21B358	TV10-111
21B361	TV10-111
21B364	TV11-61
21B701	TV7-78
21B719, -U	TV8-59
21B729S	TV11-61
21B907	TV7-78
21K186	TV10-111
21M115	TV7-78
21M143, -U	TV8-59
21M175S	TV10-111
21M183	TV10-111
21M184P	TV10-111
21M187	TV10-111
21M190	TV10-111
21M193	TV11-61
21M308	TV7-78
21M317, -U	TV8-59
21M351S	TV11-61
21M357	TV10-111

Hoffman (Cont.)

21M360	TV10-111
21M363	TV11-61
21M700	TV7-78
21M718, -U	TV8-59
21M728S	TV11-61
21M906	TV7-78
21P145, -U	TV8-59
21P177S	TV10-111
21P180S	TV11-61
21P185	TV10-111
21P192	TV10-111
21P195	TV11-61
21P310	TV7-78
21P353S	TV11-61
21P359	TV10-111
21P362	TV10-111
21P365	TV11-61
21P702	TV7-78
21P720, -U	TV8-59
21P731S	TV11-61
21P908	TV7-78
21SP179	TV11-61
21U205S	TV10-111
21U208-5	TV11-61
21W190	TV10-111
21W360	TV10-111
24B197	TV11-61
24B371	TV11-61
24B707	TV6-77
24B706	TV6-77
24M196	TV11-61
24M870	TV11-61
24P372	TV11-61
24U211-5	TV11-61
24W196	TV11-61
24W370	TV11-61
37M709	TV7-78
100	Six-54
100S	Eight-70
101S	Six-54
102	Six-54
103	Six-54
107	Seven-60
108S	Seven-61
110S	Eight-71
113	Eight-72
115	Nine-49
118	Eight-73
119	Eight-74
129	Nine-50
170 to 176	TV5-67
165	Eleven-55
180	TV6-77
183	TV6-77
184	TV6-77
185	TV6-77
187	TV6-77
195 similar to 196	
196	TV7-78
196M	TV7-78
196T	TV7-78
197	TV7-78
199	TV7-78
A200	Six-54
A202	Eight-74
204	Eleven-55
205	Eleven-55
300-17	TV8-59
300-21	TV8-59
A300	Eight-70
A301	Six-54
A302	Six-54
306-21	TV10-111
307-17	TV10-111
308-21	TV10-111
309-21	TV10-111
A309	Eight-74
310-21	TV10-111
310, 311 see A300	
315 see TV10-111	
321	TV12-79
321U	TV12-81
322	TV12-79
322U	TV12-81
323, -U	TV12-80
326	TV12-75
326U	TV12-77
335	TV16-39
336	TV15-39
348	TV17-47
350	TV17-47
351	TV17-47
352	TV17-47
353	TV17-47
355	TV18-59

Hoffman (Cont.)

356	TV18-63
357	TV18-63
358	TV18-63
359	TV18-63
360	TV18-55
B400	Eight-73
A401	Six-54
411-21	TV11-61
412-21	TV11-61
413-24	TV11-61
414-24	TV11-61
419, -U	TV13-93
420, -U	TV13-93
A500	Seven-60
A501	Seven-61
B502	Eight-72
B503	Nine-49
B508	Nine-50
B509	Nine-50
B510	Nine-50
B513	Nine-49
630 to 635	TV5-67
636	TV6-77
637	TV3-77
638	TV6-77
639	TV6-77
A700	Eight-71
P706	1960-69
866	TV5-67
867	TV5-67
868	TV5-67
870	TV5-67
871	TV5-67
872	TV5-67
876	TV5-67
877	TV5-57
878	TV5-67
880	TV6-77
881	TV6-77
882	TV6-77
883	TV6-77
884	TV0-77
885	TV6-77
886	TV0-77
887	TV0-77
890	TV5-67
891	TV5-67
892	TV5-67
893	TV6-77
894	TV6-77
895	TV6-77
896	TV6-77
897	TV6-77
950	TV5-67
950A	TV5-67
951	TV5-67
951A	TV5-67
952	TV5-67
952A	TV5-67
953	TV6-77
954	TV6-77
955	TV6-77
960	TV5-67
961	TV5-67
962	TV5-67
963	TV6-77
964	TV6-77
965	TV6-77
B1007, M1007, P1007, W1007	Use 315 like 307-17
B1081	TV12-79
K1081	TV12-79
M1081	TV12-79
1091 uses 321	
B1111	TV12-79
M1111	TV12-79
W1111	TV12-79
B1121	TV12-79
M1121	TV12-79
P1121	TV12-79
W1121	TV12-79
1123	1960-69
PG-1144	TV12-75
SG-1144	TV12-75
BG1151	TV12-80
K1151	TV12-80
MG1151	TV12-80
P1151	TV12-80
B1161	TV12-80
M1161	TV12-80
SP1161	TV12-80
W1161	TV12-80
B1277	TV16-40

Hoffman (Cont.)

K1277	TV16-40
M1277	TV16-40
P1277	TV16-49
W1277	TV16-40
B1291	TV16-40
K1291	TV16-40
M1291	TV16-40
SP1291	TV16-40
W1291	TV16-40
B1367	TV17-47
BR1367	TV17-47
K1367	TV17-47
KR1367	TV17-47
M1367	TV17-47
MR1367	TV17-47
SP1367	TV17-47
SPR1367	TV17-47
W1367	TV17-47
WR1367	TV17-47
B1371	TV17-47
BR1371	TV17-47
K1371	TV17-47
KR1371	TV17-47
M1371	TV17-47
MR1371	TV17-47
SP1371	TV17-47
SPR1371	TV17-47
W1371	TV17-47
WR1371	TV17-47
1777	TV18-55
1919	TV18-59
B3061	TV12-79
M3061	TV12-79
SP3001	TV12-79
W3061	TV12-79
B3071	TV12-79
M3071	TV12-79
P3071	TV12-79
W3071	TV12-79
B3081	TV13-93
M3081	TV13-93
P3081	TV13-93
W3081	TV13-93
P3091	TV12-79
B3191	TV12-79
M3101	TV12-79
P3101	TV12-79
W3101	TV12-79
B3114	TV12-79
M3114	TV12-79
P3114	TV12-79
W3114	TV12-79
M3181	TV13-93
SP3181	TV13-93
B3191	TV13-93
3201 uses 323	
B3221, U; M3221, U; SP3221, U; W3221, U	Use Chassis 323 323U
B3411	TV16-39
M3411	TV16-39
SP3411	TV16-39
W2411	TV16-39
B3421	TV16-39
M3421	TV16-39
SP3421	TV16-39
W3421	TV16-39
B3653	TV17-47
M3653	TV17-47
SP3653	TV17-47
W3653	TV17-47
B3663	TV17-47
M3663	TV17-47
SP3663	TV17-47
W3663	TV17-47
B3673	TV17-47
SP3673	TV17-47
W3673	TV17-47
B3683	TV17-47
M3683	TV17-47
SP3683	TV17-47
W3683	TV17-47
B3723	TV17-47
M3723	TV17-47
SP3723	TV17-47
W3723	TV17-47
B3733	TV17-47
M3733	TV17-47
SP3733	TV17-47
W3733	TV17-47
B3743	TV17-47
M3743	TV17-47
SP3743	TV17-47
W3743	TV17-47

Hoffman (Cont.)

B3753	TV17-47
M3753	TV17-47
SP3753	TV17-47
W3753	TV17-47
3803	TV18-63
3813	TV18-63
3823	TV18-63
3833	TV18-63
3843	TV18-63
3853	TV18-63

HOTPOINT CO.

MM Line	TV13-97
Q Line	TV14-33
T Line	TV13-79
U Line	TV14-45
Q2 see GE Q2 Line	
U2 see GE U2 Line	
M3 same as GE M3	
Q-3	TV15-59
U3	TV15-67
M4	TV15-51
9S101	TV13-79
9S102	TV13-79
14S201	TV14-33
14S202	TV14-33
14S203	TV14-33
14S204	TV14-33
14S206, 14S207	Same as GE Q2
14S208	TV15-59
14S209	TV15-59
17S301	TV13-97
17S302	TV13-97
17S305, 17S306	Use GE M8
17S315	TV15-51
17S320	TV15-51
17S321	TV15-51
17S322	TV15-51
21S400 use GE M3	
21S401	TV14-45
21S402	TV14-45
21S403	TV14-45
21S405 see M3	
21S406 see U2	
21S407 through 21S411 use GE U2	
21S412	TV15-51
21S415	TV15-67
21S416	TV15-67
21S420	TV15-51
21S421	TV15-51
21S451	TV14-45
21S452	TV14-45
21S455, 21S456	Uses GE U2 Line
21S457 uses U2	
21S501	TV14-45
21S502	TV14-45
21S505 use GE M3	
21S506 use GE M3	
21S507, 21S508	Uses GE U2 Line
21S509, 21S510	use GE U2
21S530	TV15-51
21S531	TV15-51
21S532	TV15-51
21S533	TV15-51
21S552	TV14-45
21S553	TV14-45
21S554	TV14-45
21S555, 21S556	Use GE U2 Line
21S560	TV15-67
21S561	TV15-67
21S605, 21S606	Use GE U2 Line
21S607, 21S608	use GE U2
21S630	TV15-51
21S631	TV15-51
24S801	TV14-45
24S802	TV14-45
24S805 through 24S807 use GE U2	

HOWARD Next Column

HOWARD RADIO CO.

12-B	Three-46
14ACB	Four-58
300	Three-47
306	Three-48
481-A, B, C, M	Nine-51
702	Four-58
718X	Five-59
765	Four-59
780	Four-60
802	Five-60
808	Five-61
868	Five-62
901	Six-55
901-A	Seven-62
901-AP	Seven-62
902-A	Eight-79
906	Seven-63
906-S	Eight-75
909-M	Eight-77
920	Seven-64

HUDSON

6E89	Ten-192
6MH081	Seven-187
6MH889	Ten-192
4389027	1956-76
8990378	1956-73

INTERNATIONAL-DETROLA

see Detrola Radio

INTERNATIONAL-HARVESTER

244079-R91	1962-47
244113-R91	1962-47

INTERNATIONAL IND.

40, 41	One-103
43, 44	One-103
66X	One-103
86	One-103
96	One-103
1019	One-102

JEWEL RADIO

955	Eleven-57
956	Eleven-57
960	Eleven-58
960U	Eleven-58
961	Eleven-58
5010U	Eleven-56
5050	Eleven-56
5057	Eleven-58
5125	1953-56
5200	1953-56
5250	1953-56
5310	1953-51

KAISER-FRAZER

100170	Eleven-136
100205	Eleven-138
100830 identical to 100170	

KOLSTER RADIO

K20, K22	One-104
K27	One-104

LAFAYETTE RADIO

CC-24, -25	Three-49
CC-55A	Three-50
E-114	Four-62
E-191	Four-63

LEAR, INC.

561	Six-66
562	Six-66
563	Six-66
565, 565BL	Seven-67
566	Seven-67
567	Seven-67
568	Seven-57
661	Seven-68
6614	Seven-70
6615	Seven-70
6616	Seven-70
6619	Seven-70

McMURDO SILVER CO.

VOMAX	Seven-76
906	Eight-159

MAGNOVOX CO.

AM2	1957-40
13 Series	TV12-85
V/U13-01AA to V/U18-04AA	TV12-85
21 Series	TV12-85
V/U31-01AA to V/U21-04AA	TV12-85
35 Series	TV19-61
36 Series	TV20-39
38 Series	TV20-39
42 Series	TV22-63
55-01	1960-70
57 Series	1963-70
59 Series	1964-59
AM-64	1963-68
65	1962-41
65-01	1961-62
71	1962-42
72 Series	1963-69
93 Series	1964-53
104	TV6-83
105 Series	TV7-83
105C	TV7-83
105E	TV7-83
105F	TV7-83
105L	TV7-83
105M	TV7-83
117	TV12-83
CR-154	Four-66
CR-156	Four-67
CT-301	TV6-83
CT-302	TV6-83
CT-303	TV6-83
CT-304	TV6-83
CT-305	TV6-83
CT-306	TV6-83
CT-307	TV6-83
CT-309	TV6-83
CT-810	TV6-83
CT-811	TV6-83
CT-313	TV6-83
CT231, CT332	TV7-83
CT333	TV7-83
CT334	TV7-83
CT335	TV7-83
CT336	TV7-83
CT337	TV7-83
CT338	TV7-83
CT339	TV7-83
CT340	TV7-83
CT341	TV7-83
CT342	TV7-83
CT343	TV7-83
CT344	TV7-83
CT345	TV7-83
CT346	TV7-83
CT347	TV7-83
CT348	TV7-83
CT349	TV7-83
CT350	TV7-83
CT351	TV7-83
CT352	TV7-83
CT353	TV7-83
CT354	TV7-83
CT355	TV7-83
CT356	TV7-83
CT357	TV7-83
CT362	TV7-83
CT363	TV7-83
CT372	TV7-83
CT373	TV7-88
CMUA440AA	TV11-65
CTA440AA	TV11-65
CMUA441AA	TV11-65
CTA441AA	TV11-65
CMUA442AA	TV11-65
CTA442AA	TV11-65
CMUA465AA through CMUA474AA	TV11-68
CTA465AA through CTA474AA	TV11-68
CMUA475AA through CMUA481AA	TV11-65
CTA475AA through CTA481AA	TV11-65
CTA/CMUA487AA to CTA/CMUA495AA all on TV12-83	

MAGNOVOX (Cont.)

CTE/CMUE492CC,
CTA/CMUA499CC and
CTA/CMUA501CC
similar to above

600	TV11-65
650	TV11-65
CR-734	1957-147

MAJESTIC (OLD)

7BP3	One-79
7P3	One-79
7BP6	One-79
7P6	One-79
8P3	One-79
6P6	One-79
9P3	One-79
9P6	One-79
15, 15B	One-80
20	One-61
55 to 58	One-82
59	One-32
60 to 62	One-83
66	One-84
70	One-85
70B	One-85
71, 72	One-85
90	One-67
90B	One-88
91, 92	One-87
93	One-38
116	One-89
130	One-90
130A	One-90
131, 132	One-90
160, 163	One-91
200 to 204	One-92
220, 223	One-98
280A, 283	One-94
290-294	One-95
380, 386	One-96
360, 368	One-97
400, 413	One-98
400A, 413A	One-99
460, 463	One-100

MAJESTIC (NEW)

2D60	Three-51
4B22	Five-63
4C10	Three-51
5A410	Six-69
5A430	Six-69
5A445	Eight-80
5A445R	Eight-80
5AK711	Eight-81
5AK731	Eight-81
5AK780	Eight-81
5BO1A	Eight-81
5BO5A	Eight-81
5C36	Five-64
5T10	Five-63
5T10W	Five-63
6C35	Five-64
6P1, 6P2	Five-63
6T23	Five-63
7C40	Five-65
7C432	Seven-75
7C447	Seven-75
7JK777R	Eight-83
7K60	Five-65
7P420	Eight-85
7S438	Six-70
7S450	Six-70
7S470	Six-70
7T20	Five-63
8S452	Seven-71
8S473	Seven-71
8S473	Eight-84
T101-L-A	Four-65
130	Three-185
TP221-A	Four-65
TP231-A	Four-65
TR-321-A	Four-64
TR-331-A	Four-64
403	Four-64
410	Three-51
G1-426, -Y	Seven-73
4501	Six-69
4501X	Five-63
4504	Six-69
4506	Eight-80
4702	Six-70
4703	Six-70

Majestic (Cont.)

4705	Eight-85
4706	Seven-75
4707	Seven-75
4708	Seven-75
4708R	Eight-83
4807	Seven-72
4608	Seven-73
4810	Seven-71

MAJESTIC (GAROD)

see other Majestic
also Garod

4L1	1955-43
5C2	1953-51
5C3	1953-51
5LA7	1953-52
5LA8	1953-52
5LA50	1953-52
5LA80	1953-52
5M1	1955-43
7P1	TV5-71
7P2	TV5-71
7P8	TV5-71
7P10	TV5-71
7P11	TV5-71
7PR12	TV5-71
7PR13	TV5-71
9P4	TV5-71
9P5	TV5-71
9PR8	TV5-71
9PR9	TV5-71
17	TV5-71
17C62	TV6-85
17FA	TV6-85
17GA uses 101	
17HA uses 101	
17JA	TV6-85
17L, -UT, -X	TV6-85
20C82	TV6-85
20C83	TV6-85
20C84 uses 108	
20F82 uses 108	
20F88 uses 108	
20F85 uses 108	
20F86 uses 108	
20F87 uses 108	
20FP88 uses 109	
20FP89 uses 109	
20K, 20KA	TV6-85
20L, 20LA	TV6-85
20T82	TV6-85
20T83	TV6-85
20T84 uses 108	
20UAT	TV6-35
20UC, 20UT	TV6-85
20X	TV6-85
21P60 uses 110	
21P61 uses 110	
21F86 uses 108	
21F87 uses 108	
70	TV6-85
A-70	TV6-85
72	TV6-85
73	TV6-85
78, 78A	TV9-73
79	TV9-73
81	TV9-73
82	TV9-73
83	TV9-73
84	TV9-73
85	TV9-78
86	TV9-73
88	TV9-73
99	TV5-71
100	TV5-71
101	TV5-71
102	TV5-71
108	TV5-71
105	TV5-71
106, -A	TV6-85
106-6 like 106	
108, -A, -C	TV6-85
108-6 like 108	
109 similar to 103	
110 similar to 106	
111 similar to 106	
120	TV5-71
121	TV5-71
123	TV9-73
124	TV9-73
124-2	TV9-73
141	TV5-71

Majestic (Cont.)

142	TV5-71
160	TV5-71
162	TV5-71
170 uses 101	
700	TV6-85
701	TV6-85
712	TV6-85
A-712	TV6-85
715	TV6-85
717	TV6-85
718	TV6-85
719	TV6-85
800 to 804	TV6-85
900	1960-72
902	TV5-71
903	TV5-71
910	TV5-71
911	TV5-71
1400	TV5-71
1401	TV5-71
1600	TV5-71
1605	TV5-71
1610	TV5-71
1710	TV5-71

MANTOLA

R260	Five-18
R261	Five-18
R423	Three-18
R653	Five-16
R654	Five-18
R662	Eight-63
R662N	Eight-63
92505	Nine-46
92506	Nine-45

MASCO

Phono.	Eight-86
52	Twelve-105
52C	Twelve-105
52CR	Twelve-105
52L	Twelve-105
52LR	Twelve-105
52R	Twelve-105

JOHN MECK IND.

XSC	TV6-89
PM-5C5-P	Eight-87
RC-5C5	Six-67
RC-5C5-A	Six-67
RC-5C5-B	Six-67
RC-5C5-C	Six-67
RC-5C5-CL	Six-68
RC-5C5-DL	Six-68
RC-5C5-P	Eight-87
6A7	Eight-88
17PCSB	TV7-87
17PCW2	TV7-87
17PTE2	TV7-87
20PCSB2	TV7-87
20PCW2	TV7-87
20PTE2	TV7-87
20PTSB2	TV7-87
20PTW2	TV7-87
20TPRS2	TV7-87
21PCS2	TV7-87
21QDCS2	TV7-87
24QDCS2	TV7-87
614T	TV6-89
MM-617C	TV7-87
MM-617M	TV7-87
MM-620C	TV7-87
MM-620T	TV7-87
JM-700	TV6-89
717C, 717T	TV6-89
JM-717C	TV6-89
JM-717C (late)	TV7-87
JM-717T	TV7-87
also	TV6-89
720C, 720T	TV6-89
JM-720C	TV6-89
JM-720T	TV6-89
JM-720T	TV7-87
JM-721C	TV7-87
JM-721CD	TV7-87
9021	TV6-89
9022	TV6-89
9023	TV6-89
9024	TV6-89
9026	TV6-89
9026	TV7-87
9032	TV7-87
9033	TV7-87

MEISSNER MFG. CO.

8C	Nine-52

MIDWEST RADIO

P-6	Seven-77
PB-6	Seven-77
Series 8	Seven-78
S-8	Seven-78
ST-8	Seven-78
STM-8	Seven-78
TM-8	Seven-78
Series 12	Seven-80
15-40	Three-58
16	Eight-89
16-84	One-105
51	Four-68
78	Seven-78
82	Five-66
90	Three-52
112	Five-67
162R	Five-68
181	Four-69
712	Seven-80
816	Eight-89

MONTGOMERY WARD

04BR-511A	Four-70
04BR-512A	Four-70
04BR-518A	Four-71
04BR-514A	Four-71
04BR-570A	Three-54
04BR-729A	Four-72
04BR-730A	Four-72
04BR-1105A	Four-73
04WG-464	Four-74
04WG-569B	Four-75
04WG-610	Four-76
04WG-611	Four-76
04WG-731A	Four-78
04WG-803	Four-77
05BR-1536A	Eleven-62
05BR-1536B	Eleven-62
05BR-1537A	Eleven-62
05BR-1537B	Eleven-62
05BR-2756A	Eleven-68
05BR-2756B	Eleven-68
05WG-1811B	Ten-65
05WG-2745B	Ten-66
05WG-2748C	Eleven-63
05WG-2748D	Eleven-63
05WG-2748E	Eleven-63
05WG-2748F	Eleven-68
05WG-2751A	Eleven-60
05WG-2752	Ten-68
05WG-2752B	Eleven-60
05WG-2752C	Eleven-61
05WG-3080C	TV5-77
05WG-8086A	TV5-77
05WG-8086B	TV5-77
05WG-8039A	TV5-77
05WG-3089B	TV5-77
14BR-511A same as 04BR-511A	
14BR-521A	Five-70
14BR-522A	Five-70
14BR-684A	Five-72
14BR-734A	Five-73
14BR-735A	Five-73
14BR-912A	Five-75
14WG-518B	Five-69
14WG-519B	Five-69
14WG-624A	Five-71
14WG-625A	Five-71
14WG-628A	Five-71
14WG-672	Four-70
14WG-808M	Five-74
14WG-803W	Five-74
15BR-1525D	Twelve-67
15BR-1526D	Twelve-67

Mont. Ward (Cont.)

15BR-1581D	Twelve-67
15BR-1582D	Twelve-67
15BR-1536B and 15BR-1537B see	Eleven-62
15BR-1543A	Eleven-64
15BR-1544A	Eleven-64
15BR-1547A	Eleven-65
15BR-1548A	Twelve-68
15BR-1549A	Twelve-68
15BR-2757A	Eleven-68
15GCB-1583	Eleven-86 also Twelve-68
15GCB-1584	Eleven-66 also Twelve-68
15GHM-1067A	Twelve-69
15GHM-1070A	Twelve-70
15GHM-1552A	Twelve-71
15GSE-1068A	Twelve-72
15GSE-1595A	Twelve-73
15GSE-2764A	Twelve-74
15GSL-1564A	Twelve-75
15GSL-1564B	Twelve-75
15GSL-1565A	Twelve-75
15GSL-1565B	Twelve-75
15GSL-1566A	Twelve-75
15GSL-1566B	Twelve-75
15GSL-1567A	Twelve-75
15GSL-1567B	Twelve-75
15HA-1558A	Eleven-67
15HA-1554A	Eleven-67
15WG-1813B	Eleven-63
15WG-2745C see 05WG-2745B	
15WG-2752D	Eleven-61
15WG-2752E	Eleven-61
15WG-8046C	TV6-93
16WG-3049A	TV6-93
15WG-3050A	TV6-93
15WG-3051C	TV6-93
15WG-3059A similar to 15WG-3049B	
25BR-1542A	1954-59
25BR-1548B	Twelve-68
25BR-1549B	Twelve-68
25GAA-934B	Twelve-76
25GSE-1555A	Twelve-73
25GSE-1558A	Twelve-73
25GSG-2016A	1953-53
25GSL-1072A	1954-60
25GSL-1560A	1954-61
25GSL-1561A	1954-61
25GSL-1814A see Sonora 314	
25WG-1570B	Twelve-77
25WG-1570C	Twelve-77
25WG-1571B	Twelve-77

Mont. Ward (Cont.)

25WG-1572B	Twelve-77
25WG-2049B and 25WG-3050A see note on 15WG-2049B	
25WG-3066A, -B	TV7-89
25WG-2071A, -B	TV7-89
25WG-2072A, -B	TV7-89
25WG-3072A, -B	TV7-89
25WG-3075A, -B	TV7-89
25WG-3077A, -B	TV7-89
25WG-2079A, -B	TV7-80
35GSE1555C see 25GSE1555A	
35WG-1570B, -C and 35WG-1571B, -72B all like 25WG-1570	
54BR-1501A	Six-72
54BR-1502A	Six-72
54BR-1508C	Six-73
54BR-1504C	Six-73
54BR-1505A	Six-71
54BR-1506A	Six-71
54WG-1801A	Six-76
54WG-2007A	Six-76
54WG-2700	Seven-81
62-49	One-106
62-68	One-106
62-70	One-106
62-72	One-106
62-97	One-107
62-99	One-107
62-123	One-110
62-131	One-110
62-133	One-110
62-142	One-110
62-144	One-110
62-152	One-110
62-158	One-110
62-185	One-108
62-187	One-108
62-190	One-108
62-196	One-108
62-288	One-109
62-265	One-111
62-425	One-111
64BR-916A	Seven-88
64BR-917B	Seven-83
64BR-1051A	Six-74
64BR-1205	Seven-84
64BR-1206	Seven-84
64BR-1208	Seven-85
64BR-1503B	Six-78
64BR-1504B	Six-73
64BR-1513	Seven-86
64BR-1514	Seven-86
64BR-2200	Seven-85
64BR-2701	Seven-87
64BR-7100	Seven-89
64BR-7110	Seven-89
64BR-7120	Seven-89
64WG-1050	Seven-90
64WG-1052	Seven-91
64WG-1207	Seven-93
64WG-1511	Seven-92
64WG-1512	Seven-92
64WG-1801	Seven-95
64WG-1804A	Six-75
64WG-1807	Seven-94
64WG-1809	Seven-92
64WG-2009	Seven-96
64WG-2500	Seven-97
64WG-2700	Seven-81
74BR-916 see Mod. 64BR-916A	
74BR-1053	Eight-90
74BR-1055	Eight-90
74BR-1501B	Nine-55
74BR-1502B	Nine-55
74BR-2001	Eight-91
74WG-1054	Eight-92
74WG-1056	Eight-98
74WG-1509	Eight-94
74WG-1510	Eight-94
74WG-1802	Eight-95
74WG-1803	Eight-95
74WG-1804	Eight-94
74WG-1805	Eight-94
74WG-2004	Eight-95
74WG-2010	Eight-100
74WG-2504	Eight-96
74WG-2704	Eight-96
74WG-2705	Eight-102
74WG-2709	Eight-98

Mont. Ward (Cont.)

84BR-1065A	Nine-54
84BR1501,-2	Nine-55
84BR-1503D	Nine-56
84ER-1504D	Nine-56
84BR-1507B	Nine-57
84ER-1517A	Ten-67
84BR-2003C	Nine-58
84GCB-1062	Nine-53
84HA-1527A	Ten-68
84HA-1528A	Ten-68
84WG-2704D	Nine-59
84WG-2712A	Nine-60
84WG-2714G	Nine-61
84WG-2721C	Nine-62
Serial 65X	TV16-43
93ER-420B	Three-55
93BR-421B	Three-55
93BR-423B	Three-55
93BR-424B	Three-55
98BR-481B	Three-55
98BR-461A	Three-56
93BR-508A	Three-57
93BR-509A	Three-57
98WG-604	Three-59
93WG-605	Three-59
98WG-663	Three-58
98WG-668	Three-58
94WG-1059A	Ten-69
94WG-2745A	Ten-66
94WG-2748A and 94WG-2748B	Eleven-83
94WG-2748C	Eleven-63
H-667P5	1959-160
GEN-769A	1964-61
GEN-951A	1964-61
JWR-958A	1964-60
JWR-956A	1964-60
JWR-1033B	1964-60
JWR-1035B	1964-60
1059A	Ten-69
GSE-1077A, GSE-1078A	Sentinel 1U-354P
GTM1084A	TV21-165
GEN-1090A	1957-47
GEN-1091A, GEN-1092A, GEN-1092A	Same as above
ER-1100A uses Raytheon 4RT1	
BR-1102A	1958-76
GEN-1115A	1959-62
GEN-1116A	1959-62
GTM-1117A see H-667P5	
1120A, B	1959-63
GTM-1201A	1960-148
GEN-1213A	1962-44
GNT-1215	1962-45
GNT-1215A	1962-45
1517A	Ten-67
1518A	Ten-67
1527A	Ten-68
1528A	Ten-68
BR-1557B	1958-77
BR-1558B	1958-77
GSL-1575A	1957-48
GSL-1575B	1957-48
GSL-1576A	1957-48
GSL-1576B	1957-48
GSL-1581A	1956-56
GSL-1582A	1956-56
GTM1583A	TV21-165
GSE-1606A, GSE-1607A	Sentinel 348
GSL-1614A	1955-44
GSL-1615A	1955-44
GSL-1616A	1955-44
GSL-1617A	1955-44
GEN-1628A	1959-64
GSL-1618A, GRX-1619A	Similar to above
GSE-1620A, GSE-1621A, GSE-1622A	Like Sentinel 352
GSE-1625A, GSE-1626A	Sentinel 356
GSE-1625A, GSE-1626A	Sentinel 1U-863
WG-1635A	1956-57
WG-1636A	1956-57
HA-1645A	1958-78

Mont. Ward (Cont.

HA-1646A 1958-78
GSL-1650A 1956-56
GSL-1651A 1956-56
GEN-1667A 1961-64
GEN-1668A 1961-64
GPS-1688A 1962-43
GTM-1689A same as set on 1960-163
GPS-1690A } Philco
GPS-1697A } K-847
GEN-1691A 1962-46
GTM-1692A } See
GTM-1698A } Westing.
GTM-1868A } V-2398-3
GTM-1720A like Westinghouse V-2420-1
GEN-1730A 1964-61
GEN-1731A 1964-61
GTM-1784A like Data on TV21-143
1811B Ten-65
GEN-1819A 1963-71
GTM-1830A } Westing-
GTM-1831A } house
GTM-1832A } V-2424-2
GEN-1850A 1960-73
GEN-1851A 1960-73
GPS-1865A 1962-43
GTM-1866A same as set on 1960-163
GPS-1867A } Philco
GPS-1872A } K-847
GEN-1869A 1962-46
GPS-1870A like Philco K-782
GEN-2030A 1961-63
GEN-2030B 1961-63
GTM2084A TV21-165
GAA-2213A 1963-72
GAA-2223A 1963-72
GAA-2243A 1963-72
GAA-2253A 1963-72
GTM2583A TV21-165
2745 Ten-66
2748 Ten-63
2749 Ten-63
2751 Ten-63
2752 Ten-63
GTM-2784A like Data on TV21-143
WG-3071 TV9-77
WG-3073 TV9-77
WG-3075 TV9-77
WG-3077 TV9-77
WG-3079 TV9-77
WG-3113A TV21-58
WG-3123A TV21-58
WG-3143A TV21-58
WG-3153A TV21-58
WG-3213A TV21-58
WG-3214A TV22-67
WG-3273A TV21-58
WG-3314A TV22-67
WG-3344A TV22-67
WG-3354A TV22-67
WG-3413A TV21-58
WG-3423A TV21-58
WG-3443A TV21-58
WG-3453A TV21-58
WG-4042A TV14-83
WG-4052A TV14-88
WG-4083A TV18-67
WG-4087A TV17-55
WG-4082A } Similar
WG-4092A } to
WG-4182A } WG-4087A
WG-4192A } TV17-55
WG-4093A TV18-67
WG-4113A TV21-58
WG-4123A TV21-58
WG-4143A TV21-58
WG-4153A TV21-58
WG-4183A TV18-67
WG-4187A TV17-55
WG-4193A TV18-67
WG-4204A TV16-43
GTM-4213A } Like
GTM-4313A } TV16-159
WG-4213A TV21-58
WG-4214A TV22-67
GTC-4220A } like
GTC-4320A } TV17-159
GTM-4221A } see
GTM-4222A } TV15-159

Mont. Ward (Cont.)

GTM-4223A } like
GTM-4323A } TV17-169
WG-4225A TV19-67
GTM-4233 like data on TV19-167
WG-4235A TV20-53
WG-4273A TV21-58
WG-4314A TV22-67
WG-4325A TV19-67
GTM-4321A } like
GTM-4322A } TV15-159
GTM-4333 like data on TV19-167
WG-4335A TV20-53
WG-4344A TV22-67
WG-4354A TV22-67
WG-4413A TV21-58
WG-4423A TV21-58
WG-4443A TV21-58
WG-4453A TV21-58
WG-4600A } like
WG-4700A } TV17-55
WG-4601A TV18-71
WG-4606A TV18-71
WG-4611A TV18-71
WG-4701A TV18-71
WG-4706A TV18-71
WG-4711A TV18-71
WG-5040A TV15-72
WG-5042A TV14-83
WG-5047A TV14-83
WG-5052A TV14-83
WG-5062A TV16-47
WG-5067A TV16-47
WG-5072A TV16-47
WG-5077A TV16-47
WG-5081A TV17-55
WG-5083A TV18-67
WG-5084A TV18-67
WG-5082A } All
WG-5086A } similar
WG-5087A } to
WG-5088A } WG-4087A
WG-5092A } see
WG-5097A } TV17-55
WG-5089A } like
WG-5099A } TV17-55
WG-5091A TV17-55
WG-5093A TV18-67
WG-5140A TV15-72
WG-5162A TV16-47
WG-5172A TV16-47
WG-5181A TV17-55
WG-5183A TV18-67
WG-5182A } All
WG-5186A } similar
WG-5187A } to
WG-5188A } WG-4087A
WG-5192A } see
WG-5197A } TV17-55
WG-5184A TV18-67
WG-5180A } like
WG-5199A } TV17-55
WG-5191A TV17-55
WG-5193A TV18-67
WG-5200A } Similar
WG-5201A } to
WG-5209A } WG-4087A
WG-5210A } see
WG-5211A } TV17-55
WG-5202A TV18-71
WG-5203A } similar
WG-5205A } to
WG-5213A } WG-5183A
WG-5204A TV18-71
WG-5206A TV18-71
WG-5207A TV18-71
WG-5208A TV18-71
WG-5212A TV18-71
WG-5217A TV18-71
WG-5220A } similar
WG-5226A } to
WG-5230A } WG-5217A
WG-5221A TV19-71
WG-5222A } All
WG-5225A } similar
WG-5232A } to
WG-5236A } WG-5221A
WG-5240A } TV19-71
WG-5246A }
WG-5224A TV20-47
WG-5227A TV19-71
WG-5231A TV19-71

Mont. Ward (Cont.)

WG-5234A TV20-47
WG-5235A TV20-47
WG-5237A TV20-47
WG-5300A } Similar
WG-5301A } to
WG-5309A } WG-4087A
WG-5310A } see
WG-5311A } TV17-55
WG-5302A TV18-71
WG-5303A } similar
WG-5305A } to
WG-5313A } WG-5183A
WG-5304A TV18-71
WG-5306A TV18-71
WG-5307A TV18-71
WG-5308A TV18-71
WG-5312A TV18-71
WG-5317A TV18-71
WG-5320A } similar
WG-5326A } to
WG-5330A } WG-5317A
WG-5321A } TV19-71
WG-5322A } All
WG-5325A } similar
WG-5332A } to
WG-5336A } WG-5321A
WG-5340A } see
WG-5346A } TV19-71
WG-5324A TV20-47
WG-5327A TV19-71
WG-5331A TV19-71
WG-5334A TV20-47
WG-5335A TV20-47
WG-5337A TV20-47

MOTOROLA, INC.

BKOA Eleven-76
GMOT Eleven-76
HNO Eleven-76
IWOTC Eleven-76
OEO Eleven-76
PCO Eleven-76
1A Eleven-73
1B Eleven-74
A1B, N 1960-93
A1R, W 1960-93
B1J 1961-98
B1W 1961-98
BC1 1963-84
C1N, W 1960-94
CT1 Eleven-73
CT1M Eleven-74
CX1 1963-86
HS-1 Seven-103
KR1 Eleven-73
NH1C Eleven-75
SR1B Eleven-74
TRR-1B TV20-72
WS1C Twelve-88
2A Twelve-91
2AT 1963-74
2F11B, R 1959-87
2F12N, W 1959-87
2F21B, -R 1958-106
2X4F like above
2M Twelve-92
2MF(Ford) Twelve-90
2MT 1963-75
2TME like 2TMF
2TMF 1963-73
2TMR 1962-50
2TMX 1963-73
2TMXD 1962-49
2TMY 1963-73
A2G, N 1960-94
A2P, W 1960-94
B2G 1961-100
B2N 1961-100
B2W 1961-100
BC2 1964-82
BK2A Twelve-91
BK2M Twelve-92
BR2RC 1957-78
BT-2 Twelve-93
C2B, P, W 1960-94
CT2A Twelve-91
CT2A6 1954-64
CT2M Twelve-92
CT2M6 1954-65
CX2 1964-81
GMT2A Twelve-91

Motorola (Cont.)

GMT2M Twelve-92
GMT2M6 1954-65
HJ2A Twelve-91
HJ2M Twelve-92
HN2A Twelve-91
HN2A6 1954-64
HN2M Twelve-92
HN2M6 1954-65
HS-2 Six-81
IL2TD see 1A
KR2A Twelve-91
KR2M Twelve-92
NH2AC Twelve-89
OE2 Nine-64
OE2A Twelve-91
OE2A6 1954-64
OE2M Twelve-92
OE2M6 1954-65
PC2 Nine-64
PC2A Twelve-91
PC2A6 1954-64
PC2M Twelve-92
PC2M6 1954-65
PD2A Twelve-91
PD2M Twelve-92
SR2A Twelve-91
SR2A6 1954-64
SR2M Twelve-92
SR2M6 1954-65
WS2C Twelve-88
3AT 1964-62
3F13B, W 1959-87
3F22 1958-106
3H24B-1 1958-107
3H24B-2 1958-107
3H24S-1 1958-107
3H24S-2 1958-107
3H25B 1958-107
3H25B-1 1958-107
3H25M 1958-107
3H25M-1 1958-107
3MF similar to 2MF
3MT 1964-62
3TME 1964-64
3TMF 1964-64
3TMR 1964-66
3TMY 1964-64
03AR 1960-75
03MR, 03MRM, and 03MRMR like 93MR
A3B, N 1961-85
B3E 1961-102
B3W 1961-102
BC3 1964-82
BK3A6 1954-64
BK3M6 1954-65
C3G, -1 1960-94
C3S, -1 1960-94
C3W, -1 1960-94
CTA3 1954-62
GMT3A6 1954-64
GMT3M6 1954-65
HJ3A6 1954-64
HJ3M6 1954-65
HN3A6 1954-64
HM3M6 1954-65
HT3A6 1954-64
HT3M6 1954-65
KR3A6 1954-64
KR3M6 1954-65
NH3C 1953-72
PD3A6 1954-64
PD3M6 1954-65
SR3A6 1954-64
SR3M6 1954-65
4MF similar to 2MF
04MA 1960-74
04MD 1960-76
04MD 1961-68
04MF 1960-76
04MPM 1960-76
04MI 1962-47

Motorola (Cont.)

AX4 1963-83
C4B, P, S 1960-94
HN4A6 uses R17A6
HN4M6 uses R16M6
5A1 Six-77
5A5 Six-79
5A7 Nine-63
5A7A Nine-63
5A9B Ten-71
5A9M Ten-71
5A9S Ten-71
5A9UB Ten-71
5A9UM Ten-71
5C1 Eleven-87
5C2 Eleven-87
5C3 Eleven-87
5C4 Eleven-87
5C5 Eleven-87
5C6 Eleven-87
5C11E 1959-84
5C12M, P, W 1959-84
5C13+ 1959-85
5C14+ 1959-85
5C15+ 1959-86
5C16NW, W 1959-85
5C17S like 5C11E
5C22+ 1958-108
5C23+ 1958-108
5H11, -U Eleven-89
5H12, -U Eleven-89
5H13, -U Eleven-89
5J1 Ten-80
5J1U Ten-80
5J2, -U Eleven-91
5K11+ 1959-89
5K21+ 1958-109
5K23+ 1958-109
5L1 Ten-80
5L1U Ten-80
5L2, -U Eleven-91
5M 1956-74
5M1 Ten-80
5M1U Ten-80
5M2 Ten-80
5M2U Ten-80
5M-12 1956-74
5MF 1955-51
5MF8 1955-53
5P21B, N, R 1959-78
5P22+ 1959-81
5P23+ 1959-81
5P31A 1958-110
5P32+ 1958-110
5P33+ 1958-110
5R11-A, -AU, -U Eleven-88
5R12-A, -AU, -U Eleven-88
5R13-A, -AU, -U Eleven-88
5R14-A, -AU, -U Eleven-88
5R14N 1959-88
5R15-A, -AU, -U Eleven-88
5R16-A, -AU, -U Eleven-88
5R23+ 1958-111
5T1 One-60
5T2 One-60
5T11G, M 1959-82
5T11R, W 1959-82
5T12+ 1959-83
5T13+ 1959-83
C5G, S, W 1960-95
5T21W-1 1958-112
5T22+ 1958-112
5T23+ 1958-112
5T24+ 1958-113
5T25+ 1958-113
5X11U Eleven-89
5X12U Eleven-89
5X13U Eleven-89

Motorola (Cont.)

5Y, 5-2 One-60
AX5 1963-83
CTA5 1956-72
HN5AC-8 1056-76
6H26S-1 1058-114
6H26S-1A 1058-144
6H27+ 1058-114
6K13+ 1050-00
5K22+ 1058-114
6L1 Eleven-02
6L2 Eleven-02
6M 1956-74
6M-12 1956-74
6MA 1956-73
6M1 Like 506
6M1-12 Like 506-12
6MR 1957-66
6P25E, N, S 1950-79
6P34E, -S 1058-115
6T, 6Y, 6-2 One-60
6T15N, S 1950-03
6TAS8 1956-78
6X11U Eleven-90
6X12U Eleven-90
6X28B, N 1069-80
6X28P, W 1950-80
6X31+ 1958-116
6X32E 1958-116
6X39A, -1 1958-117
6X39A-2 1058-117
BKA6A 1057-63
BKA6T 1057-64
BKA6X 1058-101
CR6 Seven-98
CT6 Eight-113
CTA6T 1956-80
CTA6X 1958-101
CTM6 1956-77
HS-6 Six-77
P6-2 Twelve-94
R6MA 1956-84
SM6T like 596-12
SR6 Nine-64
WR6 Seven-100
7M same as 6M
7MR 1957-66
7MX 1958-79
7XM21 Twelve-79
7XM22 Twelve-79
7X23E 1959-94
7X24S, W 1959-94
7X25P, W 1959-91
A7N uses HS-744
BKA7X 1958-101
C7N uses HS-749
CTA7X 1958-101
CTM7X 1958-80
HS-7 Seven-102
OEA7X 1958-82
PCA7X 1958-101
VWA7 1958-83
WR7 Seven-100
Power 8 1960-89
8A Nine-64
8FDT Nine-64
8FM21 Eleven-94
8FM21B Eleven-94
8GMT Nine-64
8X26E, S 1959-92
8M 1958-84
8MX 1958-85
A8J, R, S, W use HS-744
BK8 Nine-64
BK8X Nine-64
C8A, S, W uses HS-749
CR8 Nine-66
CT8 Nine-64
CT8A Eleven-76
CTA8X 1958-86
CTM8X 1958-88
FD8 Nine-64
HN8 Mine-64
HS-8 Six-78
KR8 Nine-64
NH8 Nine-64
OE8 Nine-64
P8-2 Twelve-94
PC8 Nine-64
SR8 Nine-64
WR8 Seven-100
Power 9 1960-90

Motorola (Cont.)

9AX 1950-65
9L1 see TS-18
A9B, P, W } like
A10G, N, W } HS-749
BKA9X 1050-66
C0B, G, P } use
C9B-1, + } HS-750
CT9 Ten-92
CTA0X 1050-66
CTM9X 1050-67
GM0TA Eleven-76
KR0A Eleven-76
OEA0X 1050-66
PC9A Eleven-76
PCA0X 1050-66
SR0A Eleven-76
10A Eleven-76
10AX 1061-65
10M 1960-78
10MX 1960-77
10T2 TV5-83
10VT10 TV5-83
10VT10B TV5-63
10VT10R TV5-83
10VK12 TV5-83
10VK12R TV5-83
10VK22R TV5-83
10VT24R TV5-83
C10N 1961-95
C10P 1961-95
C10W 1961-95
CT10 Ten-92
11MX 1962-48
A11A 1961-97
A11W 1961-97
C11B 1961-95
C11G 1961-95
C11S 1961-95
SF11B, N 1050-95
SH12E, N, S 1950-06
X11B, E 1960-96
X11G, R 1960-96
12AT-2 1963-79
12K1 TV5-83
12K1B TV5-83
12K2 TV5-83
12K2B TV5-83
12T1 TV5-83
12T1B TV5-83
12VF4 TV5-83
12VF4R TV5-83
12VK11 TV5-83
12VK11B TV5-83
12VK11R TV5-83
12VT13 TV5-83
12VT13B TV5-83
12VT13R TV5-83
12VT16 TV4-73
12VK18 TV4-73
12VF26B TV5-83
12VF26C TV5-83
12VF26R TV5-83
A12N 1961-104
C12B 1961-96
C12P 1961-96
C12W 1961-96
L12G 1960-89
L12N 1960-89
X12 1960-92
X12A-1 1960-92
X12E-1 1960-92
13MA 1961-66
13MAM 1961-67
AS-13 Six-80
L13S 1960-90
L13W 1960-90
14B1B TV6-105
14K1H TV5-95
14MD like 14MF
14ME like 04MF
14MF 1961-68
14MFM 1961-68
14MR 1961-70
14P1B uses TS-216
14P2 uses TS-275
14P3-1, -2 TV14-53
14P4-1 TV14-53
14P5-1, -2 TV14-53
14P5-8 TV14-53
14P6-1 TV14-53
14P7-1, -2 TV14-53
14P8-1, -2 TV14-53
14P10-1, 2 TV14-60

HOW TO USE THIS INDEX

This Master INDEX will tell you in which SUPREME volume and on what page the material you need is listed. Please refer to the easy-to-follow charts on page 2, and to the explanation at top of page 3, for guidance.

Motorola (Cont.)

14P11-1, 2 TV14-60
14P14-1 TV16-59
14T3 TV5-95
14T4 TV6-105
14T4B TV6-105
AS-14 Six-82
L14E 1960-91
R14M6 1954-65
SF14SL 1960-98
TS-14 TV5-88
TS-14B TV5-82
X14B 1961-88
X14E 1961-88
X14R 1961-88
X14W 1961-88
Y14P8-1, 2 TV14-58
Y14P4-1 TV14-53
Y14P5-1, 2 TV14-58
Y14P5-2 TV14-58
Y14P6-1 TV14-53
Y14P7-1, 2 TV14-53
Y14P8-1, 2 TV14-53
Y14P10-1 TV14-60
Y14P10-2 TV14-60
Y14P11-1 TV14-60
Y14P11-2 TV14-60
15KT24+ 1958-114
A15 1962-65
AS-15 Six-83
C15 1962-55
HS-15 Six-79
R15A6 1954-64
SF15-1 1961-110
SF15-2 1961-110
X15A 1961-89
X15E 1961-89
X15N 1961-89
16F1BH TV5-87
16F1H TV5-87
16K2BH TV5-87
16K2H TV5-87
16K2L TV5-83
16K2LB TV5-83
16T1BH TV5-87
16T1H TV5-87
16VK1B TV5-83
16VK1R TV5-83
A16 1962-65
C16 1962-65
R16M6 1954-63
SH16B, E 1960-98
X16B 1961-90
X16G 1961-90
X16N 1961-90
17F1 TV5-95
17F1A TV5-87
17F1B TV5-95
17F1BA TV5-87
17F2W TV5-95
17F2WA TV5-87
17F2B TV5-95
17F2BA TV5-87
17F4 TV5-95
17F5 TV5-95
17F5A TV5-87
17F5B TV5-95
17F5BA TV5-87
17F5 uses TS-118
17F5B uses TS-118
17F6BC uses TS-118
17F6C uses TS-118
17F8 uses TS-118
17F9 uses TS-118
17F9B uses TS-118
17F9BC uses TS-118
17F9C uses TS-118
17F12, -A, -B, -BA uses TS-325, TS-326
17F12D TV7-91
17F13 TV7-91
17F13B TV7-91
17F13BC TV7-91
17F18C TV7-91
17K1A TV5-87
17K1BA TV5-87
17K1BE, -B, 17K2BE use TS-172, or -A
17K3 TV5-95
17K3A TV5-87
17K3B TV5-95
17K3BA TV5-87
17K4A TV5-87
17K5 uses TS-118
17K5C uses TS-174

Motorola (Cont.)

17K6 uses TS-118
17K7 uses TS-118
17K7B uses TS-118
17K7BC, 17K7C uses TS-174
17K8, -A TV6-97
17K8B, -BA TV6-97
17K9A, -BA TV6-97
17K10 TV6-97
17K10C similar to Chassis TS-118
17K10D uses TS-118
17K10E TV6-105
17K10M TV5-97
17K11, -A TV6-97
17K11B, -BA TV6-97
17K11C TV6-97
17K11D TV6-97
17K12, -A, -B, -BA, -W, -WA uses TS-825 or TS-826
17K12A uses TS-226A, -B
17K18D TV7-91
17K14 TV7-91
17K14A TV7-91
17K14B TV7-91
17K14BC TV7-91
17K14C TV7-91
17K14W TV7-91
17K14WC TV7-91
17K15 TV7-91
17K15B TV7-91
17K15BC TV7-91
17K15C TV7-91
17K16 TV7-91
17K16C TV7-91
17K17, -B TV8-72
17KK4E uses TS-172
17P1-1, -2 TV14-67
17P2-1 TV14-67
17P3+ TV15-64
17P5-1 through 17P5-5A TV16-51
17P6-1✓ TV17-77
17T1 TV5-95
17T1A TV5-87
17T1B TV5-95
17T1BA TV5-87
17T2 TV5-95
17T2A TV5-87
17T2B TV5-95
17T2BA TV5-87
17T3 TV5-95
17T3A TV5-87
17T4 uses TS-118
17T4C uses TS-174.
17T5A, -C, -D TV6-97
17T5E to-F TV6-105
17T8BD TV6-97
17T6BF TV5-97
17T8C, -D TV6-97
17T6F TV6-97
17T6G TV6-105
17T7, 17T7A uses TS-325, TS-326
17T8, -A, -B, -BA uses TS-325, TS-326
17T9, -A, E, 17T10, -A use TS-325A, -B and TS-326A, -B
17T9BF TV7-91
17T9F TV7-91
17T10D TV7-91
17T11 TV7-91
17T11C TV7-91
17T11E TV7-91
17T11EC TV7-91
17T12 TV7-91
17T12B TV7-91
17T12C TV7-91
17T12W TV7-91
17T12WC TV7-91
17T13 TV7-91
17T13Y uses TS410AY
17T14 see VTS-410A
17T15A, -AE TV8-72
17T16, -B TV8-72
17T18 uses WTS-410
17T20 TV9-85
17T21 uses TS-418
17T24 uses RTS-418
17T25 uses PTS-418
17T26 uses TS-421

Motorola (Cont.)

17T27CN TV18-105
17T28-1, + TV18-105
17T80GH TV14-67
17T81GP TV14-67
17T22BZ TV16-51
17T82WH TV16-51
17T22B, M TV16-51
17T37 uses RTS-422
A17 1962-65
C17 1962-65
R17A6 1954-88
SH17E, GL 1960-99
SH17N, S 1960-99
X17B 1961-91
X17N 1961-91
X17R 1961-91
Y17K17, -B TV8-72
Y17P1-1A TV14-67
Y17P1-2A TV14-67
Y17P2-1A TV14-67
Y17P3+ TV15-84
Y17P5-1 through Y17P5-5F TV16-51
Y17P6-1, ✓ TV17-77
Y17T15A, -AE TV8-72
Y17T16, -B TV8-72
Y17T20 TV9-85
Y17T21 uses TS-418Y
Y17T27CH TV13-105
Y17T28-1, + TV18-105
Y17T80CHA TV14-67
Y17T81GPA TV14-67
Y17T32BZ TV16-51
A18 uses HS-824
C18 1982-65
HS-18 See WR-6
SH18GL, N 1960-99
XT18B 1961-94
XT18S 1961-94
19K2 TV5-89
19K2B TV5-89
19K2BE, 19K2E use TS-199, or -A
19K3 TV5-89
19K4 TV5-89
19K4B TV5-89
19K11W, WA TV19-103
19K12M, + TV19-108
19K13CW, + TV19-103
19K14M, + TV19-103
19K15CW, + TV19-103
19K16W, + TV20-57
19K17+ TV20-57
19K18+ TV20-57
19K19+ TV20-57
19K20++ TV20-57
19P1-1 TV19-89
19P1-2 TV19-89
19P8-1, 2 TV19-103
19P7+ use TS-440
19P10-1, 2 TV19-103
19P15++ TV20-79
19P16++ TV20-79
19P35BRH TV22-77
19P37++ TV22-77
19RT29++ TV21-61
19T1-3 TV19-103
19T1-4 TV19-103
19T1-5 TV19-103
19T5CH, + TV19-79
19T7-1, + TV19-79
19T11CH, + TV19-79
19T12-1, + TV19-79
19T13-1, + TV19-79
19T14CW, + TV19-79
19T20+ TV20-75
19T20++ TV21-61
19T21++ TV21-61
19T21++ TV20-75
19T22++ TV20-75
19T22++ TV21-61
19T38+++ TV22-71
19T39+++ TV22-71
19T40+++ TV22-71
19T50G+ TV22-71
19XP32 like 19P1-1
A19 uses HS-825
A19T2-3 TV19-103
A19T2-4 TV19-103
A19T2-5 TV19-103
A19T8, + TV19-79
A19T24++ TV20-75
A19T24++ TV21-51

Motorola (Cont.)

A19T25++ TV21-61
C19 1962-65
SH19 1961-111
X19A 1961-92
X19E 1961-92
Y19K11W, + TV19-102
Y19K12M, + TV19-102
Y19K18+ TV19-103
Y19K14M, + TV19-108
Y19K15+ TV19-103
Y19K16W, + TV20-57
Y19K17+ TV20-57
Y19K18+ TV20-57
Y19K10+ TV20-57
Y19K20++ TV20-57
Y19P8-1, 2 TV19-108
Y19P19-1 TV19-103
Y19P10-2 TV19-103
Y19P15BE TV20-79
Y19P16++ TV20-79
Y19P35BRH TV22-77
Y19P37++ TV22-77
Y19T1-3 TV19-103
Y19T1-4 TV19-103
Y19T1-5 TV19-103
Y19T5CH, + TV19-79
Y19T7-1, + TV19-79
Y19T11CH, + TV19-79
Y19T12-1, + TV19-79
Y19T13-1, + TV19-79
Y19T14CW, + TV19-79
Y19T20+ TV20-75
Y19T20++ TV21-61
Y19T21++ TV21-51
Y19T21++ TV20-75
Y19T22++ TV20-75
Y19T22++ TV21-61
Y19T28+++ TV22-71
Y19T39+++ TV22-71
Y19T40+++ TV22-71
Y19T50G+ TV22-71
20F1, 20F1B
20F2, 20F2B use TS-119, or -A
20K1, -B, 20K2, use TS-119A, or -B
20K3, -B, 20K4, -B, use TS-119C1, or -D
20K8, -B TV6-97
20T1, 20T1B, use TS-119A, or -B, -C
20T2, 20T2B use TS-119C1, -D
20T2A TV6-97
20T2BA TV6-97
20T3, -8 TV6-97
C20 uses HS-815
L20E 1951-93
SH20 1961-105
21C1 TV7-91
21C1B TV7-91
21C1BD, -BDY TV8-69
21C1BY, -D TV8-69
21C1DY, -Y TV8-69
21C2, -B TV8-72
21C3 TV9-79
21C4, -B TV11-79
21C6BG uses TS-537
21C6MG uses TS-587
21C7BG uses TS-528
21C7MG uses TS-528
21C8B, M use TS-542
21C9✓ TV16-79
21C10CW TV17-67
21C11B uses TS-564
21F1, -B, 21K1, -B, 21K2 all use TS-351
21F2 TV7-91
21F2B TV7-91
21F2F, -FB TV8-69
21F2FBY TV8-69
21F2FY, -Y TV8-69
21F3 TV7-91
21F3B TV7-91
21F3BD, -BDY TV8-69
21F3BY, -D TV8-69
21F3DY, -Y TV8-69
21F5, -B TV8-72
21F8B, + TV15-75
21K3, -B, -W use TS-351B
21K4 TV7-91
21K4A TV7-91

Motorola (Cont.)

21K4AY, -BD TV8-89
21K4B TV7-91
21K4BDY TV8-69
21K4BY, -C TV8-69
21K4CB, -CBY
21K4CW, -CWY TV8-60
21K4CY, -D TV8-69
21K4DY, -WD TV8-69
21K4W TV7-91
21K4WDY TV8-69
21K4WY, -Y TV8-69
21K5 TV7-91
21K5B TV7-91
21K5BD, -BDY TV8-69
21K5BY, -D TV8-69
21K5DY, -Y TV8-69
21K6 TV7-91
21K6D, -DY TV8-69
21K6Y TV8-69
21K7 TV7-91
21K7D, -DY TV8-69
21K7Y TV8-69
21K9, -Y TV8-69
21K10 TV8-69
21K10B, -BY TV8-69
21K10Y TV8-69
21K11, -B TV8-69
21K11BY, -Y TV8-89
21K12A, -AB TV8-72
21K12, 21K12B, -W use TTS-292
21K12WA TV8-72
21K18 TV8-72
21K14, -B TV8-72
21K15 TV8-72
21K16, -W TV8-72
21K17 TV8-72
21K19 TV9-85
21K20 TV9-79
21K21 TV9-79
21K22 TV9-79
21K28 TV9-79
21K24 TV9-79
21K25 uses VTS-518
21K28 Uses WTS-525
21K29, B, W TV10-117
21K30, B, W TV10-117
21K33E TV10-117
21K34 uses QTS-525
21K37B, BA TV11-85
21K37BRA TV11-85
21K38, -B TV11-69
21K39, -B TV11-85
21K40, -B TV11-85
21K41, -B TV11-79
21K42, -B TV11-79
21K43, -B TV11-79
21K44, -B TV11-79
21K45 TV11-79
21K46 uses TS-534
21K47B, -M use WTS-524
21K48B, -M TV11-85
21K50B use VTS-530
21K51B, M → TS-534
21K51BA } Use
21K51MA } TS-538
21K52B, etc. TV12-87
21K54B, -M TV12-95
21K55B, etc. TV12-87
21K56B, -M TV12-95
21K57B, -M TV12-95
21K57MCH TV12-95
21K58B, -M TV12-95
21K59M TV12-95
21K59MCH TV12-95
21K64B } Use
21K64M } QTS-587
21K65B, -M use WTS-537
21K66B, -M use TS-537
21K67B, -M use TS-538
21K68B, -M use WTS-537
21K70B, -M TV14-77
21K73B, M TV15-75
21K75+ TV15-75
21K76+ TV15-75
21K77B, M TV15-75
21K79M uses TS-542
21K80+ TV15-75
21K80B, M TV15-75

Motorola (Cont.)

21K82B, M } use
21K82B, M, W } TS-542
21K90CW TV15-75
21K97B, M TV16-79
21K98+ TV16-82
21K99B, ✓ TV16-79
21K100BA TV15-82
21K100MA TV15-82
21K101+ TV15-83
21K102CWA TV15-83
21K102+ TV15-88
21K104B, M TV16-67
21K104W TV16-67
21K105✓ TV16-67
21K107B, M TV16-67
21K108W TV16-67
21K109M TV16-67
21K110W TV16-67
21K115✓ TV16-79
21K115✓ TV16-79
21K122B } Use
21K122M } TS-556
21K123C } Use
21K123M } TS-556
21K124B, ✓ TV17-63
21K125B, M TV17-67
21K126✓ TV17-67
21K127CW TV17-67
21K129✓ TV17-67
21K130CW TV17-67
21K131CW TV17-59
21K132W TV17-59
21K134W TV17-59
21K185W TV17-59
21K136W TV17-59
21K138M see TS-564
21K139T use TS-564
21K140BM use TS-564
21K141CW use TS-564
21K150B, + TV18-89
21K151B, + TV18-89
21K152CW TV18-89
21K153B, + TV18-89
21K154CW TV18-89
21K168M } see
21K164W } TS-558
21P1B, + TV15-90
21T1, -B, 21T2, -B all use TS-351
21T3 TV7-91
21T8Y uses TS-501B
21T4A TV7-91
21T4AC TV7-91
21T4ACE TV7-91
21T4ACY TV8-69
21T4EA TV7-91
21T5A TV7-91
21T5BA TV7-91
21T7, -B TV8-69
21T7BY, -Y TV8-69
21T8 uses TS-292
21T8A, -AE TV8-72
21T10 uses VTS-505
21T11, -B TV8-72
21T11W TV8-72
21T18 uses TS-524
21T14E uses TS-507
21T15 TV9-85
21T16 TV9-85
21T17 TV0-85
21T18 TV0-79
21T19 TV9-79
21T21, B, E TV10-117
21T22, -B TV10-117
21T25CM TV11-69
21T25PK TV11-69
21T25TN TV11-69
21T26B, BA, BR, BRA, CH, CHA, TV11-85
21T27B, MA TV11-85
21T27PK TV11-85
21T28, -B TV11-85
21T29B, M see TS534
21T30B uses TS-520
21T31B, -M use VTS-534
21T32B, etc. TV12-87
21T33BG, + TV12-95
21T34B, etc. TV12-87
21T35B, -M TV12-95
21T36B, -M TV12-95
21T87B, -M TV14-77
21T39B uses TS-542
21T40+ TV15-75

Motorola (Cont.)

21T42+ TV15-75
21T44B, -M } Use
21T46B, -M } Chassis
21T46B, -M } TS-542
21T47 uses MTS-527
21T57✓✓ TV16-79
21T58+ TV15-82
21T64B, M TV16-88
21T64W As above
21T66BZ, CH TV17-63
21T67BG, MG TV17-67
21T68B, ✓ TV17-67
21T71BR → VTS-556
21T71W like 21T64✓ less tone cont.
21T78B, M, W TV18-89
21VTW, -A TV15-75
A21 1963-87
A21C5B, M TV13-115
A21C11B, M TV17-67
A21F6W TV18-115
A21K54B, M TV13-115
A21K56B, M TV18-115
A21K57B, M TV13-115
A21K57MCH TV13-115
A21K56B, M TV13-115
A21K59M, + TV13-115
A21K60B, M TV13-115
A21K61+ TV13-115
A21K62M TV13-115
A21K68CW TV13-115
A21K67 TV13-115
A21K106B, M TV16-67
A21K131CW TV17-59
A21K122W TV17-59
A21K134W TV17-59
A21K135W TV17-59
A21K136W TV17-59
A21K137B, M TV17-63
A21K138M TV17-67
A21K139✓ TV17-67
A21K140B, M TV17-67
A21K141CW TV17-67
A21K168M } use
A21K164W } TS-558
A21T83+ TV12-115
A21T85B, M TV13-115
A21T36B, M TV13-115
A21T60✓✓ TV15-67
A21T69✓✓ TV17-63
C21 1963-87
S21B, + 1959-97
SH21 1961-106
SK21B, + 1959-97
SK23B, + 1959-97
X21W 1951-112
Y21C2, -B TV8-72
Y21C2 TV9-79
Y21C4, -B TV11-79
Y21C6BG } Use
Y21C6MG } TS-537Y
Y21C7BG } Use
Y21C7MG } TS-588Y
Y21C8+ use TS-542Y
Y21C9✓ TV16-79
Y21C10CW TV17-67
Y21F5, -B TV6-72
Y21F8B, + TV15-75
Y21K12A TV8-72
Y21K12AB TV8-72
Y21K12WA TV8-72
Y21K13, -B TV8-72
Y21K14, -B TV8-72
Y21K15 TV8-72
Y21K16, -W TV8-72
Y21K17 TV8-72
Y21K19 TV0-85
Y21K20 TV9-79
Y21K21 TV9-79
Y21K22 TV9-79
Y21K23 TV9-79
Y21K24 TV9-79
Y21K26 as above
Y21K29, B, W TV10-117
Y21K30, B, W TV10-117
Y21K33E TV10-117
Y21K34 → QTS-525Y
Y21K37B, BA TV11-85
Y21K37BRA TV11-85
Y21K38, B TV11-69
Y21K39, B TV11-85

Motorola (Cont.)

Y21K40, B TV11-85
Y21K41, B TV11-79
Y21K42, B TV11-79
Y21K43, B TV11-79
Y21K44, B TV11-79
Y21K45 TV11-79
Y21K46 use TS-534Y
Y21K47B, M, use WTS-534 +UHF
Y21K48B, M TV11-85
Y21K50B, -M use VTS-530 +UHF
Y21K51B } Use
Y21K51M } TS-534Y
Y21K51BA } Use
Y21K51MA } TS-533Y
Y21K53B, + TV12-87
Y21K54B, -M TV12-95
Y21K65B, + TV12-87
Y21K56B, -M TV12-95
Y21K57B, -M TV12-95
Y21K57MCH TV12-95
Y21K58B, -M TV12-95
Y21K59M TV12-95
Y21K59MCH TV12-95
Y21K64B } Use
Y21K64M } QTS-537Y
Y21K55, -M use WTS-537Y
Y21K66B, -M use TS-537Y
Y21K67B, -M use TS-538Y
Y21K68B, -M use WTS-537Y
Y21K70B, M TV14-77
Y21K73+ TV15-75
Y21K75+ TV15-75
Y21K76+ TV15-75
Y21K77+ TV15-75
Y21K79 see TS-542Y
Y21K80+ TV15-75
Y21K81+ TV15-75
Y21K82B, M } Use
Y21K83+ } TS-542Y
Y21K90CW TV15-75
Y21K97+ TV16-79
Y21K98+ TV15-83
Y21K99+ TV16-79
Y21K100BA, MA use RTS-544Y
Y21K101+ TV15-83
Y21K102CWA uses RTS-544Y
Y21K103+ TV15-83
Y21K104+ TV16-67
Y21K107B, M TV16-67
Y21K115++ TV16-79
Y21K116++ TV16-79
Y21K122B } Use
Y21K122M } TS-556
Y21K123B } Use
Y21K123M } TS-556
Y21K124+ TV17-63
Y21K125B, M TV17-67
Y21K126+ TV17-67
Y21K127CW TV17-67
Y21K129+ TV17-67
Y21K130CW TV17-67
Y21K131CW TV17-59
Y21K132W TV17-59
Y21K134W TV17-59
Y21K135W TV17-59
Y21K136W TV17-59
Y21K142M TV17-63
Y21K150B, + TV18-89
Y21K151B, + TV18-89
Y21K152CW TV18-89
Y21K153B, + TV18-89
Y21K154CW TV18-89
Y21K163M → TS-558
Y21P1+ TV15-90
Y21T8 see RTS-292Y
Y21T8A, -AB TV8-72
Y21T10 use VTS-505Y
Y21T11, -B TV8-72
Y21T11W TV8-72
Y21T15 TV9-85
Y21T16 TV9-85
Y21T17 TV9-85
Y21T18 TV9-79
Y21T19 TV9-79
Y21T21, B, E TV10-117

Motorola (Cont.)

Y21T22, -B TV10-117
Y21T25CH TV11-69
Y21T25PK TV11-69
Y21T25TN TV11-69
Y21T26B, BA, BR, BRA, -CH, -CHA TV11-85
Y21T27B, MA TV11-85
Y21T27PK TV11-85
Y21T28, B TV11-85
Y21T29M diff. UHF Like above
Y21T30B, -M use TS-530, diff. tuner
Y21T31B, -M use VTS-534 + UHF
Y21T32B, + TV12-87
Y21T33BG, + TV12-95
Y21T34B, + TV12-87
Y21T35B, -M TV12-95
Y21T36B, -M TV12-95
Y21T37B, M TV14-77
Y21T39+ uses TS-542Y
Y21T40+ TV15-75
Y21T42+ TV15-75
Y21T44B, M } Use
Y21T45B, M } chassis
Y21T46B, M } TS-542Y
Y21T47 see MTS-537
Y21T57++ TV16-79
Y21T58+ TV15-83
Y21T61+ TV15-83
Y21T62+ TV16-79
Y21T63+ TV16-79
Y21T64B, M TV16-83
Y21T54W As above
Y21T66++ TV17-63
Y21T67BG TV17-67
Y21T67MG TV17-67
Y21T68B, + TV17-67
Y21T71BR VTS-556Y
Y21T73B, + TV18-89
Y21V1W, -A TV15-75
YA21C5B TV18-115
YA21C5M TV13-115
YA21F6W TV13-115
YA21K54+ TV13-115
YA21K56+ TV13-115
YA21K57+ TV13-115
YA21K58+ TV13-115
YA21K59+ TV13-115
YA21K60+ TV13-115
YA21K61+ TV13-115
YA21K62M TV13-115
YA21K63CW TV13-115
YA21T33+ TV13-115
YA21T35+ TV13-115
YA21T36+ TV13-115
A22 1963-87
C22 1963-87
HS-22 Eight-111
SH22 1961-107
SK22B, M 1960-99
23C4B, + TV18-75
23C5CW TV18-75
23C6B, M TV18-75
23C7CW TV18-75
23C8++ TV20-57
23C10++ TV20-57
23F20M, W TV22-83
23F21MP TV22-83
23FR20M, W TV22-83
23FR21MP TV22-83
23FR25M, W TV22-71
23FR26MP TV22-71
23FR27CW TV22-71
23FR30W TV22-71
23FR31MB TV22-71
23K1MA, WA TV17-67
23K2B, M TV17-67
23K3CW TV17-67
23K4W TV17-59
23K28B, M, W TV18-75
23K29B, M, W TV18-75
23K30B, M TV18-75
23K31CW TV18-75
23K32M, W TV18-75
23K33B, M, W TV18-75
23K34CW TV18-75
23K39CW → VTS-569
23K40CW TV18-85
23K41W TV18-85
23K42W TV18-85

Motorola (Cont.)

23K43W TV18-85
23K44W TV18-85
23K45W TV18-85
23K46MB TV18-85
23K47+ uses TS-568
23K50++ TV20-57
23K51CWA TV20-57
23K52++ TV20-57
23K53MA TV20-57
23K54CWA TV20-57
23K55++ TV20-57
23K56++ TV20-57
23K57B, + TV20-57
23K60++ TV20-58
23K61++ TV20-58
23K62++ TV20-58
23K63++ TV20-58
23K64++ TV20-58
23K65++ TV20-58
23K70W TV20-58
23K71++ TV20-58
23K72W TV20-58
23K73MB TV20-58
23K74W TV20-58
23K76++ TV21-61
23K82+ TV21-61
23K83MP TV21-61
23K84+ TV21-61
23K87M, W TV21-61
23K88W TV21-61
23K90+ TV21-61
23K91CW TV21-61
23K95M TV21-61
23K96CW TV21-61
23K97MN, WN Use TS-578
23K105W TV21-61
23K106MB TV21-61
23K107W, + TV21-61
23K109+ TV22-71
23K120M, W TV22-71
23K122M, W TV22-71
23K123MP TV22-71
23K124++ TV22-71
23K127M, W TV22-71
23K128++ TV22-71
23K129M, W TV22-71
23K132M TV22-71
23K133++ TV22-71
23K134W TV22-71
23SF3W, + } use
23SF4CW } TS-574
23SF5++ TV20-58
23SF6++ TV20-58
23SF7++ TV20-58
23SF8++ TV20-58
23SF10+ } See
23SF11+ } ++TS-582
23SF15M, + TV21-61
23SF16CW+ TV21-61
23SF17W-FM TV21-61
23SF18W-FM TV21-61
23T2B, + TV18-75
23T4BR, + TV19-75
23T5B, + TV19-75
23T5M, + TV19-75
23T5W, + TV19-75
23T12BRF TV20-58
23T13++ TV20-58
23T15BRA TV21-62
23T15BRLA TV21-62
23T15++ TV20-75
23T16+ TV20-75
23T17++ TV20-79
23T27++ TV21-73
23T28++ TV21-73
A23C7CW uses WTS-568
A23C10++ TV20-57
A23C11++ TV20-57
A23K35+ } Use
A23K36+ } Chasses
A23K40CW } WT5-569
A23K41W } and
A23K42W } STS-569
A23K43W } similar
A23K44W } to
A23K45W } VTS-569
A23K46MB } TV18-85
A23K67+ TV20-58
A23K68+ TV20-58
A23K72W TV20-58
A23K73MB TV20-58
A23K74W TV20-58

Motorola (Cont.)

A23K100++ TV21-61
A23K101++ TV21-61
A23K102++ TV21-61
A23K103W, + TV21-61
A23T8++ TV20-58
A23T18CH Uses ATS-578
C23 1963-87
TS-23 TV5-83
TS-23A TV5-83
TS-23B TV5-83
X23 1962-58
Y23C4B, + TV18-75
Y23C5CW TV18-75
Y23C6B, M TV18-75
Y23C7CW TV18-75
Y23C8++ TV20-57
Y23C10++ TV20-57
Y23F20M, W TV22-83
Y23F21MP TV22-83
Y23FR20+ TV22-83
Y23FR21MP TV22-83
Y23FR25M, W TV22-71
Y23FR26MP TV22-71
Y23FR27CW TV22-71
Y23FR30W TV22-71
Y23FR31MB TV22-71
Y23K1MA, WA TV17-67
Y23K2B, M TV17-67
Y23K3CW TV17-67
Y23K4W TV17-59
Y23K28B, + TV18-75
Y23K29B, + TV18-75
Y23K30B, M TV18-75
Y23K31CW TV18-75
Y23K32M, W TV18-75
Y23K33B, + TV18-75
Y23K34CW TV18-75
Y23K39CW uses VTS-569Y
Y23K40CW TV18-85
Y23K41W TV18-85
Y23K42W TV18-85
Y23K43W TV18-85
Y23K44W TV18-85
Y23K45W TV18-85
Y23K46MB TV18-85
Y23K47+ → TS-568Y
Y23K50++ TV20-57
Y23K51++ TV20-57
Y23K52++ TV20-57
Y23K53MA TV20-57
Y23K54++ TV20-57
Y23K55++ TV20-57
Y23K56++ TV20-57
Y23K57++ TV20-57
Y23K60++ TV20-58
Y23K61++ TV20-58
Y23K62++ TV20-58
Y23K63++ TV20-58
Y23K64++ TV20-58
Y23K65++ TV20-58
Y23K70W TV20-58
Y23K71++ TV20-58
Y23K72W TV20-58
Y23K73MB TV20-58
Y23K74W TV20-58
Y23K76++ TV21-61
Y23K82+ TV21-61
Y23K83MP TV21-61
Y23K84+ TV21-61
Y23K87M, W TV21-61
Y23K88W TV21-61
Y23K90+ TV21-61
Y23K91CW TV21-61
Y23K95M TV21-61
Y23K96CW TV21-61
Y23K97MN, WN Use TS-578Y
Y23K105W TV21-61
Y23K106MD TV21-61
Y23K107+ TV21-61
Y23K109+ TV22-71
Y23K120M, W TV22-71
Y23K122M, W TV22-71
Y23K123MP TV22-71
Y23K124++ TV22-71
Y23K127M, W TV22-71
Y23K128++ TV22-71
Y23K129M, W TV22-71
Y23K132M TV22-71
Y23K133++ TV22-71
Y23K134W TV22-71

Motorola (Cont.)

Y23SF3W, + } Use
Y23SF4CW } TS-574Y
Y23SF5++ TV20-58
Y23SF6++ TV20-58
Y23SF7++ TV20-58
Y23SF8++ TV20-58
Y23SF10+ } Use
Y23SF11+ } +TS-582Y
Y23SF15M+ TV21-61
Y23SF16++ TV21-61
Y23SF17W+ TV21-61
Y23SF18W+ TV21-61
Y23T2B, + TV18-75
Y23T4BR, + TV19-75
Y23T5B, ++ TV19-75
Y23T12+ TV20-58
Y23T13++ TV20-58
Y23T15BR TV20-75
Y23T15++ TV21-62
Y23T16++ TV21-62
Y23T18+ TV20-75
Y23T17++ TV20-79
Y23T27++ TV21-73
Y23T28++ TV21-73
24C1 uses PTS-537
24K1, -B TV8-83
24K2, -B TV8-63
24K2, -W TV8-63
24K4 TV9-79
24K5 TV9-79
24K9, -B TV11-85
24K10, -B TV11-79
24K11, -B TV11-79
24K13B TV12-87
24K13M TV12-87
24K14B, -M TV12-95
24K18 uses PTS-537
24ME 1962-51
24MF 1962-51
24MY 1962-51
24T2, -B TV10-117
24T3BR TV11-85
24T4, -B TV11-79
24T5BG TV12-87
24T5MG TV12-87
24T6B, -M TV12-95
A24 1964-84
A24K14B, M TV13-115
A24K15M, + TV13-115
A24T6B, M TV12-115
SK24B, M 1960-99
SK24W 1960-99
X24 1962-58
Y24C1 uses PTS-537
Y24K1, -B TV8-63
Y24K2, -B TV8-63
Y24K3, -W TV8-63
Y24K4 TV9-79
Y24K5 TV9-79
Y24K9, -B TV11-85
Y24K10, B TV11-79
Y24K11, B TV11-79
Y24K13B TV12-87
Y24K13M TV12-87
Y24K14B, -M TV12-95
Y24K18 see PTS-537
Y24T2, -B TV10-117
Y24T3BR TV11-85
Y24T3M like above
Y24T4, B TV11-79
Y24T5BG TV12-87
Y24T5MG TV12-87
Y24T6B-M TV12-95
YA24K14+ TV13-115
YA24K15+ TV13-115
YA24T6B, M TV13-115
25-P Three-61
SP25 1962-67
X25 1962-59
HS-26 Eight-111
SP26 1962-67
X26 1962-60
27-D-6 Three-60
27F1 1957-59
27F2 1957-59
27J2, -B TV8-63
27K3 TV8-63
27K10+ TV20-75
27K10MA, + TV21-62
27K11MA, + TV21-62
27K11+ TV20-75
27K13+ TV21-62
27K14M, W TV21-62

Motorola (Cont.)

A27K13++ TV21-62
A27K14M, W TV21-62
SP27 1962-68
X27 1962-61
Y27K2, -B TV8-63
Y27K3 TV8-63
Y27K10+ TV20-75
Y27K10++ TV21-62
Y27K11++ TV21-62
Y27K11+ TV20-75
Y27K13++ TV21-62
Y27K14M, W TV21-62
28-O Three-62
SK28B, M, W 1960-101
SK29B, M, W 1960-101
SP28 1962-69
X28 1962-62
SP29 1962-70
X29 1962-63
30-P Three-62
HS-30 Seven-101
SK30B, M 1960-101
SK30MC, W 1960-101
SP30 1962-70
XT30 like XT18
C31 } Uses
C32 } Chassis
C33 } HS-939
HS-31 Seven-104
SK31B 1960-101
SK31CW, M 1960-101
X31 1962-64
HS-32 Seven-106
SK32W 1961-86
SK33W 1961-86
34F1 1955-48
34F1C 1955-48
C34 1964-85
X34 1963-88
C35 1964-85
SK35W 1961-86
X35 1963-89
36F1, -C 1956-68
36F1G 1956-68
C36 1964-85
RC-36 Ten-81
SK36M 1960-100
X36 1963-90
37F1 1957-59
37F2 1957-59
X37 1963-91
SK37CW 1960-100
SK38B 1960-100
X38 1963-92
SK39MB 1961-86
X39 1963-93
40 Four-81
SK40-1 1961-108
SK41 1961-108
X40 1963-94
SP41 1964-100
X41, -1 1963-95
42B1 Twelve-81
SP42 1964-100
X42 1964-86
X42-1 1964-86
SK43-1 1961-109
SP43 1964-100
SP44 1964-102
SP44-1 1964-102
45B12 Six-78
HK45 1962-66
HK45-3 1963-97
SP45 Uses HS-944
46HF1, -B 1956-67
46HF1BD 1956-67
46HF1D, 1956-67
47B11 Eight-106
HK47 1963-96
X47 1964-87
X48 1964-88
49L11Q Ten-76
49L13Q Ten-76
X49 1964-89
50 One-61
50W Four-81
HS-50 Seven-103
X50 1964-89
51L1U Eleven-91
51L2U Eleven-91
51M1U Eleven-93
51M2U Eleven-93

Motorola (Cont.)

51M3U Eleven-93
51X11 Five-76
51X12 Five-76
51X15 Five-76
51X16 Five-76
HS-51 like HS-2
SP51 1964-93
X51 1964-90
52B1U Twelve-82
52B2U, 52B3U, and 52B4U use HS-305
52C1 1953-55
52C1A 1953-55
52C6 Twelve-84
52C7 Twelve-84
52C8 Twelve-84
52CW1 1953-57
52CW2 1953-57
52CW3 1953-57
52CW4 1952-57
52H11U Twelve-85
52H12U Twelve-85
52H13U Twelve-85
52H14U Twelve-85
52L1, 52L2, 52L3 similar to 52B1U
52L1A 1953-59
52L2A 1953-59
52L3A 1953-59
52R11 1953-61
52R11A Twelve-87
52R11U Twelve-87
52R12 1952-61
52R12A Twelve-87
52R12U Twelve-87
52R13 1952-61
52R13A Twelve-87
52R13U Twelve-87
52R14 1953-61
52R14A Twelve-87
52R14U Twelve-87
52R15 1952-61
52R15A Twelve-87
52R15U Twelve-87
52R16 1952-61
52R16A Twelve-87
52R16U Twelve-87
52X11U Twelve-85
52X12U Twelve-85
52X13U Twelve-85
CT52M6 uses R16M6
HS-52 Eight-111
SP52 1964-94
SR52A6 uses R17A6
SR52M6 uses R16M6
TS-52 TV5-83
53C1 1954-67
53C2 1954-67
53C3 1954-67
53C4 1954-67
53C6 1954-70
53C7 1954-70
53C8 1954-70
53C9 1954-70
53D1 1954-69
53LC1 1952-64
53LC2 1952-64
53LC3 1958-64
53R1, -U 1954-71
53R2, -U 1954-71
53R3, -U 1954-71
53R4, -U 1954-71
53R5, -U 1954-71
53R6, -U 1954-71
53X1 1954-72
53X2 1954-72
53X3 1954-72
53X4 1954-72
BK53A6 uses R17A6
GMT53A6 uses R17A6
HK53-1 1964-95
HK53-2 1964-95
HN53M6 uses R16M6
TS-53 See 12K2
X53 Uses HS-1006
54HF1 1955-47
54HF1B 1955-47
54L1 1954-66
54L2 1954-66
54L3 1954-66
54L4 1954-66
54L5 1954-66
54L6 1954-66
54X1 1955-45

Motorola (Cont.)

54X2 1955-45
54X3 1955-45
HK54-2 1964-96
ST-54
similar to ST-60
X54 1964-91
55A1 1955-49
55A2 1955-49
55A3 1955-49
55B1, -U 1956-66
55C1 1955-59
55C2 1955-59
55C2 1955-59
55C4 1955-50
55F11 Seven-101
55X11, -A Seven-102
55J1 1956-59
55J2 1956-59
55L1, -U 1956-66
55L2, -U 1956-66
55L3, -U 1956-66
55L4, -U 1956-66
55L5U 1956-66
55M1, -U 1956-66
55M2, -U 1956-66
55M2, -U 1956-66
55M4U 1956-66
55X12, -A Seven-103
55X13, -A Seven-193
56B1A, AU 1956-70
56CC1 1956-69
56A1 } All use
56A2 } HS-422
56A3 } see
56A4 } 1955-49
56CC2 1956-60
56CD1 1956-60
56CD2 1956-60
56CD3 1956-60
56CD4 1956-60
56CE1 1956-60
56CJ1 1956-60
56CJ2 1956-60
56CS1 1956-60
56CS2 1956-60
56CS3 1956-60
56CS4 1956-60
56H1 1956-58
56H2 1956-58
56H3 1956-58
56H4 1956-58
56L1A, AU 1956-70
56L2A, AU 1956-70
56L3A, AU 1956-70
56L4A, AU 1956-70
56M1A, AU 1956-70
56M2A, AU 1956-70
56M3A, AU 1956-70
56R1 1956-58
56R2 1956-58
56R3 1956-58
56R4 1956-58
56RF1 1956-69
56RF2 1956-69
56T1 1956-65
56T1A 1957-77
56T1B 1957-77
56W1, -B 1956-63
56X1 1956-63
56X1 Four-81
56X2 1956-63
56X3 1956-63
SK56-1 1952-71
ST-56 Eight-116
X56 1964-92
57A1 1957-50
57A2 1957-50
57A3 1957-50
57CC1 1957-57
57CC2 1957-57
57CD1, -A 1957-54
57CD2, -A 1957-54
57CD3, -A 1957-54
57CD4, -A 1957-54
57CE 1957-56
57CE1 1957-56
57CE2 1957-56
57CF1 1957-56
57CF2 1957-56
57CS1, -A 1957-50
57CS2, -A 1957-50
57CS3, -A 1957-50
57CS4, -A 1957-50
57H1, -A 1957-51
57H2, -A 1957-51
57H3, -A 1957-51

Motorola (Cont.)

57H4, -A 1957-51
57HFP1 1957-61
57HFP2 1957-61
57R1 1957-50
57R2 1957-50
57R3 1957-50
57R4 1957-50
57RF1 1957-60
57RF2 1957-60
57W1, -B 1957-52
57W1MC 1957-52
57X1 1957-52
57X2 1957-52
57X11 Eight-107
57X12 Eight-107
CTM57X 1958-88
SK57-1 1962-71
53A11 Nine-65
58A12 Nine-65
58-F1 Four-82
58-FRC Four-82
58L11 Nine-67
58R11 Nine-68
58R11A Ten-77
53R12 Nine-68
58R12A Ten-77
58R13 Nine-68
58R13A Ten-77
58R14 Nine-68
58R14A Ten-77
58R15 Nine-68
58R15A Ten-77
58R16 Nine-68
53R16A Ten-77
AT-58 Eleven-69
HS-58 Nine-69
59H11 Ten-78
59H12I Ten-78
HS-59 Eight-109
59L11Q Ten-79
59L12Q Ten-79
59L14Q Ten-79
59R11 Ten-72
59R12I Ten-72
59R13M Ten-72
59R14E Ten-72
59R15G Ten-72
59R16Y Ten-72
60 One-51
BKA60X 1961-72
CRA60X 1961-73
CRM60X 1961-75
CTA60X 1960-79
CTM60X 1960-80
HS-60 Eight-107
OEA60X 1961-76
PCA60X 1961-72
ST-60 Eleven-81
VWA60 1961-74
61L1 Eleven-92
61L2 Eleven-92
BKA61 1961-77
CA61X 1962-52
CRA61X like CRA60X
CRM61X see CRM60X
CTA61 1961-77
CTM61X 1961-78
CTM61XA 1961-78
OEA61X 1962-53
PCA61X 1962-54
62C1 1953-66
62C1A 1953-66
62C2 1953-66
62C2A 1953-66
62C3 1953-66
62C3A 1953-66
62CW1 1953-68
62L1U Twelve-83
62L2U Twelve-83
62L3U Twelve-83
62X11U Twelve-86
62X12U Twelve-86
62X13U Twelve-86
62X21 1953-70
BKA62 1963-79
CA62 1963-79
CRA62 1963-79
CRM62 1963-80
CTA62 1963-79
CTA62 1962-55
CTM62 1962-55
CTM62 1963-80
CYA62 1963-79
CYM62 1963-80

Motorola (Cont.)

FMC62 1963-82
HS-62 Nine-63
HS-62A Ten-71
PCA62 1963-79
63C1 1954-73
63C2 1954-73
63C2 1954-73
62LSS 1954-74
63X1, -A 1954-75
63X2 1954-75
63X3 1954-75
BKA63 1964-62
CA63 1964-68
CRA62 1964-68
CRM63 1964-69
CTA62 1964-62
CTM63 1964-62
CYA63 1964-68
CYM63 1964-69
OEA63 1964-68
PCA63 1964-62
VWA63 1964-71
VWM63 1964-70
64X1 1955-46
64X2 1955-46
65-BP1-4 Four-82
65F11,-12 Seven-104
65F21 Eight-111
65L11 Seven-102
65L12 Seven-102
65T21, -B Seven-106
65X11 Six-81
65X12 Six-81
65X13 Six-81
65X14A, -B, 65X15A
similar to HS-2
SK65 1962-67
66C1 1956-61
66C2 1956-61
66HF1, -B 1956-62
66HF1GM 1956-62
69L1 1956-71
66L2 1956-71
66MF 1956-94
66T1 1957-58
66X1 1956-64
66X2 1956-64
SK66 1962-73
67C1 1957-55
67C2 1957-55
67F61BN Eight-104
67HFK1 1957-62
67HFK2 1957-62
67HFK3 1957-62
67HFK4 1957-62
67HFP1 1957-62
67HFT1 1957-62
67L11 Eight-109
67X1 1957-53
67X2 1957-53
67X11 Nine-69
67X12 Nine-69
67X13 Nine-69
HS-67 Seven-106
SK67 1962-73
68L11 Nine-70
69L11 Ten-74
69MF 1956-96
69MS 1956-95
69X11 Ten-75
69X12I Ten-75
HS-69 Eight-104
X70 1964-86
72XM21 Twelve-79
72XM22 uses HS-303
SK73 1962-72
74MF 1958-90
SK74 1962-72
75MF 1957-68
SK75 1962-72
76MA Same as 6MA
76MF(SR) 1958-91
76T1 1957-49
76T2 1957-49
SK76 1962-72
SK77 1962-71
SK-77-2 1964-97
78MF 1957-70
SK78 1962-71
SK-78-1 1964-97
ST-78 Eleven-81
79FM21 Ten-73
79XM21 Ten-73
79XM22 Ten-73

Motorola (Cont.)

SK79 1962-71
SK-79-1 1964-97
SK80 1962-71
81F21 Five-78
83MR 1958-92
84MA 1953-94
84MF 1958-90
84MFM similar to
84 MF
84MS 1958-96
85F21 Eight-111
85K21 Eight-111
86MF 1958-91
69R1 see 89K1
TS-89 TV5-87
93MR 1959-68
94M1 1959-81
94MA 1959-69
94MF 1959-70
94MFM 1959-70
TS-94 TV5-87
95MF 1959-71
TS-95 TV5-87
SK109-4 1964-99
SK100 } Use
SK101 } HS-952
SK102 } 1962-67
101 1960-86
TS-101 TV5-89
102 1960-82
SK103 1964-100
104 1960-87
SK104 1964-100
SK105 1954-100
SK106 1964-98
SK107 1964-98
SK108 1964-100
109 1961-80
SK109 1964-98
110 1960-86
SK110 1964-98
111 1961-80
SK-111 1964-97
SK-112 1964-97
113 1961-80
114 1961-80
HS-114 Nine-67
TS-114 TV5-95
SK-115 1964-97
TS-115 TV5-95
HS-116 Nine-68
SK-116 1964-97
117 1962-56
TS-118 TV5-95
119 1962-56
HS-119 Nine-70
SK119 1964-101
TS-119, 20'' rect.
same as TS-101
TS-119A, -B, -C, -C1,
-D, like TS-119
120 1962-56
SK124 1964-99
SK125 1964-99
AC-152 Twelve-89
HS-158 Nine-65
ST-162 1956-98
HS-165 Ten-71
HS-167 Ten-72
HS-168 Ten-73
TS-172 rect. tube
similar to TS-95
TS-174 like TS-118
HS-175 Ten-74
HS-178 Ten-73
HS-181 Ten-75
HS-183 Ten-75
HS-184 Ten-77
HS-187 Ten-79
TS-196 TV6-97
202 1962-57
203 1962-57
204 1962-57
HS-206 Ten-78
TS-214 TV6-97
TS-216 TV6-105
216 1964-72
217 1964-72
HS-218 Twelve-79
TS-221 like TS-118
HS-223 Ten-80
HS-224 Ten-80

Motorola (Cont.)

HS-226 Eleven-92
HS-228 Eleven-87
TS-228 TV6-97
TS-236 TV6-97
HS-242 Eleven-88
HS-242 Eleven-89
HS-244 Eleven-89
HS-245 Eleven-90
HS-247 Eleven-94
HS-249 Ten-80
250X 1963-76
HS-250 Eleven-91
251 Four-85
HS-254 Eleven-88
HS-256 Eleven-89
HS-258 Eleven-87
HS-262 Eleven-87
HS-270 Eleven-87
HS-271 Eleven-87
HS-272 Eleven-87
TS-275 + Tone Cont.
same as TS-216
HS-280 Eleven-83
HS-281 Eleven-88
HS-288 Eleven-93
HS-288 Eleven-87
HS-289 1953-61
HS-289A 1953-61
290T 1964-76
TS-292A TV7-91
TS-292AY TV8-69
TS-282B TV7-91
TS-292B-04 TV8-69
TS-292C TV8-69
TS-292CY TV8-69
TS-292Y TV6-69
TTS-292 Like TS-
TTS-292Y + UHF
VTS-292B TV8-69
VTS-292BY TV8-69
VTS-292C TV8-69
VTS-292CY TV8-69
VTS-292Y TV8-69
WTS-292 TV8-69
WTS-292B TV8-69
WTS-292BY TV8-69
WTS-292C TV8-69
WTS-292CY TV8-69
WTS-292Y TV8-69
HS-299 1953-66
300X 1959-72
HS-300 like HS-283
301 Four-80
301 1960-85
301X 1959-78
302 1960-84
HS-303 Twelve-79
HS-305 Twelve-82
HS-306 Twelve-81
307 like 802
TS-307 TV6-97
HS-308 Twelve-83
309 Ten-91
309 1961-80
HS-309 1953-55
310 1960-85
310X 1961-82
HS-310 Twelve-84
311 1961-80
211X 1961-82
HS-312 Twelve-85
HS-313 Twelve-85
314L, V 1961-80
HS-314 Twelve-86
TS-314, -A TV6-105
TS-314B + Area Sel.
same as T-314A
HS-315 Twelve-87
TS-315 TV6-105
TS-315B
similar to TS-314B
HS-317 Twelve-87
320X 1963-77
323T 1964-78
HS-324 1953-68
TS-324A TV7-91
TS-224B TV7-91
TS-325 +tone cont.
same as TS-314B
TS-325A, -B minor
diff. from TS-325
HS-326 1953-70

Motorola (Cont.)

TS-326 Metal tube
as TS-325
H-327 like H-305
HS-329 1953-57
HS-335 1954-75
HS-336 1954-72
337 1964-72
HS-338 1954-70
339 1964-72
344 1964-72
345 1964-72
HS-347 1953-64
359 Three-64
TS-351 fil. circ.
29HP4B diff.
otherwise TS-325
HS-357 1953-59
HS-359 1954-69
HS-366 1954-67
HS-375 like HS-310
HS-383 like HS-329
HS-384 1954-71
395 1955-54
395-12 1955-54
TS-395A TV7-91
396 1956-82
396-12 1956-92
397 1958-97
397X 1959-190
HS-397 1954-73
398X 1958-98
490(early) Three-63
490(late) Ten-91
TS-400A TV7-91
401(early) Four-83
401(late) Eleven-78
TS-401 TV7-91
TS-402 TV8-72
TS-402Y TV6-72
VTS-402 TV8-72
VTS-402Y TV8-72
408 1953-73
404 1954-76
405 Six-80
406 1959-74
408 Nine-71
TS-408A TV7-91
409 Ten-93
TS-410A TV7-91
TS-410AY-03 to-08
TS-410A with UHF
VTS-410A-06 to-08
Like late TS-410A
VTS-410AY-08, -08
as above with UHF
WTS-410 like
TS-410A
412 1953-73
413T 1964-80
HS-414 1954-66
HS-415 1954-74
PTS-418 } Like
RTS-418 } TS-418
TS-418 TV9-85
TS-418Y like above
VTS-418 TV9-35
TS-421 like
TS-418 + clock
HS-422 1955-49
TS-422 TV13-105
TS-422Y TV13-105
TS-423, -Y TV14-58
TTS-422, Y TV14-58
VTS-423 similar to
TTS-423
WTS-423, Y TV14-53
TS-425 TV14-50
TS-425Y TV14-60
WTS-425 TV14-60
WTS-425Y TV14-50
HS-426 1954-71
TS-426, -Y TV14-67
TS-427 TV15-84
TS-427Y TV15-84
TS-428, -Y TV14-67
LTS-430 TV16-51
QTS-430 TV16-51
TS-430 TV16-51
HS-431 1956-58
HS-432 1955-45
TS-432 TV19-89
RTS-433 similar to
TS-433

Motorola (Cont.)

TS-423, -Y TV17-77
TS-424 TV16-59
STS-435 TV19-193
TS-435 TV19-193
WTS-435 TV19-103
QTS-436, Y TV19-79
RTS-436 TV19-79
STS-436, Y TV19-79
TS-436, Y TV19-79
WTS-436 TV19-79
HS- 440 1955-46
TS-440, -Y similar
to TS-433
TS-441, A TV20-57
TS-441Y TV29-57
HS-443 1955-47
HS-444 — 1955-48
ATS-448 TV20-57
QTS-448, Y TV20-57
RTS-448 TV20-57
STS-448, Y TV20-57
TS-448, Y TV20-57
VTS-448 TV20-57
WTS-448, Y TV20-57
TS-449, Y TV20-79
VTS-449 TV20-79
459 Three-54
451 Eleven-78
TS-453 like TS-432
HS-454 1955-59
HS-456 1955-59
HS-457 1956-60
HS-458 1956-61
HS-464 like HS-426
HS-468 like HS-414
HS-467 1955-48
HS-470 1956-66
HS-472 1956-66
HS-475 1956-62
HS-476 1956-53
HS-477 1956-63
HS-478 1956-64
HS-483 1956-65
HS-486 1956-56
HS-487 1955-58
HS-490 1956-60
HS-495 1956-67
HS-496 1956-68
HS-497 1956-69
HS-499 1956-60
500(early) Three-63
500(late) Ten-94
500X 1961-79
501(late) Eleven-79
TS-501A TV7-91
TS-501B, -C similar
to the above
PTS-592, QTS-502,
RTS-502 like TS-502
TS-502 TV8-72
TS-502Y TV8-72
TTS-502 TV8-72
TTS-502Y TV8-72
WTS-592 TV8-72
WTS-592Y TV8-72
503 1953-75
504 1954-77
505 Six-82
VTS-505 like TS-502
HS-507 1957-49
TS-507 like TS-502
HS-508 1956-66
HS-509 1956-66
HS-510 1956-66
SP511 1964-94
HS-512, -A 1956-70
HS-513, -A 1956-70
HS-514, -A 1956-70
HS-515 1956-71
TS-518 TV9-85
VTS-518 TV9-85
WTS-518 TV9-85
520T 1963-78
HS-521 1957-50
HS-522 1957-50
HS-528 1957-51
HS-524 1957-52
TS-524 like TS-502
HS-525 1957-52
QTS-525 see TS-525
uses 21AUP4A tube
QTS-525Y as above
RTS-525 TV9-79
TS-525 TV9-79

Motorola (Cont.)

WTS-525 TV9-79
HS-526 1957-53
HS-527 1957-50
HS-528 1957-54
TS-528 TV9-79
HS-529 1957-55
HS-520 1957-56
TS-580 TV11-09
TS-530Y TV11-69
VTS-530 like above + pilot light
HS-581 1957-57
TS-531 TV10-117
TS-581Y TV10-117
WTS-581 TV10-117
WTS-531Y TV10-117
HS-583, HS-524, HS-535 } Similar to HS-512
TS-538 TV11-79
TS-588Y TV11-79
TS-584 TV11-85
TS-524Y TV11-85
VTS-584 as above + pilot light
WTS-584 TV11-85
MTS-537, MTS-537Y, PTS-537, PTS-537Y } Similar TS-537,-Y with changes
QTS-537, QTS-537Y } Like TS-587
TS-587 TV12-87
TS-537Y TV12-87
TTS-537 TV12-87
TTS-587Y TV12-87
WTS-537 TV12-87
WTS-537Y TV12-87
TS-588 TV12-95
TS-538Y TV12-95
VTS-538 TV12-95
VTS-538Y TV12-95
WTS-588 TV12-95
WTS-538Y TV12-95
TS-539,-Y TV18-115
TTS-589 TV13-115
VTS-539 TV13-115
WTS-539 TV18-115
HS-540 1957-59
HS-541 1957-59
HS-542 1957-50
TS-542,-Y TV14-77
HS-548 1957-61
HS-544 1957-62
RTS-544 TV15-83
RTS-544Y TV15-83
TS-544 TV15-75
TS-544Y TV15-75
WTS-544 TV15-75
WTS-544Y TV15-75
PTS-545 TV15-90
PTS-546Y TV15-90
551 Five-79
MTS-551,-Y TV15-79
TS-551,-Y TV16-79
VTS-551 TV16-79
WTS-551,Y TV16-79
TS-552 TV16-67
TS-552Y TV16-67
HS-558 1957-77
TS-553 TV15-67
TS-553Y TV16-67
WTS-553 TV15-57
HS-554 1957-77
555 1956-85
555-12 1955-85
555 1956-85
HS-555 1987-58
TS-556,-Y TV16-83
VTS-556, VTS-555Y } Similar TS-556
TS-558,-Y TV17-59
WTS-558 TV17-59
HS-559 1958-110
HS-561 1958-110
TS-551,-Y TV17-63
WTS-551 TV17-63
HS-562 1958-115
HS-558 1958-116
HS-554 1958-115
TS-554,-Y TV17-57
WTS-564 TV17-67
HS-555 1957-51
HS-555 1957-50

Motorola (Cont.)

HS-567 1957-54
TS-567 TV18-89
TS-567Y TV18-59
QTS-558 like below
RTS-658 TV18-75
RTS-558Y TV18-75
TS-558 TV18-75
TS-558Y TV18-75
WTS-558 remote con. similar to above
STS-569 like below
VTS-559 TV18-85
VTS-559Y TV18-85
WTS-559 remote con. similar to above
ATS-570 TV20-57
KTS-570,Y TV20-57
LTS-570,Y TV20-57
MTS-570 TV20-57
PTS-570,Y TV20-57
QTS-570 TV20-57
RTS-570,Y TV20-57
TS-570,Y TV20-57
VATS-570 TV20-57
VTS-570 TV20-57
STS-570,Y TV19-75
TS-574,-Y except for audio, like TS-558,-Y
ATS-575 TV20-57
PTS-575 TV20-57
QTS-575Y TV20-57
ATS-578 like TS-578
HS-578 1958-108
TS-578,Y TV20-79
ATS-579 TV20-57
HS-579 1958-108
KTS-579,Y TV20-57
LTS-579,Y TV20-57
MTS-579,Y TV20-57
PTS-579,Y TV20-57
QTS-579 TV20-57
RTS-579,Y TV20-57
TS-579,Y TV20-57
TTS-579,Y TV20-57
VATS-579 TV20-57
VTS-579 TV20-57
++TS-581,Y TV20-75
++TS582,Y like TS-578 audio dif
ADTS-584 TV21-51
LSKTS-584 TV22-71
LSKTS-584Y TV22-71
NDTS-584 TV22-71
NDTS-584Y TV22-71
PKTS-584 TV22-71
PKTS-584Y TV22-71
SKTS-584 TV22-71
SKTS-584Y TV22-71
TDKTS-584 TV22-71
TDKTS-584Y TV22-71
TS-584,Y TV22-71
WDTS-584 TV22-71
WDTS-584Y TV22-71
WKTS-584 TV22-71
WKTS-584Y TV22-71
++TS-584 TV21-51
++TS-584Y TV21-51
DTS-585,Y TV21-73
PDTS-585,Y TV21-73
PPTS-585,Y TV21-73
SDTS-585,Y TV21-73
DTS-586,Y TV22-77
NDTS-585 TV22-77
TS-585 TV22-77
TS-587 TV22-83
HS-598 1958-114
595 1956-85
595-12 1955-85
595 1955-88
595-12 1956-88
597X 1958-101
597-12 see 595-12
HS-598 1958-105
HS-599 1958-106
600 Ten-95
600X 1958-102
HS-500 1958-111
501 Eleven-79
501X 1950-88
HS-501 1958-107

Motorola (Cont.)

HS-502 1958-107
TS-502 TV8-68
TS-502Y TV8-68
TS-508 TV9-79
505 Six-83
506 Eleven-80
HS-505 1958-114
508 similar to 505
HS-508 1958-109
509 similar to 505
TS-509 TV10-117
TS509Y TV10-117
512 1954-78
613 1955-56
614 1955-56
HS-619 1958-114
620 1955-90
521 1955-90
HS-621 1958-114
524 1957-57
HS-525 1958-112
HS-527 1958-112
HS-528 1958-113
HS-529 1958-113
HS-530 1958-117
HS-632 1958-109
HS-538 1959-78
HS-537 1959-79
HS-588 1959-80
HS-543 1958-111
HS-547 1959-81
HS-552 1959-82
HS-553 1959-83
HS-554 1959-88
HS-558 1959-84
HS-550 1959-85
HS-551 1959-85
HS-552 1959-85
HS-553 1959-85
HS-565 1959-87
HS-567 1959-87
HS-568 1959-57
HS-570 1959-88
HS-673 1959-89
HS-575 1959-90
SK575 1953-98
HS-678 1959-91
HS-579 1959-92
HS-580 1959-93
HS-588 1958-117
HS-584 1958-117
HS-588 1959-94
700 Ten-70
701(early) Five-81
701(late) Eleven-77
GV-701 1959-75
702 Twelve-94
HS-703 1959-95
HS-704 1959-95
705 Seven-109
708 Nine-71
HS-713 like HS-601
HS-728 1950-89
HS-729 1950-90
HS-730 1950-91
HS-732 1950-92
HS-735 1959-97
HS-744 1960-93
HS-745 1960-94
HS-746 1951-85
HS-749 1960-94
HS-750 1950-94
HS-749 1950-94
HS-750 1960-94
HS-752 1950-94
HS-753 1960-95
HS-758 like HS-658
HS-759 1950-96
HS-751 1960-98
HS-763 1950-98
HS-754 1960-99
HS-765 1950-99
HS-755 1960-99
HS-767 1960-100
HS-758 1960-101
HS-769 1960-101
HS-774 1960-101
HS-775 1951-86
HS-776 1961-86
HS-778 1951-86
HS-780 1960-99
HS-781 1960-100
HS-789 1960-92

Motorola (Cont.)

HS-792 1960-98
HS-793 1950-101
HS-795 1951-88
HS-795 1951-89
HS-797 1951-90
HS-798 1951-91
HS-799 1961-92
GV-800 1959-75
HS-800 1951-93
801 Eleven-77
802 Twelve-94
HS-802 1951-94
HS-809 like HS-749
HS-810 like HS-749
HS-813 1951-95
HS-813 1952-65
HS-814 1951-95
HS-815 1951-96
HS-819 1951-98
HS-820 1951-100
821 1953-75
HS-821 1951-102
HS-822 1952-55
HS-824 1951-97
HS-825 1951-104
HS-827 1951-105
HS-828 1951-105
HS-829 1951-105
829 1954-79
HS-830 1961-105
HS-831 1951-107
HS-832 1951-107
833 1955-57
HS-833 1951-108
834 1955-57
HS-835 1951-109
835 1955-57
841 1956-91
842 1955-91
843 1955-91
845 1957-72
845 1957-72
849 1957-72
852 1958-108
853 1958-103
854 1958-103
HS-850 1951-110
HS-851 1961-111
HS-859 1951-111
HS-876 1951-112
HS-877 1953-85
HS-880 1952-58
HS-881 1952-58
HS-882 1952-59
HS-883 1952-50
HS-884 1952-62
HS-885 1952-53
HS-887 like HS-802
HS-894 1962-64
HS-898 1951-110
900 1955-59
PM-900 1961-84
901 1955-59
HS-909 TV20-72
910 1956-92
911 1955-92
HS-915 1952-51
916 1956-93
918 1957-75
HS-918 1953-83
919 1957-75
HS-919 1953-83
HS-922 1952-55
928 1958-104
HS-928 1958-84
HS-931 1953-95
HS-938 1962-55
HS-939 1952-55
HS-939 1953-87
HS-942 1962-57
HS-943 1962-57
HS-944 1952-58
HS-945 1952-58
HS-945 1952-59
HS-947 1952-69
HS-948 1962-70
HS-949 1962-70
HS-950 1952-70
HS-951 1952-70
HS-952 1962-67
HS-953 1952-73
HS-954 1962-73

Motorola (Cont.)

HS-953 1962-72
HS-968 1962-72
HS-959 1962-71
HS-979 TV20-73
HS-981 1953-87
HS-995 1954-96
HS-997 1963-97
HS-998 1954-85
1000 1960-91
HS-1003 1953-89
HS-1004 1953-90
HS-1005 1963-91
HS-1006 1963-92
HS-1007 1953-93
HS-1008 1963-94
HS-1009 1963-95
HS-1011 1964-85
HS-1012 1963-98
HS-1013 TV20-74
HS-1015 like HS-953
HS-1015 1953-98
HS-1048 1954-97
HS-1049 1954-98
HS-1050 1964-97
HS-1051 1954-98
HS-1055 1954-100
HS-1058 1954-102
HS-1059 1954-100
HS-1060 1963-88
HS-1051 1954-100
HS-1102 1964-100
HS-1117 1954-95
HS-1123 1954-95
HS-1125 1954-102
HS-1134 1954-93
HS-1135 1954-94
HS-1192 1954-101
HS-1201 1964-99
FTHS-1224 TV22-85
RTHS-1224 TV22-85
1500 1961-94
HS-4124 1954-82
HS-4135 1954-84
HS-6108 1954-87
HS-5110 1954-81
HS-5111 1964-88
HS-5112 1964-89
HS-5114 1954-90
HS-5117 1954-85
HS-5118 1954-85
HS-5123 1964-91
HS-5124 1964-92
PAC18805A Twelve-90
FDH18805A2 1955-53
FDH18805B2 1955-51
FBG-18806H 1957-58
8990378 1956-73
8990576 1959-69
8990582 1959-68
8990810 like 93MR

MUNTZ TV

17A2 TV5-99
17A8 TV5-99
17A3A TV5-99
17A4 TV5-99
17A7 TV5-99
17B1 TV8-77
17B2 TV8-77
17B8 TV8-77
17B4 TV8-77
17B5 TV5-77
17B8 TV8-77
17PL(82) TV18-95
17PS TV18-95
S17PD TV17-89
S17PD82 TV17-89
S17PS TV17-89
S17PS82 TV17-89
TV17A3A like 17A3A
TV17A7 like 17A7
19PD TV20-87
19PS TV20-87
19PSA TV20-87
19PSX TV20-87
21CB TV17-89
21CB82 TV17-89
21CM TV17-89
21CM82 TV17-89
21CM(82) TV18-95
21CP++ TV18-96
21CS(82) TV18-96

MUNTZ TV (Cont.)

21CS TV17-89
21CS82 TV17-89
21CW TV17-89
21CW82 TV17-89
21LBB TV17-89
21LBB82 TV17-89
21LBM TV17-89
21LBM82 TV17-89
21LBW TV17-89
21LBW82 TV17-89
21TB TV17-89
21TB82 TV17-89
21TB(82) TV18-96
21TM(82) TV18-96
21TS(82) TV18-96
21TS TV17-89
21TS82 TV17-89
21TW TV17-89
21TW82 TV17-89
21TW(82) TV18-95
23CB,++ TV20-87
23CP1B,+ TV20-87
23CP2B,+ TV20-87
23CP3B,+ TV20-87
23CP8B,+ TV20-87
23CP10B,+ TV20-87
23CXB(82) TV18-96
23CXM(82) TV18-95
23CXW(82) TV18-95
24CB TV17-89
24CB82 TV17-89
24CB(82) TV18-96
24CPP(82) TV18-96
24CM(82) TV18-95
24CM TV17-89
24CM82 TV17-89
24CS(82) TV15-95
24CW(82) TV18-95
24CW TV17-89
24CW82 TV17-89
24LBB(82) TV18-96
24LBM(82) TV18-95
24LBW(82) TV18-95
24TB(82) TV18-95
24TB TV17-89
24TB82 TV17-89
24TM TV17-89
24TM82 TV17-89
24TS TV17-89
24TS82 TV17-89
24TW TV17-89
24TW82 TV17-89
M31 TV5-99
M31R TV5-99
M32 TV5-99
M82R TV5-99
M33 TV5-99
M34 TV5-99
37A2 TV8-77
T37AA09 TV20-87
T37AA11 TV20-87
T37AB09 TV20-87
T37AB11 TV20-87
T37AC09 TV20-87
T37AC11 TV20-87
T87L04U TV17-89
T37L05 TV17-89
T37M04U TV17-89
T37M05 TV17-89
T37Q04U TV17-89
T37Q05 TV17-89
T37P04U TV17-89
T37P05 TV17-89
T37Q04U TV17-89
T37Q05 TV17-89
T37R04U TV17-89
T37R05 TV17-89
T37S04U TV17-89
T37S05 TV17-89
T37T++ TV18-95
T37U++ TV18-96
T37V09 TV20-87
T37V11 TV20-87
T37W09 TV20-87
T37W11 TV20-87
T37X09 TV20-87
T37X11 TV20-87
T37Y09 TV20-87
T37Y11 TV20-87
T37Z10 TV20-87
M41 TV5-99
M42 TV5-99

MUNTZ TV (Cont.)

M46 TV5-99
47A4 TV10-123
49A4 TV10-123
M49 TV5-99
317T2 TV8-77
321T1 TV8-77
321T2 TV8-77
421C1 TV10-123
421C2 TV10-123
421T1 TV10-123
421T2 TV10-123
427C TV10-123
427T TV10-123
521C/UHF TV10-123
521C1 TV10-123
521C2 TV10-123
521S/UHF TV10-123
521ST1 TV10-123
521ST2 TV10-123
524C TV10-123
524T TV10-123
527C TV10-123
527T TV10-123
524C TV12-103
524TS, TW TV12-108
627C TV12-108
527TS TV12-103
724 Series TV13-125
727 Series TV18-135
1750, 1751, 1752, use TV17A3A
2053-A TV8-77
2054-A TV8-77
2055-A,-B TV8-77
2056-A TV8-77
2053, 2054, 2055, 2056 use TV17A7
2158-A TV8-77
2159-A TV8-77
2162-A TV8-77
2457-A TV8-77
2461-A TV8-77

NASH-KELVINATOR

NHSC 1953-77
AC-152 Twelve-89
8990378 1955-73

NATIONAL CARBON CO

50 One-118
52 to 54 One-112

NATIONAL CO.

MC-45 Six-84

NATIONAL UNION

G-619 Eight-122

NOBLITT-SPARKS

see Arvin

NORELCO.

L2X97T 1953-99

OLDSMOBILE

982005 One-212
982029 1963-27
982030 1953-30
982135 1954-24
982137 1964-18
982149 1964-22
982160 Three-70
982161 Three-59
982212 1964-21
982215 Five-83
982282 Five-83
982375 Seven-155
982375 Seven-154
982455 Nine-142
982544 Ten-155
982573 Ten-155
982597 Eleven-137
982598 Eleven-137
982990 1953-143
983004 1953-144
983090 1954-131
983091 1954-133
983334 1956-158
983336 1956-156
989001 1958-48
989002 1958-50
989127 1958-52

Oldsmobile (Cont.)

989129	1958-42
989181	1958-46
989170	1959-28
989171	1959-30
989172	1959-20
989387	1961-31
989392	1961-85
989393	1962-17

OLYMPIC RADIO

AA	TV10-127
AB	TV10-127
AC	TV10-127
AF similar to AB	
AH similar to AC	
AJ	TV10-127
AK	TV10-127
AL similar to AC	
BD	TV11-89
BF	TV11-89
CA	TV12-109
CB	TV12-109
CC	TV12-107
CD	TV12-107
CE	TV12-109
CG	TV12-107
CH	TV12-107
DA	TV18-139
DAU	TV18-139
DB	TV18-139
DBU	TV13-139
DF	TV18-139
DFU	TV13-139
GA	TV16-97
GAU	TV16-97
GB	TV16-97
GBU	TV16-97
GD	TV16-93
GDU	TV16-93
GF	TV16-97
GFU	TV16-97
GH	TV16-93
GHU	TV16-93
GT	TV16-89
GTU	TV16-89
GU	TV16-89
GUU	TV16-89
LY	TV20-92
LYU	TV20-92
MA	TV21-78
MAU	TV21-78
MB	TV21-78
MBU	TV21-78
ME	TV21-78
MEU	TV21-78
R	TV9-89
S	TV9-89
TK	TV7-99
TL	TV7-99
TM	TV8-83
TN	TV8-83
U	TV9-89
1CA20	TV12-109
1CA70/U	TV13-139
1CB21	TV12-109
1CB71/U	TV13-139
1CB72/U	TV13-139
1CB77/U	TV18-139
1CC22	TV12-107
1CC23	TV12-107
1CD24	TV12-107
1CD25	TV12-107
1DB17	TV12-109
1KA40	TV12-109
1KA80/U	TV13-139
1KB87/U	TV13-139
1KB88/U	TV13-139
1KC41	TV12-107
1KC42	TV12-107
1KC43	TV12-107
1TA10	TV12-109
1TA60/U	TV13-139
1TB11	TV12-109
1TB61/U	TV13-139
1TC12	TV12-107
1TD13	TV12-107
3C605	TV20-92
3C701	TV21-78
3C702	TV21-78
3C703	TV21-78
3C805	TV21-78
3C806	TV21-78
3C812	TV21-78
3C618	TV21-78

OLYMPIC (Cont.)

3C814	TV21-78
3C901	TV21-78
3C902	TV21-78
3K718	TV21-78
3K719	TV21-78
3K720	TV21-78
3K721	TV21-78
3K722	TV21-78
3K725	TV21-78
3K826	TV21-78
3K827	TV21-78
3K830	TV21-78
3K832	TV21-78
3K834	TV21-78
3K835	TV21-78
3K836	TV21-78
3T600	TV20-92
3T700	TV21-78
3T800	TV21-78
3T900	TV21-78
4CE15	TV12-109
4CF75/U	TV13-139
4CF76/U	TV18-139
4CG26	TV12-107
4CG27	TV12-107
4CH28	TV12-107
4CH29	TV12-107
4KF84/U	TV13-139
4KG44	TV12-107
4KG45	TV12-107
6-501	Six-88
6-502	Six-88
6-508	Six-88
6-504	Six-88
6-504-L	Six-88
6-507	Eight-67
6-801W, V	Seven-57
6-502	Seven-57
6-604W, V	Seven-59
6-606	Seven-58
6-608	Eight-68
6-617	Six-89
5P25	TV22-87
7-526	Eight-69
7-622	Nine-79
7-638	Nine-79
7C809	TV21-78
7C810	TV21-78
9-435V	1953-77
9-435W	1953-77
14TT91, U	TV18-89
14TT92, U	TV16-89
17C, 17D like 752	
17C44	TV7-99
17C57	TV8-83
17CA20	TV10-127
17CR20	TV9-29
17K41	TV7-99
17K42	TV7-99
17K50	TV7-99
17K55	TV8-83
17K101	TV8-83
17T40	TV7-99
17T48	TV7-99
17T56	TV8-83
17T71 like TM-17	
17T75 like TM-17	
17T83 like TM-17	
17T85 like TM-17	
17TA19	TV10-127
17TA32	TV10-127
17TA33	TV10-127
17TR10	TV9-89
17TR19	TV9-89
17TU93, U	TV16-89
17TU94, U	TV16-89
17TU98, U	TV16-89
TM-17	TV8-83
28C45	TV7-99
20C52	TV7-99
20C53	TV7-99
20D49	TV7-99
20K43	TV7-99
20K51	TV7-99
20T46	TV7-99
28T47	TV7-99
21C85	TV8-83
21C68	TV8-83
21C72	TV8-83
21C73	TV5-83
21C80, 21C81, 21C82, 21C89, 21C90, 21C91, 21C92 All these are similar to TN-21	

OLYMPIC (Cont.)

21CB35	TV10-127
21CB41	TV10-127
21CC55	TV10-127
21CC70	TV10-127
21CF61 uses AF	
21CF63 uses AF	
31CH59 uses AH	
21CL81 uses AL	
21C812	TV9-89
21CS13	TV9-89
21CU15	TV9-89
21CU18	TV9-89
21D80	TV8-83
21D64	TV8-83
21DB71	TV10-127
21DC71	TV10-127
21K81	TV8-83
21K62	TV8-83
21K63B	TV8-83
21K101 like TN-21	
21KB24	TV10-127
21KB26	TV10-127
21KB86	TV10-127
21KB76	TV10-127
21KC44	TV10-127
21KC46	TV10-127
21KC56	TV10-127
21KS22	TV9-89
21T58	TV8-83
21T69	TV8-83
21T70	TV8-83
21T74	TV8-83
21T86 like TN21	
21TB34	TV10-127
21TB40	TV10-127
21TC54	TV10-127
21TF60 uses AF	
21TF62 uses AF	
21TL80 uses AL	
21TS11	TV9-09
21TS17	TV9-89
21TU14	TV9-89
C21BD35	TV11-89
C21BF21	TV11-89
K21BD34	TV11-89
T21BD19	TV11-89
T21BF20	TV11-89
TN-21	TV8-83
TNA-21	TV8-83
22D100 to 22D117 are similar to TN-21	
22DB+	TV10-127
22DC+	TV10-127
24CJ68	TV10-137
24CJ68BK	TV10-127
24CJ68MK	TV10-127
24CK77	TV10-127
ICA96, U	TV16-97
ICA97, U	TV16-97
TA100, U	TV16-97
TB101, U	TV16-97
TD102, U	TV16-93
CA105, U	TV16-97
CB106, U	TV16-97
CB107, U	TV16-97
CD108, U	TV16-93
CD109, U	TV16-93
CD110, U	TV16-93
PKA115, U	TV16-97
PKB116, U	TV16-97
KD118, U	TV16-93
PKD118, U	TV16-93
KD119, U	TV16-93
PKD119, U	TV16-93
KD120, U	TV16-93
CF400, U	TV16-97
401	1955-61
CF401, U	TV16-97
CH402, U	TV16-93
404	1957-87
KF405	TV16-97
KF405, U	TV16-97
KH406, U	TV16-93
407	1957-88
KH407, U	TV16-93
441	1955-82
442	1955-63
445	1954-61
446	1957-89
447	1957-90
449	1954-82
489	Eleven-95
HF-500	1955-64
571	1955-64
573	1955-64

OLYMPIC (Cont.)

888	1959-98
752, 752U	TV8-197
753, 753U	TV8-107
754 like 753	
755, 755U	TV8-107
757 similar to 752	
758 similar to 752	
764, 764U	TV6-107
765 similar to 752	
766, 766U	TV6-107
768 like 753	
769	TV8-107
773 similar to 752	
791 similar to 752	
792 similar to 752	

PACKARD

416394	Eleven-135
472046	1956-151
472047	1956-152
472048	1956-152
480487	1956-160
6480488	1956-152
6480489	1956-152
7266027	1956-160
7266047	1956-152
7266067	1956-152

PACKARD-BELL CO.

RC-1S	1954-103
T-1	TV11-93
TVP-1	TV17-97
TVT-1	TV17-97
TVP-2	TV17-97
TVT-2	TV17-97
WRT-2	TV18-101
MRB1	1957-91
4RC1	1960-102
5DA	Eight-129
5FP	Six-90
5R1	1957-92
5R3 similar to 5R1	
5R5	1959-99
5R6	1960-103
5R8	1961-118
5RC1, 5RC3, 5RC4	Similar to Model 582
5RC7	1960-103
5RC8	1961-113
5R9	1963-100
5RC10	1963-100
6R1	1958-118
6RC1	1958-118
6RT2	1959-100
7R4	1962-74
8HF1	1964-103
8HF2	1964-108
V8-2	TV16-101
V6-2	TV17-93
10RP1	1958-103
T-10	TV10-131
17T1	TV17-97
17VC1	TV16-101
17VT8	TV16-101
17VT4	TV16-101
17VT8	TV16-101
17VT9	TV16-101
17VT10	TV17-93
21C1	TV15-101
21C2	TV15-101
21C3	TV17-97
21DC5	TV14-91
21DC6	TV14-91
21DC7	TV14-91
21DC16	TV18-101
21K2	TV17-97
21SC6	TV14-87
21SC7	TV14-87
21SC8	TV14-87
21SK3	TV14-87
21ST3	TV14-87
21T1	TV15-101
21T2	TV17-97
21VC8	TV17-93
21VT2	TV14-87
21VT4	TV16-101
21VT6	TV17-93
23DC5	TV18-101
23DC6	TV18-101

PACKARD-BELL (Cont.)

23DC14	TV21-86
28DC15	TV21-86
23DC16	TV21-85
28DD9	TV21-86
33DT2	TV21-86
24C1	TV15-101
24DC4	TV14-91
24SC2	TV14-87
24VT1	TV14-87
U-24	Seven-114
46-H, -HC	Three-71
48-G, -GK	Three-71
65-A	Four-90
67-E	Four-90
67-RPA	Four-90
88	TV17-97
88 Series	TV20-96
88-5	TV15-101
88-14K	TV22-91
88-14L, M	TV22-91
88S3	TV14-87
98D8	TV14-91
98D6	TV18-101
98D16, C	TV21-86
471	Eight-131
531	1954-83
532	1954-83
533	1954-83
541	1955-65
543	1955-85
551	Six-90
553	Seven-114
621	1953-54
631	1954-84
851	Six-91
662	Seven-113
673	Eight-130
771	Nine-80
771X	Nine-80
C-1461	Seven-114
1840 similar 2040	
1841, 1842 see 2040	
1941, 1942 see 2040	
2040	TV8-85
2041	TV8-85
2042	TV8-85
2043	TV8-85
2044	TV8-85
2141	TV8-85
2142	TV8-85
2143	TV8-85
2144	TV8-85
3421	TV7-103
2422	TV7-103
2423	TV7-103
2740	TV9-93
2742	TV9-93
2743	TV9-93
2744	TV9-93
3822	TV7-103
2842	TV9-93
2843	TV9-93
2844	TV9-93
2940-1	TV9-93
2941	TV9-93
3041	TV9-93
17101	TV10-131
17104	TV10-131
21102	TV10-131
21103	TV11-93
21201	TV10-131
21202	TV11-93
21204	TV10-131
21206	TV10-131
21401	TV11-93
21402	TV10-131

PHILCO RADIO

J Line	TV20-99
K Line	TV19-121
K Line	TV20-105
L Line	TV21-89
M Line	TV22-95
Al used in 51-T1443	
C1	TV6-111
CP1	TV6-111
D	TV11-97
D1	TV6-114
G-1	TV7-110
H-1	TV7-111
J-1	TV7-116
TPA-1	1956-108

Philco (Continued)

TPA-2	1956-108
C2	TV6-115
CE-2	Nine-81
F2	TV6-111
G-2	TV7-107
J-2	TV7-107
PT-2	Four-92
T-3, early	1959-101
T-3, late	1959-102
CE-4	Nine-83
D4	TV6-111
G-4	TV7-107
H-4	TV7-107
J-4	TV7-107
RT-4	TV5-114
T-4	1959-103
T-4J	1959-103
5	One-115
J-5	TV7-107
T-5	1959-104
CE-6	Nine-83
PT-6	Four-92
T-6	1959-110
UN-6-100	Nine-81
UN-6-400	Eight-133
7E10, -U	TV12-119
7E11, -E	TV12-119
7E12 like above diff. tuner	
7H20	TV18-143
7H20U	TV18-143
7H22	TV18-143
7L40, -U	TV12-115
7L41, -U	TV12-115
7L45U	TV12-115
7L70, -U	TV12-111
7L71, -U	TV12-111
7P50, -U	TV12-115
7P51 and 7P51U Similar to above	
T-7	1957-104
T-7X	1959-105
8E11	TV14-95
8E11U	TV14-95
8E13	TV14-95
8H20 like 7H20	
8H20U like 7H20U	
8H22 like 7H22	
8H25, -U	TV14-111
8L35	TV15-105
8L35U	TV15-105
8L41, -U	TV14-101
8L42, -U	TV14-101
8L43, -U	TV14-101
8L71, -U	TV14-105
8L72, -U	TV14-105
8L73, -U	TV14-195
8P51, -A	TV14-101
8P51U	TV14-101
9H25	TV15-111
9H25U	TV15-111
9H125 like 9H25	
9L35	TV15-121
9L35U	TV15-121
9L37	TV16-105
9L37U	TV16-105
9L38	TV16-105
9L38A	TV16-105
9L38U	TV16-105
9L41	TV15-116
9L41U	TV15-116
9L60	TV16-117
9L60U	TV16-117
10AT10	TV17-111
10H25, -R,	TV17-101
10H25U	TV17-101
10L31	TV17-107
10L31U	TV17-107
10L32 like 10L31	
10L32U like 10L31U	
10L41	TV17-117
10L42	TV17-117
10L43	TV17-117
10N41	TV17-117
11H25, U	TV18-115
11J27, U	TV18-115
11N50	TV18-105
11N51	TV18-105
11N51A	TV18-105
11N52	TV18-105
11N52A	TV18-105
11N53	TV18-105

Philco (Continued)

11N54	TV18-105
11N56	TV18-105
T11, CT-11	One-116
12J27	TV19-115
12J27U	TV19-115
12J28, A	TV20-99
12N50, A	TV20-105
12N50	TV19-121
12N51	TV19-121
12N51U	TV19-121
12N52	TV20-105
12N53	TV20-105
12N54	TV20-105
PT-12	Four-92
13G20, C	TV21-89
13G20U	TV21-89
13J27, U	TV21-89
13J28, U	TV21-89
18J41, U	TV21-89
13J42, U	TV21-89
13J48, U	TV21-89
13J45, U	TV21-89
13N50	TV21-89
13N50A	TV21-89
13N50U	TV21-89
13N51, U	TV21-89
13N52	TV21-89
13N53, U	TV21-89
14G20	TV22-95
14J28 like 13J28	
14J42	TV22-95
14J43	TV22-95
14J45	TV22-95
14N30	TV22-95
14N50, A	TV22-95
14N51 like 13N51	
16	One-117
18B3000	TV8-98
18BU3000	TV8-96
18B3001	TV8-96
18BU3001	TV8-95
18B3002	TV8-102
18BU3002	TV8-102
18B3100	TV8-98
18BU3100	TV8-98
18B3102	TV8-102
18BU3102	TV8-102
18B3104	TV2-109
18BU3104	TV8-109
18B3408	TV8-102
18BU3408	TV8-102
18C3610E, 18C3010L, 18C3010M	Use 301A or 301W Chassis
18D3020+	TV11-97
18D3122, U	TV11-97
19	One-126
20, 20A	One-118
M-20	Ten-111
21	One-118
22B4000	TV9-98
22BU4000	TV8-96
22B4002	TV8-102
22BU4002	TV8-102
22B4004	TV8-102
22BU4004	TV8-102
22B4008	TV8-109
22BU4008	TV8-109
22B4100	TV8-96
22BU4100	TV8-96
22B4102	TV8-102
22BU4102	TV8-102
22B4106	TV8-102
22BU4106	TV8-102
22B4108	TV8-109
22BU4108	TV8-109
22B4109HM	TV8-102
22BU4109HM	TV8-102
22B4110	TV8-109
22BU4110	TV8-109
22B4150	TV8-102
22B4301	TV8-95
22B4302	TV8-102
22BU4302	TV8-102
22B4303	TV8-96
22BU4303	TV8-96
22B4304	TV8-102
22BU4304	TV8-102
22B4308	TV8-102
22BU4306	TV8-102
22B4307HM	TV8-102
22BU4307HM	TV8-102
22B4308	TV8-109
22BU4308	TV8-109

Philco (Continued)

22B4399 uses R-91B & J2
22B4490W TV8-102
22BU4460W TV6-102
22B4402 TV8-102
22BU4402 TV6-102
22B4404 TV6-109
22B4405 TV8-109
22B4406 TV8-109
22C4006 uses 301A
22C4010 TV9-97
22C4010L TV9-97
22C4011X, 22C4011XL, 22C4011XW } Use 301 or 301A Chassis
22C4012 TV9-97
22C4013 see TV-300
22C4014 TV6-97
22C4015 see TV-300
22C4016 TV9-97
22C4018 see TV-201
22C4020 TV10-135
22C4112, 22C4117, 22C4118 } Use TV-301A Chassis
22C4119 TV9-97
22C4120 TV9-97
22C4121 see TV-301
22C4122 TV9-97
22C4123 TV9-97
22C4124 TV9-97
22C4125 see TV-300
22C4126 TV9-97
22C4127 see TV-300
22C4128 TV10-135
22C4129 see TV-350
22C4130 see TV301A
22C4130X, 22C4120XL } Use 350
22C4132L TV10-135
22C4316 TV9-97
22C4311 see TV-300
22C4312 TV9-97
22C4410 see TV-350
22D4029 use TV-320
22D4030+ TV11-97
22D4032 TV11-97
22D4033 use TV-332
22D4034, L TV11-97
22D4041 use TV-392
22D4121 use TV-330
22D4134 use TV-390
22D4135 use TV-232
22D4136+ TV11-97
22D4137 use TV-232
22D4138+ TV11-97
22D4139 use TV-330
22D4140, L TV11-97
22D4144, L TV11-97
22D4145 use TV-390
22D4148, L TV11-97
22D4150+ TV11-97
22D4151 use TV-390
22D4152+ TV11-97
23D4153 use TV-230
22D4154, L TV11-97
22D4155 use TV-382
22D4156, L TV11-97
22D4157 use TV-390
22D4158, U TV11-97
22D4159 TV11-97
22D4160, L TV11-97
22D4161 use TV-392
22D4162, L TV11-97
22D4163 use TV-440
22D4164 TV11-97
22D4165 use TV-292
22D4170 use TV-331
22D4171 use TV-322
22D4172 use TV-331
22D4320+ TV11-97
22D4321 use TV-332
22D4324+ TV11-97
22D4326 TV11-97
22D4420, 22D4422 } Combinat. use TV-392
24B6002 TV8-102
24B6104 TV8-102
24C4006 uses 301
24C6005, 24C6108 } Use TV-304
24C6010 TV9-97
24C6107 uses 354A
24C6109 TV9-97

Philco (Continued)

24C6110 TV9-97
24C6112 TV9-97
24C6310 TV9-97
24D6018 TV11-97
24D6120L TV11-97
24D6120M TV11-97
24D6122L, M TV11-97
24D6126L, M TV11-97
24D6320C, M TV11-97
M-24 1953-09
PT-25 Three-72
PT-26 Three-72
PT-27 Three-72
PT-28 Three-72
PT-29 Three-78
PT-30 Four-91
31 used in 51-T1443B
PT-31 Three-73
32 TV6-111
33 TV6-112
PT-33 Three-73
35 TV6-111
PT-35 Three-74
PT-36 Three-72
37 TV6-111
37-10 One-147
37-11 One-147
37-33 One-148
37-38 One-149
37-84 One-149
37-93 One-150
37-602 One-151
37-623 One-152
37-640 One-153
37-650 One-154
PT-37 Three-74
23 TV6-111
38-116 One-155
PT-38 Three-75
PT-39 Three-72
40-81 Three-80
40-88 Three-80
40-115 Three-81
40-124 Three-81
40-130 Three-82
40-135 Three-02
40-140 Three-03
40-145 Three-83
40-150 Three-85
40-155 Three-85
40-158 Three-84
40-160 Three-87
40-165 Three-89
40-180 Three-86
40-185 Three-86
40-190 Three-86
40-195 Three-88
40-200 Three-88
40-215 Three-90
40-216 Three-90
40-217 Three-90
40-501 Three-93
40-502 Three-93
40-503 Three-94
40-506 Three-94
40-507 Three-95
40-508 Three-96
40-509 Three-96
40-510 Three-97
40-525 Three-98
41 TV6-116
41-90 Four-97
41-95 Four-97
41-100 Four-97
41-105 Four-97
41-110 Four-93
41-220 Four-94
41-221 Four-95
41-225 Four-94
41-226 Four-95
41-230 Four-96
41-231 Four-98
41-235 Four-96
41-246 Four-98
41-250 Four-99
41-255 Four-99
41-256 Four-100
41-258 Four-101
41-260 Four-102
41-265 Four-102
41-280 Four-103
41-285 Four-103
41-287 Four-103
41-290 Four-103

Philco (Continued)

41-295 Four-105
41-300 Four-105
41-318 Four-106
41-601 Four-108
41-602 Four-108
41-603 Four-109
41-604 Four-109
41-605 Four-109
41-607 Four-109
41-600 Four-110
41-609 Four-110
41-610 Four-111
41-611 Four-111
41-620 Four-112
41-623 Four-112
41-624 Four-113
41-625 Four-112
41-705 Four-114
41-842 Four-116
41-843 Four-116
41-844 Four-116
41-851 Four-115
PT-41 Three-72
42 RF Chassis similar to 41
42-121 Five-87
42-122 Five-87
42-123 Five-87
42-321 Five-88
42-322 Five-89
42-350 Five-98
42-368 Five-91
42-706 Five-90
42-716 Five-92
42-717 Five-90
42-718 Five-92
42-724 Five-94
42-730 Five-95
42-761 Five-96
42-788 Five-98
42-842 Five-97
42-842 Five-97
42-844 Five-97
42-853 Five-97
42-854 Five-97
42-1001 Five-99
42-1002 Five-100
42-1004 Five-101
42-1012 Five-102
42-1013 Five-102
42-1016 Five-103
42-PT-2 Five-85
42-PT-4 Five-85
42-PT-7 Five-85
42-PT-10 Five-88
42-PT-87 Five-86
42-PT-88 Five-85
PT-42 Four-91
PT-43 Three-75
44 TV6-111
PT-44 Four-91
45 One-119
PT-45 Three-76
T-45(124) 1960-104
T-45(126) 1960-105
46-200 Seven-116
46-201 Seven-116
46-202 Seven-116
46-202 Seven-116
46-250 Eight-132
46-350 Eight-134
46-427 Eight-125
46-1201 Seven-115
46-1226 Eight-126
PT-46 Three-76
PT-47 Three-76
TC-47 1960-106
PT-48 Three-76
48-300 Nine-84
48-461 Nine-85
48-472 Nine-87
48-472-1 Nine-87
48-1262 Nine-86
48-1282 Nine-06
49-500 Nine-88
49-500-1 Nine-88
49-501 Nine-88
49-502 Nine-88
49-504 Nine-88
49-505 Nine-88
49-601 Nine-89
49-602 Nine-89
49-900E Nine-90
PT-49 Three-77

Philco (Continued)

49-900-I Nine-90
49-901 Nine-91
49-1401 Nine-92
58 One-120
50A One-120
50-522 Ten-102
50-522I Ten-102
50-524 Ten-102
50-526 Ten-102
50-620 Ten-103
50-621 Ten-101
50-920 Ten-105
50-921 Ten-105
50-922 Ten-105
50-925 Ten-104
50-926 Ten-104
50-1420 Ten-106
50-1421 Ten-106
50-1422 Ten-106
50-1422 Ten-106
50-1424 Ten-107
50-T1600 TV5-103
50-T1632 TV5-103
50-T1623 TV5-102
50-1718 Ten-108
T-50 1960-107
T-50(126) 1961-114
51-530 Eleven-96
51-522 Eleven-96
51-534 Eleven-96
51-537 Eleven-97
51-537-I Eleven-97
51-538 Eleven-97
51-629 see 51-631
51-631 Ten-110
51-622 see 51-631
51-920 Eleven-101
51-931 Eleven-101
51-932 Eleven-101
51-934 Ten-109
51-1330 Eleven-99
51-T1443 TV5-107
51-T1601 TV5-107
51-T1602 TV5-107
51-T1604 TV5-103
51-T1606 TV5-103
51-T1607 TV5-107
51-T1624 TV5-103
51-1720 Eleven-100
51-1731 Eleven-102
51-1732 Eleven-102
51-T1800 TV5-111
51-T1330 TV5-111
51-T1822 TV5-107
51-T1834 uses 33 and C2
51-T1625 TV5-107
51-T1836 TV5-111
51-T1828 TV5-111
51-T1870 TV5-107
51-T1871 TV5-111
51-T1872 TV5-107
51-T1874 TV5-107
51-T1875 TV5-107
51-T1876 TV5-111
51-T2102 TV5-111
51-T2130 TV5-111
51-T2132 TV5-111
51-T2133 TV5-111
51-T2134 TV5-111
51-T2136 TV5-111
51-T2138 TV5-111
51-T2170 TV5-111
51-T2175 TV5-111
51-T2176 TV5-111
PT-51 Three-77
T-51(124) 1961-114
52-540 Twelve-95
52-540-I Twelve-95
52-541 Twelve-95
52-541-I Twelve-95
52-542-I Twelve-95
52-543 Twelve-98
52-544 Twelve-97
52-544-I Twelve-97
52-544-W Twelve-97
52-545 Twelve-93
52-547 Twelve-98
52-548 Twelve-99
52-550 Twelve-98
52-640 Twelve-100
52-641 Twelve-100
52-642 Twelve-101

Philco (Continued)

52-943 Twelve-102
52-941 Twelve-103
52-942 Twelve-102
52-944 Twelve-103
52-944 Twelve-103
52-1240 Twelve-104
52-T1610 TV6-111
52-T1612 TV6-111
52-T1802, Code 123 TV6-111
52-T1802, Code 124 TV7-107
52-T1804 TV6-111
52-T1803 TV6-111
52-T1810 TV6-111
52-T1812 TV6-111
52-T1820, Code 121 uses 41 and D1
52-T1821, Code 123 uses 37 and C2
52-T1821, Code 124 TV7-107
52-T1822 TV7-107
52-T1831 TV6-111
52-T1839 TV6-111
52-T1840 TV6-111
52-T1841 TV6-111
52-T1842 TV6-111
52-T1844 TV6-111
52-T1850 code 121 uses 41 and D1
52-T1882 TV6-111
52-T2106 TV6-111
52-T2108 TV6-111
52-T2110 TV6-111
52-T2120, Code 121 uses 41 and D1
52-T2120, Code 124 TV7-107
52-T2122, Code 121 uses 41 and D1
52-T2140 TV6-111
52-T2142 TV6-111
52-T2144 TV6-111
52-T2145 TV6-111
52-T2150W TV7-107
52-T2151 TV7-107
52-T2157, Code 125 uses 42 and G2
52-T2175, Code 124 uses 35 and F2
53-T2176, Code 124 uses 25 and F2
52-T2182 TV6-111
52-T2224, Code 121 uses 41 and D1
52-T2245 TV6-111
52-T2252, Code 121 uses 41 and D1
53-T2252, Code 124 TV7-107
53-T2253, Code 121 uses 44 and D4
52-T2254, Code 121 uses 41 and D1
52-T2256, Code 121 uses 41 and D1
53-T2258, Code 121 uses 41 and D1
52-T2259, Code 121 uses 41 and D1
52-T2282 TV6-111
52-T2283, Code 121 uses 44 and D4
T-52(124) 1961-115
53 One-121
53-560 1953-80
53-561 1953-80
53-562 1953-80
53-563 1952-80
53-564 1953-80
53-565 1952-80
53-566 1953-79
53-568 1953-80
53-651 1953-81
53-652 1953-81
53-656 1953-82
53-658 1953-82
53-700 1952-84
53-701 1953-34
53-701X 1953-84
53-702 1953-84
53-706 1953-84

Philco (Continued)

53-707 1953-84
53-500 1952-85
53-804 1953-85
53-950 1953-85
53-952 1953-85
53-954 1953-85
53-956 1953-86
53-1350 1953-88
53-T1824 TV7-107
53-T1925 TV7-107
53-T1826 TV7-107
53-T1827 TV7-107
53-T1852 TV7-107
53-T1853 TV7-107
53-T1883 TV7-107
53-T1884 TV7-197
53-T1886 TV7-107
53-T2125 TV7-107
53-T2126 TV7-107
53-T2127 TV7-107
53-T2152 TV7-107
53-T2183 TV7-107
53-T2225 TV7-107
53-T2226 TV7-107
53-T2227 TV7-107
53-T2228 TV7-107
53-T2260 TV7-107
53-T2262 TV7-107
53-T2264 TV7-107
53-T2266 TV7-107
53-T2268 TV7-107
53-T2269 TV7-107
53-T2270 TV7-107
53-T2271 TV7-107
53-T2272 TV7-107
52-T2273 TV7-107
53-T2285 TV7-107
53-T2286 TV7-107
53-T2287 TV7-107
53-U2124 (UHF) uses 81 and H-1
53-U2255 (UHF) uses 81 and H-1
53-U2226 (UHF) uses 81 and H-1
53-U2227 (UHF) uses 81 and H-1
PT-53 Three-74
54 One-121
PT-55 Three-75
57 One-123
PT-57 Three-77
TC-57 1961-115
PT-59 Three-78
60 One-124
T-60 1959-106
PT-61 Three-73
T-61 1962-75
T-62 1961-116
T-63 1963-101
T-64 1963-102
PT-65 Three-77
T-65 1959-107
66 One-114
PT-66 Three-78
T-66 1961-117
PT-67 Three-79
T-67 1964-105
T-68 1964-106
PT-69 Three-79
70, 70A One-125
70 AVC One-127
70A AVC One-127
T-70 1961-118
71 Radio One-128
71 TV7-108
T-71 1962-76
T-74 1961-119
T-75 1959-108
T-76 1961-120
T-77 1962-77
T-78 1960-108
80 One-130
81 TV7-112
R-81B like 81
T-81 1964-108
82 One-132
84 One-132
84 TV7-107
T-84 1964-107
86 One-133
87 One-134

Philco (Continued)

PT-87 Five-85
PT-88 Five-05
T-88 1962-78
89 (123) One-136
T-89 1963-103
90, 90A One-137
T-90 1964-110
91 TV7-114
PT-91 Five-86
R-91B similar 91
PT-92 Five-86
PT-93 Five-86
94 TV7-107
PT-94 Five-86
PT-95 Five-86
96, 96A One-141
RT-100 1958-129
118 One-143
RT-150 1959-122
D-181 TV8-87
R-181 TV8-87
R-181U TV8-87
D-191 TV8-98
R-191 TV8-98
R-191U TV8-98
R-192U TV8-98
D-194 TV8-98
R-194 TV8-98
R-194U TV8-102
D-201 TV8-105
R-201 TV8-105
D-202 TV8-105
R-202 TV8-105
RT-202 1959-109
D-204 TV8-105
R-204 TV8-105
250 Eight-132
RT-300 1960-109
TV-300 TV9-98
301A minor differ. from TV-301
301W like 300 diff. IF strip
TV-301 TV9-98
TV-301A as above
304 minor tube diff. from 300
TV-304 as above
TV-330 TV11-97
TV-320U TV11-97
TV-331, TV-231U } Late run of TV-330
TV-232, TV-332U Like TV-330, -U
350 Eight-134
TV-350 TV9-107
354A similar 354
TV-354 TV9-107
TV-354A like above
TV-390 TV11-104
TV-392 TV11-104
TV-294 TV11-106
RT-400 1960-111
TV-400 TV10-135
427 Eight-135
TV-440 TV11-103
TV-444 TV11-103
T-500 1958-119
CR-501 Eleven-98
CR-503 Eleven-98
CR-505 Eleven-98
B569 1954-86
B570 1954-06
B572 1954-86
E574 1954-87
B573 1954-37
C-579 1955-86
D-579 1956-105
C-580 1955-66
C-583 1955-67
C-584 1955-67
D-590 1956-105
D-591 1956-105
D-592 1956-106
D-593 1956-106
D-597 1956-107
D-598 1956-106
T-600 1959-100
610 One-143
620 (late) One-144
623 One-145
B649 1954-38
650 One-146

Philco (Continued)

B650 1954-88
B651 see 53-651
B652 like 53-651
B656 see 58-651
C650 like B650
C-661 1955-68
D-661 like C-662
C-662 1955-68
C-663 1955-69
D-668 like C-662
C-667 1955-70
E-670 1957-95
F-671 like E-670
E-672 1957-95
F-678 like E-872
E-875 1957-95
F-675 like E-875
E-876 1957-95
F-675 like E-876
E-878 like C-667
G-881 1959-111
H-691 1959-112
T-709 1958-120
T-700X } Like
T-701 } T-700
T-702 1958-104
T-708 1964-111
M-709 1964-112
B710 1954-86
B711 1954-86
M-711 like M-712
B712 1954-87
B712X 1954-88
M-712 1954-118
B714 1954-87
M-714 1964-118
M-715 1964-112
C-716 1955-66
M-716 1954-113
D-717 1955-105
C-718 1955-55
D-719 1955-105
M-719 1964-114
C-720 1955-56
C-721 1955-57
C-722 1955-67
C-723 1955-67
C-724 1955-67
D-725 1956-107
D-725 1956-105
D-727 1956-106
D-728 1955-106
D-730 1956-106
D-734 1956-107
D-735 1956-105
D-737 1956-107
D-738 1956-107
E-740 1957-96
E-742 1957-95
F-742 1958-122
G-747 1960-115
E-748 1957-98
G-749 1959-112
F-750 1958-122
G-751 1959-113
F-752 1958-122
G-753 1959-113
F-754 1958-122
G-755 1959-113
F-758 1958-122
H-759 1960-115
F-760 1958-123
G-761 like F-780
H-762 1960-115
H-763 1960-116
H-764 1960-116
H-765 1960-117
J-769 1961-121
J-772 1961-121
J-773 1961-121
J-774 1961-121
J-775 1961-121
K-777 1962-81
K-778 1962-81
K-780 1962-84
K-782 1962-84
K-783 1962-84
K-784 1962-84
K-785 1962-84
L790 1963-105
L792 1963-105
L794 1963-105
L795 1963-106

Philco (Cont.)

L796 1963-105
L797 1963-106
M-798 1964-114
L799 1963-108
T-800 1958-120
B82 Nine-82
T-802 1961-124
T-803 1982-79
B894 like 53-804
T-804 1963-105
T-805 1963-110
F-809 1958-124
E-810 1957-98
E-812 1957-95
F-818 1958-124
E-814 1957-98
F-815 1958-124
E-816 1957-98
F-817 1958-124
E-818 1957-98
G-820 1959-114
G-822 1959-114
G-824 1959-114
G-826 1959-114
G-828 1959-114
H-829 1960-118
H-820 1966-119
H-822 1960-119
H-834 1960-119
H-838 1960-119
H-838 1960-117
J-838 1961-121
J-840 1961-121
J-842 1961-121
J-845 1961-121
J-846 1961-121
847 1958-182
K-847 1962-84
848 1958-132
also 1958-134
and 1958-137
K-849 1962-80
K-850 1962-80
K-851 1962-84
K-852 1962-84
K-853 1962-84
K-855 1962-84
K-855 1962-84
K-858 1962-84
L880 1963-105
L881 1963-105
L882 1968-108
L883 1963-105
L884 like L882
L885 1963-105
L886 1963-105
L888 1963-105
M-869 1964-112
M-871 1964-113
M-872 1964-113
M-874 1964-113
M-875 1964-113
T-900 like T-700
T-901 1961-125
T-902 1963-111
T-902(128) 1964-115
T-905 1958-112
T-907 1964-115
T-911 1964-120
K-912 1962-82
K-914 1962-82
925 1958-188
L925 1963-108
L927 1963-108
L928 1968-108
L929 1963-108
M-935 1964-114
M-937 1964-114
M-938 1964-114
M-939 1964-114
B958 like 53-956
B982 like 53-950
F-963 1958-123
G-963 like F-963
H-973 1960-120
F-974 1958-125
G-974 1959-115
E-975 1957-100
F-975 like E-976
G-978 1959-116
J-996 1961-125
J-997 1961-127
SA-1000 1959-120

Philco (Continued)

T-1000 1960-121
SA-1005 1960-122
1225 Eight-125
C-1334 1955-71
C-1240 1955-71
C-1341 1955-71
C-1342 1955-71
C-1343 1955-71
D-1345 like D-727
C-1347 1955-71
C-1348 1955-72
B1348 1954-89
B1350 see 58-1350
E-1351 1957-102
B1352 1954-89
E-1358 1957-102
E-1355 1957-102
E-1356 } Similar
E-1357 } to
E-1358 } C-1234
E-1350 1957-102
E-1362 Like C-1347
E-1363 1957-102
E-1370 1957-96
F-1372, -X 1958-126
G-1372 like F-1372
F-1274 1958-128
G-1375 like F-1272
H-1283 1960-122
H-1385 1960-123
F-1402 1958-126
G-1408 like F-1402
F-1404 1958-126
G-1405 like F-1402
F-1406 1958-127
G-1407 1959-119
F-1408 1958-127
G-1409 1959-118
G-1410 1959-117
H-1410 1960-123
G-1412 1960-124
H-1413 1960-123
K-1414 1962-87
H-1415 1960-123
M-1415 1964-123
H-1416 1960-124
M-1421 1964-122
J-1422 1961-128
K-1424 1962-87
J-1425 1961-128
K-1425 1962-88
M-1428 1964-119
L-1429 1963-113
L-1430 1964-119
F-1500 1958-130
SA-1500 1959-122
J-1525 1961-128
K-1525 1962-89
L-1528 1963-113
M-1529 1964-122
L-1522 1963-114
N-1537 1964-123
F-1600 1958-128
G-1605, S 1959-120
G-1608 1960-124
H-1616 1960-124
H-1618 1960-124
J-1625 1961-128
K-1628 1962-90
K-1632 1962-91
L-1650 1963-115
L-1651 1964-124
L-1652 1964-124
L-1652 1964-124
L-1655 1964-129
L-1657 1964-129
L-1679 1964-129
F-1700 1958-128
F-1702 1958-128
G-1705, S 1959-122
G-1707, S 1959-122
G-1708S 1959-121
G-1710S 1960-125
H-1714 1960-126
B1750 1954-89
B1752 1954-89
B1758 1954-89
C-1755 1955-71
E-1752 } Similar
E-1764 } to C-1347
E-1753 1957-102
E-1755 1957-108
E-1756 1957-105
F-1800 1958-131

Philco (Continued)

F-1801 1958-131
F-1802 1958-128
F-1802 1958-128
F-1804 1958-181
F-1805 1958-128
G-1806S 1959-121
G-1807S 1959-121
G-1808S 1959-121
G-1809S 1959-121
G-1811S 1959-121
G-1812S 1959-121
A-T1814 TV7-107
A-T1810 TV7-107
A-T1817 TV7-107
A-T1818 TV7-107
A-T1856 TV7-107
A-T1858 TV7-107
A-T1887 TV7-107
A-T1888 TV7-107
SA-2000 1959-121
E2002C TV12-119
UE2002C TV12-119
F2008I, SS } Use
UF2008+ } 8E11
F2005 } see
UF2005 } TV14-95
E2004F TV12-119
E2004G TV12-119
E2004SP TV12-119
UE2004F TV12-119
UE2004G TV12-119
UE2004SP TV12-119
E2008SA uses 7E12
UE2006SA use 7E11
H-2010S TV17-111
H-2010SBL TV17-111
A-T2220 TV7-107
A-T2222 TV7-107
A-T2283 TV7-107
A T2234 TV7-107
A-T2262HM uses 81
and H-1
A-T2268 uses
91A and J-2
A-T2271HM uses
91A and J-2
A-T2272 uses
81 and H-1
A-T2274 TV7-107
A-T2277 TV7-107
A-T2279 TV7-107
A-T2280 TV7-107
A-T2281 TV7-107
A-T2288 TV7-107
A-T3289 TV7-107
A-T2290 TV7-107
A-T2292 TV7-107
A-T2294 TV7-107
L2600BU TV21-89
L2500CBU TV21-89
L2602++ TV21-89
L2504++ TV21-89
M2610BE TV22-95
M2512++ TV22-95
M2514++ TV22-95
M2615GD TV22-95
F3035+ uses 8H20
UF3035+ uses 8H20U
H-3039A TV17-101
F3041+ use 8H25
UF2041+ use 8H25U
F3042F TV14-111
F3042G TV14-111
UF3042F TV14-111
UF3042G TV14-111
F3042+ use 8H25
UF3043+ use 8H25U
F3044A TV14-111
UF3044A TV14-111
F3044S } Use
F3044WA } 8H25
UF3044S } Use
UF3044WA } 8H25U
H-3046↗ TV17-101
UH-3046↗ TV17-101
H-3047↗ TV17-101
UH-3047↗ TV17-101
H-3048GL TV17-101
H-2049BL TV17-101
J-3049L TV18-115
UJ3049L TV18-115
G-3050AB, GL, PG,
use 9H25

Philco (Continued)

UG-3050AB, GL, PG,
use 9H25U
G-3052L, BL, WL,
use 9H25
UG-3052L, BL, WL,
use 9H25U
UH-3052L TV17-101
UH-3052WL TV17-191
H-3055↗ TV17-101
K2058CG TV19-115
UK3058CG TV19-115
K3059LB TV19-115
UK3059LB TV19-115
K3060BL, + TV19-115
K3218GD TV19-115
F3202C TV14-111
UF3202C TV14-111
F3204B, -L TV14-111
UF2204B TV14-111
UF3204L TV14-111
J3208 TV18-115
J3210PL TV18-115
UJ3210BL TV18-115
J3212AQ TV18-115
J3212G, GL TV18-115
UJ2212AQ TV18-115
UJ2212G TV12-115
UJ2212GL TV18-115
J3214SG TV18-115
J3214WL TV18-115
UJ2216SG TV18-115
UJ3216WL TV18-115
K3219BL see 12J27
L3219BU TV21-89
K3220GD, + TV19-115
UK3220GD TV19-115
UK3220+ TV19-115
L3221++ TV21-89
K3222WH, + TV19-115
UK3222SA TV19-115
UK3222WH TV19-115
K3223+ Use 12J27
K3224GD TV19-115
K3224SI TV19-115
L3225++ TV21-89
UK3226+ TV19-115
K3230GD TV19-115
UK3230GD TV19-115
L3232++ TV21-89
K3240GD, SL TV20-99
UK3248++ TV20-99
L3243BE TV21-89
K3244BK, SA TV20-99
L3244++ TV21-89
UK3244BK TV20-99
UK3244SA TV20-99
M3248WH } Use
M3250BK } 14J28
H-3407C TV17-117
UH-3407C TV17-117
H-3408C TV17-117
UH-3408C TV17-117
H-3410, ↗ TV17-117
UH-3410, ↗ TV17-117
H-3412↗ TV17-117
UH-3412L TV17-117
J3700C
UJ3700C } Use
J3702+ } Chassis
UJ3702+ } 11N51
J3704+
UJ2704+ } see
J3705BL } TV18-105
UJ2705+
J3712+
UJ3712+
K3720GB TV19-121
UK3720GB TV19-121
K3722BE, + TV19-121
UK3722BE TV19-121
UK2722CG TV19-121
K3724GD, + TV19-121
K3726RBE TV20-105
K3728RWH TV20-105
K3732++ TV20-106
K3733++ TV20-105
K3734++ TV20-105
L3740++ TV21-89
L3804BE TV21-89
L3804CBE TV21-89
L3808++ TV21-89
L3810++ TV21-89

Philco (Continued)

L3814RWH TV21-89
M3822GD TV22-95
M3824BK TV22-95
M3824WH TV22-95
M3826++ TV22-95
M3828RWH TV22-95
E4170 } Use
UE4170 } TV-320
E4202 TV12-115
UE4202 TV12-115
E4203 TV12-115
UE4203 TV12-115
E4204 TV12-115
E4204L TV12-115
UE4204 TV12-115
UE4204L TV12-115
E4205L, M TV12-115
UE4205L, M TV12-115
E4206SD TV12-115
E4206SL TV12-115
E4206STM TV12-115
UE4206SD TV12-115
UE4208SL TV12-115
UE4208STM TV12-115
E4207SC TV12-115
UE4207SC TV12-115
E4208S TV12-111
UE4208S TV12-111
F4219, -E TV14-101
F4210L TV14-101
UF4210, -E TV14-101
UF4210L TV14-101
F4212, -L TV14-101
UF4212, -L TV14-101
F4214STM TV14-101
F4214STN TV14-101
UF4214STM TV14-101
UF4214STN TV14-101
F4218, -L TV14-105
UF4216, -L TV14-105
G-4230E uses 9L41
UG-4230E see 9L41U
G-4231E, + see 9L35
UG-4231+ see 9L35U
G-4232L, M use 9L35
UG-4222+ use 9L35U
G-4234SL } Use
G-4234SM } 9L35
UG-4234SL } Use
UG-4234SM } 9L35U
G4240L, M TV16-117
UG4240L, M TV15-117
G4242L, M TV15-105
UG4242L, M TV16-105
H-4248BE TV17-107
UH-4248BE TV17-107
H-4250, L TV17-107
UH-4250, L TV17-107
H4251E uses 10L32
UH4251ER See 10L32
H4252MR See 10L22
H4253L, M See 10L31
UH4253↗ See 10L31U
H-4254S, ↗ TV17-117
UH-4254S TV17-117
UH-4254SL TV17-117
J4223+ } Use
UJ4223+ } 11N51A
J4324+ } see
UJ4324+ } TV18-105
K4338++ TV20-105
K4331MR TV20-105
K4332++ TV20-105
K4333MR TV20-105
K4335++ TV20-105
K4336++ TV20-105
L4338BK, BZ
uses 12N50A
L4340++ TV21-89
L4341++ TV21-89
L4343++ TV21-89
M4350++ TV22-95
M4500++ TV22-95
M4502++ TV22-95
M4504++ TV22-95
M4508M+ TV22-95
M4512++ TV22-95
M4518++ TV22-95
M4519++ TV22-96
M4520++ } Use
M4522++ } 14N51
M4524++ } Chassis
M4590++ TV22-95
M4591++ TV22-95

Philco (Continued)

M4592S++ TV22-95
E4600 TV12-115
UE4600 TV12-115
E4601SL,SM TV12-115
UE4601SL TV12-115
UE4601SM TV12-115
E4602 TV12-115
E4602L TV12-115
E4602TL TV12-115
E4602TM TV12-115
UE4602 TV12-115
UE4602L TV12-115
UE4602TL TV12-115
UE4602TM TV12-115
E4602L, M TV12-115
UE4603L, M TV12-115
E4604 TV12-115
E4604HM TV12-115
UE4604 TV12-115
UE4604HM TV12-115
E4605 TV12-111
E4605C TV12-111
E4605T TV12-111
UE4605 TV12-111
UE4605C TV12-111
UE4605T TV12-111
E4606L, + TV12-115
UE4606+ TV12-115
E4607 TV12-111
E4607L, T TV12-111
UE4607, L TV12-111
UE4607T TV12-111
C4608 Nine-82
E4608 TV12-115
UE4608 TV12-115
E4610N TV12-115
UE4610N TV12-115
E4612G TV12-115
UE4612G TV12-115
E4614S TV12-115
E4614SL TV12-115
UE4614S TV12-115
UE4614SL TV12-115
E4615M, T TV12-115
F4618, L use 8L41
UC4618 } Use
UF4618, L } 8L41U
F4620SL TV14-101
F4620SM TV14-101
UF4620SL TV14-101
UF4620SM TV14-101
F4621S, SL use 8L43
UF4621S uses 8L43U
F4622, -L TV14-101
UF4622, -L TV14-101
F4623 uses 8L71
UF4623 uses 8L71U
F4624 TV14-101
UF4624 TV14-101
F4625S, SL use 8L43
UF4625S uses 8L43U
F4626, -L TV14-105
UF4626, -L TV14-105
F4627, L use 8L72
UF4627, L use 8L72U
F4628, L use 8L41
UF4628, L use 8L41U
F4630, L use 8L43
UF4630, L use 8L43U
F4632 TV14-101
UF4632 TV14-101
F4634, L use 8L43
UF4634, L use 8L43U
F4635, L use 8L43
UF4635, L use 8L43U
G-4640L, W use 9L35
UG-4640L, M, W
use 9L35U
G-4641L, M use 9L35
UG-4641+use 9L35U
G-4642+ use 9L41
UG-4642+ use 9L41U
G-4646L, M use 9L41
UG-4846+ use 9L41U
G-4848L, M use 9L41
UG-4648+ use 9L41U
G-4650L, M use 9L41
UG-4850+ use 9L41U
G-4652+ like 9L41
G4554M, W TV16-105
UG4554M, W TV16-105
G4555SM TV15-117
UG4555SM TV15-117
G4658↗ TV16-117

Philco (Continued)

UG4658✓✓	TV16-117
G4660✓✓	TV16-117
UG4660✓✓	TV16-117
G4662M, P	TV16-117
G4664P	TV16-117
UG4664P	TV16-117
H4667✓ uses 10L31	
UH4667✓ See 10L31U	
H-4668, L	TV17-107
UH-4668, L	TV17-107
H-4670, ✓	TV17-107
UH-4670, ✓	TV17-107
H-4672, ✓	TV17-107
UH-4672, ✓	TV17-107
H4673✓ uses 10L32	
UH4673✓ See 10L32U	
H-4674, ✓	TV17-117
UH-4674, ✓	TV17-117
H4675✓ uses 10L32	
UH4675✓ See 10L32U	
H-4676, ✓	TV17-117
UH-4676, ✓	TV17-117
H4677✓ uses 10L31	
UH4677✓ See 10L31U	
H-4678, W	TV17-117
UH-4678, ✓	TV17-117
H4679✓ uses 10L31	
UH4679✓ See 10L31U	
H-4680, ✓	TV17-117
UH-4680, ✓	TV17-117
H-4682, ✓	TV17-117
UH-4682, ✓	TV17-117
H-4690, ✓	TV17-117
UH-4690, ✓	TV17-117
H-4692W	TV17-117
UH-4692W	TV17-117
H-4696✓✓	TV17-117
UH-4696✓	TV17-117
H-4698R, ✓	TV17-117
UH-4698✓	TV17-117
E4700N	TV12-115
UE4700N	TV12-115
G4710L, M	TV16-105
UG4710L, M	TV16-105
G4720L, N	TV16-105
UG4720L, M	TV16-105
H-4730, W	TV17-117
UH-4730, W	TV17-117
H4800✓ uses 10L31	
UE4800	TV12-115
UH4800✓ See 10L31U	
H4802✓ uses 10L31	
UE4802L	TV12-115
UE4802M	TV12-115
UH4802✓ See 19L31U	
J4804+ through J4838W	All use Chassis 11N51A etc.
UJ4804+ through UJ4838W	TV18-105
UE4804L	TV12-115
H-4807✓	TV17-117
UH-4807✓	TV17-117
H4809✓ uses 10L31	
UH4809M See 10L31U	
K4829MR	TV20-106
L4829MR as above	
K4831MR	TV20-105
K4832MR	TV20-105
K4833++	TV20-106
K4834++	TV20-106
K4835++	TV20-106
K4837++	TV20-106
K4840++	TV20-105
K4841++	TV20-105
K4842++	TV20-105
K4843++	TV20-106
K4844++	TV20-105
K4845++	TV20-106
K4846++	TV20-105
K4847++	TV20-105
K4848++	TV20-105
K4840++	TV20-105
K4850++	TV20-105
K4852WA	TV20-105
K4853MR	TV20-106
K4854++	TV20-105
K4857++	TV20-105
L4863++	TV21-89
K4864++	TV20-105
L4865CMR	TV21-89
L4866++	TV21-89
L4867++	TV21-89

Philco (Continued)

L4868++	TV21-89
L4869++	TV21-89
L4870++	TV21-89
L4871MR	TV21-89
L4871WA	TV21-89
L4872++	TV21-89
L4873++	TV21-89
L4874++	TV21-89
L4875++	TV21-89
L4876++	TV21-89
L4877++	TV21-89
L4879++	TV21-89
L4880++	TV21-90
L4882++	TV21-90
L4886++	TV21-90
L4888++	TV21-90
L4890++	TV21-90
L4896++	TV21-90
J4904+ / UJ4904+	Use 11N56
K4908++	TV20-105
K4910++	TV20-105
L4923++	TV21-90
L4924++	TV21-90
L4926++	TV21-90
M4936WA uses 14N51	
C-5690(HR)	1957-93
P-5701	1958-132
P-5702	1958-134
P-5703	1958-135
C-5705	1958-132
C-5707	1958-135
C-5709	1958-135
M-5741	1957-94
M-5741	1958-136
P-5801	1958-137
P-5803	1958-138
C-5809	1958-139
M-5841	1958-140
M-5944	1960-114
E6200	TV12-115
UE6200	TV12-115
E6204L	TV12-115
E6204M	TV12-115
UE6204L	TV12-115
UE6204M	TV12-115
F6206SL	TV14-101
F6206SM	TV14-101
UF6206SL	TV14-101
UF6206SM	TV14-101
E6602L	TV12-115
E6602M	TV12-115
E6602T	TV12-115
E6602TL	TV12-115
UE6602L	TV12-115
UE6602M	TV12-115
UE6602T	TV12-115
UE6602TL	TV12-115
E6604L	TV12-115
E6604M	TV12-115
E6604T	TV12-115
UE6604L	TV12-115
UE6604M	TV12-115
UE6604T	TV12-115
E6606	TV12-111
UE6606	TV12-111
E6608TN	TV12-111
UE6608TN	TV12-111
E6610L	TV12-111
E6610M	TV12-111
UE6610L	TV12-111
UE6610M	TV12-111
F6620SL	TV14-101
F6620SM	TV14-101
UF6620SL	TV14-101
UF6620SM	TV14-101
F6624T	TV14-105
F6624TL	TV14-105
UF6624T	TV14-105
UF6624TL	TV14-105
G6628L, M	TV16-117
UG6628L, M	TV16-117
G6632✓	TV16-117
UG6632✓	TV16-117

Philco (Cont.)

M9300++	TV22-96
M9500WA	TV22-96
M9502MR	TV22-96

PLYMOUTH

300	1964-21
841	1956-91
849	1957-72

PILOT RADIO

B-1	Four-117
T-1	Four-117
TP-22	Five-105
T-121	Three-99
T-122	Three-99
173	Five-105
T-186	Four-117
T-521	Eight-137
T-570	Eight-138
T-601	Eight-140
T-741	Eight-139

PONTIAC

983578	1963-28
983579	1963-23
983687	1963-23
983873	1964-24
983874	1964-22
983875	1964-24
984171	Seven-168
984172	Seven-167
984247	Nine-144
984570	Ten-165
984592	Eleven-139
984817	1953-145
984961	1955-104
988568	like 984961
988569	1956-162
988623	1957-161
988671	1958-38
988672	1958-40
988822	1958-44
968823	1953-42
988837	1958-46
986976	1959-26
988977	1959-30
988978	1959-20
989692	1962-18
989693	1961-37
989792	1961-26
989831	1962-16

PRIVAT-EAR CORP.

DL-101	Twelve-106

RCA VICTOR

HFP	1958-141
1BT2	1959-131
1BT3	1959-132
1BT32	1959-132
1BT34	1959-132
1BT36	1959-132
1BT58	1958-142
1BX5	1958-143
1BX6	1958-143
1BX7	1958-143
1C1E / 1C2	similar to RC-1202A
1C3 like C-3	
1C5 like C-4	
1CL1 like PC-1	
1F1	1961-129
1F2	1961-129
1R81	Twelve-107
1RA11	1962-94
1RA20	1962-94
1RA23	1962-94
1RA25	1962-94
1RA26	1962-94
1RA30	1962-96

R. C. A. (Continued)

1RA33	1962-96
1RA35	1962-96
1RA36	1962-96
1RA42	1962-96
1RA43	1962-96
1RA44	1962-96
1RA45	1962-96
1RA50	1962-96
1RA51	1962-96
1RA52	1962-96
1RA55	1962-96
1RA60	1962-96
1RA61	1962-96
1RA64	1962-96
1RA65	1962-96
1RC30	1962-98
1RC31	1962-98
1RC34	1962-98
1RD11	1962-94
1RD30	1962-95
1RD32	1962-95
1RD33	1962-95
1RD37	1962-95
1RD40	1962-95
1RD41	1962-95
1RD44	1962-95
1RD45	1962-95
1RD50	1962-95
1RD52	1962-95
1RD53	1962-95
1RD56	1962-95
1RD60	1962-95
1RD61	1962-95
1RD63	1962-95
1RD65	1962-95
1RG11	1962-93
1RG14	1962-93
1RG15	1962-93
1RG31	1962-97
1RG33	1962-97
1RG34	1962-97
1RG41	1962-97
1RG43	1962-97
1RG46	1962-97
1RH10	1962-92
1RH11	1962-92
1RH12	1962-92
1RH13	1962-92
1RJ19	1962-92
1T1	1961-130
1T2	1961-130
1T3	1961-130
1T4	1960-133
1T5	1960-131
1TC4	1961-130
1TP1	1961-132
1TP1E	1962-92
1TP1HE	1962-92
1TP1JE	1962-92
1TP2	1961-132
1VA14	1962-105
1VC15	1962-105
1-VE-0	1962-101
1-VE-1	1962-101
1-VE-2	1962-101
1VE075	1962-101
1VE086	1962-101
1VE094	1962-101
1VE105	1962-101
1VE106	1962-101
1VE107	1962-101
1VE205	1962-101
1VE207	1962-101
1VE224	1962-101
1VE229	1962-101
1VE246	1962-101
1-VF-1	1962-101
1-VF-2	1962-101
1VF105	1962-101
1VF106	1962-101
1VF107	1962-101
1VF205	1962-101
1VF207	1962-101
1VF224	1962-101
1VF229	1962-101
1VF246	1962-101
1YC11	1962-104
1X	Four-118
1X1 uses RC-1202A	
1X2	Four-118
1X2	1961-134
1X3	1961-134

R. C. A. (Continued)

1X4	1961-134
1X5JE like X-4	
1X51	Twelve-112
1X52	Twelve-112
1X53	Twelve-112
1X54	Twelve-112
1X55	Twelve-112
1X56	Twelve-112
1X57	Twelve-112
1X591	Twelve-111
1X592	Twelve-111
AK-1	1959-127
BR-1	1961-139
C-1	1959-133
PC-1	1960-127
PT-1	1960-128
PX-1	uses RC-1188
T-1	1960-128
TC-1	1960-132
TR-1A	1956-125
TX-1	1960-132
X-1	1959-133
2B400	Twelve-113
2B401	Twelve-113
2B402	Twelve-113
2B403	Twelve-113
2B404	Twelve-113
2B405	Twelve-113
2BX63	1953-95
2C511	1953-97
2C521	1953-96
2ES3	Twelve-114
2ES31	1953-104
2ES31E	1953-104
2ES31Q	1953-104
2ES38	Twelve-114
2ES38E	1953-104
2ES38Q	1953-104
2R51	1953-98
2R52	1953-98
2S7	1953-99
2S7ED	Nine-95
2T51	TV5-129
2T60	TV5-129
2T81	TV5-115
2US7	Twelve-114
2X61	1953-100
2X62	1953-100
2X621	1953-101
2XF91	1953-102
2XF931	1953-102
2XF932	1953-102
2XF933	1953-102
2XF934	1953-102
2XF935	1953-102
C-2	1960-127
HRD-2	1958-144
SA-2	1959-124
SES-2LE	1960-136
T-2	1960-128
X-2	1959-133
XF-2	1960-129
3-BX-671	1954-92
3-BX-672	1954-92
3-HES-5	1954-91
3-HES-5A	1954-91
3-HS-61	1955-72
3RA1	1963-116
3RA2	1963-116
3RA3	1963-119
3RA5	1963-118
3RA6	1963-118
3RA16	1963-116
3RA20	1963-116
3RA25	1963-116
3RA27	1963-116
3RA30	1963-119
3RA31	1963-119
3RA32	1963-119
3RA34	1963-119
3RA50	1963-118
3RA51	1963-118
3RA52	1963-118
3RA54	1963-118
3RA60	1963-118
3RA61	1963-118
3RA63	1963-118
3RA65	1963-118
3RB1	1963-130
3RB3	1963-130
3RB16	1963-130
3RB31	1963-130
3RB32	1963-130
3RB34	1963-130

R. C. A. (Continued)

3RC1	1963-134
3RC2	1963-132
3RC4	1963-128
3RC5	1963-128
3RC7	1963-128
3RC11	1963-134
3RC14	1963-134
3RC21	1963-132
3RC24	1963-132
3RC41	1963-128
3RC42	1963-128
3RC44	1963-128
3RC51	1963-128
3RC76	1963-128
3RD1	1963-116
3RD3	1963-116
3RD4	1963-117
3RD5	1963-117
3RD6	1963-117
3RD10	1963-116
3RD30	1963-116
3RD35	1963-116
3RD37	1963-116
3RD40	1963-117
3RD41	1963-117
3RD45	1963-117
3RD49	1963-117
3RD50	1963-117
3RD52	1963-117
3RD54	1963-117
3RD57	1963-117
3RD61	1963-117
3RD65	1963-117
3RD67	1963-117
3RD69	1963-117
3RG1	1963-126
3RG3	1963-126
3RG6	1963-126
3RG8	1963-135
3RG14	1963-126
3RG31	1963-126
3RG32	1963-126
3RG33	1963-126
3RG34	1963-126
3RG61	1963-126
3RG64	1963-126
3RG81	1963-135
3RH1	1962-124
3RH2	1963-124
3RH3	1963-124
3RH10	1963-124
3RH21	1963-124
3RH22	1963-124
3RH31	1963-124
3RH32	1963-124
3RH34	1963-124
3-US-5	1955-74
3-US-5A	1955-74
3VA11 uses RS-197	
3VC14 uses RS-198	
3-VC-35	1963-120
3VC64	1964-131
3VC82	1964-131
3-VE-0	1963-121
3-VE-1	1963-121
3-VE-2	1963-121
3-VF-1, X	1963-121
3-VF-2, X	1963-121
3VF305	1964-134
3VF306	1964-134
3VF340	1964-134
3VF346	1964-134
3VF349	1964-134
3VF405	1964-134
3VF446	1964-134
3VF516	1964-134
3VF534	1964-124
3VF604	1964-134
3VF619	1964-134
3VF646	1964-134
BC-3	1959-131
C-3	1960-127
SA-3	1959-124
SES-3	1960-136
X-3	1960-127
XF-3	1960-129
4C531	1955-76
4C532	1955-76
4C533	1955-75
4C534	1955-76
4C535	1955-76
4C541	1955-76
4C542	1955-75
4C543	1955-76
4C544	1955-75
4C545	1955-76
4C547	1955-76

R. C. A. (Continued)

4C671	1955-75
4C672	1955-75
4RA1	1964-132
4RA3	1964-132
4RA4	1964-132
4RA10	1964-132
4RA14	1964-132
4RA15	1964-132
4RA30	1964-132
4RA31	1964-132
4RA34	1964-132
4RA41	1964-132
4RA42	1964-132
4RA45	1964-132
4RC84 use RC-1209C	
4RD4	1964-132
4RD5	1964-132
4RD40	1964-132
4RD41	1964-132
4RD44	1964-132
4RD51	1964-132
4RD52	1964-132
4RD55	1964-132
4RG1	1964-137
4RG3	1964-137
4RG5	1964-143
4RG6	1964-143
4RG2 / 4RG21 / 4RG23 / 4RG26	Use RC-1208B See 1962-97
4RG11	1964-137
4RG12	1964-137
4RG16	1964-137
4RG31	1964-137
4RG34	1964-137
4RG51	1964-143
4RG52	1964-143
4RG56	1964-143
4RG61	1964-143
4RG62	1964-143
4RG66	1964-143
4RH1 / 4RH11 / 4RH12 / 4RH16	Use RC-1199E like RC-1199D
4RS3 / 4RS31 / 4RS34	Like RC-1210D + clock
4T101	TV6-125
4T141	TV6-125
4VA14 / 4VA38 / 4VA50	Use RS-197 1962-105
4VC28 / 4VC42	Use RS-198
4VC51 uses RS-175C	
4VC64	1964-131
4VC69	1964-131
4VC82	1964-131
4VE045	1964-131
4VE046	1964-131
4VF095	1964-140
4VF096	1964-140
4VF105	1964-140
4VF106	1964-140
4VF114	1964-140
4VF124	1964-140
4VF145	1964-140
4VF146	1964-140
4VF155	1964-140
4VF156	1964-140
4VF206	1964-140
4VF224	1964-140
4VF282	1964-140
4VF289	1964-140
4VF304	1964-138
4VF325	1964-138
4VF326	1964-138
4VF348	1964-138
4VF849	1964-138
4VF405	1964-138
4VF446	1964-138
4VF464	1964-138
4VF480	1964-138
4VF488	1964-138
4VF534	1964-138
4X	One-156
4X3	One-156
4X4	One-156
4X551	1955-76
4X552	1955-76
4X553	1955-76
4X554	1955-76
4X555	1955-76
4-X-641	1954-94
4X661	1955-78

HOW TO USE THIS INDEX

This Master INDEX will tell you in which SUPREME volume and on what page the material you need is listed. Please refer to the easy-to-follow charts on page 2, and to the explanation at top of page 3, for guidance.

R. C. A. (Continued)

4Y511 1956-79
BCS-4 1959-131
C-4 1960-120
R-4 One-157
SES-4JE 1950-136
SES-5 1959-128
X-4 1960-180
XF-4 1950-129
5BX41 1955-80
5C581 1955-81
5C591 1955-82
5C592 1955-82
5Q5 Three-100
5Q55 Three-100
5Q56 Three-100
5T6 One-158
5T7 One-158
5T8 One-158
5X5 Three-104
5X560 1955-76
5X562 1955-76
5X564 1955-76
P-5 Five-106
TRK-5 Three-101
TT-5 Three-101
X-5 like 6-X-641
6-B-4A 1956-115
6-B-4B 1956-115
6-B-5 1956-115
6BX5 1955-88
6BX6 1955-88
6BX8A 1956-116
6BX8B 1956-116
6BX41 uses RC-1147
6BX63 uses RC-1115
6BY4A 1956-120
6BY4B 1956-120
6C5 1956-123
6C8 uses RC-1145
6-EMP-1A 1956-113
6-EMP-1B 1956-113
6-EMP-2A 1956-113
6-EMP-2B 1956-113
6-EMP-3A 1956-113
6-EMP-3B 1956-113
6ES3, 6ES4---RS-142
6-ES-5 1956-114
6-EY-1 1956-109
6-EY-2 1956-109
6-EY-2A 1958-152
6-EY-2B 1958-152
6-EY-3C 1958-152
6-EY-15 1956-110
6-HFT-1 1956-125
6-HF-4 1956-111
6-HF-5 1956-110
6Q7 Three-100
6-RD-3 1956-112
6RF9 1955-83
6T53 TV5-115
6T54 TV5-115
6T64 TV5-115
6T65 TV5-115
6T71 TV5-115
6T72 TV5-123
6T74 TV5-115
6T75 TV5-115
5T76 TV5-115
6T84 TV5-115
6T86 TV5-115
6T87 TV5-115
6X2 Five-107
6X5 1956-122
6X7 1956-117
6X8 uses RC-1146
6XD5 1956-118
6XF9 1955-86-87
6XY5A 1956-119
6XY5B 1956-119
BX6 Ten-119
R-6 One-157
SHF-6 1958-151
7BT9J 1956-124
7BT10K 1956-121
7BX5 uses RC-1149
7BX6 1957-107
7BX7 1957-107
7BX8 1957-110
7BX9H 1957-108
7BX10 Like RC-1125
7C6 1956-123
7C6J as above
7C9 similar 4C541
7-EMP-1J 1957-111

R. C. A. (Continued)

7-EMP-1K 1957-111
7EMP2 uses ES-153
7-EP-2 1957-112
7-EP-45 1957-112
7-ES-6H 1957-112
7-ES-6J 1957-112
7-EY-1 1956-113
7-EY-2HH 1956-114
7-EY-2JJ 1956-114
7HF4 uses RS-146F
similar to ES-146C
7-HF-5 1957-113
7-HF-45 1957-114
7T103, -B TV6-121
7T104, -B TV6-121
7T111B TV6-121
7T112, -B TV6-121
7T122, -B TV6-121
7T128, -B TV6-121
7T124 TV6-121
7T125B TV6-121
7T122 TV6-121
7T142 TV6-121
R-7 One-159
R-7-A One-160
SES-7 Uses RS-175
SHF-7 1958-151
8B41 Ten-122
8B42 Ten-122
8B43 Ten-122
6BT7 1957-115
8BT8 1957-115
8BT9 1958-145
8BT10K 1957-116
8BX5 Nine-93
8BX5 Ten-121
8BX5 1958-149
8BX6 1958-150
8BX6 Nine-94
8BX7 1958-150
8BX54 Ten-121
8BX55 Ten-121
8C5 1958-145
8C6 1958-145
8C7 1957-117
8C8 1957-117
8C51 1958-145
8-EY-4DJ 1957-114
8-EY-4FK 1957-114
8-EY-31 1958-152
8F42 Nine-95
8HF45P 1958-151
8PT7010 TV12-129
8PT7011 TV12-129
8PT7012 TV12-129
8PT7014 TV12-129
8PT7020 TV12-129
8PT7021 TV12-129
8PT7022 TV12-129
8PT7024 TV12-129
8R71 Nine-97
8R72 Nine-97
8R74 Nine-97
8R75 Nine-97
8R76 Nine-97
8V7 Nine-96
8V90 Nine-102
8V91 Nine-102
8V112 Nine-108
8V151 Nine-99
8X5 1958-145
8X6 1958-145
8X8 1957-118
8X9 like 4X641
8X51 1958-145
8X52 Nine-104
8X521 Nine-103
8X522 Nine-103
8X541 Nine-105
8X542 Nine-105
8X544 to 8X547
see set 8X541
8X547 Nine-105
8X681 Nine-107
8X682 Nine-107
SHF-8 1958-154
R-8 One-161
U-8 Three-104
9BT9 1958-146
9BX5 Ten-121
9BX56 Ten-122
9C7 1958-155
9C8 1958-155

R. C. A. (Continued)

9-ED-2KF 1958-152
9-ED-2LE 1958-152
9-ED-32 1958-154
9-ES-5H 1958-152
9-ES-5JE 1958-152
9-ES-5H 1958-158
9-ES-5J 1958-153
9EY2 Ten-127
9EY31 Ten-127
9EY22 Ten-127
9EY85 Ten-127
9EY36 Ten-127
9T57 TV5-115
9T77 TV5-115
9T79 TV5-115
9T89 TV5-115
9T105 TV6-121
9T125 TV6-121
9T128 TV6-121
9T147 TV6-121
9T256 TV5-123
9TC249 uses KC824B
9TX2 1959-180
9TX-5U Three-198
9US5H 1958-156
9US5KE 1958-156
9W106 Ten-121
9X10 1958-155
9XL1 1958-157
9X551 Ten-124
9X562 Ten-124
9X571 Ten-125
9X572 Ten-125
9X641 Ten-125
9X642 Ten-125
9X651 Ten-126
9X652 Ten-126
9T7 Ten-128
9T51 Ten-129
9T510 and 9T511
similar to 9T51
R-9 One-159
SHF-9 1958-154
10X Four-120
BP-10 Four-119
R-10 One-162
U-10 Three-105
R-11 One-168
SHF-11 1959-126
SHS-11 1959-126
TPM-11 1961-140
12X Four-121
12X2 Four-121
R-12 One-161
SHF-12 1959-127
TPM-12 1961-140
13K One-164
SHF-12 1959-127
TPM-13 1961-140
VC-13 1961-140
VCR-13 1961-140
14PD8053, U through
14PD8055, TV14-140
14PD8057 TV14-140
14PD8057U TV14-140
14PD9030, U
TV15-127
14PD9032, U
TV15-137
14PD9034, U
TV15-137
14PT8021(U) and
14PT8022 TV14-140
14PT9011, U
TV15-137
14PT9012, U
TV15-137
14S7052, U TV12-127
14S7070, U TV12-127
14S7071, U TV12-137
14S7074, U TV12-137
14S7062, U } Similar
14S7063, U } to
14S7069, U } RCA
14S7072G, U } 14S7052
14S7073G, U } in
14S7079G, U } TV12-137
14VT8155 TV14-140
14VT8155U TV14-140
14VT8157 TV14-140
14VT8157U TV14-140
14X Four-122
SHP-14 1959-129

R. C. A. (Continued)

VC-14 1951-140
VCR-14 1951-140
15-BP Four-123
15-E 1953-104
15-E1 1953-104
15X Four-124
Radiola 16 One-155
15K Four-125
15T2 Four-125
15T8 Four-125
15T152 TV5-188
15X-1 Four-124
15X-2 Four-124
15X-8 Four-124
15X-4 Four-127
15X-11 Four-128
15X-18 Four-128
VC-16 1961-140
Radiola 17 One-166
17D8185, U TV14-121
17D8186, U TV14-131
17D8187, U TV14-181
17K Four-129
17K174K
uses KCS-66D
17PD8093 TV14-121
17PD8093U TV14-181
17PD8094 TV14-131
17PD8094U TV14-131
17PD8095 TV14-131
17PD8096U TV14-181
17PD9052, U
TV15-129
17PD9064, U
TV15-129
17PD9070, U
TV15-129
17PD9072, U
TV15-129
17PD9074, U
TV15-129
17PD9078, U
TV15-129
17PD9079, U
TV15-129
17PT6962 TV11-117
17PT6962U TV11-117
17PT8071 TV14-181
17PT8071U TV14-121
17PT8072 TV14-121
17PT8072U TV14-131
17PT9041, U
TV15-129
17PT9042, U
TV15-129
17PT9050, U
TV15-129
17PT9054, U
TV15-129
17PT9057, -U Use
KCS-118A, -B
17PT9059, U
TV15-129
17S849 TV8-115
17S349G, GU, U,
see above
17S350, -U TV8-115
17S350G, U TV8-115
17S351, -U TV8-115
17S252, -U TV8-115
17S260, -U TV8-115
17S851, -U TV8-115
17S450 TV9-121
17S450R, RU
TV10-151
17S451 TV9-121
17S451R, RU TV10-151
17S452 TV9-121
17S453R, RU
TV10-151
17S6022, U TV11-117
17S6025, U TV11-117
17S6026 as above
17S6027, U TV11-117
17S6082, U } Similar
17S6042, U } 17S6022
17S6044, U } +U, above
17S7090, U TV13-149
17S7092, U TV12-149
17S7093, U TV13-149
17S7099, U TV12-149
17T150 and 17T151
similar to 17T153

R. C. A. (Continued)

17T152 TV6-181
17T154
same as 17T152
17T155 TV6-131
17T160 TV5-131
17T152
same as 17T153
17T158 uses 17QP4
similar to 17T153
17T172
same as 17T153
17T172K
uses KCS-65D
17T173
same as 17T158
17T178K
same as 17T153
17T174 TV5-181
17T200 TV7-125
17T201 TV7-125
17T202 TV7-125
17T211 TV7-125
17T220 TV7-125
17T250DE TV7-132
17T251DE TV7-183
17T801, -U TV8-115
17T802, -U TV8-115
17T810, -U TV8-115
PM-17 1961-140
R-17-M One-171
VC-17 1951-140
PM-18 1961-140
Radiola 18 One-167
19K Four-181
U-20 Three-196
21D205, -U TV8-121
21D317, -U TV8-121
21D326, -U TV8-121
21D327, -U TV8-121
21D328, -U TV8-121
21D329, -U TV8-121
21D380, -U TV8-121
21D346, -U comb.
uses KCS-81D, E
21D258, -U TV8-121
21D868, -U TV8-121
21D876, -U TV8-121
21D877, -U TV8-121
21D378, -U TV8-121
21D279, -U TV8-121
21D880, -U TV8-121
21D641, U TV11-111
21D645, U TV11-111
21D647, U TV11-111
21D648, U TV11-111
21D652, U TV11-111
21D667, U TV11-111
21D670, U TV11-111
21D7174, U TV12-141
21D7175, U TV12-141
21D7176, U TV12-141
21D7177, U TV12-141
21D7215, U TV12-141
21D7216, U TV12-141
21D7217, U TV12-141
21D7225, U TV12-141
21D7227, U TV12-141
21D7425, U TV12-147
21D7427, U TV12-147
21D7445, U TV12-147
21D7446, U TV12-147
21D7447, U TV12-147
21D7479, U TV12-147
21D7485, U TV12-147
21D7487, U TV12-147
21D7488, U TV12-147
21D7505, U TV12-147
21D7506, U TV12-147
21D7507, U TV12-147
21D8281, U TV14-158
21D8282, U TV14-152
21D8205, U TV14-152
21D8206, U TV14-152
21D8207, U TV14-152
21D8525, U TV14-125
21D8526, U TV14-125
21D8527, U TV14-125
21D8528, U TV14-125
21D8545, U TV14-125
21D8546, U TV14-125
21D8547, U TV14-125
21D8565, U TV14-125
21D8566, U TV14-125
21D8567, U TV14-125

R. C. A. (Continued)

21D8588, U TV14-125
21D8505, U TV14-125
21D8507, U TV14-125
21D8508, U TV14-125
21D8528, U TV14-158
21D9182, U TV15-141
21D9185, U TV15-141
21D9187, U TV15-141
21D9195, U TV15-141
21D9197, U TV15-141
21D9475, U TV15-141
21D9477, U TV15-141
21D9495, U TV15-141
21D9496, U TV15-141
21D9497, U TV15-141
21D9515, U TV15-141
21D9530, U TV15-141
21D9524, U TV15-141
21DF8685, U } All
21DF8536, U } use
21DF8627, U } KCS-
21DF8646, U } -108K
21DF8549, U } -108L
21PD8115 TV14-117
21PT9090 Uses
KCS-117A
21PT9095, U
TV15-125
21RD8525 uses
KCS-108H
21RD9675, U
TV15-141
21RD9676, U
TV15-141
21RD9677, U
TV15-141
21RD9690, U
TV15-141
21RD9699, U
TV15-141
21RT8202 TV14-143
21RT8425 TV14-142
21RT9632, U
TV15-149
21RT9625, U
TV15-149
21RT9637, U
TV15-149
21RT9655, U
TV15-149
21RT9656, U
TV15-149
21RT9657, U
TV15-149
21S848K(U) TV9-121
21S848U, G, GU like
21S254
21S252 see 21S254
21S252U, G, GU like
21S254
21S254, -U TV8-111
21S255 see 21S354
21S355U, G, GU like
21S354
21S355K(U) TV9-121
21S357K(U) TV9-121
21S357G, -GU like
21S354
21S259G, -GU like
21S354
21S262, -U TV8-111
21S262K(U) TV9-121
21S367G, GU, U like
21S254
21S367K(U) TV9-121
21S269G, GE see
21S854
21S869K(U) TV9-121
21S500R, RU
TV10-151
21S500(U) use
KCS87C or KCS87D
21S501(U) TV9-121
21S502(U) TV9-121
21S503(U) TV9-121
21S503N(NU)
TV10-146
21S504(U) TV9-121
21S504N(NU)
TV10-146
21S505(U) TV9-121
21S505N(NU)
TV10-146
21S506(U) TV9-121

R. C. A. (Continued)

21S595N(NU)
TV10-146
21S507N(NU)
TV10-146
21S510N(NU)
TV10-146
21S511N(NU)
TV19-146
21S516N(NU)
TV10-146
21S317(U) TV9-121
21S518(U) TV9-121
21S519(U) TV9-121
21S519N(NU)
TV10-146
21S521(U) TV9-121
21S521N(NU)
TV10-146
21S522(U) TV9-121
21S522N(NU)
TV10-146
21S523(U) TV9-121
21S523N(NU)
TV10-146
21S525(U) TV9-121
21S525(U) TV9-121
21S526N(NU)
TV10-146
21S587(U) TV9-121
21S527N(NU)
TV10-146
21S548(U) TV9-121
21S548N(NU)
TV10-146
21S632, U TV11-117
21S5251(U) TV9-121
21S5252(U) TV9-121
21S6052, U TV11-117
21S6052, U TV11-117
21S6055 (U) and
21S8057, -U
Similar to above
21T159
same as 21T176
21T165
same as 21T176
21T166DE uses KCS-68F
21T174DE
uses KCS-58F
21T175DE uses KCS-68F
21T176 TV6-189
21T177 TV6-139
21T178 TV6-139
21T179 TV6-129
21T179, 21T179DE
use KCS-68E, -F
21T197DE
uses KCS-68H
21T207 uses KCS-72A
21T207G uses KCS-72A
21T208 TV7-125
21T217 TV7-125
21T218 TV7-125
21T227 TV7-125
21T228 TV7-125
21T229 TV7-125
21T242 TV7-125
21T244 TV7-125
21T883, -U TV8-115
21T812, -U TV8-115
21T214, -U TV8-115
21T815, -U TV8-115
21T316, -U TV8-115
21T322, -U TV8-115
21T823, -U TV8-115
21T324, -U TV8-115
21T242, 21T844 comb.
TV sec. similar to
Chassis KCS-78F
21T256U TV8-111
21T252, -U TV8-111
21T864, -U TV8-111
21T265, -U TV8-111
21T272, -U TV8-111
21T873, -U TV8-111
21T874, -U TV8-111
21T275, -U TV8-111
21T392(U), 21T393
use KCS-83F, or-82H
21T639(U) TV12-133
21T6082, U TV11-111
21T6083, U TV11-111
21T6087, U as above
21T6114, U TV11-111
21T6115, U TV11-111

R. C. A. (Continued)
21T6117, U TV11-111
21T6125, U TV11-111
21T6127, U TV11-111
21T6135, U TV11-111
21T6225, U TV11-111
21T6227, U TV11-111
21T6255, U TV11-111
21T6256, U TV11-111
21T6257, U TV11-111
21T7112(U) TV12-125
21T7113(U) TV12-125
21T7117, U TV12-125
21T7152, U TV12-125
21T7153, U TV12-125
21T7157, U TV12-125
21T7352 } Use
21T7352U } KCS-98E
21T7355, U TV12-125
21T7357, U TV12-125
21T7375, U, G, GU and
21T7377, U, G, GU all
use KCS-98J, K, L, M
21T7335, U TV12-147
21T7386, U TV12-147
21T7337, U TV12-147
21T7333, U as above
21T7415, U TV12-147
21T7416, U TV12-147
21T7417, U TV12-147
21T8202, U TV14-143
21T3205, U TV14-143
21T3207, U TV14-143
21T8221, U TV14-117
21T8222, U TV14-117
21T3225, U TV14-117
21T8226, U TV14-117
21T8227, U TV14-117
21T8245, U TV14-117
21T8246, U TV14-117
21T8247, U TV14-117
21T8265, U TV14-143
21T8267, U TV14-148
21T3375, U TV14-143
21T3376, U TV14-143
21T3377, U TV14-143
21T3395, U TV14-143
21T8397, U TV14-143
21T3405, U TV14-143
21T3407, U TV14-143
21T3425, U TV14-143
21T3426, U TV14-143
21T8427, U TV14-143
21T8423, U TV14-143
21T3445, U TV14-143
21T8447, U TV14-143
21T3443, U TV14-143
21T3465, U TV14-143
21T8466, U TV14-143
21T8467, U TV14-143
21T3468, U TV14-143
21T3475, U TV14-117
21T3477, U TV14-117
21T3478, U TV14-117
21T3435, U TV14-143
21T3436, U TV14-143
21T3437, U TV14-148
21T9112, U TV15-125
21T9115, U TV15-125
21T9117, U TV15-125
21T9122, U TV16-127
21T9125, U TV16-127
21T9127, U TV16-127
21T9132, U TV15-149
21T9135, U TV15-149
21T9137, U TV15-149
21T9150, -U
See KCS-122E
21T9152, U TV15-149
21T9155, U TV15-149
21T9156, U TV15-149
21T9157, U TV15-149
21T9215, U TV15-149
21T9216, U TV15-149
21T9217, U TV15-149
21T9225,+ TV15-140
21T9226,+ TV15-149
21T9227,+ TV15-149
21T9235,+ TV15-149
21T9236,+ TV15-149
21T9237,+ TV15-149
21T9238,+ TV15-149
21T9255,+ TV15-149
21T9256,+ TV15-149
21T9257,+ TV15-149

R. C. A. (Continued)
21T9258,+ TV15-149
21T9265, U TV16-127
21T9266, U TV16-127
21T9267, U TV16-127
21T9275, U TV16-127
21T9276, U TV16-127
21T9277, U TV16-127
21T9315, U TV15-149
21T9316, U TV15-149
21T9317, U TV15-149
21T9318, U TV15-149
21T9335, U TV15-149
21T9337, U TV15-149
21T9339, U TV15-149
21T9345, U TV16-127
21T9346, U TV16-127
21T9347, U TV16-127
21T9355, U TV15-149
21T9356, U TV15-149
21T9357, U TV15-149
21T9364, -U
See KCS-122E
21T9375, U TV15-141
21T9376, U TV15-141
21T9377, U TV15-141
21T9378, U TV15-141
21T9396, U TV15-149
21T9397, U TV15-149
21T9399, U TV15-149
21T9415, U TV15-149
21T9417, U TV15-149
21T9435 TV15-149
21T9436 TV15-149
21T9437 TV15-149
21VF8695, U } Use
21VF8696, U } KCS-
21VF8697, U } 108K, L
OSC-22 Three-107
Q22A Six-92
VC-22 1961-140
KS-23 1960-134
PD-23 1960-134
PM-23D 1960-134
24D655, U TV11-111
24D658, U TV11-111
24D673, U TV11-111
24D676, U TV11-111
24D679, U TV11-111
24D7295, U TV12-141
24D7296, U TV12-141
24D7297, U TV12-141
24D7315, U TV12-141
24D7317, U TV12-141
24D7545, U TV12-147
24D7547, U TV12-147
24D7566, U TV12-147
24D7563, U TV12-147
24D7587, U TV12-147
24D7705, U TV12-147
24D7706, U TV12-147
24D7708, U TV12-147
24D7726, U TV12-147
24D7728, U TV12-147
24D3655, U TV14-125
24D3657, U TV14-125
24D3676, U TV14-125
24D3673, U TV14-125
24S512(U), 24S513(U)
24S514(U) Use
Chassis KCS84F, -H
24S529, -U TV9-115
24S531, -U TV9-115
24S532, -U TV9-115
24T420, -U TV9-115
24T435, -U TV9-115
24T6142, U TV11-111
24T6235, U TV11-111
24T6237, U TV11-111
24T7272, U TV12-141
24T7275, U TV12-141
24T7277, U TV12-141
24T3325, U TV14-143
24T3327, U TV14-143
24T8385, U TV14-143
24T8387, U TV14-148
PD-24 1960-134
25X Five-103
26BP Five-110
26X-1 Five-111
26X-3 Five-111
PF-26 1960-135
PF-26D 1960-135
PD-27 Uses RS-172
28T Five-112

R. C. A. (Continued)
23X Five-113
PL-28 Uses RS-175A
R-28-P One-169
VL-28 uses RS-178
29K Five-114
29K-2 Five-114
VL-29 uses RS-178X
Q32 Six-92
R-32 One-168
VL-32 uses RS-178
VP-33 1961-136
34B222++ TV22-115
34B225++ TV22-115
34B226++ TV22-115
34B227++ TV22-115
34B245RS TV22-115
34B246RS TV22-115
34C275++ TV22-115
34C276M+ TV22-115
34C355M+ TV22-115
34C356M+ TV22-115
34C376M+ TV22-115
34C394M+ TV22-115
34C425M+ TV22-115
34C426M+ TV22-115
34C446M+ TV22-115
34C450M+ TV22-115
34C458M+ TV22-115
34C459M+ TV22-115
34C465M+ TV22-115
34C466M+ TV22-115
34C467M+ TV22-115
34C475M+ TV22-115
34C476M+ TV22-115
34C496MV TV22-115
34C504MV TV22-115
34C510MV TV22-115
34C518MV TV22-115
34D535M+ TV22-115
34D536M+ TV22-115
34D555M+ TV22-115
34D556M+ TV22-115
34D576MV TV22-115
34D584MV TV22-115
34DX535M+ TV22-115
34DX536M+ TV22-115
34X Five-115
KCS-34B TV5-123
KCS-34C TV5-123
M-34 One-169
RS-34P 1961-135
VP-34 1961-135
R-35 One-170
VP-36 1961-137
KCS-33C TV5-123
R-39 One-170
40X-80 Three-107
40X-31 Three-107
KCS-40 TV5-123
KCS-40A TV5-123
KCS-40B TV5-123
U-40 Three-106
BK-41 Three-103
BT-41 Three-103
KCS-41 TV5-128
BT-42 Three-109
CV-42 Six-97
also in Eight-143
KCS-42A TV5-123
KCS-43 TV5-123
R-43 One-171
44 One-172
45-EY-1 Eleven-105
45-EY-2 Eleven-106
45-EY-3 Eleven-105
45-EY-4 Twelve-115
45-EY-15
Eleven-105
45-EY-26
Twelve-115
45W10 Eleven-109
45X1 Three-110
45X2 Three-110
45X-3 Four-130
45X-4 Four-120
45X11 Three-110
45X12 Three-110
45X13 Three-110
45X-16 Four-130
45X-17 Four-130
45X-13 Four-132
CV45 Seven-117
KCS-45 TV5-129
KCS-45A TV5-129
RE-45 One-168

R. C. A. (Continued)
46 One-172
KCS-46 TV5-129
Radiola 47 One-173
KCS-47 TV5-115
KCS-47A TV5-115
KCS-47AT TV5-115
KCS-47B TV6-121
KCS-47C TV6-121
KCS-47D TV6-121
KCS-47E TV6-138
KCS-47F TV6-121
KCS-47G TV6-121
KCS-47GP-2 TV6-121
KCS-47T TV5-115
Radiola 48 One-174
KCS-48 TV5-115
KCS-48A TV6-121
KCS-49 TV5-115
KCS-49B, -C TV6-121
B-50 Five-116
O-50 Three-111
R-50 One-175
52E Six-94
52HE Six-94
R-52 One-168
54B1 Six-95
54B1-N Six-95
54B2 Six-95
54B3 Six-95
54B5 Eight-142
55AU Six-96
55F Six-97
55U Six-96
55X Five-118
BX55 Ten-130
R-55 One-175
56X Six-93
56X2 Six-98
56X3 Six-98
56X5 Six-99
56X10 Six-99
56X11 Six-100
R-56 Five-113
BX57 Eleven-107
RE-57 One-170
53AV Six-101
58V Six-101
59AV1 Six-103
59V1 Six-103
Radiola 60 One-176
K-60 Three-113
KCS-60 TV5-115
KCS-60A TV6-121
M-60 Three-112
R-60 Three-113
61 TV6-125
61-1 Six-93
61-2 Six-98
61-3 Six-93
61-5 Six-99
61-6 Six-105
61-7 Six-105
61-10 Six-99
KCS-62 TV6-125
63E Eight-141
63EH Eight-141
64A026M+ TV22-137
64A030M+ TV22-137
64A033M+ TV22-137
64A037M+ TV22-137
64A033H+ TV22-137
64F1 Seven-117
64F2 Seven-117
64F3 Seven-117
65AU Seven-113
65BR9 Eight-145
65F Eight-143
65U Seven-118
65X1 Seven-126
65X2 Seven-126
66-1 Seven-119
66BX Seven-120
66E Seven-122
66X1 Seven-121
66X2 Seven-121
66X3 Seven-121
66X4 Seven-121
66X9 Seven-121
66X11 Eight-144
66X12 Eight-144
66X13 Eight-144
66X14 Eight-144
66X15 Eight-144

R. C. A. (Continued)
KCS-66 TV6-131
KCS-66A TV6-131
KCS-66C uses 17QP4
similar to KCS-66
KCS-66D uses 17CP4
similar to KCS-66
67AV1 Seven-123
67V1 Seven-123
68R1 Eight-146
68R2 Eight-146
68R3, -4 Eight-146
KCS-68C TV6-139
KCS-68E
same as KCS-68C
KCS-68F
similar to KCS-68C
KCS-63Hcombination
similar to KCS-63C
RAE-68 Uses
Radiola 82
H-70 Three-114
KCS-72 TV7-125
KCS-72A TV7-125
KCS-72D-1 TV7-125
KCS-72D-2 TV7-125
KCS-72HI, -M2, like
KCS-72 + chasges
RE-73 like R-35
KCS-74 TV7-133
KCS-74M1 later
version of KCS-74
RE-75 One-168
75X11 Nine-106
75X12 Nine-106
77U Nine-101
77V1 Nine-96
KCS-78 TV8-116
KCS-73B TV3-115
KCS-78F TV3-115
KCS-73H TV3-115
KCS-73J TV3-115
KCS-78L, -M
similar to above
Radiola 80 One-177
K-80 Three-115
K-81 Three-115
KCS-31 TV8-121
KCS-81B TV8-121
KCS-81D TV8-121
KCS-31F TV8-121
KCS-81H, KCS-81K
combination sets
similar to above
KCS-81J TV3-121
Radiola 82 One-177
KCS-32 TV3-115
KCS-82B TV3-115
KCS-38 TV8-111
KCS-83B TV8-111
KCS-33C TV8-111
KCS-38D TV3-111
KCS-33E TV3-111
KCS-83F, KCS-83H
in combinations
similar to KCS-83
KCS33PC, PD, PJ, PK,
PL, PM all similar
to KCS33
KCS34C TV9-115
KCS84E TV9-115
KCS84F TV9-115
KCS34H TV9-115
KCS34J TV9-115
KCS34K TV9-115
Radiola 86 One-177
KCS37 TV9-121
KCS87A TV9-121
KCS87C, KCS87D
similar to above
KCS88 TV9-121
KCS83A TV9-121
KCS88B TV9-121
KCS88C TV9-121
KCS83D TV9-121
KCS33E TV9-121
KCS83F TV9-121
KCS88H TV9-121
KCS83J TV9-121
KCS33K TV9-121
KCS83L TV9-121
KCS38M TV9-121
KCS88N TV9-121
KCS33P TV9-121

R. C. A. (Continued)
KCS88V TV9-121
KCS88VA TV9-121
KCS-92 TV10-146
KCS-92A to - F
TV10-146
KCS-92H, J, K
TV10-146
KCS-92L, M TV10-146
KCS-93, -A TV10-151
KCS-93B, -C
TV10-151
94A064MU TV22-134
94A064MV TV22-134
94A083M+ TV22-127
94A084M+ TV22-127
94A102M+ TV22-127
94A107M+ TV22-127
94A109M+ TV22-127
94A132M+ TV22-125
94A136M+ TV22-125
94A137M+ TV22-125
94A160M+ TV22-129
94A171M+ TV22-122
94A172M+ TV22-122
94A176M+ TV22-122
94A132RS TV22-122
94A133++ TV22-122
94A136M+ TV22-122
94BK2 One-175
94BT2 One-175
KCS-94, A TV11-117
KCS-95, A TV11-117
KCS-95B C TV11-117
96K2 One-178
96T3 One-178
KCS-96, -A through
KCS-96E TV11-111
97E One-178
97KG One-178
97T One-178
KCS-97, A TV11-111
KCS-97AA TV11-111
KCS-97AB TV11-111
KCS-97AC TV11-111
KCS-97AD TV11-111
KCS-97D, E TV11-111
KCS-97F, H TV11-111
KCS-97J, K TV11-111
KCS-97N, P TV11-111
KCS-97R, T TV11-111
KCS-97U, W TV11-111
KCS-98A, C TV12-125
KCS-93E, F TV12-125
KCS-98J like -98A
KCS-93K like -98C
KCS-93L } Similar
KCS-93M } to above
HF-99 1959-125
KCS-100B TV12-129
KCS-100D TV12-129
KCS-100K TV12-129
R-100 One-179
V-100 Four-133
A-101 Eleven-109
KCS-101 TV12-133
KCS-101A TV12-133
R-101 One-179
V-101 Four-133
KCS-102B TV12-137
KCS-102D TV12-137
V-102 Four-134
KCS-103A to
KCS-103D TV12-141
KCS-103N, -P, -R, -T
all on TV12-141
KCS-104A to
KCS-104L TV12-147
KCS-104AA to
KCS-104AF TV12-147
K-105 Three-116
A106 Ten-181
KCS-107A through
KCS-107D TV14-117
A-108 Eleven-109
KCS-103C through
KCS-103F TV14-125
KCS-103H like
21D8525+ remote
KCS-103K-L like
KCS-108C, -D
audio different
DK-109 1961-139
KCS-109A through
KCS-109D TV14-131
110 One-179

R. C. A. (Continued)
110-K Four-135
DK-110 1961-139
111 One-179
111-K Four-137
DK-111 1961-139
KCS-111A through
KCS-111D TV14-140
KCS-111F TV14-140
KCS-111H TV14-140
U-111 One-130
U-112 like U-111
KCS-118A, B, E, H, K,
-M, N, P, R TV14-143
114 One-180
115 One-179
V-215 Five-121
KCS-116A through
KCS-116D TV14-158
KCS-117A TV15-125
KCS-117B TV15-125
KCS-113A, B
TV15-129
KCS-118C, D
TV15-129
120 One-181
KCS-120A, B
TV15-137
KCS-120E TV16-123
KCS-120F TV16-123
T120 TV5-123
KCS-121A through
KCS-121R TV15-141
RK-121C Nine-99
T121 TV5-123
KCS-122E and many
other suffixes
TV15-149
RS-123D Nine-99
KCS-124C through
KCS-124L TV16-127
TC124 TV5-123
TC125 TV5-123
KCS-126A TV16-135
KCS-126B TV16-135
KCS-126C, -D, etc.
Similar to above
RS-126 Seven-122
KCS-127A, TV17-123
through
KCS-127ZK TV17-123
RS-127 Eight-141
TC127 TV5-123
KCS-128A TV17-133
through
KCS-128ZU TV17-133
TA128 TV5-123
KCS-129A TV17-143
through
KCS-129ZH TV17-143
TA129 TV5-123
KCS-130A TV18-123
KCS-130+ + TV13-123
KCS-131C TV13-137
KCS-131+ + TV18-137
KCS-132K TV18-137
KCS-132+ TV13-137
KCS-132AA TV13-137
KCS-132+ + TV13-137
RS-132 Ten-127
RS-132F Eleven-105
RS-132H Eleven-105
KCS-133A+ TV19-126
KCS-134AB TV13-135
KCS-134C TV13-135
KCS-136A
through
KCS-136U TV20-115
KCS-136AB TV20-115
KCS-136YA through
KCS-136YU TV21-115
KCS-136Y+ TV22-115
KCS-136Z+ TV22-115
RS-136 Eleven-105
RS-136A Eleven-105
RS-136J 1956-109
KCS-137A TV19-133
KCS-137B TV19-133
KCS-137P TV19-133
KCS-138A TV19-133
KCS-138B TV19-133
RS-133 Eleven-106
RS-133A Eleven-106

R. C. A. (Continued)

RS-138L Twelve-115
RS-138S 1956-109
RS-138U 1956-110
RS-139A 1958-104
140P012, U Uses KCS-120B, F
140P020 U TV16-123
140P023, U TV16-123
140P024, U TV16-123
KCS-140A, TV21-121
RS-140 Twelve-115
KCS-141A TV21-127
KCS-141B,C TV21-127
KCS-141K,L TV22-122
KCS-142D TV22-184
KCS-142B TV22-124
RS-142 Twelve-114
RS-142 1953-104
RS-142A 1953-104
KCS-143A TV22-127
KCS-143B TV22-127
KCS-144A TV22-125
KCS-144B TV22-125
RS-145A 1955-73
KCS-146A TV22-137
KCS-146B TV22-137
KCS-146D TV22-137
KCS-146E TV22-137
RS-146, -X 1954-91
RS-146C 1956-111
KCS-147A TV22-129
KCS-147B TV22-129
RS-150 1956-110
RS-150B 1956-112
RS-151B 1959-124
RS-152 1956-113
RS-152A 1966-113
RS-152B 1958-152
RS-152C 1957-111
RS-152D 1957-112
RS-152D,E 1958-152
RS-152 1957-112
RS-153 1956-113
RS-153A 1958-152
RS-155 1956-113
RS-155A 1956-114
RS-157 1956-114
RS-157A 1957-112
RS-157B 1958-153
RS-157D 1959-125
RS-158 1957-113
RS-158D,F 1958-154
RS-158J 1958-144
RS-159 1957-114
RS-159B 1958-151
RS-160 1957-114
T164 TV5-123
RS-164, -A 1958-151
RS-164B 1958-141
TC165 TV5-123
TC166 TV5-123
TC167 TV5-123
RP-168 Ten-133
TC168 TV5-123
TA169 TV5-123
170P042, U Use
170P044, U KCS-126A
170P048, U TV16-135
170P049, U TV16-135
170P053, U Use KCS-126A, B
170P060, U TV16-135
170P061, U TV16-135
170P063, U TV16-135
170P064, U TV16-135
170P066, U Use
170P067, U KCS-126A
170P069J Use
170P069JU KCS 126R
170PR106 Use
170PR109 KCS-126F
170T072, U Use KCS-126C, -D
170T084, U Use
170T085, U KCS-126C
170T086, U KCS-126D
170T087, U TV16-135
170T122 Use
170T123 KCS-126A
170T124 Like data
170T124U TV16-135
170TC094 Uses KCS-126E

R. C. A. (Continued)

170TR114 Use
170TR115 KCS-126J
RS-170 1958-154
RS-170B,D 1958-152
171A032X TV18-123
171A034, U TV18-123
171A040, U TV18-123
171A042, U TV18-123
171A043, U TV18-123
171A044, U TV18-123
171A047, U TV18-123
171A052, U TV18-123
171A054, U TV18-123
171A061, U TV18-123
171A062, U TV18-123
171A067, U TV18-123
171A068, U TV18-123
171A032, U see KCS-130++
171AR044 TV18-123
171AR062 TV18-123
171AR067 TV18-123
RS-171A 1959-126
RS-171D 1961-140
RS-171F 1961-140
172A042MU See
172A042MV KCS-130
172A049MU on
172A049MV TV18-123
172A086MV, MU use KCS-130++
RS-172 1959-126
173A502+ See
173A506+ KCS-130+
RS-175 1959-128
RS-175A 1959-129
RS-175B 1961-138
RS-175C 1963-120
RS-177A 1961-140
RS-177H 1964-134
RS-177J 1964-138
RP-178 Nine-111
RS-179 1960-134
RS-179X 1960-134
RS-179 1961-140
RS-182 1960-135
RS-182A 1961-137
RS-184 1960-136
RS-184A 1960-136
RS-185 1960-136
RS-187 1961-139
RS-188 1961-136
RP-190 Eleven-111
191A192, U TV19-125
191A194, U TV19-125
191AE202 TV19-125
191AE205 TV19-125
191AE208 TV19-125
191AE209 TV19-125
191AER204 TV19-125
191E242, U TV18-135
191E244, U TV18-135
191E255, U TV18-135
191E256, U TV18-135
191E257, U TV18-135
191ER254 TV13-135
191S256 TV18-135
192A062+ TV19-133
192A064+ TV19-133
192A069MV, MU use KCS-133A
192A072+ TV19-133
192A075+ TV19-133
192A078+ TV19-133
192A070+ TV19-133
192A094+ TV19-125
192A093+ TV19-125
192A099+ TV19-125
193A48M Use
193A53M KCS-138A
193A482++ TV21-115
193A484++ TV21-115
193A487++ TV21-115
193A493+ Use
193A512+ Chassis
193A514+ KCS-133A
193A522+ -B, &-P
193A527+ see
193A520+ TV19-133
193A532++ TV21-115
193A539++ TV21-115
193A542MU TV21-121
193A542MV TV21-121

R. C. A. (Continued)

193A546++ TV21-121
193A549++ TV21-121
193B571MU TV21-127
193B571MV TV21-127
193B572++ TV21-127
193B574RS TV21-127
193B576++ TV21-127
193B578++ TV21-127
193K04M uses KCS-138A
193K040++ TV21-115
RS-193A, + 1963-123
RS-193A 1962-101
RS193B 1962-101
RS-193D 1962-101
RS-196 1962-104
RS-197 1962-105
RP-197-1 1954-95
RP-198-1, -2 like above, pickup diff.
RS-198 1962-105
RP-199 1956-126
RS-199B 1964-134
RS-199C 1964-138
RS-200 1962-100
RS-200C 1963-122
RS-202A 1964-131
RS-202B 1964-131
RS-203A 1964-140
RP-205 1957-119
210DK595 TV17-143
210DK596 TV17-143
210DK597 TV17-143
210DK635+ TV17-143
210DK636 TV17-143
210DK655 TV17-143
210DK656 TV17-143
210DK657 TV17-143
210DK670 TV17-143
210DK674 TV17-143
210DKR655 TV17-143
210DKR656 TV17-143
210DKR657 TV17-143
210DKR670 TV17-143
210DKR674 TV17-143
210DKR715 TV17-143
210DKR716 TV17-143
210DT572 TV17-143
210DT572U TV17-143
210DT575 TV17-143
210DT575R TV17-143
210DT577 TV17-143
210K240, U use KCS-123YAD
210K244SU TV17-133
210K255, U TV17-133
210K256 TV17-133
210K256SU TV17-133
210K285U+ TV17-133
210K286, U TV17-133
210K287 TV17-133
210K239, U TV17-133
210K295, + TV17-133
210K296, M TV17-133
210K297+ TV17-133
210K299, M TV17-133
210K315, + TV17-133
210K316, M TV17-133
210K317, + TV17-133
210K319, M TV17-133
210K335, + TV17-133
210K336, M TV17-133
210K237, M TV17-133
210K356, M TV17-133
210K357, M TV17-133
210K390, M TV17-133
210K394, M TV17-133
210K405 TV17-123
210K406 TV17-123
210K407 TV17-123
210K415+ TV17-133
210K416+ TV17-133
210K417M TV17-133
210K417X TV17-133
210KA465 TV17-123
210KA466 TV17-123
210KR435+ TV17-133
210KR436+ TV17-133
210KR445 TV17-133
210KR445+ TV17-133
210KR446 TV17-133
210KR446+ TV17-133
210KR455 TV17-133

R. C. A. (Cont.)

210KR455+ TV17-133
210KR456+ TV17-123
210KR457+ TV17-123
210T140, M TV17-133
210T152, + TV17-133
210T155, + TV17-133
210T156, + TV17-133
210T157, + TV17-133
210T162, U TV17-133
210T171 TV17-123
210T172, U TV17-123
210T185, U TV17-133
210T185SU TV17-133
210T136, U TV17-133
210T187, U TV17-133
210T195 TV17-123
210T196 TV17-123
210T199 TV17-123
210TR212 TV17-133
210TR212+ TV17-133
210TR215+ TV17-133
210TR222+ TV17-133
210TR225+ TV17-133
210TR227+ TV17-133
211B312, + TV18-138
211B325, + TV18-138
211B326, + TV18-138
211B327, + TV18-138
211D40C4 TV18-133
211D405 TV18-138
211D406, + TV18-138
211D407 TV18-138
211D409 TV18-133
211D485 TV18-138
211D486 TV18-138
211D487 TV18-133
211D505, + TV18-138
211D506, + TV18-133
211D507, + TV18-138
RP-217 1963-136
RP-218 1963-136
V-219 Five-121
V-221 Five-121
V-225 Five-121
230K50C4 TV17-123
230K50C4U TV17-123
230K50N6+ TV17-123
230K505SU TV17-123
230K506, U TV17-123
230K509, U TV17-123
230K536, U TV17-123
230K537, U TV17-123
230K545, U TV17-123
230K546, U TV17-123
230K549, U TV17-123
230K556, U TV17-123
230K559, U TV17-123
230KR525SU TV17-123
230KR526SU TV17-123
231B602, U Use
231B605, U KCS-131+
231B606, U see
231B607, U TV18-137
231B612, + TV18-153
231B615, U TV18-153
231B616, U TV18-153
231B617, + TV18-153
231BE622U see KCS-132+
231BE625T TV18-150
231BE626 TV13-153
231BE627 TV18-153
231BER625 TV18-153
231BER626 TV18-153
231BER627 TV18-153
231BR615 TV18-153
231BR616 TV18-153
231BR617 TV18-153
231D545U Use
231D546U KCS-131+
231D547U TV18-137
231D66C4U TV18-138
231D66N6U TV18-138
231D635, + TV18-138
231D636, + TV18-133
231D637, + TV18-138
231D645, U TV18-153
231D646, U TV18-153
231D647, U TV18-153
231D655, + TV18-133
231D656, + TV18-138
231D657, + TV18-133
231D659, + TV18-138
231D665, U TV18-133

R. C. A. (Continued)

231D666, U TV18-133
231D667, U TV18-133
231D669, U TV18-133
231D694U TV18-138
231D695, + TV18-138
231D696, + TV18-138
231D716U TV18-138
231D719U TV18-133
231D730 TV18-138
231D734 TV18-138
231DA765 Use
231DA766 KCS-127ZH
231DE533C4U Use
231DE533N4U KCS-132
231DE558C4 see
231DE558N4 TV-18
231DE535U Use
231DE536U KCS-132+
231DE537U Chassis
231DE575U Use
231DE576U KCS-132
231DE625+ ++
231DE626U in TV18
231DE595U Use
231DE596U KCS-132+
231DE597U in TV18
231DE665U TV13-139
231DE666U TV18-139
231DE667U TV18-139
231DE675U Use
231DE676U KCS-132+
231DE877U in TV-18
231DE685U Use
231DE686U KCS-132+
231DE687U in TV-18
231DE722 Use
231DE742 KCS-132+
231DE746 Chassis
231DE755 in
231DE756 TV18-137
231DER53C4 Use
231DER53N4 KCS-132
231DER685 Use
231DER636 KCS-132L
231DER687 in TV-18
231DR655 TV18-138
231DR656 TV18-138
231DR657 TV18-138
231DR665 TV18-133
231DR666 TV13-138
231DR716 TV18-133
231DR719 TV18-138
231DV115 TV18-139
231DV116 TV18-139
231DV125 TV13-139
231DV126 TV18-139
231DV146 TV18-139
231HR776 TV18-153
231HR738 TV13-153
231HR789 TV18-153
231HR797 TV13-153
231HR799 TV18-153
232B215++ TV20-115
232B216++ TV20-115
232B152+ TV20-115
232B155+ TV20-115
232B156+ TV20-115
232B157+ TV20-115
232B182+ TV20-115
232B135+ TV20-115
232B186MV TV20-115
232B192++ TV20-116
232B195++ TV20-115
232B196++ TV20-116
232B197++ TV20-116
232B212MU uses KCS-136J
232C235++ TV20-116
232C236++ TV20-116
232C237++ TV20-116
232C245++ TV20-115
232C246++ TV20-115
232C247++ TV20-115
232C255++ Use
232C256++ late
232C257++ KCS-136
232C264++ TV20-116
232C275++ TV20-115
232C276++ TV20-115
232C277++ TV20-115
232C280++ TV20-116
232C295++ TV20-116
232C296++ TV20-116
232C304++ TV20-115

R. C. A. (Continued)

232C325++ Use
232C326++ KCS-136
232C325++ TV20-115
232C236++ TV20-115
232C237++ TV20-115
232C345++ Use
232C346++ KCS-136
232C355++ TV20-116
232C356++ TV20-116
232C357++ TV20-116
232C365++ TV20-115
232C366++ TV20-115
232C367++ TV20-115
232C369MV TV20-115
232C376++ TV20-115
232C385++ TV20-116
232C386++ TV20-116
232C405++ TV20-115
232C406++ TV20-115
232C465MV TV20-115
232C466MV TV20-115
232C495MV TV20-115
232C496MV TV20-115
232C505MV TV20-115
232C506MV TV20-115
232C509MV TV20-115
232C515MV TV20-116
232C516MV TV20-116
232C519MV TV20-116
232C524++ TV20-115
232C540MV TV20-115
232C549MV TV20-115
232C555MV TV20-115
232C556MV TV20-115
232C565MV TV20-115
232C566MV TV20-115
232C567MV TV20-115
232C575MV TV20-116
232C576MV TV20-116
232C584MV TV20-116
232C596MV TV20-116
232C602++ TV20-115
232C606++ TV20-115
232C620++ TV20-116
232C628++ TV20-116
232C636MV TV20-116
232C648++ TV20-116
232D675MV TV20-116
232D676MV TV20-116
232D684MV TV20-116
232D696MV TV20-116
233B59M TV21-115
233B60+ TV21-115
233B61M TV21-115
233B602++ TV21-115
233B605++ TV21-115
233B606++ TV21-115
233B607++ TV21-115
233B615++ TV21-115
233B616++ TV21-115
233B617++ TV21-115
233C64M TV21-115
233C65M TV21-115
233C68M TV21-115
233C67M TV21-115
233C68M TV21-115
233C71M TV21-115
233C72M TV21-115
233C73M TV21-115
233C74M TV21-115
233C75R TV21-115
233C76R TV21-115
233C77M TV21-115
233C79M TV21-115
233C80M TV21-115
233C81M TV21-115
233C82M TV21-115
233C83M TV21-115
233C84M TV21-115
233C85M TV21-115
233C86M TV21-115
233C87M TV21-115
233C655++ TV21-115
233C656++ TV21-115
233C657++ TV21-115
233C664++ TV21-115
233C675++ TV21-115
233C676++ TV21-115
233C686++ TV21-115
233C715++ TV21-115
233C716++ TV21-115
233C725++ TV21-115
233C726++ TV21-115
233C727++ TV21-115

R. C. A. (Continued)

233C755RS TV21-115
233C756RS TV21-115
233C757RS TV21-115
233C795++ TV21-115
233C796++ TV21-115
233C805++ TV21-115
233C806++ TV21-115
233C325MV TV21-115
233C326MV TV21-115
233C328MV TV21-115
233C354MV TV21-115
233C366MV TV21-115
233C370MV TV21-115
233C378MV TV21-115
233D95M TV21-115
233D98M TV21-115
233D97M TV21-115
233D98M TV21-115
233D955MV TV21-115
233D956MV TV21-115
233D965MV TV21-115
233D966MV TV21-115
233D974MV TV21-115
233D986MV TV21-115
233DX95M TV21-115
233DX955MV TV21-115
233DX956MV TV21-115
240K485, M TV17-133
240K486, M TV17-133
240K495+ TV17-123
240K496X TV17-123
240K497M TV17-123
240K497X TV17-123
240KV775SU TV17-123
240KV776SU TV17-123
VC-270 1961-136
VC-271 1961-136
VC-272 1961-136
VC-273 1961-136
RK-295 1962-100
RC-341 One-180
RC-351A One-178
RC-351B One-178
RC-357K Three-112
RC-390 One-175
RC-396 Three-100
RC-404A Three-104
RC-406 Three-104
RC-408A Three-109
8-411 Eleven-103
RC-414A Three-100
RC-415 Three-113
RC-415A Three-115
RC-415C Three-115
RC-413B Three-105
RC-485 Three-103
RC-449 Three-108
QTS-450 TV20-57
VTS-450 TV20-57
RC-457 Three-110
RC-457B Four-130
RC-459 Three-110
RC-459M Four-130
RC-462 Four-124
RC-464 Five-119
RC-465 Five-106
RC-476 Three-116
RC-477 Three-100
RC-498 Three-106
RC-498A Three-106
500 Five-119
501 Five-119
RC-507 Six-92
RC-509A, C Four-125
RC-512 Four-129
RC-512A Four-131
RC-518 Four-135
RC-513A Four-137
515 Five-117
516 Five-123
517 Five-123
RC-517 Four-133
RC-517C Five-120
RC-517F Five-126
RC-517J Five-125
RC-524 Four-134
526 Five-124
527 Five-124
RC-527 Four-123
RC-527D Five-109
RC-540 Four-133
RC-541C Four-132
RC-544 Four-119
X551 Eleven-110

R. C. A. (Continued)

X552 Eleven-110
RC-559 Five-110
R-560-P Five-126
RC-564 Five-121
R-566-P Five-125
RC-569 Five-112
RC-570 Five-114
RC-589 Six-95
RC-594D Six-105
PX600 Twelve-116
RC-604 Six-101
RC-605 Six-108
RC-606 Seven-123
RC-608 Eight-146
RC-613A Nine-109
RC-615 Nine-96
RC-616 Nine-108
RC-616A Nine-102
RC-616H Nine-102
RC-618 Nine-102
RC-618A Nine-102
RC-622 Ten-131
710V2 Nine-109
810K, 810T One-182
811K One-183
AR-925 One-168
RC-1000 Four-128
RC-1000C Five-117
RS-1000 Eight-143
RC-1001 Four-120
1001B Four-121
RC-1001D Four-122
R. R. 1001 Seven-117
RS-1001 Four-120
RC-1003 Four-118
RC-1004E Six-97
also in Seven-119
and in Eight-143
RC-1004H Five-116
RC-1011 Six-98
RC-1017 Six-96
RC-1017A Seven-118
RC-1017A
Twelve-114
1022A Four-121
RC-1023 Six-99
RC-1023A Six-100
RC-1034 Seven-126
RC-1037 Seven-117
RC-1037B Nine-95
RC-1038 Seven-121
RC-1040 Seven-120
RC-1040C Nine-94
RC-1045 Eight-145
RC-1046 Eight-144
RC-1046A Eight-144
RC-1046B Eight-144
RC-1047 Eight-142
RC-1050 Nine-106
RC-1056D Ten-120
RC-1057A Nine-101
RC-1057B Ten-128
RC-1059 Nine-93
RC-1059A Ten-121
RC-1059B, -C Ten-121
RC-1060 Nine-97
RC-1060A Nine-97
RC-1061 Nine-107
RC-1064 Nine-104
RC-1065 Nine-105
RC-1065A Nine-105
RC-1065J Nine-105
RC-1065K Nine-105
RC-1065L Nine-105
RC-1065M Nine-105
RC-1066 Nine-103
RC-1066A Nine-103
RC-1068 Ten-123
RC-1069, -A, -B Ten-122
RC-1077 Ten-129
RC-1079, -A Ten-125
RC-1079B, -C Ten-124
RC-1079K
Twelve-111
RC-1079L
Twelve-111
RC-1080, -A Ten-125
RC-1080C 1953-100
RC-1080D 1955-100
RC-1082 Ten-119
RC-1085, -A Ten-126
RC-1085B 1953-101
RC-1088 Ten-130

R. C. A. (Continued)

RC-1088A
Eleven-107
RC-1088C
Eleven-107
RC-1089B
Eleven-110
RC-1089C
Eleven-110
RC-1096 Eleven-109
RC-1098, -A
Eleven-108
RC-1098B 1956-115
RC-1102, -A, -B, -C
Twelve-107
RC-1104 Twelve-112
RC-1104-1
Twelve-112
RC-1104A
Twelve-112
RC-1104A-1
Twelve-112
RC-1104B, -1104B-1
Twelve-112
RC-1164C, -D, -E,
Twelve-112
RC-1110 Twelve-116
RC-1114 Twelve-113
RC-1115 1953-95
RC-1117D 1953-99
RC-1118 1952-97
RC-1119 1953-98
RC-1120 1953-96
RC-1120A 1953-96
RC-1120B 1953-96
RC-1120C 1953-96
RC-1121 1953-102
RC-1121A 1953-102
RC-1121B 1955-86
RC-1125 1954-92
RC1126A 1956-116
RC-1128B 1956-117
RC-1129A 1955-83
RC-1130 1955-74
RC-1134 1955-79
RC-1140 1954-94
RC-1141 1955-78
RC-1141A 1955-78
RC-1142 1955-75
RC-1144 1955-76
RC-1145 1955-77
RC-1146 1955-76
RC-1146A 1956-118
RC-1147 1955-80
RC-1148 1955-82
RC-1148A 1955-81
RC-1149 1955-88
RC-1149 1958-149
RC-1150 1955-76
RC-1152 1956-119
RC-1153, -A
1956-120
RC-1156 1956-121
RC-1156A 1957-116
RC-1156B 1958-142
RC-1156C 1959-130
RC-1157 1956-122
RC-1157A 1956-123
RC-1159 1956-124
RC-1161 1957-107
RC-1161 1958-150
RC-1161A 1958-150
RC-1161A 1957-107
RC-1162 1957-110
RC-1163 1957-108
RC-1164 1958-146
RC-1164A 1958-146
RC-1164B 1958-146
RC-1166 1957-117
RC-1166A 1958-156
RC-1166B 1958-155
RC-1167 1957-118
RC-1167A 1958-157
RC-1169 1957-115
RC-1169A 1957-115
RC-1170 1958-145
RC-1170A 1958-156
RC-1178 1958-145
RC-1179 1958-145
RC-1179A 1958-145
RC-1183 1958-148
RC-1183A 1958-148
RC-1188B 1958-143
RC-1187 1959-131
RC-1187A 1959-132

R. C. A. (Continued)

RC-1188 1959-133
RC-1188A 1959-133
RC-1188A 1960-127
RC-1188B, C 1960-127
RC-1188D 1960-127
RC-1189 1960-128
RC-1189A 1960-128
RC-1189B 1960-128
RC-1190 1960-129
RC-1190A 1960-129
RC-1190B 1960-129
RC-1191 1960-130
RC-1191A 1960-130
RC-1192 1961-140
RC-1195 1960-131
RC-1196 1960-132
RC-1196A 1960-132
RC-1197 1960-133
RC-1199 1961-132
RC-1199A 1961-132
RC-1199B 1961-133
RC-1199D 1963-124
RC-1199D 1962-92
RC-1200 1961-130
RC-1200A 1961-130
RC-1200C 1962-93
RC-1201A 1961-129
RC-1201D 1962-98
RC-1202A 1961-134
RC-1202B 1961-134
RC-1202C 1961-134
RC-1202F 1962-94
RC-1202H 1962-94
RC-1202K 1962-95
RC-1202L 1962-96
RC-1202M 1962-96
RC-1202N 1962-96
RC-1202P 1962-95
RC-1202R 1962-95
RC-1202T 1962-95
RC-1202AA 1963-116
RC-1202AB 1963-116
RC-1202AC 1963-117
RC-1202AD 1963-117
RC-1202AE 1963-118
RC-1202AF 1963-118
RC-1202AH 1963-119
RC-1202U 1963-116
RC-1202W 1963-116
RC-1204, E+ 1962-124
RC-1205C 1964-184
RC-1206A 1962-101
RC-1206C 1963-121
RC-1206F 1963-121
RC-1207A TV20-125
RC-1208A 1962-97
RC-1208B 1962-97
RC-1208C, D 1963-126
RC-1208H 1963-126
also 1964-137
RC-1209A, B 1963-128
RC-1209C 1963-128
RC-1210A 1963-130
RC-1210B 1963-130
RC-1210C 1963-134
RC-1210D 1963-132
RC-1211A 1964-138
RC-1212 1963-135
RC-1213A 1964-132
RC-1213B 1964-132
RC-1213E 1964-132
RC-1213F 1964-132
RC-1213H 1964-132
RC-1214A 1964-143
RC-1215A 1964-140
RC-1215B 1964-140
N2026, SU TV17-123
5877 TV18-149
5878 TV18-149
930409 1953-105
930800 similar
to 930409
960001-1 Six-106
960001-2 Six-106
960001-3 Six-106

RADIONIC EQUIP. CO.

6W Seven-125

RAYTHEON TV

4D16-A 1956-131
4RT1 1956-132
6RT1 1956-133
6RT1 1957-141
7RT4 1957-142
8RT1 1956-134
8TP1 1956-134
8TP2 1956-134
8TP3 1956-134
8TP4 1956-134
16AY28 TV5-135
16AY211 TV5-135
17AY21 TV5-135
17AY24 TV5-135
17T1 TV7-136
17T2 TV7-136
17T18 TV9-129
17T183 like 17T18
20AY21 TV6-143
21T1 TV7-136
21T2 TV7-136
21T8 TV8-127
21T19 TV9-129
21T24 TV10-157
21T25 TV10-157
21T26AGH TV10-161
21T27 TV10-157
21T32 TV12-161
21T40 TV11-107
21T41 TV11-107
21T43 TV11-107
21T44 TV11-107
21T45 TV11-107
21T46 TV11-107
21T274AGH TV10-161
21T193 like 21T19
24T2 TV8-127
C-50B 1956-131
C-51W 1956-131
C-52R 1956-131
T-100-1 1956-132
T-100-2 1956-132
T-100-3 1956-132
T-100-4 1956-132
T-100-5 1956-132
T-150-1 1956-133
T-150-1 1957-141
T-150-2 1957-141
T-150-2 1956-133
T-150-3 1956-133
T-150-4 1956-133
T-150-5 1956-133
T-150-3 1957-141
T-150-4 1957-141
T-150-5 1957-141
UC-213B, M TV11-107
C-214B, M TV11-107
UC-215B, M TV11-107
C-216B, M TV11-107
UC-217B, M TV11-107
C-218 TV11-107
UC-219 TV11-107
M-210B, M TV11-107
UM-211B, M TV11-107
M-1611A TV5-135
M-1612A TV5-135
M-1613A TV5-135
C-1614A TV5-135
C-1615A TV5-135
C-1616A TV5-135
RC-1618A TV5-135
RC-1619A TV5-135
M-1711A TV5-135
M-1712A TV5-135
M-1712A TV5-135
C-1714A TV5-135
C-1715A TV5-135
C-1716A TV5-135
RC-1718A TV5-135
RC-1719A TV5-135
M-1738A TV7-136

HOW TO USE THIS INDEX

This Master INDEX will tell you in which SUPREME volume and on what page the material you need is listed. Please refer to the easy-to-follow charts on page 2, and to the explanation at top of page 3, for guidance.

RAYTHEON (Cont.)

M-1734A TV7-136
C-1735A TV7-136
C-1726A TV7-136
M-1750 TV9-130
M-1751 TV9-180
M-1752 TV9-180
M-1761E } Use
M-1762 } 17T182
C-2001A TV6-143
C-2002A TV6-143
C-2005A TV6-143
C-2006A TV6-143
M-2007A TV6-143
M-2008A TV6-143
M-2107A TV7-136
C-2108A TV7-136
C-2109A TV7-136
C-2110A TV7-136
C-2111A TV7-136
C-2112A to C2118A
similar to 20AY21
UM-2133A TV8-127
UM-2134A TV8-127
UM-2135A TV8-127
UM-2136A TV8-127
UM-2139A TV8-127
UM-2141A TV8-127
UM-2142A TV8-127
UM-2144A TV8-127
UM-2145A TV8-127
M-2160 TV9-130
M-2161 TV9-180
M-2162 TV9-180
C-2163 TV10-157
M-2165 TV10-157
C-2166 TV10-157
UC-2167 TV10-161
UC-2168 TV10-161
M-2171E } Use
M-2172+ } 21T193
M-2173+ } Changes
UM-2186 TV12-161
UM-2187 TV12-161
UM-2188 TV12-161
UM-2189 TV12-161
UC-2408A TV8-127
UC-2404A TV8-127
UC-2405A TV8-127
UC-2406A TV8-127
T-2500 1957-142

REGAL ELECTRONICS

1049 Eight-148

RENAULT

55555 1962-49

ROLAND

71-483 1959-134

SCOTT RADIO

800-B Seven-127

SAMPSON

BT85 1963-154

SEARS, ROEBUCK

1 Ten-147
2 Ten-147
4 Eleven-119
5 Twelve-118
6 Twelve-118
10 Twelve-117
11 Twelve-117
13 Twelve-132
14 Twelve-132
18 Ten-145
20 Ten-145
25 Twelve-120
27 Twelve-120
69 Eleven-123
R-101 Four-139
R-111 Four-139
153-19 TV7-147
163-18 TV7-147
167-16 } All use
185-16 } 549.101
180-19 } chassis
215 Eleven-120
217 and 218
same as 215

Sears (Continued)

225 Eleven-122
1017 Twelve-119
1018 same as 1017
1031 1962-106
1032 Twelve-121
1035 1962-107
1035 Twelve-121
1035A Twelve-121
1036 1962-107
1037 1962-107
1038 1962-107
1040 Twelve-121
1045 Twelve-121
1058 Twelve-122
1059 Twelve-122
1062 Twelve-122
1063 Twelve-122
1073 1962-110
1074 1962-110
1075 1962-110
1083 1962-110
1084 1962-110
1085 1962-110
1114M TV20-130
1117-17 } Air King
1130-17 } 700-100
1130 TV20-127
1131 TV20-127
1132 TV20-127
1132-17 TV7-147
1133 TV20-127
1141-20 } Air King
1145-20 } type
1163-17 } 700-100
1150 TV20-127
1151 TV20-127
1152 TV20-127
1153 TV20-127
1154 TV20-127
1155 TV20-127
1158, A TV20-127
1159, A TV20-127
1160 TV20-130
1161 TV20-130
1162 TV20-130
1163 TV20-130
1163-17 TV7-147
1164 TV20-130
1165 TV20-130
1173-17 } Air King
1173-20 } 700-100
1175-21 TV7-147
1181-20 uses type
Air King 700-100
1183-21 TV7-147
1183-21 } Air King
1188-20 } 700-100
1199-21 TV7-147
1190 TV20-127
1191 TV20-127
1191-17 uses type
Air King 700-100
1192 TV20-127
1193 TV20-127
1212 1962-108
1213 1962-108
1214 1962-108
1320 One-184
1322 One-184
1324 One-184
1326X One-184
1386 One-184
1450 One-184
1454 One-184
1456 One-184
1531 One-184
1907 One-187
1923 One-185
1933 One-185
1939 One-187
1957 One-187
1983 One-185
1993 One-185
2000 1962-109
2003 1953-120
2004 1953-120
2005 1953-120
2006 1953-120
2018 1962-111
2019 1962-111
2028 1953-117
2035 1962-112

Sears (Continued)

2036 1962-112
2037 1962-112
2038 1962-112
2046 like 1045
2075 1962-110
2076 1962-110
2077 1962-110
2100 } All use
2150 } Air King
2190A } 700-100
2130 TV20-127
2131 TV20-127
2132 TV20-127
2133 TV20-127
2134 TV20-127
2135 TV20-127
2160 TV20-130
2161 TV20-130
2162 TV20-130
2163 TV20-130
2164 TV20-130
2165 TV20-130
2170 see 100.209
2172 see 100.208
2195 see 100.208
2200 1953-118
2202 1953-118
2203 1953-118
2215 1953-119
2217 1953-119
2218 1953-119
3004 1954-103
3005 1954-103
3006 1954-103
3007 1954-104
3008 1954-104
3009 1954-104
3040 1954-105
3045 1954-105
3046 1954-105
8102X TV9-133
3104A TV9-133
3112X TV9-133
3170 see 100.210
8177 see 100.210
3187 see 100.210
3195 see 100.210
3210 1953-121
3215 1954-106
3217 1954-106
8218 1954-106
3251 Four-138
3361 Four-140
3451 Four-138
3461 Four-140
3551 Four-138
3561 Four-140
3621 Four-140
4001 1964-144
4002 1964-144
4003 1964-144
4030 1964-145
4032 1964-146
4033 1964-146
4034 1964-146
4043 1964-147
4044 1964-147
4079 1964-148
4080 1964-148
4081 1964-148
4082 1964-148
4108, -A TV9-133
4112 TV9-133
4113A, B TV9-133
4118B, C TV9-133
4119A TV9-133
4125 TV9-133
4127C, D TV9-133
4129A, B TV9-133
4133 TV9-133
4135, -B TV9-133
4140E TV9-133
4150E TV9-133
4153E TV9-133
4156E TV9-133
4170 uses Arvin
TE858-1
4414 One-186
4415 One-186
4500 One-186
4505 One-186
4506 One-186
4509-11 One-186
5036 1955-89
5042 1955-89

Sears (Continued)

5045 1955-90
5046 1955-90
5113 TV9-128
R-5561 Four-141
5601A Four-142
5732 Four-141
6011 Seven-123
6012 Seven-133
6020 1956-135
6021 1956-135
6025 1956-135
6026 1956-135
6050 Seven-129
6056A 1956-136
6057A 1956-136
6071 Seven-129
6285 Eight-149
6285A Eight-149
6320 Three-117
6321 Three-118
6322 Three-118
6323 Three-118
6324 Three-119
6325 Three-121
6337 Three-120
6253 Three-122
6354 Three-122
6355 Three-122
6362 Three-122
6364 Three-123
6368 Three-125
6382 Three-125
6400 Three-124
6401 Three-124
6402 Three-124
6403A Three-124
6404A Three-124
6405A Three-124
6406A Three-124
6421 Three-118
6424 Three-119
6425 Three-121
6437 Three-120
6438B Three-121
6439B Three-121
6440 Three-121
6449 Four-142
6493 Three-119
6497 Three-121
7003, 7004 ARVIN RE-391
7004 One-184
7006 1957-11
7007 1957-11
7010, 7011, 7012 Use ARVIN 2563
7013 1957-12
7014 1957-12
7018 1957-143
7020 48 Eight-152
7020 1957-144
7021 1957-144
7021 Eight-152
7022 1957-144
7025 1957-146
7026 1957-146
7027 1957-146
7054 Seven-130
7080 Seven-130
7080 Nine-122
7083 Five-130
7086 Eight-151
7090 Seven-130
7094 Five-129
7103 Eight-151
7116 Seven-131
7117 Seven-131
7165 Eight-152
7166 Eight-152
7210 Eight-154
7222 1957-145
8000 Eight-150
8005, 8006, 8007 Like ARVIN 5578
8009, 8010, 8011, 8012 Same As ARVIN 2585 1959-12
8013, 8014, 8015 Similar to Sears 7013
8020 Nine-120

Sears (Continued)

8038 1962-113
8070 Nine-122
8080 Nine-119
8083 Nine-122
8084 Nine-122
8086 Nine-124
8101 Nine-122
8102 Nine-124
8102A Nine-124
8102B Nine-124
8107A Nine-121
8108 Nine-121
8108A Nine-121
8144 Eight-153
8150 Eight-152
8153 Nine-123
8153A Nine-123
9002 thru 9006 Similar ARVIN 2581
9007, 9008, 9009, 9010 Same as ARVIN 2585 1959-12
9011, 9012, 9013 Like Sears 7013
9014, 9015, 9016 Same as ARVIN 3588
9019 1960-137
9020 1960-137
9021 1960-137
9022 Ten-145
9022 1960-137
9023 1980-137
9023.5 1960-137
9040, A 1962-113
9073 Ten-148
9103 Eleven-121
9105 Ten-145
9202, A 1960-138
9203, A 1960-138
9214 1960-137
9215 1960-137
9216 Same As ARVIN 8581
9217A 1960-137
9218A 1960-137
9222 1960-138
9265 Nine-73
100.201 Eleven-123
100.208, 100.209, 100.210 see data in TV7-155
100.700-100 etc. see Air King same Chassis Nos.
101.565 Three-124
101.566 Three-124
101.570 Three-119
101.571 Three-118
101.572 Three-121
101.576 Three-120
101.577 Three-122
101.582 Three-125
101.585 Three-117
101.594 Three-125
101.614 Four-139
101.615 Four-139
101.617 Four-141
101.628 Four-142
101.660-1A Six-116
101.662-2B Six-117
101.662-2D Six-118
101.666A Eight-149
101.666B Eight-149
101.667 Five-129
101.682 Five-131
101.686 Five-130
101.800 Six-119
101.801 Six-120
101.807 Eight-152
101.808 Seven-130
101.809 Nine-122
101.810 Seven-130
101.811 Seven-130
101.814 Nine-124
101.817 Nine-122
101.820 Eight-154
101.823 Eight-152
101.825 Seven-131
101.851 Nine-121

Sears (Continued)

101.852 Nine-119
101.860 Twelve-122
109.356 Four-140
109.371 Four-141
109.634 Eight-153
109.835 Nine-123
110.466 Eight-151
110.490 Eleven-121
110.700 TV6-141
110.700-1 TV5-141
110.700-2 TV5-141
110.700-10 TV5-141
110.700-20 TV5-141
110.700-40 TV5-141
110.700-50 TV5-141
182.068 uses Arvin TE258-1
132.09000 1956-135
132.39900 1957-11
132.40000 uses Arvin 2563
132.40100 1957-12
132.41000 uses Arvin RE-391
132.42700 See 8005
132.42800 See 8009
132.42900 See 8013
132.44400 See 9002
132.44500 See 7013
132.45100 1960-138
132.45102 1960-138
132.45600 See 9007
132.45700 See 9014
132.45800 See 9216
132.63901 1962-109
132.64402 1962-111
132.75901 1964-144
132.802 Four-138
132.816 Seven-133
132.818 Six-121
132.825 Seven-129
132.826 Seven-129
132.838 Eight-150
132.841 Nine-120
132.871 Ten-146
132.875 Ten-145
132.877 Ten-145
132.878 Ten-147
132.881 Twelve-118
132.896 Twelve-117
135.244 Ten-148
139.150 Six-122
431.199 Eight-153
456.51710 TV20-127
456.51711 TV20-127
456.51712 TV20-127
456.51713 TV20-127
456.51754 TV20-130
456.51755 TV20-130
478.233 Eleven-119
478.233 Twelve-120
478.239 Twelve-132
478.319 TV7-147
478.341 TV7-147
478.375 TV7-147
478.376 TV7-147
478.380 TV7-147
478.381 TV7-147
528.171 Eleven-122
528.171-1 Eleven-122
528.174 Eleven-120
528.194 Twelve-121
528.195,-1 Twelve-121
528.210 Twelve-119
528.228 1953-119
528.230 1953-117
528.238 1953-119
528.241-1 1953-121
528.259 1953-118
528.271 TV9-133
528.292 TV9-133
528.300 TV9-133
528.303 TV9-133
528.253 1954-105
528.254 1954-105
528.265 1954-106
528.32400 1955-89
528.32500 1955-89
528.34900 1955-90
528.40400 1956-135
528.40500 1956-136

Sears (Continued)

528.46500 1957-143
528.46600 1957-144
528.46700 1957-146
528.46701 1957-146
528.48000 1957-145
528.51710 TV20-127
528.51711 TV20-127
528.51712 TV20-127
528.51713 TV20-127
528.51754 TV20-130
528.51755 TV20-130
528.53071 1962-113
528.53300 1960-137
528.53310 1960-137
528.53350 1960-137
528.53400 1960-138
528.53500 1964-146
528.53580 1962-110
528.53740 1962-108
528.53760 1962-112
528.53880 1962-106
528.53940 1962-107
528.54071 1962-110
528.54400 1964-145
528.54670 1964-147
528.54880 1964-148
549.101 similar to Hallicrafters L800D
757.110 1953-120
757.120 1954-104
757.130 1954-103

SENTINEL RADIO

1U-284I Six-123
1U-284NA Six-123
1U-284NI Six-123
1U-284W Six-123
1U-285P Six-125
1U-293CT Eight-157
1U-293I Six-129
1U-293T Six-129
1U-293W Six-129
1U-294I Six-130
1U-294T Six-130
1U-294W Six-130
1U-312PG Ten-149
1U-312PW Ten-149
1U-314E Nine-126
1U-314I Nine-126
1U-314W Nine-126
1U332-I,-W similar to 332-I
1U-335PG Ten-154
1U-335PI Ten-154
1U-335PM Ten-154
1U-335PW Ten-154
1U338-I Twelve-123
1U338-R Twelve-123
1U338-W Twelve-123
1U-339-K Ten-155
1U-343 1953-122
1U-344 1953-123
1U-345P 1953-127
1U-346 1953-124
1U-347P 1953-125
1U-348P 1953-126
1U-352 1954-107
1U-353 1955-91
1U-354P 1954-108
1U-355P 1954-109
1U-356 1954-110
1U-360 1956-138
1U-363 1956-139
1U-364 1956-140
1U412 TV5-147
1U418 TV5-147
1U414 TV5-147
1U415 TV5-147
1U416 TV5-147
1U420 TV5-147
1U423 TV5-147
1U424 TV5-147
1U-458 TV7-141
1U-459 TV7-141
1U-460 TV7-141
1U-461 TV7-141
1U-631, 1U-582, 1U-534, 1U-585 40 MC version of 1U458
1U-701 TV9-137
1U-711 TV9-137
1U-714 TV9-137
1U-721 TV9-137

Sentinel (Cont.)

1U-724 TV9-137
1U-752 TV9-137
1U-755 TV9-137
1U-758 TV9-137
1U-762 TV9-137
1U-765 TV9-127
1U-768 TV9-137
1U-791 TV9-137
1U-901 TV9-148
1U-911 TV9-143
1U-914 TV9-143
1U-921 TV9-148
1U-924 TV9-143
1U-991 TV9-143
1U-1001B, 1U-1011B, 1U-1017B, 1U-1034B Similar to 1U-901 in TV-9
248 Four-143
284I Six-123
284NA Six-123
284NI Six-123
284W Six-123
285P Six-125
286P Eight-155
286PR Eight-155
289T Six-127
292K Seven-129
N292K Seven-139
293-CT Eight-157
293I Six-129
293T Six-129
293W Six-129
294I Six-120
294N Six-130
294T Six-130
309-I Eight-156
309-N Eight-156
309-R Eight-156
309-W Eight-156
312PG Ten-149
312PW Ten-149
314E Nine-126
314-I Nine-126
314W Nine-126
328K Nine-127
329-I Nine-125
329-R Nine-125
329-W Nine-125
331-I,-R,-W Ten-150
332-I,-W Ten-151
333-I,-W Ten-152
335PG Ten-154
335PI Ten-154
335PM Ten-154
335PW Ten-154
338-I Twelve-123
338-R Twelve-123
338-W Twelve-123
339-K Ten-155
343 1953-122
344 1953-123
345P 1953-127
346 1953-124
347P 1953-125
348P 1953-126
252 1954-107
353 1955-91
356 1964-110
IU-357 1955-92
IU-358 1955-92
359P 1956-137
IU-365 1956-141
IU-367 1956-142
IU-368 1956-142
412 TV5-147
413 TV5-147
414 TV5-147
415 TV5-147
416 TV5-147
420 TV5-147
423 TV5-147
424 TV5-147
429, 430, 431 similar to 423
433 TV6-147
IU-438 TV6-147
439 TV6-147
IU-439 TV6-147
440 TV6-147
IU-440 TV6-147
441 TV6-147
IU-441 TV6-147
443 TV6-147

Sentinel (Cont.)

IU-443 TV6-147
444 TV6-147
IU-444 TV6-147
500 TV8-135
510 TV8-135
511 TV6-135
512 TV8-135
518 TV8-185
515 TV8-185
532 TV8-125
542 TV8-185
552 TV8-135
554 TV8-125
562 TV8-185
564 TV8-135
701 see IU-701
711 see IU-711
712 see IU-711
714 see IU-714
715 see IU-714
721 see IU-721
722 see IU-721
724 see IU-724
725 see IU-724
CR-729 1958-158
901 see IU-901
911 see IU-911
914 see IU-914
921 see IU-921
924 see IU-924
991 see IU-991
IU-1101 TV11-122
IU-1111 TV11-122
IU-1121 TV11-122
IU-1124 TV11-122
IU-1126 TV11-122
IU-1127 TV11-122
IU-1131 TV11-122
IU-1134 TV11-122
IU-1136 TV11-122
IU-1137 TV11-122
IU-1145 TV11-122
IU-1147 TV11-122
IU-1155 TV11-122
IU-1157 TV11-122
IU-1161 like -1121
IU-1164 like -1124
IU-1165 like -1126
IU-1171 like -1131
IU-1174 like -1134
IU-1175 like -1126
2911 see IU-911
2914 see IU-914
21011B, 21017B like IU-901 plus Remote Control
21101 TV11-122
21121 TV11-122
21145 TV11-122
IU-21161 see 21121
IU-21164 see 21121
IU-21165 see -1126

SILVER (McMURDO) CO.

906 Eight-159
VOMAX Seven-76

SILVERTONE

see Sears, Roebuck

SONORA RADIO

78 Seven-141
100 Nine-129
101 Nine-129
102 Nine-128
105 Eleven-124
212 Seven-134
215 Seven-137
218 Seven-136
219 Seven-136
220 Seven-136
222 Seven-138
224 Seven-141
230 Seven-134
238 Seven-141
WA-243 Eight-161
WA-244 Eight-161
WAU-243 Eight-161
WAU-244 Eight-161
WD-233 Eight-162
WD-249 Eight-162
WDU-233 Eight-162
WDU-240 Eight-162

Sonora Radio (Cont)

WGF-241 Eight-160
WGF-242 Eight-160
WGFU-241 Eight-160
WGFU-242 Eight-160
245 Seven-136
299 Ten-156
300 Ten-156
302 TV5-151
303 TV5-151
306 Ten-156
314 Eleven-124
315 Eleven-124
700 TV2-129
RBM/RBMU Seven-135
RBU Seven-135
RDU Six-132
RGMF/RGMFU Seven-134
RKR/RKRU Seven-137
RMR Seven-136
RQ/RQU Seven-138
RWF/RWFU Seven-141
RX Six-133
RY Six-133
RYM/RYMU Seven-141
RZ/RZU Seven-142

SONY CORP.

TV 8-301W TV20-133
TR-84 1962-114
TR-86 1962-115
TR-608 1962-116
TR-610 1962-117
TR-620 1962-118
TR-730 1964-150
TR-815B, Y 1962-119
TR-7170 1964-151

SPARKS-WITHINGTON

SPARTON

See also Magnavox

CB TV16-149
DC TV16-149
4E3 1953-128
5A3 1954-112
5A3C 1954-112
5B3 1953-129
5B3C 1953-129
5C8 1953-120
5-06 Six-134
5-07PA Eight-164
5-16 Eight-163
6-06 Eight-166
6-26 Eight-165
6-26-PA Eight-165
6B9 Nine-131
6L8 1954-111
7-46,-PA Seven-142
8L3 same as 8W10
8L9 Nine-132
8M10 Eleven-125
8W10 Eleven-125
10-21 Five-126
10T201 uses 22V174
11T209 uses 22V214
11T210 TV9-147
11T309 uses 22V214
12A203 uses 22V214
12A204 TV9-147
12A209 uses 22V214
12A210 TV9-147
12A309 uses 22V214
14A203 uses 22V214
14A204 TV9-147
17A204 like 23U214
18 Series TV16-149
18A204 like 23U214
19A210 like 23U214
20T210 like 23U214
21S173A TV8-139
21S214 TV8-139
21T204 like 23U214
22V174 like 23U214
22V214 tuner diff.
22U214 TV9-147
24U174 TV8-139
24U213 TV8-139
24U214 TV8-139
25CD202 (20" tube) similar to 26SS171

Sparton (Cont.)

25D173, -A are similar to 26SS171
25S172 TV6-153
25SD201A TV6-153
26SD160 TV5-155
26SS160 TV5-155
26SS160B TV5-155
26SS160L TV5-155
26SD170 TV5-155
26SD170D TV6-153
26SD171 TV6-153
26SS171, -A TV6-153
26SD172, -A TV6-153
26SS172, -A TV6-153
26SS172B like above
27D213 TV7-151
27D214 like 27D213
29U213 and 29U214 similar to 27D213
51-01 1959-135
51-04 1959-135
51-07 1959-135
51-09 1959-135
51-11 1959-135
121 Nine-132
141X Eleven-125
141XX Eleven-125
142X Eleven-125
142XX Eleven-125
230 1954-112
232 1954-112
239 1954-112
241 uses 8W10
242 uses 8W10
301 1953-128
305 1953-128
309 1953-128
311C 1954-112
312C 1954-112
315C 1954-112
319C 1954-112
320C 1953-129
321C 1953-129
325C 1953-129
329C 1953-129
342 1953-130
345 1953-130
349 1953-130
350 1954-111
351 1954-111
360 1953-129
361 1953-129
365 1953-129
369 1953-129
380 uses 8L3
381 uses 8L3
511 Four-145
518, 518X One-191
526 Seven-145
530-X Three-128
531-X Five-134
532-X Five-134
540-LX Three-129
558 One-191
568 One-191
578, 578X One-191
580-X Three-130
589 One-192
590-1 Three-131
591 One-189
593 One-189
600 One-192
601-S Four-146
610 One-192
620 One-192
651 Four-147
652-X Five-135
660-M Three-132
CR-729 1958-158
CR-734 1957-147
737AC One-192
761 Four-148
770 Three-133
770PA Three-133
846, -PA Seven-143
880-A Three-133
930 One-188
931AC One-189
1030 Nine-130
1030A Nine-130
1040X Eleven-125
1040XX Eleven-125
1041X Eleven-125

Sparton (Continued)

1041XX Eleven-125
1058 Nine-132
1059 Nine-132
1060 Nine-132
1061 Nine-132
1064 Nine-132
1068 One-190
1072 Nine-132
1078 One-190
1085 Eleven-125
1086 Eleven-125
1090 Eleven-125
1091 Eleven-125
1091 early Four-149
1210 and 1211 uses 8W10 Chassis
1300 1954-111
1301 1954-111
1304 uses 8L3
1305 uses 8L3
5025 TV5-155
5026 TV5-155
5029 TV5-155
5030 TV5-155
5035 TV5-155
5036 TV5-155
5037 TV5-155
5076 TV5-155
5077 TV5-155
5079 TV5-155
5080 TV5-155
5082 TV5-155
5083 TV5-155
5088 TV5-155
5089 TV5-155
5090 TV5-155
5107 TV6-153
5107X TV6-153
5108 TV6-153
5207 TV6-153
5207A TV6-153
5208 TV6-153
5210 uses 26SS172B
5220 uses 26SD172C
5225 uses 26SD172C
5226 uses 26SD172C
5262 TV6-153
5162X TV6-153
5163X TV6-153
5165X TV6-153
5166X TV6-153
5175X TV6-153
5178X TV6-153
5191 TV6-153
5192 TV6-153
5263 TV6-153
5265 TV6-153
5266 TV6-153
5268 TV6-153
5270 to 5273 use 26SD172C
5288, 5289, and 5292 to 5299 all use 25CD202
5321 Five-137
5325 and 5326 use 26D173A
5342A TV7-151
5343A TV7-151
5362 and 5363 use 25D173A
5382A TV7-151
5383A TV7-151
5384A TV7-151
5385A TV7-151
5386A TV7-151
5521 Five-137
10352 TV7-151
10353 TV7-151
11322A TV8 139
11324A TV8-139
15312A TV8-139
15314A TV8-139
20312 TV8-139
20313 TV8-139
21322 TV8-139
21322A TV8-139
21324 TV8-139
22312, 22313, 23322, 23323 } Use 29U213 same + UHF

Sparton (Continued)

31322 TV8-139
32324 TV8-139
33322 TV8-139
34324 TV8-139
35342 TV8-139
35343 TV8-139
36342 TV8-139
36343 TV8-139
39312, 39313 } Use 27D214
40312, 40313, use 29U214
41322, 41323, use 27D214
42322, 42323, 42324 } Use 29U214 Chassis
43342, 45344 } Use 27D214
46344 see 29U214
47352, 47353, use 27D214
48352, 48353, use 29U214
50312 TV8-139
50314 TV8-139
58112 TV8-139
58114 TV8-139

SPIEGELS, INC.

130 Three-135
601 Three-134
TA-616 Five-138
T-618 Five-138
631-6 Three-135
822 Five-139
922 Five-139
EP-2450 Five-138
DP7002-4 Five-138
DP-7014 Five-139
DP-7450 Five-138
P Three-134

STEWART-WARNER

01-6G Three-136
01-6G-Z Three-136
01-6K Three-137
01-6M Three-137
02-4A Three-138
03-5S Three-139
03-6J Three-140
03-6J-Z Three-140
03-6L Three-140
03-6L-Z Three-140
A-6S Three-141
07-32 Three-141
11-5V Four-150
11-5W Four-151
11-6T Four-153
11-6T-S Four-153
11-8D Four-154
11-8D-Z Four-154
15-5Y Four-152
17T-9620A TV9-151
17T-9620B TV9-151
21C-9210C, -CX similar to 9210C
21C-9211D TV7-155
21C-9211E TV7-155
21C-9211F TV7-155
21C-9211G as above
21C-9300E TV8-143
21C-9300F TV8-143
21C-9300G TV8-143
21C-9300K TV8-143
21C-9300KB TV8-143
21C-9300L TV8-143
21C-9300LB TV8-143
21C-9300M TV8-143
21C-9300MB TV8-143
21C-9300P TV8-143
21C-9340K, KB, L, LB, M, MB, P, similar to 21C-9300
21C-9630C TV9-151
21C-9630CB TV9-151
21C-9630D TV9-151
21C-9700R TV9-154
21C-9700RB TV9-154
21C-9700W TV9-154
21C-9700WB TV9-154
21C-9700X TV9-154
21C-9700XB TV9-154
21T-9211B TV7-155

Stew.-Warner (Cont)

21T-9211C TV7-155
21T-9300A TV8-143
21T-9300AA TV8-143
21T-9300B TV8-143
21T-9300D TV8-143
21T-9300H TV8-143
21T-9300HA TV8-143
21T-9300R TV8-143
21T-9300RB TV8-143
21T-9300S TV8-143
21T-9300T TV8-143
21T-9340A, -R, -RB similar to 21T-9300
21T-9630A TV9-151
21T-9630AB TV9-151
24C-9360 TV8-143
24C-9370 TV8-143
27C-9310 TV8-143
27C-9350 TV8-143
A41T1 Eight-167
A51T1 Eight-168
A51T2 Eight-168
A51T3 Eight-168
A51T4 Eight-168
C51T1 Nine-134
C51T2 Nine-134
51T46 Seven-146
51T56 Seven-146
51T126 Seven-147
51T136 Seven-147
51T146 Seven-147
51T176 Seven-147
61T16 Six-135
61T26 Six-135
61TR36 Seven-148
61TR46 Seven-148
A61CR1 Eight-169
A61CR2 Eight-169
A61CR3 Eight-169
A61CR4 Eight-169
A61P1 Nine-135
A61P2 Nine-135
A61P3 Nine-135
B61T1 Nine-136
B61T2 Nine-136
62T36 Seven-149
R-100A, B, E One-193
R-102 One-195
112 One-194
R-134 One-197
R-136 One-196
R-160 One-198
205A Five-140
205B Five-140
205F Five-141
205G Five-142
206B Five-143
206C Five-143
206D Five-144
206E Five-144
206G Five-145
207D Five-146
208B Five-147
208C Five-147
950AC One-199
1121 One-194
1341-1349 One-197
1361-1369 One-196
9000-B Six-137
9001 Seven-150
9002A, B, P, R, Six-139
9005-A, B Six-141
9007-A Six-143
9007-F, G Six-143
9009-B Six-145
9013-A Seven-152
9014-E Six-147
9020-A Eight-168
9032 Eight-167
9034 Eight-169
9036-A Nine-135
9036-B Nine-135
9036-C Nine-135
9045-A Nine-134
9045-B Nine-134
9046-A Nine-136
9046-B Nine-136
9120-A -B TV5-159
9120-C -D TV5-159
9120-E-F TV5-159
9121-A TV5-159
9121-B TV5-159

Stew.-Warner (Cont)

9151-A Ten-157
9152-A, -B, Ten-160
9153-A Eleven-127
9154-C Eleven-128
5154-CZ Eleven-128
9156-A Eleven-129
9160-A to -E Twelve-125
9161-A Twelve-126
9161-B Twelve-126
9161-C Twelve-126
9162-A Twelve-124
9162-B Twelve-124
9162C to 9162F similar to above
9164-A Twelve-124
9164-B Twelve-124
9165-A 1953-131
9165-B 1953-131
9166-A see 9151-A
9170-B 1954-113
9170-C 1954-113
9170-D 1954-113
9175-B, -BU 1954-114
9175-G, -GU 1954-114
9175-H, -HU 1954-114
9180-B, -H 1954-115
9181-A, -C 1954-116
9181-D to -F 1954-116
9182-C, -H, 1954-116
9186-A, -B 1954-116
9187-B 1954-116
9187-E, -J 1954-116
9200 TV6-159
9202 TV6-159
9203 TV6-159
9204 TV6-159
9210C TV7-155

STROMBERG-CARLSON

HFT 1954-117
HI FI ET 1954-117
1X TV10-166
1XP TV10-166
1X21 TV10-166
1X22 TV10-166
1XP21 TV10-166
1XP22 TV10-166
BP-1 1954-118
C-1 Twelve-127
HFP-1 1954-117
EP-2 1955-94
C-3 1955-93
T-4 1955-93
C-5 1955-93
17 TV5-165
17RP TV5-165
17RP2 TV5-165
21T TV9-157
K-21 TV11-128
KH-21 TV11-128
22T TV9-157
K-22 TV11-128
KH-22 TV11-128
116C TV5-165
116RP TV5-165
116T TV5-165
317 TV6-167
321 TV6-167
400 Three-142
402 Three-143
417 Series TV7-159
421 Series TV7-159
450 Three-144
480 Three-145
515 Four-155
520 Four-156
521 Series similar to 421
530 Four-157
535 Four-157
600 Five-149
621 Series similar to 421
621A TV8-153
622 TV8-153
624 TV8-153
624RP TV8-153
625, -RP TV8-153
635 One-200
900 Five-149
920 Five-150

STROMBERG-CARLSON (Continued)

925 Five-151
955 Five-153
1000 Five-149
1020 Six-151
1025 Five-151
1055 Five-153
1100 Six-149
1101 Seven-154
1110 Seven-156
1120 Six-151
1121 Seven-158
1200 Nine-137
1202 Nine-137
1204 Nine-138
1500 Ten-161
1507 Eleven-130
1608 Eleven-131

STUDEBAKER

AC-2745 1956-149
AC-2746 1956-150
AC-2747 1956-149
AC-2748 1956-150
AC2786 Like Motorola 596-12
AC-2905 1958-28
AC-2906 1958-30
AC-2977 1961-26
AC-2978 1961-27
AC-3084 1961-26
AC-3085 1961-27
AC-3086 1961-26
AC-3087 1961-27
AC-3216 1963-23
AC-3217, AC-3246, AC-3255 } Like Chevrolet 988413
AC-3247 1963-23
AC-3256 1963-23
AC-3351 1964-22
AC-3352 1964-24
AC-3353 1964-22
AC-3354 1964-24
AC-3377 1964-24

SUPERIOR INST.

CA-11 Six-157

SYLVANIA ELECTRIC

1-356 TV6-171
1-366 TV6-171
1-387 TV6-171
1-437-1 TV6-171
1-437-3 diff. I.F. but like 1-437-1
1-441 TV6-171
1-462-1 TV6-171
1-502-1 TV6-171
1-504-1 TV7-167
1-504-2 TV7-167
1-508-1 TV7-167
1-508-2 TV7-167
1-510-1 TV7-167
1-510-2 TV7-167
1-514-1 TV8-159
1-514-3 TV8-159
1-514-4 TV8-159
1-518-1 TV8-164
1-518-2 TV8-164
1-518-3 TV8-164
1-520-1, & 3, -4, -7, -8 TV8-159
1-522-1, -2 TV9-161
1-525-1, 2 TV13-157
1-526-1 to -6 TV10-167
1-527-1, -2 TV10-167
1-530-1, to -6 similar to 1-520-1
1-532-1 TV11-133
1-532-2 TV11-133
1-532-3 thru -4 Similar to above
1-532-5, -6, -7 TV12-165
1-533-1 TV11-138
1-533-2 TV11-138
1-533-7, -8, -9 Similar to above
1-537-5 TV15-153

SYLVANIA Continued

1-537-6 TV15-153
1-539-3 TV15-153
1-539-4 TV15-153
1-541-7 TV17-147
1-541-8 TV17-147
1-541-9 TV17-147
1-541-0 TV17-147
1-542-1 through 1-542-8 TV16-141
1-544-1 TV17-153
1-544-2 TV17-153
1-544-3 TV17-153
1-545-1 TV17-147
1-601-1 Twelve-130
1-601-2 1953-134
1-601-3 1953-134
1-601-4 1954-119
1-601-5 1954-119
1-602-1 Twelve-129
1-602-2 1953-133
1-603-3 1953-133
1-602-4 1955-96
1-602-5 1955-96
1-602-6 1955-96
1-602-7 1955-96
1-602-9 1957-148
1-603-1 1954-120
1-603-2 1954-120
1-604-1 1953-135
1-605-1 1955-98
1-606-1 1954-122
1-607-1, 2, 3 1956-143
1-607-4 1956-145
1-607-5 1957-149
1-607-6 1957-149
1-609-6 1958-161
1-609-7 1959-136
1-610-1 1956-146
1-611-1 1956-146
1-612-1 1957-151
1-612-2 1957-152
1-615-1 1957-150
1-615-2 1957-150
1-616-2 1960-140
1-617-1 1958-159
1-617-4 1960-139
1-621-1 1958-161
1-621-2 1958-161
1-623-1 1958-162
1-624-1 1958-162
1-629-1, 2 1959-137
1-630-1, 2 1959-138
1-631-1 1959-139
1-632, 1, 2 1959-140
1-635-1 1960-142
1-637-1 1960-144
1-638-1, 2, 3 1960-145
1-639-1 1959-136
1-640-1 1959-141
1-642-1 1959-141
1-645-1 1959-142
1-647-1 1961-146
5C03 1959-136
4C09 1961-150
4C15 1961-150
4P05 1961-157
4P06 1961-157
4P14 1961-149
4P15 1961-149
4P19W, + 1962-123
4T09 1961-150
4T15 1961-150
5C10B, P 1961-143
5C11B, T 1961-143
5C12R, T, W 1961-143
5C13 1961-144
5C16, 5C17 } see 5C1D 1961-143
5C18 like 5C12
5P10 1960-144
5P11 1960-144
5P16 1961-147
5T10B, P 1961-143
5T11B, T 1961-143
5T12R, T, W 1961-143
5T13 1961-144
5T16 like 5T10
5T17 1961-152
5T18 see 5T12
6F17 1961-153

SYLVANIA (Cont.)

6F18 1961-154
6P08 1962-121
6P09 1962-121
6T14 1961-145
7K10 1961-155
7K11 1961-155
7P12 1960-145
7P13 1960-139
8F15 1961-148
8F16 1961-148
8P18 1961-151
TH10W uses 682-4
14P101 TV13-157
14P201 TV13-157
AK15 1962-127
AT15 1962-127
AK16 1962-127
AK16 1962-127
AT16 1962-127
TH16 1962-125
17D13R, T TV18-155
17D14W TV18-155
17D15R, T TV18-155
17D17R, W TV18-155
17D18T, W TV18-155
17D19G, S TV18-155
17P110 TV15-153
17P206 TV15-153
AK17 1962-127
AK18 1962-127
19L17 TV20-141
19P08 TV21-133
19P09 TV22-151
19P10 TV19-147
19P11 TV19-147
19P12 TV22-151
19P14 TV22-151
19P35 TV22-151
19P36 TV22-151
19T01 TV18-161
19T08 TV21-133
19T10 TV19-147
19T11 TV19-147
19T12W uses 546-4
19T18 TV19-147
19T19 TV19-147
19T20 uses 563-4
19T21 TV22-151
AK19 1963-160
AK20 1963-160
AT20 1963-160
TH20 1963-158
21C07 TV18-161
21C09 TV18-161
21C401 TV11-133
21C402 TV10-167
21C403 TV11-133
21C404, 21C405 Use 1-532-3
21C414 TV16-141
21C501 TV11-138
21C502 TV11-138
21C508 TV12-165
21C509 TV12-165
21C519 TV16-141
21C524 TV16-141
21C601 TV11-138
21C605, 21C607 Use 1-533-7
21C616 TV16-141
21C621 TV16-141
21D802 TV11-138
21T101 TV11-133
21T102 TV11-133
21T103 TV10-167
21T104 TV11-133
21T105, 21T106 Use 1-532-3
21T110 see 1-532-3
21T121 TV15-153
21T201 TV11-138
21T207 TV12-165
21T208 TV12-165
21T218 TV16-141
21T301 TV11-138
21T303 see 1-533-7
21T305 TV16-141
AK21 1963-160
AT21 1963-160
22M TV6-171
22M-1 TV6-171
AK22 1963-160
23B, 23M TV6-171
23C08 TV18-161

SYLVANIA (Cont.)

23C09 TV18-161
23C10 TV18-161
23C11 TV18-161
23C17 TV17-153
23C18 TV17-153
23C18 TV18-161
23C19 TV17-153
23C20 TV18-161
23C20 TV17-153
23C21 TV17-153
23C26 TV18-161
23C27 TV18-161
23C28 TV18-161
23C29 TV18-161
23C30B, + TV18-163
23C31B, + TV18-163
23C32B, + TV18-163
23C33B, + TV18-163
23C34B, + TV18-163
23C35B, + TV18-163
23C36B, + TV18-163
23C37F TV18-163
23C38F, W TV18-163
23C39F TV18-163
23C84 TV22-143
23E01 use 562-3, -4
23H53 TV20-137
23H54 TV20-137
23H100 TV22-143
23H110 TV22-143
23L45 use 550-1, -2
23L47F uses 555-1
23L48 TV19-141
23L49 TV19-141
23L51D TV19-141
23L52 TV19-141
23L62 TV21-137
23L63 TV21-137
23L66 TV21-137
23L67 TV21-137
23L70 TV21-137
23L71 TV21-137
23L72 TV21-137
23L73 TV21-137
23L74 TV21-137
23L77, 23L80, 23L81, 23L83 Use 569-1, 3 similar TV21-137
23L86 TV22-143
23L87 TV22-143
23L89 TV22-143
23M-1 TV6-171
23M101 TV18-161
23S22 TV17-147
23S23 TV17-147
23S24 TV17-147
23T09 TV18-161
23T10 TV18-161
23T11 TV18-161
23T12 TV18-161
23T12 TV17-153
23T13 TV17-153
23T13 TV18-161
23T14 TV17-153
23T14 TV18-161
23T15E TV18-163
23T16B, + TV18-163
23T17B, + TV18-163
23T41W uses 555-5
23T44B, + TV19-141
23T60 TV21-137
23T61 TV21-137
23T78 TV22-143
23T79 uses 569-1
23T82 TV22-143
23V42 uses 555-5
23V46B, + TV19-141
23V50B, + TV19-141
23V64 TV21-137
23V65 TV21-137
23V68 TV21-137
23V69 TV21-137
23V90 TV22-143
AK23 1963-160
24C601 TV11-133
24C603 see 1-533-9
24M, -1 TV6-171
24M3 TV6-171
24T101 TV11-133
24T201 TV12-165
24T301 TV11-138
FT24 1963-157
25M TV6-171

SYLVANIA (Cont.)

SC25 1963-159
SC26 1964-153
45C13 1961-146
45C14 1961-146
45C20 1962-124
45C31-1 1963-155
45P18 1962-120
45P19 1961-156
45P20 1964-152
45P21 1963-161
45P22 1963-161
45P25 1963-161
45P26 1963-161
45P32 1964-152
45P34 1964-156
45P35 1964-156
Y45C20 1953-161
55C31-1 1963-155 and 1963-156
55C36-1 1963-155 and 1963-156
55P19 1962-122
Y55C20 1962-126
71M, -1 TV6-171
72B, -1 TV6-171
72M, -1 TV6-171
73B, 78M TV6-171
74B, -1 TV6-171
74M, -1 TV6-171
75B, 75M TV6-171
105-14 TV8-159
105B, -BU TV7-167
105M, -MU TV7-167
120-20 TV8-159
120B, -BU TV7-167
120M, -MU TV7-167
126B, -BU TV7-167
126L TV7-167
126M, -MU TV7-167
150A, -L, and 155A, -L, -M, use 1-437-3
172K, -KU TV7-167
172M, -MU TV7-167
175-18 TV8-164
175B, -BU TV7-167
175L TV7-167
175M, -MU TV7-167
176B, -BU TV7-167
176L TV7-167
176M, -MU TV7-167
177B, -BU TV7-167
177M TV7-167
178B, -BU TV7-167
178M, -MU TV7-167
200, 205 Both use 1-504-2
220, 225, 226 Use late version 1-510-2
250 uses 1-504-2
275 uses 1-510-2
300 TV8-159
320 TV8-159
325 TV8-159
326 TV8-159
372 TV8-164
373 TV8-164
375 TV8-154
376 TV8-164
377 TV8-164
400-1, -2 1963-155
405-1 1964-152
406-1 1964-152
407-1 1964-156
410 uses 1-530-1
433 1953-135
454 1954-122
511 TV10-167
511B Twelve-130
511H, -M Twelve-130
512BR Twelve-130
512CH Twelve-130
512GR Twelve-130
512RE Twelve-130
512YE Twelve-130
513 1953-134
514 uses 1-530-1
515 1956-143
518 1955-96
519 1956-143
525 uses 1-530-1
529 uses 1-530-1
541B, -H Twelve-129

SYLVANIA (Cont.)

541M Twelve-129
542BR Twelve-129
542CH Twelve-129
542GR Twelve-129
542RE Twelve-129
542YE Twelve-129
543 1953-133
546-1, -2 TV19-147
546-3, 4, 5 TV19-147
548 1955-96
548-1 thru
548-7 TV18-155
549-1 thru
549-9 TV18-161
550-1, 2, 3 TV18-163
550-7, 8, 9 TV18-163
552-1, 2 TV18-161
552-9 TV18-161
554-1, -2 TV20-137
555-1, 2, 3 TV19-141
555-5, 6, 7 TV19-141
558-1, -2 TV20-141
562-3, -4 similar to 555-1
563 1953-134
563-1, 2 TV21-133
563-4, 5, 7 TV21-133
565-1, 2 TV21-137
565-3, 4, 7 TV21-137
568 1954-119
569-1, -2, -3, -4 like 565-1
571-1, -2 TV22-151
571-3, -4 TV22-151
573-1, -2 TV22-151
574-3, -4 TV22-151
575-1 through 575-6 TV22-143
575-9, -0 TV22-143
593 1953-133
596 TV9-161
598 1955-96
612 TV10-167
614 TV10-167
614 1955-98
622 TV10-167
630-5 thru
630-8 1961-143
630-9 like above
631-2, 3 1961-144
632-3 1961-145
646-5 TV20-137
646-6, -7 1963-155
649-1, 2 1961-147
651-1 thru -4 1961-143
G651 1963-161
652-1 1961-148
653-1 1961-148
G657 1963-161
661-1 1961-149
664-1 1962-120
666-1, -2 1962-121
668-1, 2 1961-150
671-2 TV20-137
673-1 1961-151
676-1 1961-152
677-1 1961-153
678-1 1961-154
679-1 1961-155
680-1 1961-156
681-1 1962-122
682-1, -2 1962-123
682-3 1962-123
682-4 as above
690-1 1961-157
691-1 1962-124
696-3 1963-157
700-2 1962-125
700-4 1963-158
701-1, -2 1963-161
701-2 1963-159
702-1 1962-126
702-2 1964-158
711-1, -2 1963-160
711-1, -2 1962-127
711-3 1962-127
711-3, -5 1963-160
718-1, -2 1963-161
G718 1963-161
801-2 1963-156
823 TV18-161

SYLVANIA (Cont.)

918 1955-95
1100 1961-143
1102 1956-145
1107 1959-137
1108 1959-138
1111 1961-143
1160 1961-143
1202 1957-150
1212 1961-143
1219 1961-143
1286 1961-143
1300 1961-143
1301 1961-143
1303 1959-139
1304 1959-140
1306 1961-143
1309 1961-143
1322 1961-143
1400 1961-143
1512 1961-143
1519 1961-143
1600 1961-143
1701 1961-143
1704 1961-143
1708 1961-143
1709 1961-143
2101 1957-149
2108 1959-137
2109 1959-138
2202 1957-149
2300 1961-147
2301 1957-150
2302 1957-148
2305 1959-140
2400 1961-147
2500 1961-147
2600 1961-147
2700 1961-147
2800 1960-145
2900 1960-145
3100 1960-139
3201 1956-146
3202 1957-152
3203 1958-159
8204 1958-159
3211 1960-139
3302 1956-146
3303 1957-152
3304 1957-152
3305 1958-160
3401 1957-151
3406 1960-140
4307 1958-161
4308 1958-161
4309 1958-161
4312 1959-136
4397 like 4307
4398 like 4308
4399 like 4309
4406 1958-162
4413 1959-142
4416 1959-141
4419 1959-141
4422 1959-142
4501 1958-162
4708 1960-142
5151 1956-143
5184 1954-119
5484 1955-96
5485 like 5484
6010 like 1400
6022 1962-127
6025 1962-127
6028 1962-127
6029 1962-127
7058 uses 682-4
G9200 1963-161
G9400 1963-155

TELE-KING RADIO

RD-1 1953-136
RE-1 1953-137
REP-1 1953-138
RE-2A 1953-139
RKC-54 1954-126

TELE-TONE RADIO

AH Twelve-131
AZ Twelve-131
BL Twelve-131
BO Twelve-132
185 Twelve-131
190 Twelve-131
200 Twelve-131
214 Twelve-131
228 Twelve-131
230 Twelve-132

TEMPLETON RADIO

E-510 to E-519 Eight-170
G-513 Eight-170
G-515 Eight-170

TOSHIBA

7TP-30 1964-157
7TP-403Y 1964-157

TRANSFORMER CORP.

51 One-202
53 One-202
55 One-202
480 One-203

TRAV-LER RADIO

12L50 TV5-173
14B50 TV5-173
14C50 TV5-173
16G50 TV5-173
16R50 TV5-173
16R60 same 16R70
16R70 TV5-173
16T50 TV5-173
17P6025 see data on TV17-159
19A50 TV5-173
36A2 TV7-175
36B2 TV7-175
46-37 1958-163
46A3, 46B3, 46C3 Later versions of 36A2
47A3 TV9-167
48-314 1959-143
48A3 TV9-167
48A4 TV9-167
48C4 TV9-167
49A4 TV9-167
55-37 1955-99
55-38 1955-99
55-39 1955-99
55C42 1957-153
55C46 1957-153
56-38 like 55-38
56C42, 56C45, 56C46 Like 55C42 & 55C46
56C220 1958-164
56C221 like 56C220
56C230 1958-164
56C231 1958-164
56C232 1958-164
56C233 1958-164
56C240 1958-164
59C221, 59C230, 59C231, 59C232, 59C233 SEE 56C230 in 1958-164
60C300 1961-158
60C301 1961-158
60C302 1961-158
60C303 1961-158
60C320 1961-158
60C321 1961-158
60C322 1961-158
60C323 1961-158
61C300, 61C301, 61C302, 61C303 like 60C300 see 1961-158

TRAV-LER (Continued)

65C45 1957-154
90-105 1959-144
102 Six-153
T200 1958-163
T201 1958-163
T202 1958-163
T203 1958-163
T204 1958-163
T210 1960-146
T211 1960-146
T212 1960-146
T213 1960-146
217-32 TV7-175
217-33 TV7-175
217-37 TV7-175
217-331 TV7-175
217-371 TV7-175
220-34 TV7-175
220-35 TV7-175
221-36 TV7-175
236 1958-163
236 1960-146
TR-280A 1959-143
TR-281A 1959-143
TR-282A 1959-143
TR-283A 1959-143
TR-284B, TR-285B, TR-286B, TR-287B Similar to TR-280A 1959-143
317-44 uses 46B3
317-47 uses 46A3
321-46 uses 46A3
321-48 uses 46A3
324-49 uses 46C3
412E4 TV11-143
412E5 TV11-143
412F4 TV11-143
412F5 TV11-143
412G5 TV11-143
412K5 TV11-143
412L5 TV11-143
417E4 TV11-143
417E5 TV11-143
417F5 TV11-143
417G5 TV11-143
419E5 TV11-143
500 Six-154
501 Six-154
510A4 TV11-143
511A4 TV11-143
513A4 TV11-143
513A5 TV11-143
514A4 TV11-143
514A5 TV11-143
517-56 TV11-143
517-67 TV11-143
517-82, -U TV11-143
517-100 TV11-143
518B4 TV11-143
518B5 TV11-143
521-73 TV11-143
521-75 TV11-143
521-76 TV11-143
521-77 TV11-143
521-78 TV11-143
521-79, -U TV11-143
521-80, -U TV11-143
521-81, -U TV11-143
521R90 1955-99
521-R90, U TV11-143
521-R91, U TV11-143
521R91 1955-99
521-110 TV11-143
521-115 TV11-143
524-83 TV11-143
524-84, -U TV11-143
524-85, -U TV11-143
524-86, -U TV11-143
600 Six-154
943-38 TV16-150
947-28 TV16-150
953-28 TV16-150
975-48 TV16-150
1130 1961-158
1150-19 TV17-159
1156-39 TV17-159
1159-120 similar to 1156-39
X1770 TV17-159
1778 TV17-159
1790 TV17-159
5002 Six-153

HOW TO USE THIS INDEX

This Master INDEX will tell you in which SUPREME volume and on what page the material you need is listed. Please refer to the easy-to-follow charts on page 2, and to the explanation at top of page 3, for guidance.

TRAV-LER (Continued)

5015 Ten-162
5019 Eight-171
5022 Eleven-133
5028 Eight-172
5044 Ten-162
5051 Eight-171
5060 Eleven-133
5061 Eleven-133
5066 Eleven-134
5091 1954-123
5170 Twelve-133
5171 Twelve-133
5172 Twelve-134
5180A, -B, -M 1954-123
5182B, -M 1954-124
5210 Twelve-134
5210-60, U TV11-143
5210-61, U TV11-143
5220 1958-164
5300 1953-140
5301 1953-140
5305 1954-124
5356 1954-125
5510 1955-99
6050 see Eleven-59
6053 see Eleven-59
6300 Same as 5300
6305 same as 5305
6514 1956-148
6515 1956-148
6521 1960-146
7000 Six-154
7001 Six-154
7003 Six-154
7004 Eight-172
7005 Six-154
7014 Six-154
7015 Six-154
9051 1954-125
9052 1954-125
9060 1954-125
9061 1954-125
9064 1956-148

TRUETONE
see Western Auto

UNITED AMERICAN
60, 61 One-204

UNITED MOTORS
see DELCO
R-640 One-205
R-663 Three-148
R-664 Three-150
R-665 Three-149
R-666 Three-151
R-667 Three-151
R-668 Three-152
H-669 Three-152
R-673 Three-153
R-675 Three-154
R-677 Three-155
R-678 Three-156
R-705 Nine-143
R-1115HI Three-158
R-1115LO Three-157
R-1116 Three-159
R-1117 Three-160
R-1118 Three-161
R-1119 Three-162
R-1120 Three-163
R-1125 Three-164
R-1131 Three-165
R-1171 Four-160
R-1172 Four-160
R-1173 Four-160
R-1176 Four-159
R-1181 Four-159
R-1186 Four-161
R-1188 Four-161
R-1230 Seven-162
R-1231 Seven-162
R-1232 Seven-162
R-1234 Seven-163
R-1235 Seven-163
R-1236 Eight-173
R-1237 Eight-173
R-1238 Eight-173
R-1244 Nine-140
R-1245 Nine-140
R-1246 Nine-140
R-1401 Five-154

United Mot. (Cont)

R-1402 Five-154
AC-2745 1956-149
AC-2746 1956-150
AC-2747 1956-149
AC-2748 1956-150
4037 One-207
100170 Eleven-136
100205 Eleven-138
100330 identical to 100170
364441 One-208
416394 Eleven-135
472046 1956-151
472047 1956-152
472048 1956-152
480487 1956-160
600565 One-209
601574 One-210
980441 One-207
980690 Seven-166
980733 Seven-166
980744 Eight-174
980745 Eight-174
980782 Ten-163
980797 Nine-141
980798 Nine-141
980899 Ten-164
980980 like 980899
981320 1953-141
981321 1953-142
981550 1954-127
981551 1954-129
981651 similar to 981550
981652 similar to 981551
981707 1956-153
981708 1956-154
982006 One-212
982375 Seven-165
982376 Seven-164
982455 Nine-142
982544 Ten-166
982573 Ten-166
982697 Eleven-137
982698 Eleven-137
982990 1953-143
983004 1953-144
983090 1954-131
983091 1954-133
983204 similar to 983090
983205 see 983091
983334 1956-158
983336 1956-156
984171 Seven-168
984172 Seven-167
984247 Nine-144
984570 Ten-165
984592 Eleven-139
984817 1953-145
984961 1955-104
985100 One-211
985793 Seven-169
986515 Eleven-140
986516 Twelve-28
986668 1953-30
986669 1953-29
987086 1956-159
987087 1955-100
987088 1955-102
987187 1956-164
987364 1956-159
987366 like 987088
987368 1956-160
987573 1957-155
987575 1957-157
987693 1957-159
988568 like 984961
988569 1956-162
988623 1957-161
6480488 1956-152
6480489 1956-152
7253207 Seven-170
7260405 Eleven-135
7260905 Eleven-135
7264165 1954-135
7264185 1954-135
7264195 1954-135
7265825 1955-106
7265845 1955-106
7266027 1956-160
7266047 1956-152
7266067 1956-152

U.S. RADIO & TV

10 One-213
46, 46A One-214
47, 47A One-214

VIDEO CORP. OF AMERICA

600 TV5-171
900 TV5-171

VOCALINE CO.

CC-1 Twelve-128
CC-2 Twelve-128

WALGREEN DRUG CO.

T-501 Five-155
520 Three-166
530 Three-166
562 Five-155

WARDS
see Montgomery Ward

WARWICK MFG. CO.

0-53 Three-167
10-70 Three-167
C100 Six-155
C101 Six-155
C102 Seven-171
C103 Seven-171
C104 Six-155
C105 Six-155
C108 Six-156
C110 Eight-176
11011 Eight-173

WEBSTER-CHICAGO
WEBCOR

14X278-1,2 1959-145
14X280-1 1959-146
14X280-2 1959-148
14X307 1959-147
14X310-1 1961-159
14X331 1961-160
73X014-1 1959-145
100 Twelve-135
100-1 Twelve-135
100-27 Twelve-135
100-55 Twelve-135
100-62 Twelve-135
100-64 Twelve-135
101 Twelve-135
121 1953-147
122 1953-147
123 1953-147
124 1953-147
125 1953-147
210 Twelve-142
1050-1A 1961-159
BC1055 1961-160
MC1055 1961-160
WC1055 1961-160
1172-1 1961-159
1153 1964-158
1296 1963-162
1353 1964-159
1354 1964-158
1356 1964-159
1450 1964-159
1953 1959-145
1954-1 1959-146
1956 1959-147
1963 1959-148
1991 1959-145

WELLS-GARDNER

4B5 Three-168
5A25S Three-169
6B18 Four-163
7C15 Three-170
7D One-110
37D14-600 Six-158
ALL below TV11-151
321A59C-A-504
321A59C-A-554
321A59U-A-504
321A59U-A-554
324A59C-A-576
324A59U-A-576
2321A59C-A-508
2321A59C-A-556
2321A59U-A-508
2321A59U-A-556
2324A59C-A-560
2324A59U-A-560

WESTERN AUTO

2AW2 Seven-180
2D1185A TV6-178
2D1185B TV6-178
2D1190 TV6-178
2D1194 TV6-178
2D1330A TV8-178
2D1331A TV8-178
2D1336A TV8-178
2D1345A TV8-178
2D1352A TV8-143
2D1353A TV8-143
2D1411 see Raytheon 17T18
2D1316A, 2D1326A, 2D1415A, 2D1416A, 2D1426A, 2D2313A, 2D2315A, 2D2414A, 2D2415A, 2D2422A — All use Raytheon Chassis 17T1, 17T2, 21T1, or 21T2, see TV7-136
2D1411A same as Raytheon 21T19
2D1430C similar to 2D1331A
2D1430, 2D1431 — see 2D1330A
2D2052 TV6-178
2D2334A TV8-178
2D2423A, 2D2424A see Raytheon 17T18
2D2423, 2D2424, 2D2425, 2D2426 — ALL employ Raytheon 17T18
2D2425A, 2D2426A see Raytheon 21T19
2D2431, 2D2433 — See 2D1330A
2D2431C 2D2433A similar to 2D2334A
2DC1040A TV17-163
2DC1041A TV17-163
2DC1042A TV17-163
2DC1043A TV17-163
2DC1044A TV17-163
2DC1045A TV17-163
2DC1130A TV18-165
2DC1131A TV18-165
2DC1132A TV18-165
2DC1133A TV18-165
2DC1134A TV18-165
2DC1135A TV18-165
2DC2040A TV17-163
2DC2041A TV17-163
2DC3000 uses Trav-ler 1156-39
4B19 Six-164
4B114 Seven-176
4B115 Ten-167
4C11 Twelve-147
4CL4 1954-143
4P11 Eleven-146
4P12-A Twelve-146
5D116 Six-162
5D120 Six-162
5D127 Ten-167
5D162 Eleven-144
5D165 Eleven-145
5P110 Seven-179
6D110 Six-161
6D117 Seven-175
8AF29 Eleven-143
9AF25B 1953-163
17T8, 21T14, 21T16 — All use Raytheon 17T1, 21T1
23P1-634 Seven-180
25BD2-606 Seven-177
25C23-11 Eleven-147 also Twelve-148
25D26-002 Ten-168
25D26-006 Ten-168
25D26-006 Eleven-141
26A76-650 Seven-173
26A94-862 Ten-169
26C19-61 Seven-178
27A96-952 Eleven-142
225D26-002 Eleven-141

Western Auto (Cont)

227A96-906 Ten-170
237 Twelve-143
325D27-202 Twelve-144
D-924 Three-175
D-976 Three-171
D-1034A Eleven-142
D-1034B Eleven-142
D-1034C Eleven-142
D-1046A Eleven-142
D-1046B Eleven-142
D-1046C Eleven-142
D-1046D Eleven-142
D-1070 Three-172
D-1080 Three-173
D-1091 Three-174
D-1145 Five-159
D-1175 Four-164
D-1176 Five-159
D-1190 Four-165
D-1191 Four-166
D-1294 Five-160
D-1644 Seven-172
D-1645 Seven-173
D-1747 Eight-177
D-1748 Eight-177
D-1836 Nine-145
D-1846 Nine-146
D-1946 Ten-169
D-2002 Ten-167
D-2003 Ten-167
D-2004 Ten-167
D-2017 Ten-168
D-2017 Eleven-141
D-2018 Ten-168
D-2026 Eleven-143
D-2027A Ten-170
D-2042 Eleven-144
DC2082B 1961-161
DC2083B 1961-161
D-2102A Eleven-145
D-2103A Eleven-145
D-2108 Twelve-143
D-2109 Twelve-143
DC2172A 1961-161
DC2173A 1961-161
D-2205 1953-162
D-2214A 1953-162
D-2216A Twelve-68
D-2216B Twelve-68
D-2217A Twelve-68
D-2217B Twelve-68
D-2226A 1953-163
D-2237A Twelve-144
D-2255 1953-164
D-2263 Twelve-145
D-2325-A 1953-165
D-2383 1953-166
D-2386 1954-137
D-2387 1954-137
D-2388 1954-137
D-2389 1954-137
D-2410A 1954-138
D-2411A 1954-138
D-2412A 1954-138
D-2413A 1954-138
D-2418 1954-139
D-2419 1954-139
D-2420 1954-139
D-2552A 1956-165
D-2553A 1956-165
D-2562A 1955-108
D-2563A 1955-108
D-2584 1954-143
D-2585 1954-143
D-2604 Six-160
D-2605 Seven-180
D-2607 Seven-180
D-2610 Six-162
D-2611 Six-162
D-2615 Six-161
D-2616 Seven-175
D-2620 Six-163
D-2622 Seven-174
D-2624 Eight-179
D-2630 Eight-179
D-2634 Eight-180
D-2661 Six-164
D-2665 Seven-176
D-2718 Eight-179
D-2745 Eight-182
D-2815 Nine-147
D2832A 1959-149
D2832F 1959-149

Western Auto (Cont)

D2834A 1959-149
D2834B 1959-149
DC2988A 1959-150
DC2989A 1959-150
DC3085C 1961-162
D-3120A Eleven-146
DC3160 1961-162
D-3210A Twelve-146
D-3300 1954-140
D-3351 1954-141
D-3352 1954-141
D-3353 1954-141
D-3465A 1954-142
D-3500A 1956-166
D-3503A 1955-109
D-3504A 1955-109
D-3615 Seven-177
D-3619 Seven-179
D-3635 Six-165
D-4118 Twelve-147
D-4142A Eleven-147 also Twelve-148
D-4240 Five-158
D-4255 Five-160
D-4320B 1954-144
D-4425B 1955-110
D-4426B 1955-110
D-4630 Seven-178
D-4832 Nine-148
234031 Twelve-145

WESTINGHOUSE ELEC.

ED-1 1964-163
ED-2 1964-163
WR-4 One-174
WR-5, 6, 7 One-177
WR-10 One-159
WR-10-A One-160
WR-12 One-159
WR-12K1 Five-163
WR-12X1 Five-163
WR-12X2 Five-163
WR-12X3 Five-162
WR-12X5 Five-162
WR-12X6 Five-162
WR-12X7 Four-169
WR-12X16 Five-161
H14T170 TV13-161
H14T171, -A TV13-161
H14T172, A TV13-161
H14T198 TV13-161
H14T199 TV13-161
H14TU170 TV13-161
H14TU171 TV13-161
H14TU172 TV13-161
H14TU198 TV13-161
H14TU199 TV13-161
WR-15 One-163
WR-15A One-162
17T241 TV14-175
17TU241 TV14-175
17T242 TV14-175
17TU242 TV14-175
17T243 TV14-175
17TU243 TV14-175
17T244 TV14-175
17TU244 TV14-175
17T245 TV14-175
17TU245 TV14-175
H17C287 TV16-153
H17C288 TV16-153
H17C289 TV16-153
H17C290 TV16-153
H17C291 TV16-153
H17CU287 TV16-153
H17CU288 TV16-153
H17CU289 TV16-153
H17CU290 TV16-153
H17CU291 TV16-153
H17T175, E TV13-161
H17TU175 TV13-161
H17T176, E TV13-161
H17TU176 TV13-161
H17T177, E TV13-161
H17TU177 TV13-161
H17T237C TV13-161
H17TU237A TV13-161
H17T238C TV13-161
H17TU238A TV13-161
H17T239C TV13-161
H17TU239A TV13-161

Westinghouse (Cont)

H17T247 TV15-159
H17T249 TV15-159
H17T250 TV15-159
H17TU247 TV15-159
H17TU249 TV15-159
H17T250R Similar to V-23654
H17TU250 TV15-159
WR-17 One-157
WR-18 One-161
H21K111 TV12-171
H21K111A TV13-167
H21KU111 TV12-171
H21KU111A TV13-167
H21K112 TV12-171
H21K112A TV13-167
H21K112B TV13-167
H21KU112 TV12-171
H21KU112A TV13-167
H21KU112B TV13-167
H21K113 TV12-171
H21K113A TV13-167
H21K113B TV13-167
H21KR113A TV13-167
H21KR113F TV13-167
H21KU113 TV12-171
H21KU113A TV13-167
H21KU113B TV13-167
H21K114 TV12-171
H21K114B TV13-167
H21KR114A TV13-167
H21KR114F TV13-167
H21KU114 TV12-171
H21KU114A TV13-167
H21KU114B TV13-167
H21K115 TV13-167
H21KR115A TV13-167
H21KU115+ TV13-167
H21K116 TV13-167
H21K116A TV13-167
H21KU116,+ TV13-167
H21K185+ TV13-167
H21KU185+ TV13-167
H21K186+ TV13-167
H21KU186+ TV13-167
H21K187A TV13-167
H21KU187+ TV13-167
H21K187B TV13-167
H21K187L TV13-167
H21K188 TV13-167
H21KR188+ TV13-167
H21KUR188+ TV13-167
H21K189 TV13-167
H21KR189+ TV13-167
H21KUR189+ TV13-167
H21KR190+ TV13-167
H21KRU190 TV13-167
H21KUR190+ TV13-167
H21KR191+ TV13-167
H21KRU191 TV13-167
H21KUR191+ TV13-167
H21K194 TV13-167
H21K194C TV13-167
H21K194L TV13-167
H21K194N TV13-167
H21KU194+ TV13-167
H21K204, B TV14-161
H21KU204 TV14-161
H21K204D TV15-167
H21K205D TV15-167
H21K205, H TV14-161
H21KU205 TV14-161
H21K210, A TV15-172
H21K211, A TV15-172
H21K212 TV14-161
H21KU212 TV14-161
H21K213 TV14-161
H21KU213 TV14-161
H21K214 TV14-161
H21KU214 TV14-161
H21K215 TV14-161
H21KU215 TV14-161
H21K216 TV14-161
H21KU216 TV14-161
H21K223 TV14-171
H21KU223 TV14-171
H21K224 TV14-171
H21KU224 TV14-171
H21K225 TV14-171

Westinghouse (Cont)

H21KU225 TV14-171
H21K226 TV14-171
H21KU226 TV14-171
H21K227 TV14-171
H21KU227 TV14-171
H21K228 TV14-171
H21KU228 TV14-171
H21K229 TV14-171
H21KU229 TV14-171
H21K232 TV14-171
H21KU282 TV14-171
H21K233 TV14-171
H21KU233 TV14-171
H21K234, H21KU234, H21K235, H21KU235, H21K236, H21KU236 — K types use V-2371 and KU use V-2381
H21K256, H21KU256, H21K257, H21KU257 — use V-2371, V-2381
H21KU210, A TV15-172
H21KU211, A TV15-172
H21K270 TV16-161
H21K271 TV16-161
H21K272 TV16-167
H21K273 TV16-167
H21K274 TV16-167
H21K275 TV16-167
H21K276 TV16-167
H21K305 TV16-173
H21K306 TV16-173
H21K308 TV16-173
H21K309 TV16-173
H21K310 TV16-173
H21K311 TV16-173
H21K312 TV16-173
H21K313 TV16-173
H21KU270 TV16-161
H21KU271 TV16-161
H21KU272 TV16-167
H21KU273 TV16-167
H21KU274 TV16-167
H21KU275 TV16-167
H21KU276 TV16-167
H21KU305 TV16-173
H21KU306 TV16-173
H21KU308 TV16-173
H21KU309 TV16-173
H21KU310 TV16-173
H21T101 TV12-171
H21T101B TV13-167
H21TU101 TV12-171
H21TU101A TV13-167
H21T104 TV12-171
H21TU104 TV12-171
H21T105 TV12-171
H21TU105 TV12-171
H21T106 TV12-171
H21TU106 TV12-171
H21T107 TV12-171
H21T107A TV13-167
H21TU107 TV12-171
H21TU107A TV13-167
H21T107B TV13-167
H21TU107B TV13-167
H21T108 TV12-171
H21T108A TV13-167
H21T108B TV13-167
H21TU108 TV12-171
H21TU108+ TV13-167
H21T180+ TV13-167
H21TU180+ TV13-167
H21T181A TV13-167
H21TR181+ TV13-167
H21TRU181 TV13-167
H21TUR181+ TV13-167
H21TR182+ TV13-167
H21TRU182 TV13-167
H21TUR182+ TV13-167
H21TR183+ TV13-167
H21TRU183 TV13-167
H21TUR183+ TV13-167
H21TR184+ TV13-167
H21TRU184 TV13-167
H21TUR184 TV13-167
H21T185 TV13-167

Westinghouse (Cont)

H21TRU185 TV13-167
H21TR188+ TV13-167
H21TRU188 TV13-167
H21TUR188 TV13-167
H21TR189C TV13-167
H21TRU189 TV13-167
H21TUR189 TV13-167
H21T201, B TV14-161
H21TU201 TV14-161
H21T201D TV15-167
H21T202, B TV14-161
H21TU202 TV14-161
H21T202D TV15-167
H21T203A TV15-167
H21T203 see V-2371
H21T206, A TV15-172
H21T207, A TV15-172
H21T217 TV15-167
H21TU203A TV15-167
H21TU203, H21TU205A — use V-2381
H21TU206, A TV15-172
H21TU207, A TV15-172
H21T218, A TV14-171
H21TU218+ TV14-171
H21T219A TV14-171
H21TU219+ TV14-171
H21T220, A TV14-171
H21TU220+ TV14-171
H21T221, A TV14-171
H21TU221+ TV14-171
H21T222, A TV14-171
H21TU222+ TV14-171
H21T262 TV16-161
H21T263 TV16-161
H21T264 TV16-161
H21T265 TV16-161
H21T266 TV16-161
H21T267 TV16-161
H21T268 TV16-161
H21T269 TV16-161
H21T270 TV16-161
H21T271 TV16-161
H21T300 TV16-173
H21T301 TV16-173
H21T302 TV16-173
H21TU262 TV16-161
H21TU263 TV16-161
H21TU264 TV16-161
H21TU265 TV16-161
H21TU266 TV16-161
H21TU267 TV16-161
H21TU268 TV16-161
H21TU269 TV16-161
H21TU302 TV16-173
H24K125, H24KU125 through H24K128 and H24KU128 TV12-171
H24K126B TV13-167
H24K126E TV13-167
H24K127B TV13-167
H24K128B TV13-167
H24KR126A TV13-167
H24KR126F TV13-167
H24KR127F TV13-167
H24KU126B TV13-167
H24KU127B TV13-167
H24KU128B TV13-167
H24K130 use V-2343
H24KU130 " V-2353
H24T117, H24TU117 through H24T122 and H24TU122 TV12-171
WR-27 One-169
WR-32 One-179
WR-33 One-169
WR-35 One-179
WR-36 One-181
WR-42X3 Five-164
WR-42X7 Five-164
H-44AC1A 1959-167
H-44AC2A 1959-167
H-45AC1A 1959-167
H-45AC2A 1959-167
H-46AC1 1959-166
H-46AC2 1959-166
H-46AC3 1959-166
H-48SE1 1959-168
H-48SE2 1959-168
H-48SE3 1959-168

Westinghouse (Cont)

H-48SE4 1959-168
H-48SE5 1959-168
H-51MP1 1960-162
H-51MP2 1960-162
H-51MP3 1960-162
H-52MPS1 1960-163
H-52MPS2 1960-163
H-52MPS3 1960-163
H-54ACS1 1960-162
H-54ACS2 1960-162
H-55ACS1 1960-163
H-55ACS2 1960-163
H-56ACS1 1960-160
H-56ACS2 1960-160
H-57ACS1 1960-161
H-57ACS2 1960-161
H-60ACS1 1960-159
H-60ACS2 1960-159
H-61MP2 1961-172
H-61MP3 1961-172
H-62MPS2, H-62MPS3 — like V-2508-02
H-62MPS1A 1964-167
H-62MPS2A 1964-167
H-62MPS3A 1964-167
WR-62K1 Five-165
WR-62K2 Five-165
H-63AC1 1961-176
H-63AC2 1961-176
H-64ACS1 1961-172
H-64ACS2 1961-172
H-65ACS1 1961-177
H-65ACS2 1961-177
H-66ACS1 1961-176
H-66ACS2 1961-176
H-67ACS1 1961-175
H-67ACS2 1961-175
H-68ACS1 1961-174
H-68ACS2 1961-174
H-69ACS1 1962-139
H-69ACS1A 1964-167
H-70ACS-1 1961-173
H-70ACS1A 1963-171
H-70ACS-3 1961-173
H-70ACS3A 1963-171
H-70ACS-4 1961-173
H-70ACS4A 1963-171
H-72MP1 1962-142
H-72MP2 1962-142
H-75AC1, H-75AC2 — Use V-2508-5
H-75AC1A 1964-167
H-75AC2A 1964-167
H-75AC1, H-75AC2, H-75AC4 — Use V-2508-5, 1961-176
H-76ACS1 1962-142
H-76ACS2 1962-142
H-77ACS1, H-77ACS2 — Use V-2508-6
H-78ACS1 1962-138
H-78ACS2 1962-138
H-79ACS1 1962-141
H-79ACS1B 1964-171
H-79ACS2B 1964-171
H-79ACS2 1962-141
H-81ACS1 1962-140
H-81ACS2 1962-140
H-84ACR1 1963-173
H-85MP1 1964-168
H-85MP2 1964-168
H-85MP3 1964-168
H-86ACS1A 1964-170
H-86ACS2A 1964-170
H-86ACS3 1964-170
H-88ACS1 1964-171
H-89ACS1 1964-169
H-90ACS1 1964-171
H-90ACS2 1964-171
H-90ACS3 1964-171
H-96AC1 1964-167
H-96AC2 1964-167
HF100BN 1958-172
HF101BN 1958-172
HR102S 1959-164
HR103S 1959-164
H-104 Seven-181
HF104DP 1958-173
H-105 Seven-181
HF105DP 1958-173
HF106DP 1958-173
H-107 Seven-181
H-108 Seven-181
H-110 Seven-182

Westinghouse (Cont)

HF-110AN 1959-165
H-111 Seven-182
HF-111AN 1959-165
HF117DP, S, HF118DP, S, HF119DP, S — use chassis V-2501-1
H-122 Six-167
H-124 Six-166
H-125 Six-166
H-126 Six-166
H-130 Six-167
H-133 Eight-183
H-137 Seven-182
H-138 Seven-182
H-148 Eight-184
H-157 Eight-185
H-164 Nine-149
H-165 Nine-150
H-166 Nine-149
H-166A Nine-149
WR-166 Three-176
H-167 Nine-149
WR-170 Three-176
WR-178-L Four-167
WR-175 Four-167
WR-184 Four-168
H-185 Nine-151
WR-186 Four-169
H-188 Nine-152
H-190 Nine-153
H-191 Nine-153
H-191A Nine-153
H-195 Nine-151
H-198 Ten-171
H-199 Ten-172
H-202 Nine-154
H-204 Nine-154
H-210 Ten-173
H-211 Ten-173
H-220 same as H-190
H-300T5 Ten-175
H-301T5 Ten-175
H-302P5 Ten-174
H-303P4 Ten-176
H-304P4 Ten-176
H-305C8 Ten-177
H-306C8 Ten-177
H-307T7 Eleven-149
H-308T7 Eleven-149
H-309P5 Eleven-151
H-309P5U Eleven-151
H-310T5 Ten-179
H-310T5U Ten-179
H-311T5 Ten-179
H-311T5U Ten-179
H-312P4 Ten-180
H-312P4U Ten-180
H-313P4 Ten-180
H-313P4U Ten-180
H-314P4, -U Ten-180
H-315P4, -U Ten-180
H-316C7 Eleven-149
H-317C7 Eleven-149
H-318T5 Eleven-148
H-318T5U Eleven-148
H-320T5 Eleven-148
H-320T5U Eleven-148
H-321T5 Eleven-148
H-321T5U Eleven-148
H-322T5 Eleven-148
H-322T5U Eleven-148
H-323T5 Eleven-148
H-323T5U Eleven-148
H-324T7 Eleven-149
H-324T7U Eleven-149
H-325T7 Eleven-149
H-325T7U Eleven-149
H-326C7 Eleven-149
H-328C7 Eleven-149
H-331P4U & H-332P4 Twelve-152
H-333P4U Twelve-152
H-334T7U Eleven-149

Westinghouse (Cont)

H-334T7UR Twelve-149
H-335T7U Eleven-149
H-336T5U Eleven-148
H-337T5U Eleven-148
H-338T5U Eleven-148
H-341T5U Eleven-148
H-342P5U Eleven-151
H-343P5U Eleven-151
H-345T5, and H-346T5 same as H-338T5U
H-348P5, to H-349P5 same as H-342P5U
H-350T7 Twelve-153
H-351T7 Twelve-153
H-354C7 Twelve-153
H-355T5 Twelve-151
H-356T5 Twelve-151
H-357C10 Twelve-153
H-359T5 Twelve-151
H-360T5 Twelve-151
H-361T6 Twelve-156
H-365T5 Twelve-151
H-366T5 Twelve-151
H-367T5 Twelve-151
H-368P5 Twelve-150
H-369P5 Twelve-150
H-370T7 Twelve-153
H-371T7 Twelve-153
H-372P4 Twelve-155
H-373P4 Twelve-155
H-374T5 Twelve-151
H-375T5 Twelve-151
WR-375 Three-177
H-376P4 Twelve-155
H-377 Twelve-155
H-377 1954-150
H-378T5 1953-167
H-379T5 1953-167
H-380T5 1953-167
H-381T5 1953-167
H-382T5 1953-168
H-383T5 1953-168
H-384T5 see V-2157
H-385T5 1953-169
H-386T5 1953-169
H-387T5 1953-169
H-388T5 1953-169
WR-388 Four-170
H-389T7 and H-390T7 similar to V-2180-1
H-391T5 1954-147
H-392T5 1954-147
H-393T6 similar to H-361T6
H-394T5 1954-147
H-397T5 1954-149
H-398T5 1954-149
H-400P4 1953-170
H-401P4 1953-170
H-402P4 1953-170
H-403P4 1953-170
H-404T5 1954-147
H-405P5 1954-146
H-406P5 1954-146
H-409P4 1954-150
H-410P4 1954-150
H-411P4 1954-150
H-414P4 1954-148
H-415P4 1954-148
H-417T5 1954-152
H-418T5 1954-152
H-420T5 1954-147
H-421T5 1954-147
H-422P4 1954-151
H-423P4 1954-151
H-424P4 1954-151
H-425P4 1954-151
H-434T5 1954-145
H-435T5 1954-145
H-435T5A 1958-170
H-436T5 1954-145
H-437T5 1954-145
H-437T5A 1958-170
H-438T5 1954-145
H-438T5A 1958-170
H-440T5 uses V-2189

Westinghouse (Cont)

H-443T5 1955-113
H-444T5, -A 1955-113
H-444T5, -A 1955-113
H-445T5, -A 1955-113
H-446T5, -A 1955-113
H-447T4 1955-111
H-448T4 1955-111
H-449T4 1955-111
H-451T5 to H-454T5 all use V-2184-1
H-457T6 1955-114
H-458T6 1955-114
H-459T6 1955-114
H-460T6 1955-114
H-461P4 1954-148
H-462P4 1954-148
H-463P4 1954-148
H-464P4 1954-148
H-465R6 1955-114
H-466R6 1955-114
H-467R6 1955-114
H-468R6 1955-114
H-471T5, H-472T5, H-473T5, H-474T5, use V-2184-5
H-475T5 1955-116
H-476T5 1955-116
H-477T5 1955-116
H-478T5 1955-116
H-479P4 1954-148
H-486T5 1955-116
H-487T5 1955-116
H-488T5 1955-116
H-489T5 1955-116
H-490P4 1955-115
H-491P4 1955-115
H-492P4 1955-115
H-493P4 1955-115
H-494P4 1955-112
H-495P4 1955-112
H-496P4 1955-112
H-499T5A 1955-118
H-499T5, H-500T5, H-501T5, H-502T5, H-503T5 all use Chassis V-2184-6
H-499T5B 1957-164
H-500T5A 1955-118
H-500T5B 1957-164
H-501T6B 1957-164
H-501T5A, H-503T5A — Use V-2238-1
H-503T5B 1957-164
H-504P4 1955-117
H-505P4 1955-117
H-506P4 1955-117
H-507P4 1955-117
H-508P4 1955-115
H-511P4 1956-168
H-512P4 1956-168
H-519P4, H-520P4, H-521P4 — Use V-2188-2 Chassis
H-523T4 1956-169
H-524T4 1956-169
H-525T4 1956-169
H-526T5A uses V-2259-1
H-536T6 1956-167
H-538T4 1956-169
H-539T4 1956-169
H-540T4 1956-169
H-541T5 1956-170
H-542T5 1956-170
H-543T5 1956-170
H-544T5 1956-170
H-545T5 1956-170
H-546T5 1956-170
H-547T5 1956-171
H-548T5 1956-171
H-549T5 1956-171
H-550T5 1956-171
H-551T5 → V-2238-1
H-551T5B 1957-164
H-557P4 1957-166
H-558P4 1957-166
H-559P4 1957-166
H-562P4 1957-165
H-563P4 1957-165
H-563P4A 1957-165
H-564P4 1957-165
H-564P4A 1957-165

Westinghouse (Cont)

H-565P4 1957-165
H-585T5 similar to V-2259-2 1957-164
H-570T4 1958-165
H-571T4 1958-165
H-572T4 1958-165
H-574T4 1957-163
H-575T4 1957-163
H-576T4 1957-163
H-577T4 1967-163
H-580T5, H-581T5, H-583T5 — Like V-2259-2 + clock
H-587P7 1967-167
H-588P7 1957-167
H-589P7 1957-167
H-598P4 1957-166
H-599P4 1957-166
H-598P4, H-599P4, H-600P4 — ALL use V-2271-1
1957-166
602P7 1957-170
H-610P5 1957-168
H-611P5 1957-168
H-612P5 1957-168
H-617P7, A 1957-171
H-618P7, A 1957-171
H-619P7, A 1957-171
H-621P6 1958-168
H-622P6 1958-168
H-626T5, H-627T5, H-628T5 — Similar to V-2259-2
H-626T16 TV5-184
H-627K16 TV5-184
H-628K16 TV5-184
H-629K16 TV5-184
H-629T4A 1959-151
H-630T4A 1959-151
H-630T14 TV5-184
H-631T4A 1959-151
H-632T5 1958-169
H-632T5A 1959-154
H-633C17 TV5-179
H-633T5 1958-169
H-633T5A 1959-154
H-634C17 TV5-179
H-636T6 1958-171
H-636T6A 1959-155
H-636T17 TV5-184
H-637T6 1958-171
H-637T6A 1959-155
H-637T14 TV5-184
H-638K20 TV5-179
H-639T17 TV6-182
H-640T17 TV6-182
H-641K17 TV6-182
H-642K20 TV6-182
H-642K20A TV6-182
H-643K16 TV5-179
H-644T6 1958-171
H-645T6 1968-171
H-646K17 TV6-182
H-647K17 TV6-182
H-648T4 1958-166
H-648T20 TV6-182
H-649T7A 1959-156
H-649T17 TV6-181
H-650T7A 1959-156
H-650T17 TV6-181
H-651K17 TV6-182
H-651P6 1958-167
H-651T17 TV6-181
H-652K20 TV6-182
H-652P6 1958-167
H-653K24 TV6-182
H-653P6 1958-167
H-654T17 TV6-182
H-655K17 TV6-181
H-655P5 1959-157
H-656K17 TV6-181
H-656P5 1959-157
H-657K17 TV6-181
H-657P5 1959-157
H-658T17 TV6-182
H-659P4 1959-158
H-659T17 TV6-181
H-660C17 TV6-182
H-660P4 1959-158
H-661C17 TV6-182
H-662K20 TV6-182

Westinghouse (Cont)

H-662P4 1959-159
H-663P4 1959-159
H-663T17 TV6-181
H-664K17 TV6-181
H-664P4 1959-159
H-666P5 1959-160
H-665T16 TV6-182
H-667P5 1959-160
H-667T17 TV7-179
H-668T17 TV7-179
H-669T5, H-670T5, H-671T5 All like V-2259-2 + clock
H-673K21 TV7-179
H-673T5, H-674T5, H-675T5 All use chassis V-2390-3
WR-674 Three-178
H-676T21 TV7-179
H-677T4 1959-152
H-678K17 TV7-179
H-678T4 1959-152
H-679K17 TV7-179
H-679T4 1959-152
H-681T5 1959-161
H-661T17 TV7-179
H-682T5 1959-161
WR-682 Four-168
WR-682A Four-168
H-683T5 1959-161
H-685P8 1959-162
H-686P8 1959-162
H-688K24 TV7-179
H-669T16 TV7-179
H-690K21 TV7-179
H-690P5 1959-163
H-691K21 TV7-179
H-692T21 TV7-179
H-693P8 1959-153
H-694P8 1959-153
H-695K21 TV7-179
H-695P8 1959-153
H-697P7 1960-148
H-698P7 1960-148
H-699K17 TV7-179
H-699P7 1960-148
H-700T5 1960-147
H-700T17 TV7-179
H-701T5 1960-147
H-701T17 TV7-179
H-702K17 TV7-179
H-702T5 1960-147
H-703K17 TV7-179
H-704T5 1960-151
H-704T17 TV7-179
H-705K17 TV7-179
H-705T5 1960-151
H-706T5 1960-151
H-706T16 TV7-179
H-708T5 1960-152
H-708T20 TV7-179
H-709T5 1960-152
H-710T5 1960-152
H-710T21 TV7-179
H-711T5 1960-152
H-711T21 TV7-179
H-712P9 1961-164
H-712P9A 1963-166
H-713P9 1961-164
H-713P9A 1963-166
H-713T21 TV7-179
H-714K21 TV7-179
H-715K21 TV7-179
H-715T5 1960-153
H-716T5 1960-153
H-716T17 uses V-2208-1
H-718K20 TV7-179
H-718T5 1960-156
H-718T5A 1961-167
H-719T5 1960-156
H-719T5A 1961-167
H-720K21 TV7-179
H-720T5 1960-156
H-720T5A 1961-167
H-721K21 TV7-179
H-721L5 uses V-2401-3
H-722K21 TV7-179
H-722T6 1960-157
H-723K21 TV7-179

Westinghouse (Cont)

H-723T6 1960-157
H-724T20 TV7-179
H-725P6 1960-150
H-725P6A 1961-166
H-725T20 TV7-179
H-726P6 1960-150
H-726P6A 1961-166
H-727P6 1960-150
H-727P6A 1961-166
H-728P6 1960-150
H-728P6A 1961-166
H-729P7 1960-158
H-730C21 TV7-179
H-730P7 1960-158
H-732C21 TV7-179
H-732P7 1962-133
H-732P7GP 1962-133
H-733C21 TV7-179
H-733P7 1962-133
H-733P7GP 1962-133
H-737P7 1961-168
H-737T17 uses V-2216-5
H-738P7 1961-168
H-740T21, H-742K21, and H-743K21, use V-2233-1
H-742T4, H-743T4, H-744T4 Use V-2239-7 1959-151
H-746K31, G-747K21 use V-2233-4
H-746T5A 1962-130
H-747T5A 1962-130
H-748T5 1961-163
H-749T5 1961-163
H-750T5 1961-163
H-750T21 uses V-2221-1 or V-2233-3
H-751T21, H-752T21, use V-2217-4, -5
H-751P4, H-752P4 Similar to H-659P4
H-753K21 uses V-2221-1 or V-2233-3
H-753L5 1961-163
H-754K21 TV7-179
H-755K21 uses V-2233-2
H-755L5 1961-163
H-756K21, H-757K21 use V-2217-4, -5
H-756T5 1961-169
H-757T5 1961-169
H-758K21 & H-759K21 use V-2217-5
H-759T6 1961-170
H-760T6 1961-170
H-760T21, H-761T21, use V-2233-2
H-761N7 1962-134
H-762N7 1962-134
H-764N7 1962-134
H-765N7 1962-134
H-765T17 TV8-169
H-765TU17 TV8-169
H-766L4 Uses V-2239-8
H-766L4A 1962-137
H-766T17 TV8-169
H-766TU17 TV8-169
H-769P7, H-770P7 Use V-2402-1
H-769T21 uses V-2243-1
H-770T21 TV8-169
H-770TU21 TV8-169
H-771P6, + 1961-166
H-771T21 TV8-169
H-771TU21 TV8-169
H-772K21 TV8-169
H-772KU21 TV8-169
H-772P6, + 1961-166
H-773K21 TV8-169
H-773KU21 TV8-169
H-773P6, + 1961-166
H-774K21 TV8-169
H-774KU21 TV8-169
H-775K21 TV8-169
H-775KU21 TV8-169
H-775L6, H-776L6 Use V-2401-2
H-775L6A 1962-132

Westinghouse (Cont)

H-776L6A 1962-132
H-776T21 TV8-169
H-776TU21 TV8-169
H-777N7 1962-134
H-778N7 1962-134
H-779N7 1962-134
H-780N7 1962-134
H-782K21 TV8-169
H-782KU21 TV8-169
H-782T4 1963-163
H-783K21 TV8-169
H-783KU21 TV8-169
H-784K21 TV8-169
H-784KU21 TV8-169
H-784L5, H-785L5 like H-700T5
H-785K21 TV8-169
H-785KU21 TV8-169
H-786K21 TV8-169
H-786KU21 TV8-169
H-787K21 TV8-169
H-787KU21 TV8-169
H-788C21 TV8-169
H-788CU21 TV8-169
H-789C21 TV8-169
H-789CU21 TV8-169
H-790C21 TV8-169
H-790CU21 TV8-169
H-790P6 1962-129
H-790P6GP 1962-129
H-791K21 TV8-169
H-791KU21 TV8-169
H-792K21 TV8-169
H-792KU21 TV8-169
H-791P6 1962-129
H-791P6GP 1962-129
H-793K21, H-793KU21 uses V-2243-1
H-793P6+ 1963-165
H-793P6GP uses V-2397-5
H-794C21 TV8-169
H-794CU21 TV8-169
H-795P6, + 1962-136
H-796P6, + 1962-136
H-798P7, + 1962-133
H-799P7, + 1962-133
H-799T17B uses V-2310
H-800L5, H-801L5, H-802L5 like H-753L5 1961-163
H-803T5 1962-128
H-804L5 1962-131
H-805L5 1962-131
H-806L5 1962-131
H-808L5 1962-130
H-809L5 1962-130
H-810T17 TV8-169
H-810TU17 TV8-169
H-811T17, H-811TU17 use V-2240-1
H-814P7, H-815P7 uses V-2404-2
H-815T24 TV8-169
H-815TU24 TV8-169
H-816L5 1962-128
H-817K24 TV8-169
H-817KU24 TV8-169
H-820L5 1963-164
H-821L5 1963-164
H-822K21, H-822KU21
H-823K21, H-823KU21 all use V-2243-4
H-823L5, H-824L5 use V-2395-3
H-825T5, H-826T5 use V-2395-2
H-827T4 1963-168
H-828T4 1963-168
H-827T21, H-827TU21
H-828T21, H-828TU21
H-829T21, H-829TU21 use V-2263
H-829T4 1963-168
H-830T5 1963-169
H-830K21 uses V-2243-1
H-830KU21 uses V-2263
H-831K21 uses V-2243-1
H-831KU21 uses V-2263

Westinghouse (Cont)

H-831T5 1963-169
H-832T5 1963-169
H-833L4 1963-168
H-835L5 1963-169
H-834K21, H-834KU21
H-835K21, H-835KU21
H-836T21, H-836TU21 use V-2263 or V-2273
H-837L5 1963-169
H-838K21, H-838KU21
H-839K21, H-839KU21 use V-2263
H-838K21B TV9-171
H-838KU21B TV9-171
H-838L5 1963-169
H-839N5 1964-162
H-841P6, + 1963-170
H-841T21 TV9-171
H-841TU21 TV9-171
H-842P6, + 1963-170
H-842T21 TV9-171
H-842TU21 TV9-171
H-843K21 TV9-171
H-843KU21 TV9-171
H-844K21 TV9-171
H-844KU21 TV9-171
H-844T5, H-845T5 See 1963-169
H-846P8++ 1964-160
H-847K21 TV9-171
H-847KU21 TV9-171
H-848K21 TV9-171
H-848KU21 TV9-171
H-848N5 1964-161
H-849N5 1964-161
H-850N6 1964-164
H-851N6 1964-164
H-852N6 1964-164
H-853K24 TV9-171
H-853K24A TV11-155
H-853KU24 TV9-171
H-854K24 TV9-171
H-854K24A TV11-155
H-854KU24 TV9-171
H-855LN6 1964-164
H-856LN6 1964-164
H-861T21 TV9-171
H-861TU21 TV9-171
H-862T21 TV9-171
H-862TU21 TV9-171
H-863T21 TV9-171
H-863TU21 TV9-171
H-864L6, H-865L6 use V-2401-4
H-864T21 TV9-171
H-864TU21 TV9-171
H-865T21 TV9-171
H-865TU21 TV9-171
H-866T21 TV9-171
H-866TU21 TV9-171
H-863T21A, -TU21A, H-864T21A, -TU21A, H-865T21A, -TU21A, H-866T21A, -TU21A, use V-2263
H-867T21 TV9-171
H-867TU21 TV9-171
H-868T21 TV9-171
H-868TU21 TV9-171
H-869K24 TV9-171
H-869K24A TV11-155
H-869KU24 TV9-171
H-869KU24 TV11-155
H-870K24 TV9-171
H-870K24A TV11-155
H-870KU24 TV9-171
H-871N6 1964-164
H-871T21 TV9-171
H-871TU21 TV9-171
H-872N6 1964-164
H-872T21 TV9-171
H-872TU21 TV9-171
H-873N6 1964-164
H-873T21 uses V-2313
H-873T21A, -TU21A uses V-2263
H-875LN6 1964-164
H-875T24(A) TV9-171
H-875T24B TV11-155
H-875TU24 TV9-171
H-876LN6 1964-164
H-876T24 TV9-171

Westinghouse (Cont)

H-876T24B TV11-155
H-876TU24 TV9-171
H-877LN6 1964-164
H-877T24 TV9-171
H-877T24B TV11-155
H-877TU24 TV9-171
H-878K24 TV9-171
H-878KU24 TV9-171
H-879T21, H-880T21 Use V-2312
H-880T5 1964-166
H-881K24 TV9-171
H-881K24A TV11-155
H-881KU24 TV9-171
H-881T5 1964-166
H-882T21 TV10-171
H-882TU21 TV10-171
H-883T21 TV10-171
H-883TU21 TV10-171
H-884K21 TV10-171
H-884KU21 TV10-171
H-885K21 TV10-171
H-885KU21 TV10-171
H-886K21 TV10-171
H-886KU21 TV10-171
H-887K21 TV10-171
H-887KU21 TV10-171
H-888C24 TV11-155
H-888CU24 TV11-155
H-889C24 TV11-155
H-889CU24 TV11-155
H-892T17A, H-894T17A Use V-2316
H-892T17 TV10-175
H-892TU17 TV10-175
H-894T17 TV10-175
H-894TU17 TV10-175
H-896T21 TV10-175
H-896TU21 TV10-175
H-898T21 TV10-175
H-898TU21 TV10-175
H-899T21 TV10-175
H-899TU21 TV10-175
H-900C21 TV10-175
H-900CU21 TV10-175
H-901C21 TV10-175
H-901KU21 TV10-175
H-902K21 TV10-175
H-902KU21 TV10-175
H-903K21 TV10-175
H-903KU21 TV10-175
H-904K21 TV10-175
H-904KU21 TV10-175
H-905K21 TV10-175
H-905KU21 TV10-175
H-908T17 TV10-175
H-908TU17 TV10-175
H-909T17 TV10-175
H-909TU17 TV10-175
H-910T17 TV10-175
H-910TU17 TV10-175
H-908T17A, H-909T17A, H-910T17A Use V-2316 or V-2326
H-912T21 TV10-175
H-912TU21 TV10-175
H-913T21 TV10-175
H-913TU21 TV10-175
H-914T21 TV10-175
H-914TU21 TV10-175
H-916T17, H-916TU17, H-919T17, H-919TU17, H-920T17, H-920TU17, H-921T17, H-921TU17 For all see TV10-175 Models with suffix "A" TV11-159
H-924T21, H-924TU21, H-927T21, H-927TU21, H-928T21, H-928TU21, H-929T21, H-929TU21 For all see TV10-175 Models with suffix "C" TV11-159
H-934T21 TV11-163
H-934TU21 TV11-163
H-935T21 TV11-163
H-935TU21 TV11-163
H-938K21 TV11-163
H-938KU21 TV11-163
H-939K21 TV11-163
H-939KU21 TV11-163
H-941K21 TV11-163

Westinghouse (Cont)

H-941KU21 TV11-163
H-942K21 TV11-163
H-942KU21 TV11-163
H-950T24 TV11-163
H-950TU24 TV11-163
H-951T24 TV11-163
H-951TU24 TV11-163
H-954K24 TV11-163
H-954KU24 TV11-163
H-955K24 TV11-163
H-955KU24 TV11-163
H-956K24 TV11-163
H-956KU24 TV11-163
H-965K21, H-965KU21 For all TV10-175
H-966K21, H-966KU21 For -C TV11-159
H-974T21 TV11-159
H-974TU21 TV11-159
H-975T21 TV11-159
H-975TU21 TV11-159
H-976T21 TV11-159
H-976TU21 TV11-159
H-978T17 TV11-159
H-978TU17 TV11-159
H-979T17 TV11-159
H-979TU17 TV11-159
H-980T17 TV11-159
H-980TU17 TV11-159
H-F1000 1960-159
H-F1001 1960-159
H-F1002 1960-159
H-F1003 1960-159
H-F1010A 1961-171
H-F1011A 1961-171
H-F1012A 1961-171
H-F1013A 1961-171
H-F1016A uses V-2512-3
H-F1020 1963-172
H-F1021 1963-172
H-F1022 1963-172
H-F1023 1963-172
H-F1050B 1961-171
H-F1051B 1961-171
H-F1052B 1961-171
H-F1053B 1961-171
H-R1100 1960-164
H-R1101 1960-164
H-R1102 1960-164
H-R1103 1960-164
H-R1200 1960-164
H-R1201 1960-164
H-R1202 1960-164
H-R1203 1960-164
H-R1204 1960-164
H-M1310B 1962-144
H-M1311B 1962-144
H-M1312B 1962-144
H-M1313B 1962-144
H-M1410 1962-144
H-M1411 1962-144
H-M1412 1962-144
H-M1413 1962-144
H-M1430 1963-174
H-M1431 1963-174
H-M1432 1963-174
H-M1433 1963-174
H-M1650, H-M1651, H-M1652, H-M1653 Similar to data on 1963-174
H-M1700 1962-143
H-M1701 1962-143
H-M1702 1962-143
H-M1703 1962-143
H-M1710, H-M1711, H-M1712, H-M1713 like H-M1700 group 1962-143
H-M1750, H-M1751, H-M1753 Use Chassis V-2515-1
H-M1760 1964-172
H-M1761 1964-172
H-M1763 1964-172
H-M1790 1964-172
H-M1791 1964-172
H-M1793 1964-172
H-M1810A/B 1964-172
H-M1811A/B 1964-172
H-M1813A/B 1964-172
H-M1815A/B 1964-172
H-M1910 1964-172

Westinghouse (Cont)

H-M1911 1964-172
H-M1913 1964-172
H-M1914 1964-172
V-2136 Eleven-149
V-2136-1 Eleven-149
V-2136-2 Eleven-149
V-2136-4 Eleven-149
V-2136-5R Twelve-149
V-2136-5U Eleven-149
V-2137-1 Ten-172
V-2137-2 Ten-171
V-2137-4 Ten-177
V-2144 Ten-173
V-2144-1 Ten-173
V-2148 Ten-175
V-2151-1 Ten-174
V-2153 Ten-176
V-2153-1 Ten-180
V-2156 Eleven-151
V-2156-1U Eleven-151 also Twelve-150
V-2156-2 1954-146
V-2157 Eleven-148
V-2157U Eleven-148
V-2157-1 Eleven-148
V-2157-1U Eleven-148
V-2157-2, V-2157-2U Eleven-148
V-2157-4U Eleven-148
V-2157-5 Twelve-151
V-2157-6 Twelve-151
V-2157-7 Twelve-151
V-2157-8 Twelve-151
V-2157-9 Twelve-151
V-2157-10 1953-168
V-2157-11 1953-169
V-2157-12 1953-169
V-2157-13 1954-147
V-2157-14 1954-147
V-2158-3A TV5-179
V-2161, -U Ten-179
V-2162-4 TV5-179
V-2164U Twelve-152
V-2164-2 1953-170
V-2171 TV5-184
V-2172 TV5-184
V-2175 TV5-184
V-2175-1 used in H-641K17
V-2175-3 TV6-182
V-2175-4 TV6-182
V-2175-5 used in H-641K17
V-2176 TV5-184
V-2178-1 TV6-182
V-2178-3 TV6-182
V-2180-1 Twelve-153
V-2180-2 Twelve-153
V-2180-5 Twelve-153
V-2180-7 Twelve-153
V-2180-7S Twelve-153
V-2180-8 Twelve-153
V-2180-11 similar to V-2180-1
V-2181-1 Twelve-156
V-2181-2 as above
V-2182-1 Twelve-155
V-2182-2 1954-148
V-2184-1 1953-167
V-2184-2 1954-149
V-2184-4 1955-111
V-2184-5 similar to V-2184-1

Westinghouse (Cont)

V-2184-6 similar to V-2184-1
V-2185-1 1954-150
V-2135-2 1955-112
V-2186-1 1954-152
V-2188-1 1954-151
V-2188-2 see above
V-2189-2 1954-145
V-2189-4 1955-113
V-2139-7 1956-167
V-2192-1 to
V-2192-6 TV6-182
V-2194,-1 TV6-182
V-2194-3 TV6-182
V-2200-1 TV6-181
V-2201-1 TV6-182
V-2202-2 TV6-182
V-2202-3 (two SU4G) similar to V-2202-2
V-2203-1 TV6-182
V-2204-1 TV6-181
V-2206-1 TV6-182
V-2207-1 TV7-179
V-2208-1 similar to V-2207-1
V-2214-1 TV7-179
V-2215-1 to -3 TV7-179
V-2216-1 TV7-179
V-2216-2 TV7-179
V-2216-3 TV7-179
V-2216-5 TV7-179
V-2217-1 to -5 TV7-179
V-2218-1 TV7-179
V-2218-11 TV7-179
V-2219-1 TV7-179
V-2220-1 to -4 TV7-179
V-2220-11 TV7-179
V-2221-1 similar to V-2207-1
V-2229-1 1955-114
V-2229-2 1955-114
V-2229-3 1955-114
V-2233-1 to -4 Like V-2217-4 with changes
V-2234-1 1955-115
V-2236-1 1955-116
V-2236-2 1955-116
V-2237-1 1955-117
V-2237-2 1956-168
V-2238-1 1955-118
V-2239-1 1956-169
V-2239-2 1956-169
V-2239-2 1957-163
V-2239-4 1958-165
V-2239-5 1958-166
V-2239-6 1959-152
V-2239-7 1959-151
V-2239-8 as above with clock
V-2240-1 TV8-169
V-2240-2 TV8-169
V-2243-1 TV8-169
V-2243-4 like above
V-2247-1 TV8-169
V-2249-1 TV8-169
V-2250-1 TV8-169
V-2259-1 1956-170
V-2259-2 1957-164
V-2259-3 1960-147
V-2259-7 1962-128
V-2259-8 1962-128
V-2261-1 1956-171
V-2261-2 as above + appl. outlet
V-2263 like V-2243-4
V-2268-1 to V-2266-4 1957-165
V-2271-1 1957-166
V-2273 like V-2263
V-2278-1 1957-167
V-2278-2 1957-168
V-2278-3 1957-171
V-2278-4 1958-167
V-2278-5 1959-153
V-2295-1 1957-170
V-2296-1 1958-168
V-2311 TV13-161
V-2310, V-2312 Like V-2314

Westinghouse (Cont)

V-2313 TV9-171
V-2313-15 TV9-171
V-2313-25 TV9-171
V-2313-35 TV9-171
V-2314 TV9-171
V-2314-15 TV9-171
V-2314-25 TV9-171
V-2315 TV10-171
V-2316 TV10-175
V-2317 TV10-175
V-2318 TV11-155
V-2320, V-2322 Like V-2324
V-2321 TV13-161
V-2323 TV9-171
V-2323-101 TV9-171
V-2323-201 TV9-171
V-2323-301 TV9-171
V-2324 TV9-171
V-2325 TV10-171
V-2326 TV10-175
V-2327 TV10-175
V-2328 TV11-155
V-2340 TV11-159
V-2341 TV11-159
V-2342 TV11-163
V-2343 TV11-163
V-2344 TV12-171
V-2345 TV12-171
V-2346 TV13-167
V-2347 TV13-167
V-2350 TV11-159
V-2351 TV11-159
V-2352 TV11-163
V-2353 TV11-163
V-2354 TV12-171
V-2355 TV12-171
V-2356 TV13-167
V-2357 TV13-167
V-2364-1 TV15-172
V-2364-2 TV15-172
V-2364-3 TV15-172
V-2364-4 TV15-172
V-2365+ TV15-159
V-2365-11 TV16-153
V-2365-12 TV16-153
V-2366-1 TV15-167
V-2366-2 TV15-167
V-2370 TV13-161
V-2371 TV14-161
V-2372 TV14-171
V-2373 TV14-175
V-2374-1 TV16-161
V-2374-2 TV16-161
V-2375-1 TV16-167
V-2375-2 TV16-167
V-2376-1 TV16-173
V-2376-2 TV16-173
V-2377-1 TV16-161
V-2377-2 TV16-161
V-2378-1 through TV17-173
V-2378-6 TV17-173
V-2378-11, 12 similar to above
V-2380 TV13-161
V-2381 TV14-161
V-2382 TV14-171
V-2383 TV14-175
V-2384-1 TV17-169
V-2384-2 TV17-169
V-2384-5 TV18-169
V-2334-6 TV18-169
V-2384-14 TV18-169
V-2384-15 TV18-169
V-2389-1 TV18-175
V-2389-2 TV18-175
V-2389-3 TV18-175
V-2390-1 1958-169
V-2390-3 1958-170
V-2390-4 1959-154
V-2391-1 1958-171
V-2391-2 1958-171
V-2391-6 1959-156
V-2392-4 1959-156
V-2393-1 1959-157
V-2393-3 1960-148
V-2393-4 1962-129
V-2394-1 1959-158
V-2394-2 1959-159
V-2394-3 1959-160
V-2394-5 See above
V-2395-1 1959-161

Westinghouse (Cont)

V-2395-1A 1962-130
V-2395-2 1961-163
V-2395-3 1961-163
V-2395-7 1962-130
V-2395-8 1963-164
V-2396-1 1959-182
V-2397-1 1959-163
V-2397-3 1960-150
V-2397-4 1961-166
V-2397-6 1963-165
V-2398-1 1960-151
V-2398-2 1960-152
V-2398-3 1962-131
V-2399-1 1961-164
V-2399-6 1963-166
V-2400-1 1960-153
V-2400-3 like above
V-2401-1 1960-156
V-2401-2 1960-157
V-2401-3 1961-167
V-2401-4 1962-132
V-2402-1 1960-158
V-2403-1 1962-133
V-2403-3 1962-136
V-2403-4 1962-138
V-2403-5 1962-136
V-2404-1 1961-168
V-2404-2 as above
V-2407-1 1962-134
V-2407-2 1962-134
V-2409-1 TV19-153
V-2409-2 TV19-153
V-2409-3 TV19-153
V-2409-4 through
V-2409-8 TV20-147
V-2409-11 TV20-151
V-2409-12 TV20-151
V-2409-13 TV20-151
V-2410-1 1961-169
V-2410-2 1961-170
V-2411-1 TV19-161
V-2411-2 TV19-161
V-2411-3 TV19-161
V-2411-4 TV19-161
V-2411-5 TV19-161
V-2411-6 TV19-161
V-2412-1 TV19-167
V-2412-2 TV19-167
V-2412-5 TV19-167
V-2412-6 TV19-167
V-2412-11 TV19-167
V-2412-12 TV19-167
V-2414-1 TV19-157
V-2414-2 TV19-157
V-2414-3 TV20-155
V-2414-4 TV20-155
V-2414-5 TV20-155
V-2416-1 through
V-2416-9 TV20-161
V-2416-11 TV20-161
V-2416-12, -13, -14 similar to above
V-2416-15, -16 like V-2416-1
V-2417-1 through
V-2417-6 TV20-167
V-2420-1 1962-137
V-2420-3 1963-163
V-2423-1 1963-168
V-2423-2A 1963-168
V-2424-1,2 1963-169
V-2425-1 1963-170
V-2426-3,M 1964-160
V-2427-1 1964-161
V-2427-2 1964-162
V-2428-3 1964-164
V-2428-4 1964-164
V-2435-1 through
V-2435-13 TV21-143
V-2436-1,2 TV21-153
V-2435-7 through
V-2436-11 TV21-153
V-2437-1 through
V-2437-12 TV21-157
V-2438-1,2 TV21-165
V-2438-5, -6 like above + inst. on

Westinghouse (Cont)

V-2443-1 through
V-2443-4 TV22-157
V-2444-1 through
V-2444-10 TV22-165
V-2450-1 1964-166
V-2500-1 1958-172
V-2501-1 1958-178
V-2502-5 1959-164
V-2503-2 1959-165
V-2503-3 1959-166
V-2503-5 1959-168
V-2506-2 1959-167
V-2506-3 1959-167
V-2506-5 1961-177
V-2506-6 1962-138
V-2507-1 1960-159
V-2507-2 1960-160
V-2507-3 1960-161
V-2507-4 1961-176
V-2507-5 1961-175
V-2507-6 1961-174
V-2507-7 1962-139
V-2507-7 1964-167
V-2507-8 1961-173
V-2507-11 1962-140
V-2507-12 1962-141
V-2507-14 1963-171
V-2507-15 1963-172
V-2508-1 1960-162
V-2508-2 1964-167
V-2508-02 1960-163
V-2508-3 1960-162
V-2508-3 1961-172
V-2508-04 1960-163
V-2508-5 1961-176
V-2508-5 1964-167
V-2508-6 1961-172
V-2508-7 1961-172
V-2508-11 1962-142
V-2508-11 1964-168
V-2508-13 1964-168
V-2508-14 1964-167
V-2509-1 1960-164
V-2509-2 1960-164
V-2510-7 1962-144
V-2510-14 1963-174
V-2511-5 1962-144
V-2512-3 1961-171
V-2515-1 1962-143
V-2515-4 1964-172
V-2515-5 see above
V-2515-8 1964-172
V-2516-1 1963-174
V-2518-1 1963-173
V-2522-1 1964-171
V-2522-2 1964-171
V-2522-3 1964-171
V-2523-1 1964-169
V-2527-1 1964-170
V-2527-2 1964-170
H-P3000, U TV21-165
H-P3001, U TV21-165
H-P3002, U TV21-165
H-P3004 uses V-2438-5
H-P3100, U, H-P3101, U Like V-2365
H-P3150U TV18-169
H-P3160, U TV19-167
H-P3160B, BU TV19-167
H-P3161, U TV19-157
H-P3161B, BU TV19-167
H-P3169, U TV21-157
H-P3170, U TV20-161
H-P3171, U TV20-161
H-P3172, U TV20-161
H-P3173, U TV20-161
H-P3174 TV20-161
H-P3176, U TV20-161
H-P3177 see above
H-P3178, -U uses V-2416-1, -2
H-P3179, U TV21-157
H-P3180, U TV21-157
H-P3161, U TV21-157
H-P3182, H-P3183 Use V-2437-3
H-P3165, U TV21-157
H-P3190, U TV21-157
H-P3191 as above

Westinghouse (Cont)

HP3200, U TV17-169
H-P3210U TV18-169
H-P3211U TV18-169
HP3300, U TV17-169
HP3301, U TV17-169
H-P3310, U TV19-167
H-P3311, U TV19-167
H-P3312, U TV19-167
H-P3320, U TV20-161
H-P3321, U TV20-161
H-P3322, U TV20-161
H-P3323, U TV20-161
H-P3324 TV20-161
H-P3325 TV20-161
H-P8826 TV20-161
H-P3327 TV20-161
H-P3326 TV20-161
H-P3329 TV20-161
H-P3330, U TV20-161
H-P3331, U TV20-161
H-P3332, U TV20-161
H-P3333, U TV20-161
H-P3340, H-P3341, H-P3342 See V-2416-13, V-2416-14
H-P3363 TV21-157
H-P3370, U TV21-157
H-P3371, U TV21-157
H-P3373, U TV21-157
H-P3380 TV21-157
H-P3381, U TV21-157
H-P3390, H-P3393 Use V-2437-8
H-P3396, U use V-2437-5
H-P3400, U TV19-153
H-P3400A, UA TV20-151
H-P3401A, UA TV20-151
H-P3402A, UA TV20-151
H-P3410, U TV20-147
H-P3411, U TV20-147
H-P3412, U TV20-147
H-P3420, U TV21-143
H-P3421, U TV21-148
H-P3423 TV21-153
H-P3424 TV21-153
H-P3425 TV21-153
H-P3430, U TV22-157
H-P3433 TV22-157
H-P3450 TV19-153
H-P3451 TV19-153
H-P3452 TV19-153
H-P3452A TV20-151
H-P3460 TV20-147
H-P3461 TV20-147
H-P3463 TV20-147
H-P3470 TV21-143
H-P8471 TV21-143
H-P3478 TV21-143
H-P3473 TV22-157
HT-3500, U TV16-161
HT-3501, U TV16-161
HT-3502, U TV16-161
H-T3660, U TV19-157
H-T3560B, UB TV20-155
H-T3561B, UB TV20-155
H-T3562B, UB TV20-155
H-T3563B, UB TV20-155
H-T3570, U TV21-143
H-T3571, U TV21-143
H-T3572, U TV21-143
H-T3573, U TV21-143
H-T3600, U TV20-167
H-T3601, U TV20-167
H-T3603, U TV20-167
H-T3604, U TV20-167
H-T3605, U TV20-167
H-T3606, U TV20-167
H-T3607, U TV20-167
H-T3608, U TV20-167
H-T3640 TV22-165
H-T3643, U TV22-165
H-T3670 TV21-143
H-K3680, U TV22-165
H-K3681, U TV22-165
H-K3683, U TV22-165
H-K3685 TV22-165

Westinghouse (Cont)

HT3700, U TV17-173
HT3701, U TV17-173
HT3702, U TV17-173
H-T3710, U TV19-161
H-T3711, U TV19-161
H-T3712, U TV19-161
H-T3720, U TV20-167
H-T3721, U TV20-167
H-T3723, U TV20-167
H-T3730U TV20-167
H-T3732U TV20-167
H-T3740, U TV21-153
H-T2741, U TV21-153
H-T3743, U TV21-153
H-K3760, U TV22-165
H-K3761, U TV22-155
H-K3763, U TV22-165
HK3800, HK3801, HK3802 Use V-2377-1, TV16-161
H-K3810B, UB TV20-155
H-K3811B, UB TV20-155
H-K3820, U TV21-143
H-K3821, U TV21-143
H-K3822, U TV21-143
H-K3830, U TV22-165
H-K3831, U TV22-165
H-K3832, U TV22-165
H-K3850, U TV19-157
H-K3851, U TV19-157
H-K3852, U TV19-157
H-K3860, U TV21-143
H-K3870, H-K3871 Use V-2436-5
H-K3900, U TV20-167
H-K3901, U TV20-167
H-K3902, U TV20-167
H-K3910, U TV21-153
H-K3911, U TV21-153
H-K3912, U TV21-153
H-K3913, U TV21-153
H-K3920, H-K3921 Use Chassis
H-K3923 V-2436-1
H-K3960, U TV21-153
H-K3961, U TV21-153
H-K3970, U, H-K3971, U Like V-2436-7
HK4000, U TV17-173
HK4001, U TV17-173
HK4002, U TV17-173
H-K4010, U TV19-161
H-K4011, U TV19-161
H-K4012, U TV19-161
H-K4013, U TV19-161
H-K4020, U TV20-167
H-K4021, U TV20-167
H-K4023, U TV20-167
H-K4030 TV20-167
H-K4031 TV20-167
H-K4032 TV20-167
H-K4033 TV20-167
H-K4040, U TV21-143
H-K4041, U TV21-143
H-K4043, U TV21-143
H-K4050 TV19-161
H-K4051 TV19-161
H-K4052 TV19-161
H-K4053 TV19-161
H-K4070 TV22-165
H-K4071 TV22-165
H-K4073 TV22-165
HK4100, U TV17-173
HK4101, U TV17-173
HK4102, U TV17-173
HK4103, U TV17-173
H-K4110, U TV19-161
H-K4111, U TV19-161
H-K4112, U TV19-161
H-K4113, U TV19-161
H-K4120, U TV20-167
H-K4121, U TV20-167
H-K4122, U TV20-167
H-K4123, U TV20-167
H-K4130 TV20-167
H-K4131 TV20-167
H-K4150 TV19-161
H-K4151 TV19-161
H-K4152 TV19-161
H-K4153 TV19-161
HK4200, U TV17-173

Westinghouse (Cont)

HK4201, U TV17-173
HK4202, U TV17-173
H-K4210 TV19-161
H-K4211, U TV19-161
H-K4212, U TV19-161
H-K4213, U TV19-161
H-K4214, U TV19-161
H-K4215, U TV19-161
H-K4220, U TV20-167
H-K4221, U TV20-167
H-K4223, U TV20-167
H-K4230 TV20-167
H-K4231, U TV20-167
H-K4240, H-K4241, H-K4242, H-K4243 Use Chassis V-2436-1 TV21-153
HK4300 TV17-173
HK4400 TV17-173
HK4401 TV17-173
HK4402 TV17-173
HK4403 TV17-173
H-K4410 TV18-175
H-K4411 TV18-175
H-K4412 TV18-175
H-K4413 TV18-175
HK4500 TV17-173
HK4501 TV17-173
HK4502 TV17-173
HK4503 TV17-173
H-K4511 TV18-175
H-K4512 TV18-175
H-K4513 TV18-175
H-K4514 TV16-175
H-K4515 TV18-175
HK4600 TV17-173
HK4601 TV17-173
HK4602 TV17-173
HK4800 TV17-173
HK4901U, HK4902U, HK4903U Use Chassis V-2378-11
H-K4910U TV16-175
H-K4911U TV16-175
H-K4912U TV18-175
H-K4913U TV18-175
H-C5200 TV20-155
H-C5201 TV20-155
H-C5203 TV20-155
H-C5220 TV21-143
H-C5221 TV21-143
H-C5223 TV21-143
H-C5230, U TV22-165
H-C5231, U TV22-165
H-C5233, U TV22-165
H-C5250, H-C5251, H-C5253 Use V-2436-12 TV21-143
H-C5300 TV21-153
H-C5301 TV21-153
H-C5302 TV21-153
H-C5303, U TV21-153
H-P9090 TV20-147
H-P9091 TV20-147

WILCOX-GAY CORP.

6A10 Seven-184
6A20 Seven-184
6B10 Seven-183
6B20 Seven-183
6B30 Seven-183
6B32 Seven-183
6B45B Eight-181
6B45M Eight-181
6B45W Eight-181
9J9 Three-179
A-70 Three-179
A-89 Four-171
A-91 Four-171
A-92 Four-171
A-93 Four-171
A-94 Four-171
A-101 Four-171
A-102 Four-171
A-104 Five-166
A-105 Five-166
A-107 Five-167
Recordio Three-179

ZENITH RADIO CORP.

see Next Page

ZENITH RADIO CORP.

L Series TV8-181
1L20 1964-186
1L21 1964-186
2L20 1964-185
SRS2 1959-172
ZP2 1964-186
3B30 1959-170
3B30 1960-165
3B32 1960-177
3K01 1963-185
3K02 1963-185
3L01 1964-185
3L-01 1954-154
3M-02 1954-153
2R-03 like 3M-02
3X01 1956-172
3Y02 1956-173
3Y03 1956-174
3Y04 1956-175
3Y05 1956-176
3Z04 1959-169
4A-01 Three-197
4A-02 Three-196
4A-02 Three-197
4A-04 Three-196
4A40 like 4Z40
4A41 1958-174
4A42 like 4Z41
4B-01 Four-184
4B-02 Five-169
4B-03 Five-169
4B-04 Five-170
4B-05 Five-171
4B22 1959-170
4B22Z 1960-165
4B23 1959-170
4B24 1959-172
4B25 1959-172
4B25 1960-166
4B-422 Three-180
4B-437 Three-180
4B-466 Three-180
4B-468 Three-180
4B-515 Three-197
4B-536 Three-197
4B-639 Five-170
4C-21 Eight-187
4C-52 Six-168
4C-53 Six-168
4C-54 Eight-188
4F-227 One-215
4G21 TV20-190
4G24 1962-156
4H-40 Twelve-158
4J-40 Twelve-162
4K-01 1953-179
4K-016 Six-168
4K21 TV21-188
4K22 TV21-188
4K-035 Six-168
4K-040 Eight-188
4K-040G Eight-188
4K-40 1953-180
4K-422 Three-181
4K-435 Three-181
4K-465 Three-181
4K-466 Three-181
4K-515 Three-196
4K-535 Three-196
4K-600 Four-184
4K-616 Five-169
4K-625 Five-169
4K-640 Five-171
4K-658 Five-169
4L-02 1953-183
4L-03 1954-156
4L21 1964-187
4L-40 1953-180
4L-41 1953-184
4L-42 1953-182
4T-42 1955-128
4Z40 1957-172
4Z41 1957-172
5A-01 Three-199
5A01 like 5Y01
5A02 see 5Z02
5A-02 Three-198
5A-03 Four-173
5A06 like 5Z06
5A08 1958-176
5A09 like 5Z07
5A10 like 5Z10
5A-10 Four-174

Zenith (Continued)

5A41 1958-175
5B-01 Four-185
5B01 1959-173
5B-02 Five-172
5B-03 Five-172
5B04 1959-174
5B-04 Five-174
5B-05 Five-175
5B-06 Five-175
5B06 1959-174
5B-07 Five-176
5B-13 Five-177
5B10 1959-175
5B11 1959-175
5B20 1959-176
5B22 1959-177
5B23 1960-167
5B24 1959-178
5B27 1960-168
5B29 1960-166
5C-01 Six-170
5C-02 Six-172
5C-04 Six-172
5C07 1960-169
5C09 1960-170
5C-40 Eight-190
5C-40Z Eight-190
5C-50 Seven-186
5C-51 Eight-186
5D01 like 5B01
5D-011 Six-170
5D12 1961-181
5D20 1961-178
5D-027 Six-170
5D-610 Four-185
5D-611 Five-172
5D-625 Four-105
5D-627 Five-172
5D-810 Nine-155
5D-811 Nine-155
5E-01 Nine-155
5E-02 Nine-155
5F02 1962-146
5F03 1961-179
5F04 1961-179
5F05 1963-177
5F13 1961-180
5F29 1961-190
5F-134 One-216
5F-166 One-216
5G-002 Eight-190
5G-003Z Eight-190
5G-01 Ten-181
5G-02 Ten-181
5G-03 Ten-182
5G09 1961-182
5G-036 Eight-186
5G29 1962-157
5G-41 Ten-183
5G-438 Three-182
5G-467 Three-182
5G-500 Three-199
5G-501 Three-199
5G-504 Four-173
5G-510 Four-174
5G-524 Four-174
5G-537 Three-198
5G-572 Three-198
5G-602 Five-176
5G-617 Five-175
5G-636 Five-175
5H-01 Eleven-152
5H07 1962-147
5H-41 Twelve-160
5J02 1963-178
5J-03 Twelve-163
5J04 1963-178
5J13 like 5F13
5J-217 One-217
5J-247 One-217
5J-255 One-217
5K-02 Twelve-167
5K-03 similar to 5J-03
5K-04 1953-185
5K10 1962-177
5K29 1963-188
5K-027 Seven-186
5K-637 Five-174
5L-03 has phono similar to 5J-03
5L-06 1954-155
5L-07 1954-155

Zenith (Continued)

5L07 1964-175
5L-08 1954-157
5L-09 1954-157
5L29 1964-187
5L-41 1953-186
5M-02 1954-158
5M-02Z1 1955-119
5R-01 1955-120
5R-03 1955-122
5R-05 1955-121
5R-07 1955-122
5R-10 1955-123
5R-20 1955-124
5R-080 Six-172
5R-086 Six-172
5R-303 One-218
5R-312 One-218
5R-316 One-218
5R-217 One-218
5R-337 One-218
5R-680 Five-173
5R-686 Five-177
5S-29 One-219
5S-56 One-219
5S-119 One-206
5S-126 One-206
5S-127 One-206
5S-150 One-206
5S-151 One-206
5S-161 One-206
5S-201 One-220
5S-218 One-220
5S-220 One-220
5S-228 One-220
5S-237 One-220
5S-250 One-220
5S-252 One-220
5T03 1956-179
5T04 1956-188
5T06 1956-180
5X06 1956-181
5X07 1956-181
5X-230 One-221
5X-248 One-221
5X-274 One-221
5Y01 1956-178
5Y40 1957-173
5Z01 1957-174
6Z02 1957-174
5Z03 1957-175
6Z04 1957-176
5Z05 1957-177
5Z06 1957-178
6Z07 1957-179
5Z08 1957-180
5Z10 1957-181
5Z21 1957-182
5Z21 1958-186
6A-02 Three-201
6A03 1958-177
6A-04 Three-201
6A-05 Three-202
6A-05R Four-189
6A-08 Three-208
6A-10 Three-200
6A-16 Four-175
6A-19 Four-176
6A-20 Four-177
6A-24 Four-187
6A-25 Four-188
6A-26 Four-186
6B-02 Five-178
6B-04 Five-179
6B-05 Five-186
6B05 1959-179
6B06 1959-180
6B-06 Five-181
6B-08 Five-182
6B-09 Five-183
6B-14 Five-189
6C-01 Seven-188
6C03 1960-171
6C-05 Six-174
6C-21 Six-176
6C-22 Six-178
6C-23 Six-180
6C-40 Six-182
6C-50 Eight-192
6CT41Z1 1960-183
6CT41Z5 like 6CT41Z1
6D01 1961-183
6D-014 Seven-188
6D-015 Six-174

Zenith (Continued)

6D-029 Seven-188
6D-030 Six-174
6D-512 Four-175
6D-516 Four-187
6D-520 Four-186
6D-525 Three-200
6D-526 Three-200
6D-538 Four-186
6D-539 Four-175
6D-612 Five-179
6D-615 Five-100
6D-620 Five-189
6D-622 Five-179
6D-623 Five-180
6D-628 Five-179
6D-630 Five-180
6D-644 Five-169
6D-815 Nine-156
6D-2620 Five-189
6E-03 Nine-157
6E-06 Nine-156
6E-89 Ten-192
6ET42Z1 1961-188
6ET42Z2 1961-188
6G-001 Six-182
6G-01 Ten-184
6G-05 Ten-185
6G-05Z1 Twelve-157
6G-038 Eight-192
6G-501 Four-176
6G-533 Four-108
6G-560 Four-188
6GT40Z1 1961-186
6GT40Z2 1961-186
6GT41Z1 like 6CT41Z1
6GT42Z2 1962-150
5H-01 Eleven-153
6H-02 Eleven-153
6H03 1962-148
6H06 1962-149
6J-02 Twelve-166
6J-03 Twelve-166
6J-05 Twelve-164
6J-436 Three-186
6J-462 Three-186
6JT40Z1 1963-184
6JT41Z1 1963-184
6JT45Z1 1963-182
6K-02 similar to 6J-02
6K-03 1953-187
6L-03 1953-187
6K05 1964-181
6KT40Z1 1964-176
6KT40Z8 1964-177
6KT41Z1 1964-179
6KT42Z1 1964-178
6KT45Z1 1964-178
6KT43Z1 1963-180
6KT44Z1 1963-180
6KT47Z1 1964-174
6L02 1964-182
6L06 1964-182
6L-20 1954-159
6MF-080 Seven-185
6MH-081 Seven-187
6MH-889 Ten-192

Zenith (Continued)

6R-03 1955-125
6R-060 Six-180
6R-084 Six-176
6R-087 Six-178
6R-481 Three-184
6R-485 Three-183
6R-583 Three-208
6R-631 Five-178
6R-683 Five-181
6R-684 Five-181
6R-687R Five-181
6R-660 Five-181
6R-880 Nine-157
6S-27 One-222
6S-53 One-222
6S-128 One-223
6S-127 One-223
6S-147 One-223
6S-152 One-222
6S-157 One-222
6S-203 One-224
6S-222 One-224
6S-223 One-224
6S-229 One-224
6S-239 One-224
6S-241 One-224
6S-254 One-225
6S-256 One-225
6S-429 Three-185
6S-469 Three-185
6S-532 Four-189
6S-546 Three-202
6S-556 Three-202
6S-596 Four-177
6S-597 Four-177
6S-632 Five-182
6S-646 Five-182
6S-656 Five-182
6T40 1956-190
6T41 1956-190
6V-27 One-226
6V-62 One-226
6Z03 1957-183
6Z05 1957-184
AP6B 1958-180
AP6J, V 1958-180
BP6B, L, V 1959-181
YP6B 1956-185
YP6F 1956-185
ZP6B, -F, -G as above
7A-01 Three-203
7A-02 Three-204
7A02 like 7T02
7A03 1959-182
7A04 like 7T04
7A05 1958-178
7A-11 Four-190
7AT42 1958-182
7AT42Z1 1958-182
7AT43 1958-185
7AT43Z3 1958-185
7AT44Z1 1959-190
7AT45Z1 1959-185
7AT46Z1 1960-189
7AT47Z 1959-187
7AT47Z2 1959-187
7AT47Z4 1959-187
7AT48Z 1959-184
7AT48Z2 1959-184

Zenith (Continued)

7AT48Z4 1959-184
7B-02 Five-184
7B-04 Five-190
7C02 1960-172
7C05 1960-174
7C06 1960-174
7CT40Z1 1960-179
7CT40Z2 1960-179
7CT43Z1 1960-185
7D-119 One-227
7D-126 One-227
7D-127 One-227
7D-138 One-227
7D-148 One-227
7D-151 One-227
7D-162 One-227
7D-168 One-227
7E-02 Nine-158
7E-22 Nine-160
7F-01 Ten-180
7F-02 Ten-186
7F03 1961-184
7F-04 Ten-186
7F20L TV21-189
7FT45Z1 1961-185
7G-01 Ten-188
7G-02 Ten-189
7G-605 Five-190
7GT40Z2 1962-152
7GT43Z1 like 7CT43Z1
7H-02 Eleven-154
7H-02Z Eleven-154
7H-02Z1 Twelve-161
7H-02Z2 Twelve-161
7H-04 Eleven-155
7H-04Z Eleven-155
7H-04Z1 Twelve-161
7H-04Z2 Twelve-161
7H-822 Nine-158
7H-921 Ten-186
7H-922 Ten-186
7J-03 Twelve-161
7J04 1963-179
7J-20 Twelve-168
7J-232 One-229
7J-259 One-229
7K-01 1953-193
7K-20 and 7K-21 similar to 7J-20.
7K31 1963-190
7KT43Z1, 7KT43Z5 } Uses 710
7KT45Z1 1964-180
7L04 1964-184
7L-05 1953-188
7R-887 Nine-160
7S-28 One-230
7S-53 One-230
7S-204 One-228
7S-240 One-228
7S-242 One-228
7S-258 One-228
7S-260 One-228
7S-261 One-228
7S-323 One-231
7S-342 One-231
7S-343 One-231
7S-363 One-231
7S-364 One-231
7S-366 One-231
7S-449 Three-188
7S-490 Three-189
7S-529 Three-204
7S-530 Three-204
7S-547 Three-204
7S-557 Three-204
7S-558 Three-204
7S-559 Three-204
7S-585 Three-203
7S-598 Four-190
7S-681 Five-184
7S-682 Five-184
7S-685 Five-184
7T02 1956-182
7T04 1956-182
7X03 1956-182
7XT40 1956-184
7XT40, #2 1957-186
7XT40Z 1957-186
7XT40Z1 1957-186
7Y02 1956-182
7Y03 1956-182

Zenith (Cont.)

7YO3Z like above
7Y04 1956-182
7Z20 1958-187
7ZT41 1957-190
AP7F 1958-181
BP7F 1959-181
ZP7L 1957-185
8A-01 Three-205
8A02 like 8Y02
8A-03 Three-206
8A-04 Four-178
8AT40Z2 1958-184
8AT41Z2 1959-186
8AT42Z2 1959-188
8B-01 Five-185
8C-01 Seven-190
8C01 1960-175
8C02 1960-175
8C-20 Six-184
8C-21 Six-187
8C-40 Six-188
8CT40 1960-181
8CT40Z2 1960-181
8CT41 1960-187
8CT41Z2 1960-187
8G-005 Six-188
8G-20 Ten-190
8G-21 Ten-190
8H-20 Eleven-156
8H-023 Seven-190
8H30 TV20-190
8H-032 Six-184
8H-033 Six-104
8H-034 Seven-190
8H-050 Six-184
8H-051 Six-184
8H-052 Six-184
8HT40Z2 1962-154
0KT41Z2 uses 755
8L-20 like 8L-21
8L-21 1953-190
8R-21 like 8L-21
8S-129 One-222
8S-154 One-222
8S-448 Three-190
8S-451 Three-190
8S-463 Three-190
8S-531 Three-206
8S-548 Three-206
8S-563 Three-206
8S-564 Three-206
8S-586 Three-205
8S-593 Four-178
8S-594 Four-178
8S-647 Five-185
8S-661 Five-185
8T-01 1955-126
8Y02 1956-186
AP8J 1958-181
YP8L 1956-185
ZP8 1964-186
ZP8L same as YP8L
9B26 1960-177
9G26 1962-158
9H20LZ1 1963-186
9H20LZ1 TV21-190
9H-079 Six-187
9H-081 Six-187
9H-082 Six-187
9H-085 Six-187
9H-088 Six-187
9L20 1964-188
9S-202 One-223
9S-232 One-223
9S-242 One-233
9S-244 One-232
9S-262 One-233
9S-263 One-233
9S-264 One-233
AP9B 1958-180
10A-1 Three-207
10A-2R Four-192
10A-2 Four-179
10A-3R Four-191
10B-1, -2 Five-186
10H-20 Eleven-158
10H-551 Four-179
10H-571 Four-179
10H-571R Four-191
10H-573 Four-191
10L-20 1954-160
10S-130 One-234

HOW TO OBTAIN DIAGRAMS

The most economical way to secure diagrams and service material you need is to buy SUPREME manuals. This INDEX will permit you to select the volume where any particular material is included. As an extra service, Supreme Publications also will sell service data and diagrams on any Radio or TV model listed in this Index. The charge for material for each radio model is $1, and for any TV model listed $1.50. All material will be sent Airmail. Send orders to:

Supreme Publications

1760 Balsam Road, Highland Park, Illinois

(Warehouse and Branch Office in Chicago, Illinois)

Zenith (Continued)

10S-147 One-234
10S-153 One-234
10S-155 One-234
10S-156 One-234
10S-157 One-234
10S-160 One-234
10S-443 Three-191
10S-452 Three-191
10S-464 Three-191
10S-470 Three-191
10S-491 Three-191
10S-492 Three-191
10S-531 Three-207
10S-549 Three-207
10S-566 Three-207
10S-669 Five-186
10S-690 Five-186
HFY10L, Y 1956-175
SRS10 1959-178
11A20 1958-188
11A21 1958-190
11C-21 Six-190
11C-21Z Eight-189
11L8T25 1964-189
11S-474 Three-192
12A-1 Four-180
12A-6 Five-187
12A-57 One-235
12A-58 One-235
12H-090 Six-190
12H-091 Six-190
12H-092 Six-190
12H-093 Six-190
12H-094 Six-190
12H-678 Five-187
12H-679 Five-187
12K25 1963-189
12L-57 One-235
12L-58 One-235
12S-205 One-236
12S-222 One-236
12S-245 One-236
12S-265 One-236
12S-266 One-236
12S-267 One-236
12S-268 One-236
12S-445 Three-194
12S-453 Three-194
12S-471 Three-194
12S-475 Three-194
12S-494 Three-194
12S-550Z Four-180
12S-568E Four-180
12S-568Z Four-180
12S-569E Four-180
12S-569Z Four-180
12S-595Z Four-180
12U-158 One-237
12U-159 One-237
HFY12E, R 1956-175
14B-1 Five-192
14K20 TV22-173
HF14, HF14E 1954-153
HFR14 uses 3M-02
HFX14, -E 1956-174
15A25 TV14-181
15A26, Q TV15-179
15B20, Q TV15-179
15K37, T TV22-173
15K87Q, Q+ TV22-173
15S-479 Three-193
15S-495 Three-193
15Z30 TV13-179
15Z31 TV13-179
HF15E 1954-153
HF15R 1954-153
HF15E, -R 1954-153
HFR15 uses 3M-02
HFY15E, R 1956-176
SRS15 1959-178
16C20, -Q TV16-179
16C21, -Q TV16-179
16C21Z TV16-179
16C22Q TV16-179
16C23 TV16-179
16C24 TV16-179
16D21, -Q TV17-179
16D25, -Q TV17-179
16E20 Like 16C20
16E21, -Q TV17-179
16E23 like 16E21
16E25, -Q TV17-179
16E27, -Q TV17-179

Zenith (Continued)

16F21 like 16E21
16F23, -Q TV18-181
16F25, -Q TV18-181
16F25T TV18-181
16F26, -Q TV18-181
16F26T TV18-181
16F27, Q, T TV19-173
16F28, -Q TV18-181
16G20, Q TV19-173
16G21, Q TV19-173
16G22, Q TV19-173
16G23, Q TV19-173
16G27, Q TV19-173
16G27QT, T TV19-173
16H20Q TV20-173
16H21 TV20-173
16H22, Q TV20-173
16H23, Q TV20-173
16H27, T TV20-173
16H28, QS TV20-174
16J20, Q TV20-173
16J22, QS TV20-174
16J23, Q TV20-175
16J27, Q, T TV20-173
16J28, Q, S TV20-175
16K20 TV21-171
16K22, QS TV21-171
16K23 TV21-171
16K23Q, QS TV21-171
16K26 TV21-171
16K27, Q TV21-171
16K27T, QT TV21-171
16K28QS TV21-171
16K30, QS TV22-173
16K32, QS TV22-173
16K33, Q+ TV22-173
16K34, Q+ TV22-173
16K36, QS TV22-173
16K38QS TV22-173
16T20 TV10-181
16X20 TV11-171
16Y20 very similar to above
16Z20 TV12-175
16Z21 TV12-175
16Z25, -U TV13-175
HFR16 like 3M-02
17A20, -Q TV14-181
17A21Q TV14-181
17A30, Q TV15-179
17A31Q TV15-179
17B20, Q TV15-179
17B21Q TV15-179
17B22 TV15-179
17D20 TV17-179
17G28 TV19-173
17G28Q TV19-173
17T20 TV10-181
17X20 TV11-171
17X22 TV11-171
17X23 TV11-171
17Y20, 17Y22, 17Y23 Similar to above
17Z20 TV12-175
17Z21 TV12-175
17Z22, -Q TV12-175
17Z23, -Q TV12-175
17Z30 TV13-179
17Z31 TV13-179
17Z32 TV13-179
17Z33 TV13-179
17Z34Q TV13-179
HF17E 1958-186
HF17H, -R 1958-186
HFY17E, R 1956-173
18C20, -Q TV16-179
18C24Q TV16-179
18D20, -Q TV17-179
18E20, -Q TV17-179
HFZ18R 1957-182
19A20, -Q TV14-181
19A30, Q TV15-179
19B20, Q TV15-179
19K-20 TV7-185
19K-22 TV7-185
19K-23 TV7-185
19K24 like 19K22
19L25 TV8-181
19L26 TV8-181
19L27 TV8-181
19L28 TV8-181
19M20 TV9-179
19M20Z TV9-179

Zenith (Continued)

19M21 TV9-179
19M21Z TV9-179
19R20 TV9-179
19R21 TV9-179
19R22 TV9-179
19X21 TV11-171
19X22 TV11-171
19X24 TV11-171
19Y22 Like above
19Z22 TV12-175
19Z22Q TV12-175
19Z32 TV13-179
HFZ19E 1957-182
20H20 TV6-185
20J21 TV6-185
20J22 TV6-185
20M20 TV9-179
20M20Z TV9-179
20M21 TV9-179
20M21Z TV9-179
HFR-20E 1955-124
21J20 TV6-185
21J21 TV6-185
21K-20 TV7-185
21K20Z like 21K20
21L21 TV8-181
GV21 1962-156
HF21E, -R 1958-186
HFR-21R 1955-124
22H-20 TV5-187
22H-21 (PM focus) similar to 23H22
22L20 TV8-181
22R20 TV9-179
22R21 TV9-179
22T20, 22T21 } Same as 19R21
22X20 TV11-171
22X21 TV11-171
22X22Q TV11-171
22Y20, 22Y21 are Similar to above
22Z20 TV12-175
22Z20Q TV12-175
22Z30 TV13-179
23H-22 TV5-187
23H-22Z TV5-187
24H-20 TV5-187
24H-21 TV5-187
37T996, 37T998, 42T999 } Use 28F20, 28F22
40 1963-180
LPS45J, L 1964-185
50 1961-186
50 One-238
50K 1963-180
50L 1964-177
XD50C, + 1961-181
52 One-238
54 One-238
60 1963-180
60 to 62 One-238
64 One-238
67 One-238
XD60C, + 1961-179
GPS80 1962-156
KPS-80 1963-185
90 1963-184
100 1961-188
HF110G, J 1959-169
SF112 1959-172
SF112E, R, W 1960-165
SF114E, R, W 1960-168
HF116E, R 1959-176
HF117 1959-177
HF118 1959-177
SPE122E, R, W 1960-167
125 1968-184
130 1964-174
150 1962-150
SF174 1960-165
SF174R 1959-170
SF177E, R 1959-170
200 1959-184
265 1964-178
275 1960-179
300 1958-182
300 TV21-184
400 1962-152
A400 see Z400

Zenith (Cont.)

Z400 1957-172
H-401 Twelve-158
K-401 1953-180
L-401 1953-180
MP401 1964-185
SP401 1964-185
A402 1958-174
J-402 Twelve-162
T-402F, -V, -Y 1955-128
Z402 1957-172
L-403F, G, R, Y 1953-184
M-403G, -L, R, V, W, Y use 4L-41
A404L see Z404
T404F, L, P 1956-177
T404V, -W 1956-177
Z404 1957-172
T405F, L, P 1956-177
T405V, -W 1956-177
L-406 1953-182
K-412 1958-179
450 1959-185
474 One-239
475 1961-185
490 1964-180
500 1956-184
500 1957-186
500D 1958-184
500E 1960-181
500H 1962-154
MP500 1963-186
G-503 Ten-183
H-503 Twelve-160
A504 1958-175
L-505 1953-186
M-505F, R, Y use 5L-41
MP505 1963-186
J506G 1963-177
Y506L 1957-173
J508B, + 1963-177
Z508B 1957-177
Z508L, V 1957-177
B509C, + 1959-175
H509C, P, W 1962-146
R-509F, -R 1955-121
R-509V, -W, -Y 1955-121
A510F, W, Y like Z510G 1957-181
G-510 Ten-181
K-510 Twelve-167
K510BA, + 1963-177
K-510W Twelve-167
K-510Y Twelve-167
M-510G, -R 1954-158
M-510W, -Y 1954-158
R-510Z1 1955-119
Z510G, R, W 1957-181
B511B, + 1959-175
G-511 Ten-181
H-511 Eleven-152
H-511W Eleven-152
H-511Y Eleven-152
R-511F, -R 1955-120
R-511V, -W 1955-120
Z511R 1957-174
A512W, A512Y } Similar to Z512Y
F512C, + 1961-180
J512C, + see 5F13
R-512F, -R 1955-123
R-512V, -W 1955-123
Z512F, G 1957-174
Z512Y 1957-174
A513F, G, R like Y513R 1956-178
B513F, L 1959-173
B513V, Y 1959-173
D513F, + like 5B01
J513C, + 1963-178
Y513F, G 1956-178
Y513R 1956-178
Y513W 1956-178
B514F, + 1959-174
E514B, + 1961-179
J-514 Twelve-163
J514F, + 1963-178
R-514, F, V, W, use 5L-06

Zenith (Continued)

X514V, W 1956-181
A515F, L, V, W, Y like Z515 1957-178
B515B, + 1959-174
K-515 similar J-514
L-515 1954-155
Z515, W, Y 1957-178
A516G, L, W like Z519R 1957-179
G-516 Ten-182
G516C, + 1961-182
L516B, C, L, W use 5G09
K-518 uses 5J-03
L-518 uses 5L-03
519F, G, R, W 1956-181
C519C, L 1960-169
C519P, W 1960-169
H519 1962-147
L519C, + 1964-175
R-519R, -W 1955-122
Z519P, R 1957-179
Z519V, W, Y 1957-179
Z519PD, -RD, -VD, -WD use 5X07
C520B, V, W 1960-170
L-520 1964-155
R-521F, -G 1955-122
R-521R, -W, -Y 1955-122
T521F, G 1956-179
T521R, W, Y 1956-179
T522F, G 1956-180
T522R, V, W 1956-180
also 1955-122
Z522, G 1957-175
Z522R, V 1957-175
T524R, -V, -W use Chassis 5L07
Z524W, Y 1957-176
K-526W, -Y 1953-185
T545 1956-188
Z550G 1957-180
A555 1958-176
L-565E, -R 1954-157
L-566 1954-157
T575C, L, V, W use 5J02
585 One-239
T600, -L 1956-190
602 One-238
612 One-238
B615, F, G, L 1959-179
G-615 Ten-185
H-615Z1 Twelve-157
J-615 Twelve-164
K615B, C, W 1964-181
Z615F, -G 1957-184
Z615R, -W 1957-184
J-616 Twelve-165
622 One-238
K-622, F, G, W 1953-187
L-622F, G, W 1953-187
R-623, -F 1955-125
R-623R, -W, -Y 1955-125
A624G 1958-177
A624W, -Y 1958-177
C624C, V, W 1960-171
L624 1964-182
Z624, -G 1957-183
Z624W, Y 1957-183
642 One-238
645 1964-178
650 1963-182
G-660 Ten-184
HF660 1959-180
SFD660 1961-178
H-661E Eleven-153
H-661R Eleven-153
G-663 Ten-184
J-664 Twelve-166
G-665 Ten-184
H-665 Eleven-153
H-665R Eleven-153
H-665RZ Eleven-153
H-665Z Eleven-153
J-665E Twelve-166
J-665R Twelve-166
K-666R similar to 6J-02

Zenith (Continued)

670 1964-178
672 One-238
675 1960-183
L-677E, -R 1954-159
700L 1958-185
705-07 One-240
710 1960-185
711, 712 One-240
715 One-239
D720C, P 1961-183
L-721 1953-188
H722C, G, W 1962-149
L722C, G, W 1964-183
A723F, R, W like T723 1956-182
H-723 Eleven-155
H-723Z Eleven-155
H-723Z1 Twelve-161
H-723Z2 Twelve-161
L723C, G, W 1964-184
T723 1956-182
Y723, -G 1956-182
Y723R, W 1956-182
A724G, L, Y like T724 1956-182
C724G, L, P 1960-172
G-724 Ten-189
H-724 Eleven-154
H-724Z Eleven-154
H-724Z1 Twelve-161
H-724Z2 Twelve-161
T724 1956-182
Y724G, R, W 1956-182
C725C, F, L 1960-174
G-725 Ten-188
K-725 1953-192
J727C, + 1963-179
B728C, + 1959-182
F728C, + 1961-184
A730E, -R 1958-178
C730, E, R 1960-174
J-733, -G Twelve-161
J-733, -G Twelve-161
X733G, R, Y 1956-182
Y733G, R, Y 1956-182
Z733G, R, Y similar to the above
750 One-240
750L 1959-186
755 1960-187
755, 756 One-239
760 1959-188
HF774E 1958-187
HF774H, R 1958-187
K-777 similar to 7J-20
785 One-239
800 1957-190
T-825F, -G, -R 1955-126
Y832E, R 1956-186
A835E, R see 8Y02
C835E, H, R 1960-175
G-844 Ten-190
C845L, M 1960-175
C845W, Y 1960-175
HFR845R, HFR846E, H use 8R-21
L-845R 1953-190
L-846E, -H 1953-190
850 1959-187
J-880 or J-880R similar to H-880R
H-880R Eleven-157
H-880RZ Eleven-156
L880E uses 8L-20
G-881 Ten-190
G-882 Ten-190
G-883 Ten-190
G-884 Ten-190
G-885 Ten-190
900 1959-190
950 1960-189
1004 One-234
1005 Three-191
1007 Three-195
H-1083E Eleven-158
L1083E 1954-160
H-1086R Eleven-153
L1086R 1954-160

Zenith (Continued)

H-1087R Eleven-158
1103 Three-192
HF1178RD 1958-188
HF1185MD 1958-188
HF1185RD 1958-188
1202 One-235
1203 One-237
1204 One-236
1207 Three-194
1208 Three-195
HF1284D 1958-190
HF1284ED 1958-190
HF1284LD 1958-190
HF1284YD 1958-190
HF1286RD 1958-190
A1410L TV15-179
B1410L, LZ TV15-179
A1411P TV15-179
B1411P, PZ TV15-179
A1412G TV15-179
B1412G, GZ TV15-179
B1413G, GZ TV15-179
C1415L TV16-179
D1415L uses 16C20
C1416B TV16-179
D1416G uses 16C20
E1416G uses 16E20
F1416G see 16C20
C1417L TV16-179
D1417L uses 16C20
1503 Three-193
1504 Three-195
A1510L TV14-181
Z1510L TV13-175
A1511G TV14-181
Z1511B TV13-175
A1512J TV14-181
Z1512J TV13-175
A1515W TV14-181
K1620++ TV22-173
B1715L TV15-179
C1715L TV16-179
A1716L TV15-179
B1716C TV15-179
C1716C TV16-179
A1717G TV15-179
B1717J TV15-179
C1717J TV16-179
A1718G TV15-179
B1718B TV15-179
A1719J TV15-179
B1719P TV15-179
C1719P TV16-179
B1720C TV15-179
C1720C TV16-179
M1800+ TV9-179
R1800+ TV9-179
D1801L uses 16C20
E1801B, L use 16E20
D1803B uses 16C20
E1803C, L use 16E20
F1805C, F TV18-181
F1806B, L TV18-181
F1807C, L TV18-181
D1810B TV17-179
E1810B TV17-179
D1811C TV17-179
E1811C TV17-179
A1812R uses 15Z30
D1812L TV17-179
E1812L TV17-179
K1812E, -R TV7-185
L1812E, -R TV8-188
R1812+ TV9-179
Z1812RZ TV13-179
D1814P TV17-179
E1814P TV17-179
T1814R TV10-181
X1814R TV11-171
Z1814R, Y TV12-175
A1815P uses 15Z31
K1815E, -R TV7-185
Z1815J, R use 16Z20
T1816+ TV10-181
X1816+ TV11-171
Z1816C, + TV12-175
A1817G, A1817L } Use 15Z31
Z1817+ TV13-179
Z1818C, + TV12-175
Z1819JZ TV13-179
A1819J, A1820W } Use 15Z31

Zenith (Continued)

K1820E, -R TV7-185
L1820E, R TV8-188
K1846E, -R TV7-185
L1846E, -R TV8-188
K1850E, -R TV7-185
K1880R TV7-185
H1925C, L TV20-173
MT1950-1 1963-185
ST1950T-1 1963-185
MT1951 1964-185
ST1951 1964-185
MT1954 1963-185
ST1954T 1963-185
MT1955 1964-185
ST1959 1964-185
MT1970 1963-186
T1980C, G TV21-171
T1985C, J TV21-171
T1990G TV21-171
T1990G2 TV22-175
T1995W2 TV22-175
K2000W TV21-171
A2001L TV15-179
B2001L TV15-179
C2001L TV16-179
K2004++ TV22-173
K2005++ TV22-173
K2008++ TV22-173
D2010C TV17-179
E2010C TV17-179
F2010C TV18-181
K2012++ TV22-173
K2014++ TV22-173
D2015L TV17-179
E2015L TV17-179
K2015W, I TV21-171
K2020J, I TV21-171
T2025WA TV21-171
T2025W2 TV22-175
T2025W } Use
T2026H, R } 16J23
T2027M } TV20-175
T2026++ TV22-175
J2026R TV6-185
J2027E TV6-185
T2027MA TV21-171
T2027M2 TV22-175
J2027R TV6-185
J2029E TV6-185
J2029R TV6-185
J2030E TV6-185
J2030R TV6-185
J2031R uses 20J21
J2040E TV6-185
T2040++ TV22-175
H2041R TV6-185
J2042R TV6-185
T2042++ TV22-175
J2048R TV6-185
J2044E TV6-185
J2044R TV6-185
T2044++ TV22-175
H2050E,+ TV20-173
T2050+ TV20-175
T2050++ TV21-171
J2051E TV6-185
2052A, B, C One-240
T2052M,+ TV21-171
T2052++ TV22-175
H2052R TV6-185
2053 One-239
H2053E TV6-185
J2053R TV6-185
J2054R TV6-185
J2055R TV6-185
T2055++ TV22-175
H2060+ TV20-173
H2070W TV20-173
T2070+ TV20-175
T2070++ TV21-171
T2072HA,WA TV21-171
T2072+ TV20-175
T2073M TV20-175
T2073MA TV21-171
T2075L, W TV20-175
T2075++ TV22-175
T2077H, R TV21-172
T2079M TV21-172
T2080E,+ TV21-172
T2080++ TV22-175
J2100G, L use 16J20
J2100L TV20-174
K2100G, L TV21-171
K2100++ TV22-173

Zenith (Continued)

G2101C, F TV19-173
H2101C, F TV20-173
J2101+ TV20-174
G2102L,+ RV19-173
H2102R, W TV20-173
J2102L, W use 16J20
G2103L, LZ TV19-173
H2103L TV20-173
J2103L TV20-174
H2104C, G TV20-173
T2104C, G TV20-175
F2105C TV19-173
F2105C TV18-181
G2105C, L TV19-173
H2105B, L TV20-173
T2105L TV20-175
J2108C, J TV20-174
K2108B, L TV21-171
K2108++ TV22-173
J2109B, L TV20-174
K2109F, J TV21-171
K2109J2 TV22-173
F2110G TV19-173
F2110B, G TV18-181
G2110B, G TV19-173
H2110G, J TV20-173
J2110G TV20-174
K2110L TV21-171
K2110L2 TV22-173
P2111L, P TV19-173
F2111L, P TV18-181
P2112J, W TV18-181
F2112W TV19-173
G2112J, W TV19-173
P2120E,+ TV18-181
G2120E,+ TV19-173
H2122C, L TV20-173
J2122C TV20-174
K2123L TV21-171
J2124L TV20-174
H2125J, L TV20-173
J2125J, L TV20-174
H2126J TV20-173
J2126J TV20-174
J2126R TV6-185
J2127E TV6-185
J2127R TV6-185
K2127L,+ TV21-171
K2127++ TV22-173
J2129E,-R TV6-185
J2130E,-R TV6-185
J2140E TV6-185
J2142R TV6-185
J2143R TV6-185
J2144E,-R TV6-185
J2151E TV6-185
J2153R TV6-185
J2154R TV6-185
J2155R TV6-185
T2205G2 TV22-175
G2211C TV19-173
H2211C TV20-173
J2211C TV20-174
K2211J TV21-171
K2211J2 TV22-173
H2212F, G TV20-173
J2212F, G TV20-174
G2213G TV19-173
H2213G TV20-173
K2213L TV21-171
K2213L2 TV22-173
F2214L TV18-181
G2214L TV19-173
H2214G TV20-173
J2214F, L TV20-174
K2214F, J TV21-171
K2214F2 TV22-173
K2214J2 TV22-173
F2215J, L TV18-181
G2215J, L TV19-173
G2216L TV19-173
T2220R TV10-181
K2220R TV11-171
Z2220R, Y TV12-175
A2221J, Y TV14-181
A2221L, R TV15-179
B2221R, Y TV15-179
B2221RZ,✓ TV16-179
C2221R, Y TV16-179
Z2221RZ TV13-179
D2222✓ uses 16C21
T2222+ TV10-181

Zenith (Continued)

X2222+ TV11-171
Z2222C, + TV12-175
A2223+ TV14-181
A2223+ TV15-179
B2223+ TV15-179
B2223✓✓ TV16-179
C2223E,✓ TV16-179
Z2223+ TV13-179
T2224E, R TV10-181
X2224+ TV11-171
B2225+ TV15-179
C2225E,✓ TV16-179
H2226R TV5-187
J2226L TV20-174
H2227R TV5-187
H2227E TV5-187
H2228J TV20-173
J2228J TV20-174
K2228L,+ TV21-171
M2228+ TV9-179
K2229R TV7-185
L2229E, R TV8-188
M2229+ TV9-179
R2229+ TV9-179
T2229 uses 19R21
X2229R TV11-171
Z2229R TV12-175
Z2229RD like above
Z2229RZ TV13-179
F2230E,+ TV18-181
K2230E,-R TV7-185
M2230+ TV9-179
R2230+ TV9-179
T2230 uses 19R21
X2230E, R TV11-171
Z2230E, R TV12-175
Z2230+ TV13-179
H2231L TV20-173
J2231L TV20-174
K2231L TV21-171
K2231++ TV22-173
X2232E, R TV11-171
Z2232 + like above
L2235E, R. TV8-188
L2236E, R TV8-188
M2237+ TV9-179
D2240✓ uses 16C21
K2240E,-R TV7-185
A2241+ use 17Z32
Z2243+ TV13-179
Z2244+ TV13-179
A2245E, R TV14-181
A2245, E, R TV15-179
B2245,+ TV15-179
B2245✓ TV16-179
C2245E,✓ TV16-179
A2246E, R TV15-179
B2246E, R TV15-179
C2246E,✓ TV16-179
B2247+ TV15-179
C2247E,✓ TV16-179
X2247E, R TV11-171
Z2247E,+ TV12-175
K2248E, R TV11-171
Z2248+ use 17Z22
B2249, H, R TV15-179
C2249H,✓ TV16-179
M2249+ TV9-179
R2249+ TV9-179
Z2249E, R use 17Z22
Z2249+ TV13-179
A2250M, R TV14-181
B2250+ TV15-179
D2250✓ uses 16C21
H2250R TV5-187
M2250+ TV9-179
R2250+ TV9-179
T2250 uses 19R21
A2251E, R TV14-181
M2251+ uses 19L28
Z2251+ TV13-179
A2252R TV15-179
M2259+ TV9-179
A2253E, R TV15-179
R2253M TV9-179
T2253M uses 19R22
B2254+ TV15-179
C2254E,✓ TV16-179
D2254✓ } use
D2255✓ } 16C21
K2254M TV11-171
H2255E TV5-187

Zenith (Continued)

Z2255E, R TV12-175
T2256 uses 19R21
X2256E, R TV11-171
R2257E, R TV9-179
T2257 uses 19R22
X2257, E, R TV11-171
Z2257E,+ TV12-175
Z2257+ TV13-179
K2258E,-R TV7-185
L2258E, -R TV8-188
M2258RZ uses 19L28
R2258+ TV9-179
X2258E, R TV11-171
Z2258E,+ TV12-175
L2259E, -R TV8-188
K2260R TV7-185
L2260R TV8-188
M2260+ TV9-179
L2261E, -H TV8-188
M2261+ TV9-179
T2261 uses 19R22
L2262C, -R TV8-188
T2262 uses 19R22
K2263E TV7-185
X2264+ TV11-171
K2266, -R TV7-185
L2266R TV8-188
K2267E TV7-185
L2267E, H TV8-188
M2267+ TV9-179
K2268R TV7-185
K2270H, -R TV7-185
L2270 TV8-188
K2280 1956-172
K2280E, R TV11-171
L2281 1954-156
L2281, -E TV8-188
L2281R TV8-188
Z2281E, R } Use
Z2282E, R } 17Y22
A2282E, R TV14-181
A2282E, R TV15-179
B2282, E, R TV15-179
C2282E,✓ TV16-179
Z2282+ TV13-179
C2284H, R TV16-179
L2285R TV8-188
K2286R (TV) TV7-185
K2286R radio
uses 7K-21
K2287R TV7-185
L2287R TV8-188
K2288E TV7-185
K2290R TV7-185
K2291E TV7-185
L2291E TV8-188
D2301R, Y TV17-179
E2301R, Y TV17-179
F2301R, Y use 16F21
D2302R TV17-179
E2302R TV17-179
G2304R, W TV19-173
H2304R, W TV20-173
D2315L,✓ TV17-179
E2315L, Y TV17-179
E2316E,✓ TV17-179
D2317E,✓ TV17-179
H2328EZ TV5-187
H2328RZ TV5-187
A2329J TV14-181
A2329R TV15-179
B2329R TV15-179
A2330E, R TV15-179
B2330E, R TV15-179
C2330E, R TV16-179
B2335, E, R TV15-179
F2340E, R, W } Use
F2341E, R, W } Cbassis
F2342E, R, W } 16E21
D2345E,✓ TV17-179
E2345E,✓ TV17-179
E2346E,✓ TV17-179
D2347E,✓ TV17-179
E2347E,✓ TV17-181
D2348E,✓ TV17-179
E2348E,✓ TV17-181
H2349+ uses 16G23Q
D2350H,✓ TV17-179
E2350H,✓ TV17-181
H2352RZ TV5-187
H2353EZ TV5-187
D2355E,✓ TV17-179

Zenith (Cont.)

A2358E, R TV14-181
B2358E, R TV15-179
C2358E,✓ TV16-179
A2359+ TV14-181
B2359, E TV15-179
C2359E, W TV16-179
R2359E, R TV9-179
T2359 uses 22T20
X2359E TV11-171
Z2359+ TV13-179
Z2359E uses 22Z20
Z2359,-R TV12-175
A2360M, R TV15-179
B2360M, R TV15-179
C2360M, R TV16-179
R2360R TV9-179
T2360R uses 22T20
X2360R TV11-171
Z2360R TV12-175
Z2360RZ TV13-179
A2362M, R TV14-181
X2362+ TV11-171
X2365+ TV11-171
R2367E, Y TV9-179
T2367 uses 22T20
R2368R TV9-179
D2381E,✓ TV17-179
T2383R uses 22T20
X2383, R TV11-171
D2384H, R TV17-179
E2384H, R TV17-181
R2387R TV9-179
T2387R uses 22T20
R2391R TV9-179
T2391 uses 22T20
X2391EQ TV11-171
D2430E,✓ TV17-179
H2437E TV5-187
H2437R TV5-187
H2438R TV5-187
H2439R TV5-187
H2449E TV5-187
H2445R TV5-187
H2447R TV5-187
D2458E,✓ TV17-179
E2458E,✓ TV17-181
D2460M, R TV17-179
E2460M, R TV17-181
D2462H TV17-179
D2464L, W TV17-179
SFH2500T 1963-185
SK2501T 1963-185
SL2501 1964-185
SFF2503T 1961-190
SFF2504T 1962-157
SFD2505E 1960-166
SFD2505R, W 1960-166
SFF2505T 1961-190
SFF2505T 1962-157
SL2505 1964-187
SK2506T 1963-188
SK2508T 1963-188
SF2530 1960-177
SFF2535-1 1962-158
M2570R, MZ TV9-179
L2571R TV8-188
L2572R TV8-188
L2573E TV8-188
L2574R TV8-188
L2575E TV8-188
L2592R TV8-188
L2593H TV8-188
MH2600 1963-185
RK2600 1963-185
MK2601 1963-185
ML2601 1964-185
MK2602 1963-186
SFF2603 1961-190
MK2603 1963-186
SFF2604-1 1962-157
SFF2605 1961-190
SFF2605-1 1962-157
ML2605 1964-187
MK2606 1963-186
ML2606 1964-187
SFF2606 1961-190
MK2607 1963-186
ML2607 1964-187
SFF2607 1961-190
SFF2607-1 1962-157
ML2608 1964-187
ML2610 1964-187
ML2636 1964-187
X2636E, R TV11-171

Zenith (Continued)

Z2636+ like above
Z2637E,+ TV12-175
X2640E, R TV11-171
ML2688 1964-189
MK2670 1963-189
ML2670 1964-189
X2670E, R TV11-171
R2671E, R TV9-179
T2671 uses 22T21
X2671R TV11-171
Z2671E, R use 17Z23
X2672E TV11-171
Z2672E, R TV12-175
A2673E, R TV14-181
A2673E, R TV15-179
B2673, E, R TV15-179
C2673E,✓ TV16-179
D2673E,✓ TV17-179
X2674+ TV11-171
MK2675 1963-189
ML2675 1964-189
Z2675+ TV13-179
MK2685 1963-189
ML2685 1964-189
K2700R2 TV22-173
G2705R, Y TV19-173
H2705R, Y TV20-173
J2705R, Y TV20-174
K2705R, Y TV21-171
K2705++ TV22-173
T2706++ TV21-172
T2706W TV20-175
G2707R, Y TV19-173
H2707R, Y TV20-173
J2707R, Y TV20-174
T2707L, Y TV21-171
K2708++ TV22-173
F2710Y TV18-181
F2712E, R, W TV18-181
G2715Y TV19-173
H2715Y TV20-173
G2717E,+ TV19-173
H2717+ TV20-173
J2717E,+ TV20-174
K2717E,+ TV21-171
K2717++ TV22-173
G2730E,+ TV19-173
F2735E, R, W TV18-181
G2735L,+ TV19-173
H2735+ TV20-173
J2735E,+ TV20-174
K2735+ TV21-171
K2735++ TV22-173
G2736E,+ TV19-173
H2736+ TV20-173
J2736+ TV20-174
K2736E,+ TV21-171
K2736++ TV22-173
F2737E, R, W TV18-181
G2737E,+ TV19-173
H2737+ TV20-173
J2737+ TV20-174
K2737E,+ TV21-171
K2737++ TV22-174
F2738E,+ TV18-181
G2738E,+ TV19-173
H2738+ TV20-173
J2738+ TV20-174
K2738E,+ TV21-171
K2738++ TV22-174
F2739E, R, W TV18-181
G2739E,+ TV19-173
H2739+ TV20-173
J2739+ TV20-174
K2739E,+ TV21-171
F2740E, R, W TV18-181
G2740H,+ TV19-173
H2740H,+ TV20-173
J2740+ TV20-174
J2741+ TV20-174
K2742H,+ TV21-171
K2742++ TV22-174
E2747E,✓ TV17-181
K2748H,+ TV21-171
K2748++ TV22-174
G2749H,+ TV19-173
H2749+ TV20-173
J2749+ TV20-174
F2751+ use 16E23
F2752R, W, Y TV18-181
G2752R,+ TV19-173
H2753E, W TV20-173

Zenith (Continued)

E2755E,✓ TV17-181
F2755H,+ TV18-181
G2755H,+ TV19-173
H2755+ TV20-173
J2755+ TV20-174
F2756E, R, W TV18-181
G2756E,+ TV19-173
H2756+ TV20-173
J2756+ TV20-174
K2756L,+ TV21-171
K2756++ TV22-174
H2760+ TV20-173
G2762W TV19-173
H2762W TV20-173
E2764W TV17-181
J-2766 Twelve-168
G2780E,+ TV19-173
H2781+ TV20-173
MK2784+ TV21-171
RK2784+ TV21-171
MK2785++ TV22-174
ML2785 1964-188
RK2785++ TV22-175
P2786E, R, W TV18-181
G2786E,+ TV19-173
H2786+ TV20-173
MH2786+ TV20-175
MK2786+ TV21-171
MK2786++ TV22-174
ML2786 1964-188
G2787W TV19-173
H2787W,+ TV20-173
MH2787W TV20-175
MK2787M, R TV21-171
MK2787M2 TV22-175
H2789M, R TV20-173
MH2789M, R TV20-175
MJ2789+ TV20-175
MK2789M, R TV21-171
F2858R, W TV18-181
F2860M, R TV18-181
F2862W TV18-181
L2876E, -R TV8-188
L2878R TV8-188
L2879E TV8-188
L2894HU TV8-188
J2968R TV6-185
R2975R TV9-179
R2976E TV9-179
R2979E TV9-179
R2994EU TV9-179
R2994HU TV9-179
T2994 uses 22T21
X2994+ TV11-171
A3000E, R TV14-181
A3000E, R TV15-179
B3000E, R TV15-179
C3000E, R TV16-179
E3000R, Y TV17-181
Z3000E, R TV12-175
Z3000+ TV13-179
A3001+ TV14-181
A3001E, R TV15-179
B3001E, R TV15-179
C3001E,✓ TV16-179
Z3001E, R use 17Z22
D3002E,✓ TV17-179
E3002E,✓ TV17-181
A3004, E, R TV14-181
A3004, E, R TV15-179
B3004, E, R TR15-179
C3004E,✓ TV16-179
D3004E,✓ TV17-179
E3004E,✓ TV17-181
F3004+ use 16F21
Z3004E, R TV12-175
Z3004+ TV13-179
D3005E,✓ TV17-179
E3005E,✓ TV17-181
A3006+ TV14-181
A3006+ TV15-179
B3006, E, R TV15-179
C3006E,✓ TV16-179
D3006E,✓ TV17-179
E3006E,✓ TV17-181
Z3006E, R TV12-175
A3007R TV15-179
B3007E, R TV15-179
C3007E,✓ TV16-179
D3007E,✓ TV17-179
E3007E,✓ TV17-181

Zenith (Continued)

A3008E, R	TV14-181
A3008E, R	TV15-179
B3008R	TV15-179
C3008R	TV16-179
D3008R	TV17-179
E3008R	TV17-181
Z3008E, R	TV12-175
Z3008+	TV13-179
A3009E, H	TV15-179
B3009, E, Y	TV15-179
C3009E, ✓	TV16-179
D3009E, ✓	TV17-179
E3009E, ✓	TV17-181
A3010E, +	TV14-181
A3010E, R	TV15-179
B3010+	TV15-179
C3010E, ✓	TV16-179
D3010E, ✓	TV17-179
Z3010+	TV13-179
Z3010E, +	TV12-175
A3011, E, Y	TV15-179
B3011, E, Y	TV15-179
C3011E, ✓	TV16-179
D3011E, ✓	TV17-179
F3011+ uses 16E21Q	
A3012H, R	TV14-181
A3012H, R	TV15-179
B3012H, R	TV15-179
C3012H, R	TV16-179
D3012H, R	TV17-179
E3012H, R	TV17-181
Z3012H, R	TV12-175
Z3012+	TV13-179
A3013H	TV14-181

Zenith (Continued)

A3013H	TV15-179
B3013H	TV15-179
C3013H	TV16-179
D3013H	TV17-179
E3013H	TV17-181
A3014H, R	TV14-181
A3014H, R	TV15-179
B3014H, R	TV15-179
C3014H, R	TV16-179
D3014W	TV17-179
E3014W	TV17-181
Z3014+	TV13-179
Z3014H, R	TV12-175
D3015L	TV17-179
E3015L	TV17-181
T3025WA	TV21-172
T3025W2B	TV22-175
T3025W, T3026H, R, T3027M	Use 16J23Q TV20-175
T3026+A	TV21-172
T3026+2B	TV22-175
T3027MA	TV21-172
T3027M2B	TV22-175
T3042++	TV22-175
J3069E	TV6-185
T3072H, W	TV20-175
T3073M	TV20-175
H3074R	TV6-185
T3074L, W	see 16J22
T3074LA, WA	TV21-172
T3075LA, WA	TV21-172
T3075L2B	TV22-175
T3075L, W	TV20-175
T3075W2B	TV22-178

Zenith (Continued)

T3077H, R	TV21-172
T3079M	TV21-172
T3080E, +	TV21-172
T3080++	TV22-178
H3168R uses 22H20	
J3169E	TV6-185
H3267R	TV5-187
H3273E, H-3274R	See 22H20
K3300Y2	TV22-174
H3308R, Y	TV20-173
J3308R, Y	TV20-174
K3308R, Y	TV21-171
K3308++	TV22-174
F3310E, R, W	TV18-181
G3310E, +	TV19-173
H3310+	TV20-173
J3310+	TV20-174
K3310E, +	TV21-171
F3311R, W, Y	TV18-181
G3311R, +	TV19-173
H3311+	TV20-173
J3311+	TV20-174
K3311R, +	TV21-171
K3311++	TV22-174
H3340+	TV20-173
J3340+	TV20-174
K3340E, +	TV21-171
K3340++	TV22-174
G3341E, +	TV19-173
H3341+	TV20-173
J3341+	TV20-174
K3341H, +	TV21-171
K3341++	TV22-174

Zenith (Continued)

F3342E, R, W	TV18-181
H3342+	TV20-173
J3342+	TV20-174
K3342H, +	TV21-171
K3342++	TV22-174
H3343+	TV20-173
J3343+	TV20-174
H3345+	TV20-174
J3345+	TV20-174
K3345L, +	TV21-171
G3346E, +	TV19-173
F3348R, W	TV18-181
G3348R, W	TV19-173
G3349+ uses 16G23Q	
H3349+	TV20-174
G3350E, +	TV19-173
F3350E, R, W	TV18-181
H3350+	TV20-174
J3350+	TV20-174
K3350L, +	TV21-171
K3350++	TV22-174
F3353W	TV18-181
G3353E, W	TV19-173
H3353W	TV20-174
E3354E, ✓	TV17-181
F3354H, M, R	TV18-181
G3354M, R	TV19-173
H3354+	TV20-174
H3355H	TV20-174
J3355+	TV20-174
E3356E, ✓	TV17-181
K3358W, Y	TV21-171
K3358++	TV22-174

Zenith (Continued)

F3359M	like 16E21
F3360W, Y	TV18-181
G3360W, Y	TV19-173
H3360W, Y	TV20-174
J3360W, Y	TV20-174
F3364W, Y	TV18-181
F3368M, R	TV18-181
G3368M, R	TV19-173
H3368M, R	TV20-175
K3368M, R	TV21-171
F3370W	TV18-181
H3373, H3374, H-3467	all use 24H20
F3375L	TV18-181
G3375L	TV19-173
H3375H	TV20-174
J3375H, 1	TV20-175
F3380W, Y	TV18-181
F3385H	TV18-181
G3385H	TV19-173
H3385H	TV20-174
J3385H, 1	TV20-175
K3385H2	TV22-174
K3385H	TV21-171
MK3386+	TV21-171
MK3886	1963-186
F3388W	TV18-181
G3388W	TV19-173
G3388	1962-157
H3388W	TV20-174
MJ3388H	TV20-175
MK3388	1963-186
MK3388H	TV21-171

Zenith (Continued)

MK3388H2	TV22-175
H3469E	TV5-187
H3475R	TV5-187
H3477R	TV5-187
H3478E	TV5-187
Z4000+	TV13-179
Z4000E, R	TV12-175
Z4006+	TV13-179
A4007E, R	TV14-181
A4007F, R	TV15-179
B4007E, R	TV15-179
C4007E, R	TV16-179
A4012H, R	TV15-179
B4012H, R	TV15-179
C4012H, R	TV16-179
5408	One-215
5420	Three-181
5513	One-219
5516	One-206
5518	One-216
5521	One-220
5523	One-221
5524	One-217
5528	One-218
5536	Three-182
5619	One-222
5621	One-226
5634	One-223
5638	One-224
5644	One-225
5672P	Three-183
5675	Three-184
5678	Three-185
5679	Three-186
5704	One-230

Zenith (Continued)

5707	One-227
5709	One-228
5711	One-229
5714	One-231
5724	Three-188
5725	Three-189
5801	One-232
5808	Three-190
6905	One-233
7200	1964-188
7500	1963-189
and	1964-189
S-8500	Three-208
S-8500Z	Four-181
S-8501	Three-208
S-9000	Four-181
S-9001	Five-188
S-9002	Five-188
S-9010	1953-183
S-9011	1954-154
S-9012	1954-154
S-12600	Eight-187
S14028	Eleven-159
S14029	Eleven-159
S14030	Eleven-159
S14031	Eleven-159
S14036	Eleven-159
S-14053	1953-171
S-14054	1953-171
S-14056 to S-14064 all like S-14053	
S-61017	1964-189
S-61363	1964-189
S-62259	1964-185

SUPREME Radio & TV Manuals



AMAZING OFFER

RADIO & TV SERVICE DATA

Your best, complete source for all needed RADIO and TV diagrams and helpful servicing data. Most amazing values. Only $2.50 and $3 per giant volume. Cover all important makes, models of all periods.

What diagrams and service data do you need? Service material on every model and chassis listed in this Master INDEX is in SUPREME manuals. These are giant volumes which have factory issued data on all important TV sets, stereo, AM, FM, auto, and portable radios, of all periods through 1966. The very best service material at lowest cost, only $2.50 and $3 per complete annual volume. Order form and complete description at left and on page 47.



Helpful illustrations.

Needed data for quick radio servicing.

Some Diagrams are printed on double pages 11 x 17 inches



DIAGRAMS on large pages, 8-1/2 x 11 inches

Waveforms.

Test points.

Voltages.

Service hints.

Factory revisions.



Easy to follow alignment, minimum of equipment.



Helpful printed board views, reference to diagrams, top and bottom views as needed.

Instructions how to get to parts quickly, where to find, what to remove, voltages expected.

Dial stringing information



NO-RISK ORDER COUPON

TELEVISION SERVICE MANUALS

Supreme TV manuals are best for faster, easier TV repairs. Lowest priced. Factory data on practically all sets. Complete circuits, all needed alignment facts, wiring board views, waveforms, voltages, production changes, and double-page schematics. Only $3 per large annual manual. Check volumes wanted.

☐ *New* 1966 TV, $3. ☐ Additional 1965 TV, $3.
☐ Early 1965 TV, $3. 1964 TV, $3. ☐ 1963 TV, $3.
☐ Additional 1962 TV, $3. ☐ Early 1962 TV, $3.
☐ 1961 TV Manual, $3. ☐ 1960 TV Manual, $3.
☐ Additional 1959 TV, $3. ☐ Early 1959 TV, $3.
☐ 1958 TV Manual, $3. ☐ Additional 1957 TV, $3.
☐ Early 1957 Television, $3. ☐ 1956 TV Manual, $3.
☐ Additional 1955 TV, $3. ☐ Early 1955 TV, $3.
☐ 1954 TV, $3. ☐ Master Index to all Manuals, 25¢

RADIO DIAGRAM MANUALS

Here are low-priced radio manuals that simplify repairing. Cover everything from most recent 1966 radios to pre-war old-timers; home radios, stereo, combinations, transistor portables, FM, and auto sets. Large schematics, all needed alignment facts, printed boards, voltages, dial stringing, hints. Volumes are big, 8½ x 11", about 190 pages, each.

$2.50

☐ *New* 1966 Manual, only $2.50 ☐ 1965, ☐ 1964,
☐ 1963, ☐ 1962, ☐ 1961, ☐ 1960, ☐ 1959, ☐ 1958,
☐ 1957, ☐ 1956, ☐ 1955, ☐ 1954, ☐ 1953, ☐ 1952,
☐ 1951, ☐ 1950, ☐ 1949, ☐ 1948, ☐ 1947, ☐ 1946,
☐ 1942, ☐ 1941, ☐ 1940, ☐ 1926-38, EACH, $2.50

☐ Auto Radio 1964-65 Diagram Manual, $2.50

SUPREME PUBLICATIONS

1760 Balsam Road, Highland Park, ILL.

Rush today **TV** and **Radio** manuals checked in no-risk order form of this ad. Send postpeid, I am enclosing full price. You guarantee my complete satisfaction or my money back.

Name: _____

Address: _____

City: _____ State: _____

Supreme Publications
Sold by All Leading Parts Jobbers

INDEX

SUPPLEMENT

Use this Index Supplement for 1965, 1966 models and additions.
Use main Index, pages 3 through 42, for earlier Radio & TV sets.
For instructions on how to use Index, see pages 2 and 3.

ADMIRAL CORP.

1D4 TV23-3
1D7 TV24-15
1D42-2 TV23-3
1D413-2 TV23-3
1D760-1 TV24-15
10310-1 TV25-11
10311-1 TV25-11
10312-1 TV25-11
10313-1 TV25-11
10611-1 like G6
10755-1 TV25-3
2B2 1966-6
2D4 TV23-3
2D42-1 TV23-3
2D413-1 TV23-3
2D413-4 TV23-3
20421-1 TV25-16
2G609+ } Like G6
2G632+ } TV24-9
2K1,A,B 1965-9
G2-1 TV25-7
G2-2 TV25-7
3D4 (TV) like D4
3D413-3 see D4
30611-1 like G6
3J2A 1965-9
3L2A,B 1965-9
4A4 1965-3
4C4 1965-12
4E4 1966-11
4F4 1966-20
4G640-1 } Remote
4G641-1 } types of
4G645-1 } G6
D4 TV23-3
5D6D 1965-5
5D6E,F 1965-5
5E6 1965-4
5K6 1965-5
5L6 1965-5
5M6 1965-5
5V6,A 1966-12
5W6 1966-12
6W3,A 1965-6
G6 TV24-3
7D43-1 TV23-15
7D413-1 TV23-15
D7 TV24-15
8A4 1966-15
8E4 1966-16
8D3 1965-12
8D418-1 TV23-3
8F3 1966-4
8G423-1 TV25-16
8K2-1N 1965-7
8K2-2N 1965-7
8K2-3N 1965-7
8E4 1966-3
8L3 1966-20
8N2 1965-8
9D4 like 8D4
9D410-1 like 8D4
9G410-1 TV25-16
9G412-1 TV25-16
9G413-1 TV25-16
9G414-1 TV25-16
10A2 1966-17
10J1 1965-5
12A2 1965-10
12B2 1966-18
12H1 1966-14
16P3B see TV21-7
16UP3B see TV21-7
20C5,A 1966-7
C21B12-1+ TV24-9
C21C12-1+ TV24-9
C21C15-1+ TV24-9
22C5,A 1966-7
D42-1 TV23-3
D44-1 TV23-3
D44-2 TV23-3
D44-4 TV23-3
D61-1 TV23-9
D61-2 TV23-9
D61-4 TV23-9
SP65S see 1965-3
YG171 1966-14
YD201GP,A 1966-3
YD202GP,A 1966-3
YD242 1966-4
YD243 1966-4
YD257 1966-5
YH301GP 1966-15
YH302GP 1966-15
G310-1 TV25-11
G310-4 TV25-11
YH312 1966-16
YH313 1966-16
YH321 1966-17
G336-1 TV25-11
YG411 1966-18
D415-1 TV23-3
D416-1 TV23-3

Admiral, Continued

D416-2 TV23-3
D416-4 TV23-3
G416-1 TV25-16
G417-1 TV25-16
G422-1 TV25-16
TM441 1966-18
PA451 1966-20
PS461 1966-20
G601-2 like G6
D610-1 TV23-9
D610-2 TV23-9
D610-4 TV23-9
G610-2 TV24-3
G610-3 TV24-3
G612-1 TV24-3
G613-1 TV24-3
G617-2 TV24-3
G618 like G6
G620-1 TV24-3
G620-2 TV24-3
G620-3 TV24-3
Y701A 1965-10
YG703 see 1965-3
YG713 see 1964-4
PA731 1965-10
TM731 1965-10
PS751 1965-10
G760-1 TV25-3
G760-2,-3 TV25-3
D761-1 TV24-15
YG763 see 1964-5
YG773 }
YG774 }
YG777 }
YG783 } See
YG784 } data on
YG789 } 1964-5
YG790 }
YG793 }
YG801 }
YG809 }
YG827 1966-12
YG829 1966-12
YG837 1966-12
YG839 1966-12
YG841 1966-12
YG851 1966-12
YG861 1966-12
YG873 see 1964-5
PG910 TV25-7
PG912 TV25-7
PG919 TV25-7
PG927 TV25-7
YG1027 1966-6
YG1029 1966-6
YG1037 1966-6
YG1047 1966-6
YG1057 1966-6
PD1124 TV24-9
PG1129 TV24-9
PD1130 TV24-9
PD1131 TV24-9
PD1132 TV24-9
PD1139 TV24-9
PD1303 TV24-9
PD1304 TV24-9
PG1308 TV24-9
PD1310 TV24-9
PG1310 TV24-9
PD1311 TV24-9
PG1311 TV24-9
PD1312 TV24-9
PD1319 TV24-9
PG1319 TV24-9
PG1320 TV24-9
PG1322 TV24-9
PG1325 TV24-9
PG1329 TV24-9
PG1330 } Use
PG1332 } C21C12
PG1335 } etc.
PG1339 } TV24-9
YG1507 1966-11
YG1527 1966-11
YG1531 1966-11
YG1547 } Use
YG1558 } 8N2
YG1561 } 1965-9
YG1571 1966-7
PG2101M TV25-16
PG2108M TV25-16
PG2110M TV25-16
PG2119M TV25-16
PG2127M TV25-16
PG2134 TV24-3
PG2137 TV24-3
PG2139 TV24-3
PG2144 TV24-3
PG2149 TV24-3
PGS2134 } Remote
PGS2137 } see G6
PGS2139 } TV24-9
PG2151M TV25-16

Admiral, Continued

SMG2201 1966-7
SRG2201 1966-7
SMG2205 1966-7
Y2411GP 1965-7
Y2413GP 1965-7
Y2421GP 1965-7
Y2423GP 1965-7
Y2437A uses 6M3A
Y2441 1965-7
TD3000 TV23-3
TDU3000 TV23-3
CD3001 TV23-3
CDU3001 TV23-3
LG3001M TV25-16
SMG3001 TV24-3
and 1966-7
SMDU3001 } For TV
SRDU3001 } see
SMDU3002 } 3D4
SRDU3002 TV23-3
TD3001 TV23-3
TDU3001 TV23-3
CD3002 TV23-3
CDU3002 TV23-3
SMG3002 TV24-3
and 1966-7
LD3011 TV23-3
LDU3011 TV23-3
LG3011 TV24-3
TG3011 TV24-3
CG3012 TV24-3
LD3012 TV23-3
LDU3012 TV23-3
LG3012 TV24-3
TG3013 TV24-3
LG3015 TV24-3
LG3021 TV24-3
TG3021 TV24-3
TGS3021 like G6
LG3022 TV24-3
TG3022 TV24-3
LG3025 TV24-3
TG3031 TV24-3
LG3041 TV24-3
LG3045 TV24-3
LG3049 TV24-3
LG3051 } Use
LG3055 } 10611-1
LG3059 } like G6
Y3321A 1965-5
Y3323A 1965-5
Y3381A 1965-5
Y3383A 1965-5
Y3408 1965-6
Y3411 1965-6
Y3412 1965-6
LDU3445 TV24-15
LDU3449 TV24-15
LDU3461 TV24-15
LDU3465 TV24-15
TDU3500 TV23-3
TDU3501 TV23-3
Y3503 1965-3
Y3508 1965-3
Y3509 1965-3
Y3513 1965-5
Y3517 1965-5
Y3519 1965-5
Y3523 1965-5
Y3528 1965-5
Y3529 1965-5
Y3543 1965-5
Y3554 1965-5
Y3557 1965-5
Y3559 1965-5
Y3564 1965-5
Y3568 1965-5
Y3569 1965-5
Y3573 1965-5
Y3577 1965-5
Y3579 1965-5
LG3701 TV25-16
SMG3701 1966-7
SMG3701 TV25-3
Y3703 1965-4
SMG3705 1966-7
and TV25-3
Y3708 1965-4
Y3709 1965-4
TG3710 TV25-3
Y3710 1965-4
SMG3711 TV25-3
and 1966-7
TG3711 TV25-3
TG3713 TV25-3
Y3714 1965-4
Y3717 1965-4
Y3720 1965-4
LG3721 TV25-16
TG3721 TV25-3
LG3722 TV25-16
LG3725 TV25-16
Y3727 1965-4

Admiral, Continued

Y3729 1965-4
CG3731 TV25-3
CG3732 TV25-3
LG3741 TV25-3
LG3742 TV25-3
LG3745 TV25-3
LG3771 TV25-3
LG3775 TV25-3
LG3801 TV25-3
LG3805 TV25-3
LG3819 TV25-3
D4117-1 like D4
LD5001 TV24-15
Y5009 1965-9
LD5011 TV24-15
Y5017 1965-9
LD5021 TV24-15
LD5025 TV24-15
Y5027 1965-9
Y5037 1965-9
Y5097 1965-9
LG5201 TV24-15
LD5205 TV24-15
LG5401 TV25-3
LG5411 TV25-3
LG5415 TV25-3
Y6001 1965-9
Y6002 1965-9
Y6021 1965-9
Y6022 1965-9
P6200 TV23-15
UP6200 TV23-15
P6201 TV23-15
UP6201 TV23-15
P6203 TV23-15
UP6203 TV23-15
P6204 TV23-15
UP6204 TV23-15
P6209 TV23-15
UP6209 TV23-15
P7004B } See
UP7004B } 16L3B
PG7021 TV25-11
PG7030 TV25-11
PG7031 TV25-11
PG7039 TV25-11
PG7047 TV25-11
YG8001,M 1966-7
YG8002,M 1966-7
YG8011,M 1966-7
YG8012,M 1966-7
YG8025,M 1966-7
YG8031,M 1966-7
YG8045,M 1966-7
YG8051,M 1966-7
YG8061,M 1966-7
YG8075,M 1966-7
Y8157 1965-8
Y8177 1965-8
Y8181 1965-8
Y8201 1965-8
YG8201 1966-18
Y8202 1965-8
YG8215 1966-18
YG8229 1966-18
Y8601 1965-10
Y8615 1965-10
Y8629 1965-10
PG9201 TV25-11
TG9201H TV25-11
PG9210 TV25-11
PG9211 TV25-11
PG9218 TV25-11
PG9227 TV25-11
PG9300M TV25-16
PG9309M TV25-16
P9414 TV23-3
UP9414 TV23-3
PG9420M TV25-16
P9421 TV23-3
PG9421M TV25-16
UP9421 TV23-3
P9423 TV23-3
UP9423 TV23-3
P9428 TV23-3
UP9428 TV23-3
P9430 TV23-3
UP9430 TV23-3
P9439 TV23-3
UP9439 TV23-3
P9551C } Use
UP9551C } 16M3C
P9553C } 16UM3C
UP9553C } TV21-7
P9621 TV23-3
PG9621M TV25-16
UP9621 TV23-3
P9623 TV23-3
UP9623 TV23-3
PG9625M TV25-16
P9628 TV23-3
UP9628 TV23-3
P9630 TV23-3

Admiral, Continued

UP9630 TV23-3
PG9637M TV25-16
P9639 TV23-3
UP9639 TV23-3
P9640 TV23-3
UP9640 TV23-3
P9649 TV23-3
UP9649 TV23-3
T9728 TV23-9
TG9728 TV24-3
TU9728 TV23-9
P9731 TV23-9
UP9731 TV23-9
P9734 TV23-9
UP9734 TV23-9
PG9734 TV24-3
PGS9734 } Remote
PGS9737 } see G6
PGS9739 } TV24-9
PG9737 TV24-3
P9739 TV23-9
PG9739 TV24-3
UP9739 TV23-9
P9741 TV23-9
UP9741 TV23-9
PG9744 TV24-3
P9749 TV23-9
PG9749 TV24-3
UP9749 TV23-9
P9751 TV23-9
UP9751 TV23-9
P9752 TV23-9
UP9752 TV23-9
UP9808 TV23-3

AMERICAN MOTORS

4TMR AU1-90
AM4TMR AU1-95
D4TMR AU1-90
8991320 AU1-35
8991321 AU1-35

ARVIN

13R07 1965-13
13R08 1965-13
14R18 1965-14
14R68 1965-15
15R75 1965-16
64R29 1965-18
64R38 1965-17
1.81001 1965-14
1.81501 1965-15
1.81601 1965-17
1.82001 1965-16
1.84701 1965-18
1.86401 1965-13

ATR-KARADIO

400 AU1-79
401 AU1-79
600 AU1-80
612 AU1-80
707(N) AU1-81
707P AU1-82

AUTOMATIC RADIO

662 Six-18
666 Six-18
CY-4025 AU1-5
TPC-4026 AU1-6
PC-4029 AU1-6
BP-4030 AU1-6
CYP-4032 AU1-5
TCM-4041 AU1-6
TCX-4042 AU1-6
CPV-4048 AU1-6
C-4049 AU1-5
CP-4050 AU1-5
NY-4105 AU1-4
VTP-4106 AU1-4
RP-4253 AU1-5
N-4299 AU1-5
NP-4300 AU1-5

BENDIX

4TBA AU1-35
4TBAM AU1-35
4TBC AU1-42
4TBCC AU1-40
4TBCH AU1-40
4TBCL AU1-40
4TBCT AU1-40
4TBC2 AU1-40
4TBD AU1-46
4TBLH AU1-44
4TBLL AU1-44
4TBM AU1-46
4TBO AU1-46
4TBQ AU1-42
4TBVE AU1-44
F4TBC AU1-48
F4TBE AU1-48

Bendix, Continued

F4TBF AU1-48
F4TBM AU1-48
F4TBS AU1-48
44BCS AU1-38
44BI AU1-38

BUICK

980649 AU1-7
980655A AU1-7
980659 AU1-65
980675 AU1-51

BULOVA WATCH

430 1965-20
S-912 1965-19

CADILLAC

7286315 AU1-51

CHEVROLET

985672 AU1-7
985773 AU1-7
985776 AU1-7
985815 AU1-7
985831 AU1-7
985832 AU1-7
985857 AU1-7
985875 AU1-7
985876 AU1-7
985877 AU1-65
985921 AU1-65
985958 AU1-7

CORONADO

60-9925A 1965-34
RA60-9930B 1965-34

CHRYSLER

335 AU1-65
336 AU1-65
348 AU1-42
351 AU1-65
352 AU1-65
353 AU1-65

DELCO

335 AU1-65
336 AU1-65
351 AU1-65
352 AU1-65
353 AU1-65
AC-3473 AU1-7
AC-3474 AU1-7
AC-3475 AU1-7
AC-3476 AU1-7
AC-3498 AU1-65
AC3499 AU1-65
AC-3500 AU1-65
AC-3506 AU1-7
980649 AU1-7
980655A AU1-7
980659 AU1-65
980675 AU1-51
982249 AU1-7
982250 AU1-51
982251 AU1-65
982252 AU1-7
984075 AU1-7
984076 AU1-7
984077 AU1-7
984078 AU1-65
985672 AU1-7
985773 AU1-7
985776 AU1-7
985815 AU1-7
985831 AU1-7
985832 AU1-7
985857 AU1-7
985875 AU1-7
985876 AU1-7
985877 AU1-65
985921 AU1-65
985958 AU1-7
2234040 AU1-7
7286315 AU1-51

DELMONICO

4T-20U TV23-21
TVM-11 TV24-23
PTV-19UHF TV23-25
TVM-33 TV24-23
120 1965-21
150 1965-21
CTM-235 TV23-29
FMS-411 1965-22

DODGE

206 AU1-44
221 AU1-44
334 AU1-42
354 AU1-112

DUMONT

41P01 TV24-29
46P01 TV25-25
46P02 TV25-25
49P03 TV25-25
49P06 TV25-25
B-190 TV23-35
B-191 TV23-35
B-192 TV23-35
B-193 TV23-35
B-195 TV23-35
B-196 TV23-35
B-198 TV23-35
B-201 TV23-35
B-202 TV23-35
B-220 TV23-35
B-221 TV23-35
B-222 TV23-35
524 1965-27
525 1965-27
526 1965-27
120708D TV23-35
120710F TV23-35
120712A TV23-35
120721F TV23-35
120725B TV23-35
120746 TV24-29
120780A TV25-25
120783A TV25-25
120810A TV25-25

EMERSON RADIO

11P01 TV24-29
11P02 TV24-29
11P03 TV24-29
11P04A TV25-21
13C01A TV25-31
13C02,A TV25-31
13C03,A TV25-31
13C04 TV25-31
13C05 TV25-31
13C06 TV25-31
13C07 TV25-31
13C08 TV25-31
13C09 TV25-31
13C10 TV25-31
13C11 TV25-31
13K01 TV25-31
13K02 TV25-31
13K03 TV25-31
13K04 TV25-31
13T01A TV25-31
16P01 TV25-25
16P02A TV25-25
16P03 TV25-25
16P04 TV25-25
16P05 TV25-25
19P04 TV25-31
19P05 TV25-31
19P06 TV25-31
19P08 TV25-25
19P09A TV25-25
19P10 TV25-25
19P11 TV25-25
19P12 TV25-25
19P13 TV25-25
19P16 TV25-25
19P17 TV25-25
19P18 TV25-25
19P20 TV25-25
19P23 TV25-25
31L02 } All use
31L03 } 120580
31L04 } etc.
31L05 } see
31L06 } 1962-20
31L7 1966-22
31L8 1966-22
31L09 1966-21
31L10 1966-21
31L11 1966-21
31L12 1966-24
31L13 1966-24
31L14 1966-24
31L15 1966-26
31L17 1966-26
31T01 1965-32
31T02 } Use
31T03 } 120578
31T04 } 1962-20
31T05 } All use
31T06 } 120685
31T07 } see
31T08 } 1964-29
31T09 1966-21
31T10 1966-21
31T11 1966-21
31T12 1966-24
31T13 1966-24
31T15 1966-26
31T17 1966-26
32P01A 1966-27
32P01 1965-31

Emerson, Continued

32P02 1965-31
32P06,A 1966-27
32P07,A 1966-27
32P09 1966-28
32P10 1966-28
32P11 1966-28
32P12 1966-27
899 1965-26
T1800C TV23-35
T1805C TV23-35
T1806C TV23-35
T1808C TV23-35
U1808C TV23-35
R1819C,D TV23-35
T1822C TV23-35
U1822C TV23-35
T1823C TV23-35
U1823C TV23-35
T1824C TV23-35
U1824C TV23-35
T1825C TV23-35
T1826C TV23-35
T1827C TV23-35
U1827C TV23-35
T1828C TV23-35
U1828C TV23-35
T1832C TV23-35
T1833C TV23-35
T1835C TV23-35
T1837C TV23-35
T1838 TV23-35
U1838 TV23-35
T1839 TV23-35
T1840,A TV23-41
U1840,A TV23-41
T1841,A TV23-41
U1850 TV23-35
U1851 TV23-35
U1852 TV23-35
T1855 TV23-41
U1855 TV23-41
T1860 TV23-41
U1860 TV23-41
U1876 like TV23-35
P-1925A 1965-23
P1927 1965-23
P-1930 like 120558 1963-36
P-1934 like P-1936 on 1964-38
P-1935 1965-23
P-1938 1965-23
P-1939 1965-27
P-1940 1965-27
P-1941, P-1942 } Use 120547B
P-1943 like 120548 1963-36
P-1944 1965-30
P-1945 uses 120567B 1964-62
P-1946 1965-30
P-1947 like 120558 1963-36
C2011 TV23-41
D2011 TV23-41
120664,L 1965-26
120671A,B TV23-41
120671E TV23-41
120673C,D TV23-41
120674A TV23-35
120675B,E TV23-35
120677A TV23-35
120679A TV23-35
120680C TV23-35
120681D,G TV23-35
120683C TV23-35
120690A TV23-35
120691B TV23-35
120694C TV23-35
120697A,E TV23-41
120698D TV23-41
120698K TV25-25
120702A,E TV23-41
120707B similar to data on TV23-35
120715 1965-23
120716 1965-23
120719 1965-27
120720C 1965-27
120724 1965-23
120725B similar to data on TV23-35
120726 1965-30
120737J similar to data on TV23-35
120740F TV23-41
120743E TV23-41
120744G TV23-41
120745 1965-31
120746 TV24-29
120747 1965-32
120750G, 120751G } Like TV23-41
120753J TV23-41 and TV25-25
120755G see TV23-41
120756 see TV23-35
120758A TV25-31
120759A TV25-31
120760A TV25-31
120764J TV25-25

Emerson, Continued

120765K TV25-25
120771 TV25-21
120772A TV25-31
120773A TV25-31
120774A TV25-31
120775G TV25-25
120776G TV25-25
120777G TV25-25
120779A,B TV25-25
120780A,+ TV25-25
120781A,+ TV25-25
120782A,+ TV25-25
120783A TV25-25
120784A TV25-25
120785A TV25-25
120788B TV24-29
120789 1966-22
120791 1966-21
120792 1966-21
120793 1966-21
120794 1966-21
120795 1966-26
120796 1966-26
120797 1966-26
120798 1966-26
120810A TV25-25
120811A TV25-25
120813A TV25-25
120818 1966-24
120819 1966-24
120826 1966-21
120828 1966-21
120832 1966-27
120833 1966-27
120836 1966-28
471538 1965-32

FORD

C4AA-18806 AU1-88
C4AZ AU1-48
C4DA-18805 AU1-46
C4GA-18806 AU1-88
C4GY AU1-48
C4MA-18805 AU1-46
C4MY AU1-48
C4OA-18805 AU1-46
C4SZ AU1-48
C4VY AU1-48
RV4F AU1-101

GAMBLE-SKOGMO

60-9925A 1965-34
RA60-9930B 1965-34

GENERAL ELECTRIC

AA TV23-47
AB TV25-37
BY TV24-35
DA TV23-53
DB TV24-41
EA TV23-59
MX TV21-29
SA TV23-63
SB TV25-43
TA TV24-45
T2AB 1966-38
T7 1965-48
TU50 1966-35
PAM109ABG TV23-63
M111A++ TV23-63
SAM111ASD TV23-63
M113A++ TV23-63
M114YEB, M115YEB } Use SY Chassis
M117AWD TV23-63
PAM119A++ TV23-63
M150B++ TV25-43
M152B++ TV25-43
M154BBN TV25-43
M181A++ TV23-63
PAM200AVY TV23-59
PAM201AVY TV23-59
PAM203AEB TV23-59
M205AVY TV23-59
SAM207A++ TV23-59
M206Y++, M207Y++ } Use LY Chassis
SAM209A++ uses EA
SAM211AVY TV23-59
SAM211AWD TV23-59
M218Y++, PAM218Y+, M219Y++, PAM219Y+ } Use LY Chassis TV21-45
TU222-1 through TU222-12 1965-45
T295 1965-36
SAM332Y++ TV24-35
SAM333Y++ TV24-35
SAM334YM+ TV24-35
SAM335Y++ TV24-35
SAM360Y++ TV24-35
SAM361Y++ TV24-35
SAM362Y++ TV24-35
SAM363Y++ TV24-35
RW365 TV23-58
M400ASD TV23-53
M400BGR uses DB
CAM401ASD uses DA
M401ASD TV23-53
M401BBG TV24-41

General Electric +

PAM401BWD TV24-41
M402A++ TV23-53
C403D 1965-37
M403A++ TV23-53
M403B++ TV24-41
PAM403A++ uses DA
M405BWD, M407B++, M409BWD } Use Chassis DB
M411A++ TV23-53
M413A++ TV23-53
M413B++ TV24-41
R413A++ TV23-53
R413B++ TV24-41
M415A++ TV23-53
M415B++ TV24-41
M414B++, M416BWD } Use DB
M425B++ use DB
PAM426Y++ use MY
C480A, C481A } Like C430A
M500BBG TV25-43
TU500 1966-35
M501AVY TV23-59
M503B++ TV25-43
C505B 1965-37
M505A++ TV23-59
M505BBN TV25-43
C506B 1965-37
M509B++ TV25-43
C545A,B, C546A,B, C547A,B } See C465A 1963-40
C550A,B 1965-40
C551A,B 1965-40
C555A 1965-36
C590B see C540A
A-600 1965-35
C++603AVY use DA
CBR608YVY, SAR608YGN } Use MY
SAR608XGN uses MX
C+R621AVY use DA
SAM718X++ uses MX
CAM719XBZ uses MX
PAM719AWD uses AA
SAM719X++ uses MX
M720B++ TV25-37
M720X++ use MX
SBM720XWD uses MX
CAM721ABZ uses AA
M721AEB TV23-47
M721X++ use MX
SBM721XWD uses MX
CAM722BBG TV25-37
CAM723BBG TV25-37
M723A++ TV23-4
SAM724X++ use MX
SAM725X++ use MX
CAM726B++ TV25-37
CAM727B++ TV25-37
M730B++ TV25-37
M731AMD TV23-47
M731AWD TV23-47
M733A++ TV23-47
M733BWD TV25-37
M734BMP TV25-37
M735A++ TV23-47
R735A++ TV23-47
SAM736X++ use MX
M737AWL TV23-47
SAM737X++ use MX
SAM739AWD uses AA
M740BWD TV25-37
P740A 1966-31
M741BPN TV25-37
P741A 1966-31
PAM741A++ use AA
M742BMP TV25-37
M743BCL TV25-37
M743A++ TV23-47
M745A++ use AA
M747A++ use AA
M751BWD TV25-37
M752BMP TV25-37
M753A++ use AA
M755A++ use AA
M757A++ use AA
SAM758X++ use MXT
PAM758Y++, PAM759Y++ } Use AY Chassis
M759A++ TV23-47
SAM759X++ use MXT
M760B++ TV25-37
SAM760X++ use MX
M761A++ TV23-47
SAM761X++, SAM762X++, SBM762X++ } Use MX
M762BMD TV25-37
M763A++ TV23-47
M763BWD TV25-37
R763A++ TV23-47
SAM763X++, SBM763X++ } Use MX
M764BMP TV25-37
PAM764MD uses AY
M771BMD TV25-37
M771BWD TV25-37
SAM776XMD uses MX
SAM777XMD uses MX

General Electric +

F780H 1966-30
TR803ABG TV24-45
TR805AEB TV24-45
P891A 1966-29
P910AA 1965-38
P911AA 1965-38
P914AA 1965-38
P915E 1966-31
P916E 1966-31
P917E 1966-31
P920A 1965-41
P950A 1965-38
P955E 1966-32
P960A 1965-38
P995A 1965-38
P996A 1965-38
T1110A like C505B
C1410A 1966-33
C1411A 1966-33
C1412A 1966-33
P1700A 1966-34
P1701A 1966-34
P1704A 1966-34
RP2020A,B 1965-42
RP2021 1965-42
RP2040A 1965-43
RP2041A 1965-43
RP2100 1965-42
RP2101 1965-42
RP2108 1965-42
RP2110 like RP2130
RP2128 like RP2110
RP2140 1965-43
RP2142 1965-43
RP2143 1965-43
RP2150, RP2153, RP2158 } Like RP2050 1963-57
RP2180, RP2181, RP2190, RP2191 } All like RP2080 1964-54
RP2230, RP2231 } Like RP2130
RP2290A, RP2291A,B } Like RP2190
RC4640A 1965-44
RC4641 1965-44
RC4642 1965-44
RC4650A,B 1965-44
RC4651 1965-44
RC4652 1965-44
RC4660 1965-44
RC4661 1965-44
RC4662 1965-44
RC4670, RC4671, RC4672, RC4675, RC4679 } Like RC1660 1964-55
P9151E 1966-31
P9161E 1966-31
P9171E 1966-31

GMC

2234040 AU1-7

HITACHI

TH-600 1965-49
TH-812 1965-50
TH-848 1965-52

HOFFMAN

MARK 10 TV12-79

MAGNAVOX

1T121D TV23-69
1T122D TV23-69
1T123D TV23-69
1T124D TV23-69
2AM-70 1965-53
2ST686 1965-57
2ST687 1965-57
2ST690 1965-57
44 Series TV24-53
47 Series TV23-69
AM82 1965-56
AM83 1965-54
R207 1965-57
R252 1966-39
A505 1966-41
A551 1965-61
A590 1965-61
AM-802 1966-40
T-914 TV25-47

MATSUSHITA

RE-124 1966-42

MONTGOMERY WARD

WG-1248B TV23-73
GEN-1250A 1965-62
GEN-1251A 1965-62
GEN-1257A 1965-63
GTM-1264A like sets on TV22-157
GEN-1336A 1966-43
GTM-1364A TV23-166
GEN-1802A 1965-64
GEN-1803A 1965-64
GEN-1804A 1965-64

Montgomery Ward +

GEN-1805A 1965-64
GEN-1806A 1965-64
GEN-1808A 1966-44
GEN-1837A 1966-44
GEN-1847A 1966-44
GEN-1857A 1966-44
GTM-1864A like sets on TV22-157
GEN-1877A 1966-44
GEN-1897A 1966-44
GTM-2165A TV23-159
GTM-2264A like sets on TV22-157
GTM-2265A TV23-159
GTM-2564A TV23-166
GTM-2565A TV25-155
WG-2785A TV24-59
GTM-2865A TV24-147
WG-3315A TV23-76
WG-3345A TV23-76
WG-3355A TV23-76
WG-4315A TV23-76
WG-4345A TV23-76
WG-4355A TV23-76
WG-4515A TV24-59
WG-4545A TV24-59
WG-4555A TV24-59
FJB-6540C AU1-84
FJB-6615A AU1-84
FJB-16586A AU1-83

MOPAR

also see Motorola

206 AU1-44
218 AU1-44
221 AU1-44
334 AU1-42
348 AU1-42
414 AU1-38
415 AU1-38

MOTOROLA

AC1A see 1965-70
EFM-1 uses HS-939
SK1B like HS-1260
XF1C 1966-63
AC2A see 1965-70
CX2B,N,++ use HS-6110 1964-81
XP2C 1966-68
XT2B 1966-59
AC3A uses HS-939
XP3C 1966-64
XT3B 1966-59
4AT AU1-86
4MT AU1-86
4TME AU1-88
4TMF AU1-88
4TMR AU1-90
4TMVG AU1-92
4TMVT AU1-92
4TMVW AU1-92
AC4B 1966-69
AF4TMR AU1-95
BC4 1965-66
BK4PM AU1-99
CT4PM AU1-99
D4TMR AU1-90
OE4PM AU1-99
PC4PM AU1-99
RV4F AU1-101
AC5B 1966-45
TM5A 1966-70
BC6A 1966-62
B7 1965-65
TC7B 1966-60
XP7C 1966-66
B8 1965-65
TC8B 1966-60
B9 1965-65
BC9B 1966-62
B10 1965-65
BC11 1965-66
XC11B 1966-59
12BP70AA TV24-85
12BP71AL TV24-85
12BP71A+ TV24-85
BC12 1965-66
XC12B 1966-59
BT13A 1966-62
XC13B 1966-59
14AT AU1-102
TT14B 1966-60
XC14B 1966-59
TT15B 1966-60
BT16B 1966-62
19BP100BE TV25-61
19BP101A TV24-73
19BP103A TV24-73
19BP104A TV24-73
19BP105A TV24-73
19BP116BE,W, like sets on TV24-73
19BP116B+ TV25-61
19BP117BA TV25-61
19BP118B+ TV25-61
19BT107+ TV23-86
19BT108+ TV23-86
19BT109+ TV23-86
19BT120++ TV25-57
19BT121++ TV25-57
19BT122++ TV25-57

Motorola, Continued

19BT124++ TV25-57
19P31+, 19P33+, 19P34+ } Use ++TS-449 TV20-79
19M5++ like data on TV22-77
19T36CHA like data on TV22-77
19T36CH(N) see ++TS-449 TV20-79
19T54+ see TV22-71
19T56B+ TV23-86
19T57+++ TV23-86
19T58+++ TV23-86
A19T23CH see ATS-449 TV20-79
Y19P31+, Y19P33+, Y19P34+ } Use ++TS-449Y TV20-79
Y19M5++ like data on TV22-77
Y19T36CHA like data on TV22-77
Y19T36CH(N) see ++TS-449 TV20-79
Y19T54+ TV22-71
Y19T56B+ TV23-86
Y19T57++ TV23-86
Y19T58++ TV23-86
21BT130++ TV25-57
21BT131++ TV25-57
21BT132++ TV25-57
23BK150++ TV23-86
23BK152++ TV23-86
23BK153AD TV23-86
23BK154++ TV23-86
23BK155AS TV23-86
23BK157AS TV23-86
23BK158++ TV23-86
23BK160AW TV23-86
23BK161++ TV23-86
23BK162++ TV23-86
23BK163AS TV23-86
23BK164A+ TV25-53
23BL165BW TV25-53
23BL173A+ TV25-53
23BL174AS TV25-53
23BL175B+ TV25-57
23BL176BM TV25-57
23BL177BS TV25-57
23BL178BC TV25-57
23BS171A+ TV25-53
23BT101A+ TV25-53
23BT102A+ TV25-57
23BT103AW TV25-57
23BU170A+ TV25-53
23BU172AS TV25-53
23K86+ use TS-578
23K89+ use LTS-578
23K125M,W, 23K126MP } See TV22-71
23K136M,W TV23-79
23K138M,W TV23-79
23K140MP TV23-79
23K142M,W TV23-79
23LK412B 1966-90
23LK413B 1966-90
23LK414B 1966-90
23LK415B 1966-90
23LK416B 1966-90
23PK400+, 23PK402AS } Use VTS-587Y
23SK400+, 23SK402AS } see TV22-83
23T25CH see TS-578
23T26MPGA like data on TV22-77
23T30 see TV22-71
23T35E TV23-79
23T37++ TV23-79
AT23A 1966-46
Y23K86M,W, use Chassis TS-578Y
Y23K89M,W,+ use Chassis LTS-578Y
Y23K125M,W, Y23K126MP } See TV22-71
Y23K136++ TV25-53
Y23K136M,W TV23-79
Y23K138M,W TV23-79
Y23K140MP TV23-79
Y23K142M,W TV23-79
Y23T25+ see TS-578
Y23T26MPGA like data on TV22-77
Y23T30+ like data on TV22-71
Y23T35E,+ TV25-53
Y23T35E TV23-79
Y23T37++ TV23-79
Y23T39WGA TV23-86
Y23T51GR like data on TV22-71
A25 1965-69
AT25B uses HS-4137
A26 1965-70
A27 1965-70
AT28A, AT29A } Like data on 1965-70
AT30B 1966-69
AT31B 1966-69
C38 1965-70

Motorola, Continued

C39 1965-70
AC40A 1966-45
AC41A, AC42A } Like data on 1965-70
AC43B 1966-69
SP53 1965-73
SP-54 1965-73
X58 1966-47
X60 1966-47
X61 1966-52
X62 1966-50
BKA64 AU1-86
CKA64 AU1-86
CKM64 AU1-86
CRA64 AU1-106
CRM64 AU1-106
CTA64 AU1-86
CTM64 AU1-86
CYA64 AU1-106
CYM64 AU1-106
OKA64 AU1-86
PCA64 AU1-86
VWA64, VWM64 } Similar to VW463
X64 1966-54
X65 1966-48
XP68B 1966-55
XP69B 1966-56
HK70 uses HS-1049
XP73B 1966-57
PP80A 1965-93
HK81 1965-81
PT81A 1965-93
ST82A 1965-88
PP90A 1965-90
PP91A 1965-90
PP92A 1965-90
FMA-100 AU1-99
MP100B 1966-89
SK102 uses HS-1049
SKR120 1965-72
SKR121 1965-72
SKR124 1965-72
SKR125 1965-72
SK135 1965-78
SKR135 1965-74
SK136 1965-74
SKR136 1965-74
SK145 1965-77
SKR145 1965-77
SK147 1965-79
SKR147 1965-79
SK148 1965-79
SKR148 1965-79
SK150 1965-79
SKR150 1965-79
SK151 1965-82
SKR151 1965-82
SK152 1965-82
SKR152 1965-82
SK154 1965-79
SKR154 1965-79
SKR155 1965-82
SKR156 1965-82
SKR157 1965-82
SKR158 1965-82
SKR159 1965-82
SKR160 1965-82
SK161 1965-74
SKR161 1965-74
SK162 1965-74
SKR162 1965-74
SK163 1965-77
SKR163 1965-77
SK164 1965-79
SKR164 1965-79
SK165 1965-79
SKR165 1965-79
SK166 1965-74
SKR166 1965-74
SKR167 1965-74
SK172A 1965-88
SK173A 1965-88
PK175A 1965-91
SK175A 1965-88
PK176A 1965-91
SK176A 1965-88
PK177A 1965-91
SK177A 1965-88
PK178A 1965-91
SK178A 1965-88
PK180A 1965-92
SK180A 1965-84
SK181A 1965-84
PK182A 1965-92
SK182A 1965-84
PK183A 1965-92
SK183A 1965-84
PK190A 1965-90
SK190A 1965-84
PK191A 1965-90
SK191A 1965-84
SK192A 1965-84
SK193A 1965-84
SD194A 1965-84
SD195A 1965-84
SD196A 1965-84
PP200B 1966-88
PP201B 1966-88
219 AU1-103
220 AU1-103
232 1966-72

Motorola, Continued

233	1966-72
235S	1966-72
294	AU1-108
TM295M	1966-74
TM296M	1966-76
PP301B	1966-90
PP302B	1966-90
SP310B	1966-90
TM316M	1966-78
324	AU1-110
TM325M	1966-80
TM326M	1966-82
TM336M	1966-84
354	AU1-112
PM400B	1966-90
PM401B	1966-90
414	AU1-114
424	AU1-110
TS449	TV20-79
++TS-449,Y	TV20-79
SM450B	1966-90
SM451B	1966-90
SM452B	1966-90
SM453B	1966-90
VTS-454	TV24-65
WTS-454	TV24-65
SK500B through SK509B	1966-90
524	AU1-116
TM526A	1966-86
LTS-578,Y } Like NLTS-578,Y } TS-578	
TS-578,Y	TV20-79
TDTS-586Y	TV24-73
WNDTS-586Y	TV24-73
WZDTS-586Y	TV24-73
ZDTS-586Y	TV24-73
VTS-587Y like TS-587	TV22-83
KTS-588,Y	TV25-53
KTS-588	TV23-79
PKTS-588,Y	TV23-79
SKTS-588	TV25-53
TS-588	TV25-53
VKTS-588,Y	TV25-53
DTS-589Y	TV23-86
JTS-589	TV25-57
KTS-589,Y	TV23-86
NDTS-589,Y	TV23-86
NJTS-589	TV25-57
NKTS-589Y	TV23-86
PKTS-589Y	TV23-86
QDTS-589Y	TV23-86
TS-589	TV23-86
WKTS-589C	TV25-57
ZDTS-589C	TV25-57
ZKTS-589	TV25-57
DTS-596	TV25-61
NDTS-596	TV25-61
SDTS-596	TV25-61
HS-1128	1965-72
HS-1130	1965-73
HS-1137	1965-74
HS-1138	1965-74
HS-1141	1965-79
RS-1147	1965-72
HS-1150	1965-78
HS-1181	1965-73
HS-1185	1965-77
HS-1186	1965-77
HS-1197	1965-79
HS-1198	1965-79
HS-1199	1965-82
HS-1200	1965-82
HS-1200-1	1965-82
HS-1222	1965-74
HS-1239	1965-77
HS-1241	1965-84
HS-1242	1965-90
HS-1253	1965-73
HS-1259	1965-84
HS-1260	1965-88
HS-1261	1965-91
HS-1262	1965-92
HS-1264	1965-84
HS-1266	1965-90
HS-1269	1965-93
HS-1323	1965-88
HS-1328	1965-84
HS-2334	1966-90
HS-2336	1966-90
HS-2339	1966-90
HS-2347	1966-88
HS-2348	1966-89
HS-2349	1966-90
HS-4108	1965-65
HS-4109	1965-65
HS-4123	1965-65
HS-4134	1965-66
HS-4135	1965-66
HS-4137	1965-69
HS-4141	1965-70
HS-4143	1966-46
HS-4146	1965-70
HS-4152	1966-45
HS-6127	1966-47
HS-6131	1966-50
HS-6133	1966-48
HS-6136	1966-51
HS-6137	1966-52
HS-6139	1966-54
HS-6202	1966-55

Motorola, Continued

HS-6207	1966-56
HS-6208	1966-57
HS-7201	1966-59
HS-8201	1966-62
HS-8202	1966-62
HS-8206	1966-60
HS-8207	1966-60
HS-66200	1966-63
HS-66201	1966-68
HS-66202	1966-64
HS-66206	1966-66
HS-67201	1966-69
HS-68202	1966-69

MUNTZ TV

3210	TV24-79
3211	TV24-79
3311	TV24-79
3411	TV24-79
3519	TV24-79
3520	TV24-79
3521	TV24-79
3522	TV24-79
3523	TV24-79
3525	TV24-79
4310	TV24-79
7310	TV24-79
7410	TV24-79
7510	TV24-79

OLDSMOBILE

982249	AU1-7
982250	AU1-51
982251	AU1-65
982252	AU1-7

OLYMPIC

NB	TV23-93
NBU	TV23-93
9P39U	TV24-85
9M40	TV24-85
9M40U	TV24-85
306	TV23-96
C945	TV23-93
C946	TV23-93
C950	TV23-93
C951	TV23-93
C952	TV23-93
C953	TV23-93
C955	TV23-93
K965	TV23-93
K966	TV23-93
K967	TV23-93
K968	TV23-93
K970 through K979	TV23-93

PACKARD-BELL

5R11	1965-94
5R12	1965-94
5RC13	1965-94
5RC14	1965-94

PANASONIC

RE-124	1966-42

PHILCO CORP.

N Line	TV23-97
P Line	TV25-69
P10ST	1966-100
15G20	TV23-97
15J25	TV25-69
15J25	TV23-97
15J27	TV23-97
15J27	TV25-69
15N30	TV23-97
15N50	TV23-97
16J27	TV25-69
16JT26,A	TV25-69
16N35	TV25-69
22B4005 } Same as 22B4007 } 22B4004	
22BU4005 as above	
22BU4C07 as above	
P25ST	1966-104
T-69	1965-95
NT-600	1965-98
NT-601	1965-96
P710	1966-97
P720	1966-96
N-721	1965-103
P-721	1966-96
P-722	1966-96
N-723	1965-105
P-723	1966-96
N-724	1965-105
P-724	1966-96
N-725	1965-106
N-727	1965-106
N-730	1965-107
N-731	1965-108
N-732	1965-108
N-795	1965-104
NT-802	1965-101
NT-807	1965-109
NT-808	1965-110
NT809	1966-95
NT814	1966-98
NT815	1966-99
N-880	1965-103
P880	1966-96

Philco, Continued

P881	1966-96
P882	1966-96
N884	1965-105
P884	1966-96
N-885	1965-105
P885	1966-96
NT-900	1965-102
NT-906	1965-111
T-908	1965-112
NT-913	1965-114
P933	1966-97
N-940	1965-107
P941	1966-97
N-942	1965-108
N-944	1965-108
M-1001	1965-118
P1002	1966-100
NT-1004	1965-116
N1200	TV24-89
N1204	TV24-89
P1441	1966-106
P1442	1966-106
P1444	1966-107
P1445	1966-108
P1446	1966-108
N-1508	1965-124
P1511	1966-109
P1513	1966-110
P1515	1966-110
M-1620	1965-118
M-1662	1965-118
M-1663	1965-118
M-1664	1965-118
M-1666	1965-122
M-1669	1965-122
M-1680	1965-122
M-1688	1965-122
M-1689	1965-122
M-1700	1965-118
M-1701	1965-118
M-1704	1965-122
P1710	1966-104
P1718	1966-100
P1719	1966-104
P1722	1966-104
P1735	1966-104
P1737	1966-104
UN2620WH	TV23-97
UN2622GY	TV23-97
M3221BE see 13J27	
M3232BGD see 13J27	
M3300GY	TV23-97
UN3300++	TV23-97
M3304BK	TV23-97
UN3304BK	TV23-97
P3309TN	TV25-69
P3310++	TV25-69
P3312WH,Y	TV25-69
P3314GY,WH	TV25-69
P3390BK	TV25-69
M3501V	TV23-97
M3504++	TV23-97
M3508WA	TV23-97
M3509D	TV23-97
UN3530WH	TV23-97
UN3532B+	TV23-97
UN3534++	TV23-97
UN3536++	TV23-97
P3540TN	TV25-69
P3542BR,WH	TV25-69
P3544MA,WA	TV25-69
P3552BE	TV25-69
P3554WA	TV25-69
P3555WH	TV25-69
P3556MA,WA	TV25-69
UN3590++	TV23-97
UN3592++	TV23-97
P3594WA	TV25-69
M3600++	TV23-97
P3609BK,IV	TV25-69
UN3610++	TV23-97
P3616WA	TV25-69
P3620MA,WA	TV25-69
P3902BE	TV25-69
P3904MA,WA	TV25-69
P3906WA	TV25-69
P4320BK	TV25-69
P4322MB,WA	TV25-69
P4324MB,WA	TV25-69
M4513++ use 14N50	
UN4530++	TV23-97
UN4532++	TV23-97
UN4534++	TV23-97
UN4536MA	TV23-97
P4540MB,WA	TV25-69
P4542MB,WA	TV25-69
P4544WA	TV25-69
P4546++	TV25-69
P4548PC,WA	TV25-69
P4550WA	TV25-69
P4552CE,MA	TV25-69
UN4720MB	TV23-97
UN4722++	TV23-97
P4734WA	TV25-69
UN4938MB	TV23-97
UN4940++	TV23-97
UN4942++	TV23-97
UN4944++	TV23-97
UN4946++	TV23-97
M9301++ } Use M9303++ } 14N30	
UN9306BK	TV23-97

Philco, Continued

UN9308++ use 15N30	
UN9310++	TV23-97
UN9312++	TV23-97
M9509++ } Use M9511++ } 14N30	
UN9516WA	TV23-97
UN9518++	TV23-97
UN9520++	TV23-97
UN9522++	TV23-97
UN9524++	TV23-97
UN9526WA	TV23-97

PONTIAC

984075	AU1-7
984076	AU1-7
984077	AU1-7
984078	AU1-65

RCA VICTOR

VFE-01W	1965-125
VFE-03	1965-130
VGE-03W	1966-122
AG-005J	TV25-107
VFE-05+, RS-202D, similar	1964-131
VFR-05M,W	1965-133
VFT-05M,W	1965-133
VGP-05A,+	1966-123
6AB1M } Use 6AB2M } KCS-146D	
VGP-08A,+	1966-123
9AB3M see KCS-142A	
9AB4M see KCS-147A	
9AB32RS } Use 9AB34RS } KCS-143C	
VFP-09E,T	1965-130
RGH-10	1966-119
VFP-10E uses RS-197	1962-105
VFT-10E	1965-133
VGP-11+	1965-130
RFA-11V,+	1965-126
RFB-11V uses RC-1210A	1963-130
RFC-11 uses RC-1210C	1963-134
RFD-11V,+	1965-126
VFP-11A,+	1965-130
RFG-12 similar to data on	1965-131
RGA-12Y	1966-120
RGH-12	1966-116
RHA-12G,+	1966-111
AG-013+	TV25-107
RHD-13N,Y	1966-111
RFA-15A,+	1965-126
RFC-15E,W	1965-128
RFD-15V	1965-126
RFS-15W	1965-128
RGA-15A,+	1966-120
VGE-15M	1966-121
17PD8099	TV14-131
RGG-17B	1966-112
RHA-17A,+	1966-111
RHD-17A,+	1966-111
RHH-17	1966-117
RFC-19W	1965-128
RFD-19G,+	1965-126
VFP-19B,T	1965-130
VFR-19M	1965-133
VFT-19M	1965-133
AF-020J	TV24-105
RFG-20A,+	1965-131
RGD-20N,+	1966-120
VFP20 uses RS-198	
AF-021E,+	TV24-105
RHD-21A,+	1966-111
RHG-21	1966-113
VFP-21A,T	1965-130
VGP-21+	1965-130
RGG-22A,+	1966-112
VFT-22W	1965-133
RGD-24,+	1965-138
RFG-25B,E	1965-131
RGG-25B,+	1966-112
RHG-25	1966-113
VFE-25L, RS-202D similar	1964-131
VFR-25L	1965-133
VFT-25L	1965-133
VGP-25E,T	1966-122
VFT-26W	1965-137
RGA-27	1966-111
VFT-27L	1965-137
VFT-28M	1965-137
AG-028J } Use AG-030N } KCS-152C	
AG-029A,+	TV24-105
RGG-29E	1966-114
RHC-29W	1966-124
RHD-29W	1966-128
VFT-29W	1965-137
RGD-30	1966-111
RHG-30E	1966-115
VFT-30W	1965-137
VFT-31L	1965-137
RHC-33W	1966-124
VGP-34E,G	1966-122
RHC-37L	1966-124
RGA-39W	1966-118
VFP-32E,G	1965-130

RCA Victor, Cont.

34B26M uses KCS-136YA	
34G29M } Use 34C31M } Chassis 34C32M } KCS-136ZA 34C33M } etc.	
34C41M } Use 34C52M } Chassis 34C54M } KCS-136ZK	
34C83XM uses KCS-136+	TV21-115
34CB34SM } Use 34CB34GM } Chassis 34CB34SM } KCS-136ZK 34CB34GM } etc. 34CB37M } see 34CB56AM }	TV22-115
RHA-39W	1966-128
RGA-40W	1966-118
RHC-41W	1966-124
VFP-43A	1965-130
VGP-43E,T	1966-122
VFT-44W	1965-136
AF-045J	TV24-95
RHC-45F	1966-124
AF-049E,+	TV24-95
RHC-49B	1966-124
VFP-49E	1965-130
AG-050E,J	TV25-121
AF-051J	TV23-137
VFT-52M	1965-136
VFT-54L	1965-136
VFT-56C	1965-136
VFP-58A	1965-130
VFP-60E	1965-130
6AA013MU } Use 6AA013MV } KCS-146D 6AA052M+ } Chassis 6AA054M+ } see 6AA056M+ } TV22-137	
AG-065+	TV25-121
VFP-65E	1965-132
VFT-65W	1965-136
AF-071E,G	TV23-137
AF-071H,T	TV23-137
VFT-72W	1965-136
AF-073A,E,V use KCS-151A	
VGP-72	1966-121
VFT-74L,Z	1965-136
VFT-76W	1965-136
VFT-82M,V	1965-136
AG-083+	TV25-95
VFT-83F,V	1965-136
VGP-83	1966-121
VFT-84E	1965-136
VFT-85W	1965-136
VFT-86L	1965-136
AG-089+	TV25-95
AF-090E,H	TV24-95
AF-091E,G,H, use KCS-143F	TV22-127
9AA123RS	TV22-119
9AA144M+ } Use 9AA146M+ } KCS-142D K9AA192M+ } Use K9AA193M+ } KCS-140A	
9AA203M+ } Use 9AA209M+ } KCS-143A	
9AA211M+ } Use 9AA216M+ } KCS-147A	
9AA233M+ } Use 9AA236M+ } KCS-143D 9AA237M+ } KCS-143E	
9AA252++ } Use 9AA253++ } KCS-141K 9AA256M+ } TV22-122	
AF-095H,+	TV24-95
AG-095++	TV24-95
AF-097W,Y	TV22-127
AF100A,B use KCS-148A	TV23-131
AF-101A,B	TV23-131
AF-111E,W, use KCS-144D	
AF-115E,W, use KCS-148F	
AF-117E	TV23-131
AF-117V,W	TV23-131
AG-118E,W, use KCS-148N	TV25-99
AF-125B,E	TV23-127
AG-127B,E	TV25-99
AG-133E,W	TV25-99
KCS-136MA	TV25-91
KCS-136MB	TV25-91
KCS-136MJ	TV25-91
KCS-136X+	TV23-120
also	TV24-100
KCS-136ZA thru -ZL similar	TV22-115
KCS-137P	TV22-119
AF-141L	TV23-127
AF-141U,W	TV23-127
AF-141UR,+ } Use AF-143E,++ } KCS144N	
KCS-142AA	TV24-95
KCS-142AC	TV24-95
KCS-142R	TV24-95
KCS-142U	TV24-95
KCS-142XA	TV24-95
AG-143+	TV25-103

RCA Victor, Cont.

KCS-143C like KCS-143A	TV22-127
KCS-143D,E,F like KCS-143A	TV22-127
KCS-144D similar to KCS-144A	
KCS-144E	TV25-95
KCS-148A,B	TV23-131
KCS-148F like data on	TV23-131
KCS-148N	TV25-99
KCS-149A	TV23-127
KCS-149AA	TV25-103
KCS-149A+	TV25-103
KCS-149W,P like data on	TV23-127
KCS-151A	TV23-137
KCS-152A	TV24-105
KCS-152C	TV24-105
KCS-153A	TV25-107
KCS-153B	TV25-107
KCS-154A	TV25-115
KCS-154B	TV25-115
KCS-155	TV25-121
AG-159B,H	TV25-103
AG-167++	TV25-103
AG-185J	TV25-115
AG-187W,Y	TV25-115
RS-188B	1965-125
AG-189++	TV25-115
RS-203C	1965-133
RS-206A	1965-132
RS-210A	1965-136
BF211E,+	TV23-120
BF-211++	TV24-100
RS-212A	1965-137
BF-213E,+	TV24-100
RS-216A	1966-121
RP-219-39	1965-130
RP-219-42	1965-130
RP-219-49	1965-130
RP-219A++	1965-130
RS-219A,B	1966-121
RS-225,-A	1966-123
BG-249++	TV25-91
CF263M,W	TV24-100
CF265+	TV23-120
CF265++	TV24-100
CF270M,+	TV24-100
CF273W	TV24-100
CF274L	TV24-100
CF276V,W	TV24-100
CF277C,+	TV24-100
CG-281M,+	TV25-91
CG-287+	TV25-91
CG-299W	TV25-91
CG-305L	TV25-91
CF315M,W also	TV23-120
	TV24-100
CG-317+	TV25-91
CG-323+	TV25-91
CG-329M,W	TV25-91
CF335M,+	TV24-100
CF336M,+	TV24-100
CF339M,W	TV24-100
CF341M,W	TV24-100
CF343M,W	TV24-100
CF345W	TV24-100
CF347L	TV24-100
CF349V,W	TV24-100
CF351C,+	TV24-100
CG-351W	TV25-91
CG-353M,W	TV25-91
CF-355M,W	TV24-100
CF356W	TV24-100
CF357L	TV24-100
CF359M,W also	TV24-100
	TV23-120
CG-359M,W	TV25-91
CG-365W	TV25-91
CF369M,W	TV23-120
CF369M,W	TV24-100
CF371W	TV24-100
CG-371L	TV25-91
CF373L	TV24-100
CF375F,V	TV24-100
CG-377+	TV25-91
CG-383S	TV25-91
DF455+	TV23-120
DF457M,W	TV23-120
DF467W	TV23-120
DF469L	TV23-120
RC-1210E,F	1965-128
RC-1213A	1966-120
RC-1213AA	1966-111
RC-1213AB	1966-111
RC-1213A	1965-126
RC-1213AX	1965-126
RC-1213CD	1965-126
RC-1213J	1965-126
RC-1213JX	1965-126
RC-1213K,L	1965-126
RC-1213K	1966-120
RC-1213P	1965-138
RC-1213M	1966-111
RC-1213R	1966-111
RC-1213W	1966-111
RC-1215D,E	1965-133
RC-1215J,K	1965-136
RC-1215M	1965-137
RC-1219A also	1965-131
	1966-112

RCA Victor, Cont.

RC-1219B	1966-112
RC-1219D	1966-113
RC-1220A	1966-124
RC-1221A	1966-114
RC-1221B	1966-115
RC-1222A	1966-116
RC-1224	1966-118
RC-1224C	1966-128
RC-1224D	1966-128

RAMBLER

AF4TMR	AU1-95
8991320	AU1-35
8991321	AU1-35

RIVERSIDE

FJB-6540C	AU1-84
FJB-6615A	AU1-84
FJB-16586A	AU1-83

SEARS, ROEBUCK

5008	1965-139
5009	1965-139
5036	1965-142
5037	1965-142
5038	1965-142
5039	1965-142
5045	1965-140
5046	1965-140
5120	TV24-115
5121	TV24-115
5150	TV24-120
5151	TV24-120
5152	TV24-120
5153	TV24-120
5155	TV24-120
5156	TV24-120
5157	TV24-120
5158	TV24-120
5163	TV24-120
5164	TV24-120
5165	TV24-120
6055	1966-132
6056	1966-132
6103	TV25-131
6104	TV25-131
6120	TV25-127
6121	TV25-127
6124	TV25-127
6125	TV25-127
6126	TV25-127
6200	1966-134
6202	1966-131
6203	1966-131
6204	1966-131
6208	1966-130
6209	1966-130
6210	1966-130
6211	1966-130
6223	1966-129
6224	1966-129
6225	1966-129
6238	AU1-118
6239	AU1-119
132.83601	1965-139
132.84101	1965-140
132.90301	1966-131
132.91301	1966-130
456.61450 through 456.61455	TV24-120
456.61460 through 456.61461	TV24-120
456.61466	TV24-120
456.61467	TV24-120
456.61474	TV24-120
456.61475	TV24-120
456.61510 through 456.61513	TV24-120
456.61560	TV24-115
456.61561	TV24-115
456.61606	TV25-127
456.61607	TV25-127
528.61340	TV24-120
528.61341	TV24-120
528.61450 through 528.61455	TV24-120
528.61460	TV24-120
528.61461	TV24-120
528.61466	TV24-120
528.61467	TV24-120
528.61474	TV24-120
528.61475	TV24-120
528.61480	TV24-120
528.61481	TV24-120
528.61484	TV24-120
528.61485	TV24-120
528.61510 through 528.61513	TV24-120
528.61560	TV24-115
528.61561	TV24-115
529.61340	TV24-120
529.61341	TV24-120
529.61450 through 529.61455	TV24-120
529.61460	TV24-120
529.61461	TV24-120
529.61466	TV24-120
529.61467	TV24-120
529.61474	TV24-120
529.61475	TV24-120
529.61510 through 529.61513	TV24-120

Sears, Roebuck +
528.61606 TV25-127
528.61607 TV25-127
528.63101 1965-142
528.63131 1966-129
528.63140 1966-134
528.63470 1966-132
528.63471 1966-132
529.61606 TV25-127
529.61607 TV25-127
562.10110 TV25-131
562.10111 TV25-131
750.62380 AU1-118
750.62381 AU1-119
750.62390 AU1-118
750.62391 AU1-119
833.62740 AU1-122
833.62741 AU1-120

SHARP ELECTRONICS
FMA-11 1965-145
12TP-8 TV25-141
16TP-5 TV23-147
16TP-5V TV23-147
19TS-6(V) TV23-152
BP-374 1965-143
BP-460 1965-144
BP-485 1965-146
TRP-601 TV23-143

SONY
TV4-203UW TV24-127
TV5-305UW TV25-135
TR-8 1965-147
TR-8 1966-135
TR-830 1965-148
also 1966-136

STUDEBAKER
AC-3473 AU1-7
AC-3474 AU1-7
AC-3475 AU1-7
AC-3476 AU1-7
AC-3498 AU1-65
AC-3499 AU1-65
AC-3500 AU1-65
AC-3506 AU1-7

SYLVANIA
P01-1 1966-141
P02-1 1966-142
P03-1 1966-143
B04-1,-2 TV25-147
B05-1 TV25-153
B05-2,-3 TV25-153
19P16 uses 573-7
19P16-1 TV24-133
19P19-1 TV24-133
19P34 uses 571-1
19P36-1 TV24-133
19P37 TV24-133
19P38 TV24-133
19P38-1 TV25-153
19P39 TV24-133
19P39-1 TV25-153
19P40 TV24-133
19P41 TV24-133
19P41-1 TV25-153
19P42 TV25-153
19T30,-1 TV24-133
19T31,-1 TV24-133
19T32,-1 TV24-133
21C529 similar to 1-541-7
23C111 TV23-155
23E01 TV24-141
23E02 TV24-141
23H20 TV24-133
23H30 TV24-133
23L85 uses 575-7
23L121 TV23-155
23L124 TV23-155
23L133 TV23-155
23L135 TV23-155
23L135-1 TV24-133
23L137 uses 575-7
23L140 TV23-155
23L141 TV23-155
23L144 TV24-141
23L145 TV24-141
23L146 TV24-141
23L159 TV24-133
23L160 TV24-133
23L161 TV24-133
23L163 TV25-147
23L164 TV25-147
23L165 TV25-147
23L166 TV25-147
23L167 TV25-147
23T101 TV23-155
23T102 TV23-155
23T105 TV24-133
23T106 TV24-133
23T106-1 TV25-147
23T110 TV24-133
23T111 TV24-133
23V128 TV23-155
AT30, AK35, AK36, AK37 } Use 711-6,-7,-8 see 1963-160
AT40 1966-137

Sylvania, Continued
45P30, 45P31 } Like 45P20
45P36 see 1964-152
45P38, 45P39 } Use 407-2,-3
45P41 1965-155
45P50 1966-141
45P60 1966-142
45P61 1966-143
AK45 1966-137
AK46 1966-137
TR50 1966-138
U50-1,-2 1966-137
TR54 1966-139
TR86 1966-140
309-1 1965-149
324-1 1965-150
325-1 1966-138
328-1 1966-139
335-1 1966-140
370-1 1965-152
371-1 1965-156
406-3 like 406-1
407-2,-3, like
407-1 see 1964-156
408-1,-2 1965-151
413-1 1965-155
SG508K,+ 1965-151
SG511M,W 1965-151
SC515M,W 1965-153
SC521M,W 1965-153
SC526K 1965-153
SC541W 1965-154
SC542++ 1965-154
SC543 1965-154
SC561M,W 1965-154
573-7,-8, like 573-1 on TV22-151
575-7,-8 like 575-1 see TV22-143
581-1,-2 TV23-155
581-3,-4 TV23-155
583-1 through 583-6 TV24-133
584-1 through 584-7 TV24-133
585-3,-4 TV24-133
585-5 TV24-133
589-1 TV24-141
589-3,-4 TV24-141
711-6,-7,-8, like 711-1 see 1963-160
SC721 1965-157
SC724 1965-157
SC740 1965-158
SC741 1965-158
SC743 1965-158
SC744 1965-158
SC746 1965-158
SC748 1965-158
802-1,-2 1965-153
802-5 1965-157
803-1,-2 1965-154
803-5 1965-158

TENATRONICS
UM701 AU1-124
UA702 AU1-124
SM751 AU1-125

WESTINGHOUSE
H-75AC1E 1966-151
H-75AC2E 1966-151
H-91ACS1 1965-169
H-92ACS1 1965-169
H-94ACR1 like H-84ACR1 1963-173
H-97ACS1A like data on 1964-167
H-99AC1 1965-170
H-99AC2 1965-170
H-100AC1 1965-172
H-100AC2 1965-172
H-102ACS1 1965-172
H-102ACS2 1965-172
H-105ACS1 1965-171
H-106ACS1 1965-171
H-107ACS1 1965-171
H-110AC1, H-110AC2 } Use V-2537-1
H-111MF1 1965-172
H-111MF2 1965-172
H-112ACS1A, H-112ACS2A } Like V-2536
H-113ACS1 similar to V-2534-2
H-114AC1 1966-151
H-115ACS1, H-116ACS1, H-120ACS1, H-121ACS1, H-127ACS1, H-127ACS6 } Use V-2537-2
H-120ACS1 1965-169
H-121ACS1 1965-169
H-127ACS1 1966-151
H-127ACS6 1966-151
H-200T5 1966-147
H-201T5 1966-147
H-205L5 1966-147
H-210L5 1966-147
H-211L5 1966-147
H-215L5 1966-147
H-216L5 1966-147
CP-466 similar to V-2524-3

Westinghouse, Cont.
CR-500 1966-147
CR-501 1966-147
CR-515 1966-147
CR-520 1966-147
CR-521 1966-147
CR-525 1966-145
CR-526 1966-145
CR-560 uses V-2461-1 1965-164
CR-566 1966-148
H-707P6GPA 1966-150
H-834L4 like H-833L4 1963-168
H-853LN6 uses V-2428-6
H-854N6 uses V-2428-7
H-890P6GP 1965-159
H-893P8GP 1965-160
H-897P8 1965-160
H-898P8 1965-160
H-899P8 1965-160
H-902P6GP 1965-164
H-903P8GP 1965-162
H-904P8GP 1965-162
H-907P8 1965-163
H-910T5, H-911T5, H-912L5, H-913L5, H-916L5 } Use Chassis V-2424-1 see 1963-169
H-915N6 like H-850N6 1964-165
H-930L5, H-931L5, H-932L5, H-933L5, H-934L5 } Use Chassis V-2424-6 V-2424-7 like V-2424-1
H-935L5 1963-169
H-936L5 1963-169
H-953XP8 1966-148
H-954P6 1966-144
H-955P6 1966-144
H-956L6 1966-144
H-957L6 1966-144
H-957L6A 1966-145
H-957L6B 1966-145
H-958L6 1966-144
H-958L6A 1966-145
H-968PL 1966-149
H-970X 1966-146
H-972XL 1966-146
H-974XL 1966-146
H-F1030 1965-169
H-F1031 1965-169
H-F1033 1965-169
H-M1720 similar to V-2515-11
H-M1740 similar to V-2515-11
H-M1770, H-M1771, H-M1773 } Use V-2515-8 1964-172
H-M1780,A 1965-166
H-M1781 1965-166
H-M1783 1965-166
H-M1820, H-M1821, H-M1823 } Like V-2515-4 1964-172
H-M1840, H-M1842, H-M1843 } Use V-2515-12 1964-172
H-M1920, H-M1921, H-M1923, H-M1924 } Use V-2515-4 see 1964-172
V-2428-6, V-2428-7, V-2428-10 } See 1964-164
V-2446-1 through V-2446-6 TV23-159
V-2446-10 TV23-159
V-2455-1 1965-159
V-2455-3 1965-160
V-2455-4 1965-160
V-2455-5 1965-160
V-2456-1 1965-163
V-2461-1 1965-164
V-2461-2 1966-150
V-2463-1 1966-144
V-2463-2 1966-144
V-2463-3 1966-145
V-2463-4 1966-145
V-2463-5 1966-146
V-2463-6 1966-145
V-2466-1 1966-147
V-2466-7 1966-147
V-2472-1 TV23-166
V-2472-2 TV23-166
V-2474-1 through V-2474-13 TV24-147
V-2475-1 TV24-155
V-2475-4 TV24-155
V-2475-11 through V-2475-13 TV24-155
V-2478-1 TV24-163
V-2478-2 TV24-163
V-2484-1 TV25-157
V-2484-2 TV25-157
V-2484-4 TV25-157
V-2484-11 TV25-157

Westinghouse, Cont.
V-2484-12 TV25-157
V-2485-11 TV25-165
V-2515-11 1965-166
V-2515-12 like V-2515-4 1964-172
V-2524-1 1965-169
V-2524-2 1965-169
V-2524-3 1965-169
V-2526-1 1965-170
V-2534-2 1965-171
V-2536-1 1965-172
V-2537-1 1965-172
V-2537-2 1965-171
V-2537-3 1965-172
V-2538-2 1966-151
V-2539-1 1966-151
V-2580-1 1966-148
V-2585-1 1966-149
H-P3009 TV23-159
H-P3010,U TV23-159
H-P3011,U TV23-159
H-P3012,U TV23-159
H-P3014,U TV23-159
H-P3015 TV23-159
H-P3019,U TV23-159
H-P3020,U TV23-166
H-P3029 TV24-147
H-P3030 TV24-147
H-P3031 TV24-147
H-P3032 TV24-147
H-P3035 TV24-147
H-P3039 TV24-147
H-P3040 TV24-155
H-P3041 TV24-155
H-P3051 TV25-157
H-P3052 TV25-157
H-P3056 TV25-157
H-P3057 TV25-157
H-P3061 TV25-157
H-P3062 TV25-157
H-P3250 TV24-147
H-P3255 TV24-155
H-P3256 TV24-155
H-P3260 TV24-147
H-T3610,U use V-2417-5,-6
H-T3620 TV25-157
H-K3628 TV25-157
H-K3629 TV25-157
H-T3630, H-T3631, H-T3633 } Use V-2444-8 TV22-165
H-K3690 TV24-147
H-K3693 TV24-147
H-K3764 similar to V-2444 TV22-165
H-K3770,U Use V-2417-5
H-K3773,U
H-K3780 TV24-147
H-K3781 TV24-147
H-K3782 TV24-147
H-K3783 TV24-147
H-K3790 TV25-157
H-K3793 TV25-157
H-K3840 TV24-147
H-K3841 TV24-147
H-K3890,U Use V-2417-5
H-K3891,U
H-K3940 TV25-157
H-K3941 TV25-157
H-K4080 TV24-155
H-K4081 TV24-155
H-K4083 TV24-155
H-K4182 TV24-155
H-K4183 TV24-155
H-K4250 TV25-165
H-K4251 TV25-165
H-K4252 TV25-165
H-K4253 TV25-165
H-05240 TV24-147
H-P8000 TV24-163
H-P8001 TV24-163
H-P8003, H-P8004 } Use V-2478-1
H-P8020 TV24-163
H-P8021 TV24-163
H-P8023 see V-2478



THIS IS A MARK OF SUPREME PUBLICATIONS

ZENITH RADIO
1M30T20 TV25-171
3L03 1965-185
3L04 like 3L01
3L05 1965-185
4LT20Z2 1966-152
4LT21Z2 1966-152
5J13 1965-173
5L02 1965-173
5M02 1966-153 and 1966-156
5M03 1966-154
5M04 1966-156
5M05 1966-156
5M06 1966-155
5M13 1966-157
5N02 1966-158
5N03 1966-159
5N07 1966-160
5N09 1966-160
5N12 1966-161
5N13 1966-161
6KT50Z1 uses 40
6KT50Z8 like 40
6L05 1965-174
6LT45Z2 1965-178
6M06 1965-175
6N03 1966-162
6N05 1966-163
7L01 1965-186
7L02 1965-176
7L03 1965-177
7M03 1966-164
7M04 1965-177 and 1966-165
7MT44Z2 1966-166
7MT45Z8 1966-167
7MT45Z9 1966-167
8KT40Z2 1965-184
8LT25Z 1965-187
8LT40Z1 1965-180
8LT45Z1 1965-182
8LT45Z3 1965-182
8MT41Z2 1966-168
8MT50Z8 1966-169
8MT50Z9 1966-169
8MT51Z8 1966-170
8MT51Z9 1966-170
8MT52Z8 1966-171
8MT52Z9 1966-171
8NT04 1966-174
LP8 1964-186
10L23 1965-189
10LT20 1965-188
14L20 TV23-173
14L25 TV23-173
14L26 TV23-173
14M20 TV24-171
14M23 TV24-171
14M25 TV24-171
14M27 TV24-171
14M28 TV24-171
14M29 TV24-171
14M30 TV24-171
14M31 TV24-171
14N26 TV25-179
14N29 TV25-179
14N32 TV25-179
14N34 TV25-179
15L22 TV23-173
15L23 TV23-173
15L27 TV23-173
15M22 TV24-171
16L24 TV23-173
16M24 TV24-171
LP850 1965-185
SA55 1966-172
59 1966-171
LP875 1965-185
80 1966-170
MP890 1966-173
180 1966-169
285-500E1 1965-184
T305C,+ 1966-153
T315R,+ 1966-155
RM401 like MM401
500H-1 1965-180
500L 1965-182
M506C,+ 1966-156
M506C,+ 1966-156
N506C,+ 1966-159
M507B,+ 1966-154
M508B,+ 1966-156
N508B 1966-159
L509J,L,W 1965-173
N509C,+ 1966-161

Zenith, Continued
M511C,+ 1966-154
N511C,+ 1966-158
M512B,+ 1966-157
N512A 1966-161
L513C,+ 1965-173
N513B,+ 1966-158
L514C,+ 1965-173
N514C,+ 1966-158
N516J,+ 1966-160
N519C,+ 1966-160
L615G,L,W 1965-174
N615C,+ 1966-163
N624A,+ 1966-162
645L 1965-178
705M 1966-167
710M 1966-166
M722C,L,W 1965-175
M723A,C,W 1965-177
L724C,L,W 1965-176
L727C,L,W 1965-177
M729A 1966-164
M730W 1966-165
755M 1966-168
M860 1966-152
M875 1966-152
1290L,Y TV25-171
L1615B3 TV23-173
L1615L3 TV23-173
M1615L1,+ TV23-174
M1615++ TV24-171
L1620L3 TV23-173
L1620Y3 TV23-173
M1620Y+ TV24-171
M1620Y1,+ TV23-174
T1978++ TV24-171
T1978+5A TV25-179
T1981++ TV23-174
T1982++ TV24-173
T1982+5A TV25-179
T1984L5, T1988W, T1991R,W } Use Chassis 14M27
T1985+3 TV23-174
T1986+U TV24-172
T1987+ TV23-174
T1989+U+ TV24-172
T1990+3 TV23-174
T1996L uses 14K20
T1997+U TV24-172
M2000C++ TV24-171
N2000C+ TV25-179
M2001++ TV24-171
N2001L+ TV25-179
M2002F+ TV24-171
M2002L+ TV24-171
N2002W+ TV25-179
M2003++ TV24-171
L2004C3 TV23-173
L2004F3 TV23-173
L2004++ TV24-171
N2004+ see 14M27
L2005+3 TV23-173
M2005++ TV24-171
N2005+ see 14M28
L2009R3 TV23-173
L2009W3 TV23-173
L2012L TV23-173
L2012+3 TV23-173
M2012+ TV24-171
L2014+3 TV23-173
M2014++ TV24-171
T2015++ TV24-172
SA2017+ see 14M23
T2018++ TV24-172
T2020++ TV24-172
SA2022R,W TV23-174
T2023R3 TV23-174
T2023W3 TV23-174
T2024++ TV23-174
T2028W,+ TV24-172
T2028W3 TV23-174
T2029+ TV23-174
T2029+6 TV24-172
T2030+6 TV24-172
T2030M3 TV23-174
SA2031++ TV23-174
SA2032++ TV23-174
SA2032+U6 TV24-171
SA2034++ TV24-173
T2035WU4 TV24-173
T2036+U4 TV24-173
T2040R3 TV23-174
T2040W3 TV23-174
T2044+U4 TV24-173
T2045R3 TV23-174
T2045W3 TV23-174
T2045+U6 TV24-172
SA2054W3 TV23-174
SA2046+ see 14M23
T2055+3 TV23-174
T2070+3 TV23-174
T2080+3 TV23-174
T2081R3 TV23-174
T2081W3 TV23-174
L2109F3 TV23-173
L2109J3 TV23-173
M2109++ TV24-171
L2110+3 TV23-173
M2110+U TV24-171
N2109+, M2110+ } Use 14M28
L2127++ TV23-173

Zenith, Continued
M2127++ TV23-174
M2127++ TV24-171
L2150L3 TV23-173
L2150Y3 TV23-173
M2150++ TV23-174
M2150++ TV24-171
L2155+3 TV23-173
M2155++ TV23-174
M2155++ TV24-171
N2180L,LV TV25-179
N2185X,XV TV25-179
N2190++ TV25-179
H2200L1 uses 14L25
H2200LU,+ TV24-171
N2205L uses 14M28
N2205L+ TV25-179
L2210L3 TV23-173
M2210++ TV24-171
N2210+ uses 14M28
L2214L3 TV23-173
M2214LU TV24-171
N2214W see 14M28
L2231++ TV23-173
M2231++ TV23-174 and TV24-171
N2231+ use 14M27
L2240++ TV23-173
N2270W TV25-179
H2300LU,+ TV24-171
SL2420 uses 3L01
ML2420-3 1965-186
ML2601-3 1965-186
ML2602-3 1965-186
ML2603-3 1965-186
ML2608-3 1965-188
ML2610-3 1965-188
ML2636-3 1965-188
ML2670-3 1965-187
ML2675-3 1965-187
ML2685-3 1965-187
L2705++ TV23-173
M2705++ TV24-171
M2706++ TV24-171
N2705R,+, N2706F,+, N2708+ } See Chassis 14M23
SA2707W3 TV23-174
SA2707WU3 TV23-174
T2707W3 TV23-174
L2708++ TV23-173
M2708++ TV24-171
L2717+3 TV23-173
M2717++ TV24-171
N2717+ see 15M22
N2731++ through N2742R,W } See Chassis 14M23
M2733++ TV24-171
L2735++ TV23-173
M2735++ TV23-174
L2736++ TV23-173
M2736++ TV24-171
L2737++ TV23-173
M2737++ TV24-171
L2738++ TV23-173
M2738++ TV24-171
L2742+3 TV23-173
M2742+U TV24-171
L2746H3 TV23-173
L2748+3 TV23-173
L2756+3 TV23-173
MM2780WU4 TV24-172
MM2780W uses 16M24
RM2780WU4 TV24-172
RM2780W see 16M24
SA2780WU TV23-174
MM2781+U4 TV24-172
MM2781H,R see 16M24
RM2781+U4 TV24-172
MM2782MU4 TV24-172
RM2782MU4 TV24-173
ML2784R3 TV23-173
ML2784W3 TV23-173
MM2784++ TV24-171
RL2784+3 TV23-173
RM2784+U TV24-171
ML2785+3 TV23-173
ML2786-3 1965-189
ML2786W3 TV23-173
MM2785+U TV24-171
SA3080WD TV23-174
L3308++ TV23-173
L3311+3 TV23-173
M3311++ TV24-171
N3311W uses 15M22
N3331W, N3332H, N3333M } See Chassis 14M23
M3333+U TV24-172
L3340++ TV23-173
L3341H3 TV23-173
L3342H3 TV23-173
L3350R3 TV23-174
L3350W3 TV23-174
M3350WU TV24-171
M3352MU TV24-171
L3355H3 TV23-174
M3355HU TV24-171
7200-3 1965-188
7500-3 1965-187
S-60803 TV24-190
S-60804 TV24-190

HOW TO USE THIS INDEX

To find the material you need on every radio, TV, stereo, and auto set covered by all Supreme Publications manuals use the main Index section on pages 3 through 42, for models through 1964, and use the supplement Index section on pages 43-46, for 1965, 1966, and other additions. For further instructions and manual-volume chart see pages 2 and 3.

SUPREME TV & Radio Manuals

ORDER FORM

SIMPLIFIES TV REPAIRS

These giant TV manuals have complete circuits, needed alignment facts, printed boards, servicing hints, production changes, voltage charts, waveforms, and double-page schematics. Here are your authentic service instructions to help you do expert work quicker; and priced at only $3 per large annual manual.

COVER ALL POPULAR SETS

Here is your service data for faster, easier TV repairs. Lowest priced. Best by comparison. *Supreme* **TV** manuals have all needed service material on every popular TV set. Helpful, practical, factory-prepared data that will really make TV servicing easy for you. Benefit and save with these amazing values in service manuals. Only $3 per large volume. Used by 184,000 wise servicemen for faster repairs. Join them; begin to make TV repairs easily and quickly.

RADIO DIAGRAMS

Your best source for all needed RADIO diagrams and service data. Covers everything from most recent 1966 radios to pre-war old-timers; home radios, stereo, combinations, transistor portables, FM, auto sets. Only $2.50 for many volumes. Every manual has large schematics, all needed alignment facts, printed boards, voltages, trimmers, dial stringing, and hints. Volumes are big, 8½x11 inches, about 190 pages. See coupon at right for list of SUPREME popular radio service manuals ►

Simplified Radio Servicing by COMPARISON Method

Revolutionary different **COMPARISON** technique permits you to do expert work on all radio sets. Most repairs can be made without test equipment or with only a volt-ohmmeter. Many simple, point-to-point, cross-reference, circuit suggestions locate the faults instantly. Plan copyrighted. Covers every radio set — new and old models. This new servicing technique presented in handy manual form, size 8½ x 11 inches, 48 pages. Over 1,000 practical service hints. 26 large, trouble-shooting blueprints. Charts for circuit analysis. 114 tests using a 5c resistor. Developed by M. N. Beitman. New edition. Price only..... **$1.50**

TELEVISION SERVICING COURSE

Let this new course help you in TV servicing. Amazing bargain, complete, only $3, full price for all lessons. Giant in size, mammoth in scope, topics just like a $200.00 correspondence course. Lessons on picture-faults, circuits, adjustments, short-cuts, UHF, alignment facts, hints, antenna problems, trouble-shooting, test equipment, picture analysis. Special, only **$3**



RADIO MATHEMATICS

Explains arithmetic and simple algebra in connection with units, color code, meter scales, Ohm's law, alternating currents, ohmmeter testing, wattage rating, series and parallel connections, capacity, inductance, mixed circuits, vacuum tubes, curves, the decibel, etc., and has numerous examples. Only ..... **25¢**

Supreme Publications

Sold by All Leading Parts Jobbers

SUPREME PUBLICATIONS

1760 Balsam Rd., Highland Park, ILL.

★ Ship immediately Radio and TV manuals in quantities marked below.

Most-Often-Needed TELEVISION Manuals @ $3.

QUANTITY	VOLUME #TV	YEAR COVERED
	TV-25	1966
	TV-24	Late 1965
	TV-23	Early 1965
	TV-22	1964
	TV-21	1963
	TV-20	Late 1962
	TV-19	Early 1962
	TV-18	1961
	TV-17	1960
	TV-16	Late 1959
	TV-15	Early 1959
	TV-14	1958
	TV-13	Late 1957
	TV-12	Early 1957
	TV-11	1956
	TV-10	Late 1955
	TV-9	Early 1955
	TV-8	1954
	TV-5	1951

Most-Often-Needed RADIO Manuals @ $2.50

QUANTITY	VOLUME #R	YEAR COVERED
	R-26	1966
	R-25	1965
	24	1964
	23	1963
	22	1962
	21	1961
	20	1960
	19	1959
	18	1958
	17	1957
	16	1956
	15	1955
	14	1954
	13	1953
	12	1952
	11	1951
	10	1950
	9	1949
	8	1948
	7	1947
	6	1946
	5	1942
	4	1941
	3	1940
	1	1926-1938

Master INDEX to above manuals, 25¢

TRAINING BOOKS

___Auto Radio 1964-1965 Diagrams, $2.50
___Radio Servicing Course, new ed. 2.50
___Simplified Radio Servicing, 1.50
___Radio Mathematics (Self-help) .25
___Practical Radio & Electronics, 3.95
___Answer booklet to above course, .25
___Television Servicing Course, 3.00

☐ I am enclosing $..... Send postpaid.
☐ Send C.O.D. I am enclosing $...deposit.

Name: _____

Address: _____

_____

HOW TO USE RADIO-TV DATA

To be a repairman is to take on someone else's troubles. A completely dead radio set. Vertical sync bad, picture roll. Next job may be anything. Almost every fact needed for quick fault finding and adjustment can be presented in a diagram and additional service data. Here is help to permit you to know what is wrong, get promptly to the section at fault, test a couple of parts, finish the repair in minutes instead of wasting hours. Easy? Yes. Maybe you have never realized how to use factory released service data such as published by Supreme Publications.



Use service data to quickly disassemble and get at the chassis, find the section at fault with simple signal tracing tests (using the diagram, of course), and then a couple more measurements to diagnose the fault. Voltage values, scope patterns, pictures of printed boards included, all help. Use this material to select replacement parts needed. If alignment is required, you have instructions. Even factory recommended changes (used in later version of sets) included. This is the help you need for real speed-servicing, handling the tough dogs, breezing through usual repairs. This is the kind of service data you obtain from low-priced, factory authorized, SUPREME radio and TV manuals.

The engineers and technical editors at Supreme Publications are experienced in practical servicing and, because of this, succeeded in issuing service manuals that give you all technical help needed for fast repairs. Radio and TV material is separated in annual volumes and presented in easy-to-use form. This factory authorized material guarantees correctness. All important manufacturers included. Every popular set is to be found in one of the manuals. Radio material from the 30's through 1966. Television data from early 1951 through modern 1966 sets. Radio volumes include all types of sets, AM, FM, stereo, portables, and auto. Complete TV data including giant double-page diagrams. These large, 8-1/2 x 11", manuals are priced at only $2.50 and $3, postpaid.



No need to spend money every week for folders. Just once a year get a $3 TV volume and a $2.50 Radio manual for the whole year of coverage. If you ever need data for some rare radio or TV (perhaps of a TV made in limited quantities or an antique radio), Supreme Publications usually can find such material for you and the charge is one dollar. But you will find almost every model and chassis covered in easy-to-use, amazingly low-priced SUPREME manuals.

SUPREME PUBLICATIONS