MECHANICAL REPLACEMENT PARTS

ITEM	PART No.
Bracket (2) (Chassis Mounting)	31360
Bracket (Dial Lamp)	31974
Bracket (Retaining Cabinet)	31982
Bracket (2) (Rod Aerial Support) (563-MAY, 563-MAZ)	33196
Cabinet Back	32466
Cabinet Body and Fret	32464
Clamp, Spring (Retaining Clock Dust Cover)	33019
Clip (Retaining I.F.)	27780
Clip (Retaining Spindle)	2524
Clip (Retaining 4 pin socket)	21915
Clock Assembly (563-MA, 563-MAY)	31736
Clock Assembly (563-MAZ)	20894
Cover (Power Transformer)	20150
Dial Scale—Northern	32231
Southern	32232
Drive Bearing	27529
Drive Cord	9576/21
Drive Drum Assembly	31381
Drive Spindle	31981
Drive Spring	1741
Dust Cover (Clock)	33018
Fret Cloth Code No.	212043
Gasket (Front Panel to Cabinet)	31972
Grommet (Power Cable) Code No.	389005
Knobs, Clock:	
Alarm	33134
Slumber	33135
Hands Set	33136
Radio, Alarm, OFF-ON	33137

ITEM	PART No.
Knob (Radio)	31984
Lamp Holder	4194
Light Mask	31998
Mounting Screw (Oscillator Coil)	31373
Nameplate	27748
Nut (Retaining Cabinet Back)	26523
Nut (Retaining Volume Control)	5926
Plate (Large, Underneath Cabinet)	31985
Plate (Small, Underneath Cabinet)	31986
Pointer Assembly	31976
Pulley Bracket Assembly	31975
Pulley, Drive Cord	31365
Pulley Post (Pulley No. 31365)	31366
Socket, 4 pin (Clock) (563-MA, 563-MAY)	28313
Socket, 5 pin (Clock) (563-MAZ) Code No.	793062
Socket, valve 7 pin Code No.	794576
Socket, valve 9 pin Code No.	793037
Spacer (Dust Cover Mounting)	33141
Terminal Panel Assembly, 2 way	32822
Terminal Panel Assembly, 3 way	32824
Terminal Panel Assembly, 4 way	32823
Terminal Panel Assembly, 5 way	32836
Test Outlet	27685
Volume Control Cable	34363
Washer (Oscillator Coil Mounting)	7910

When ordering, always quote the above part numbers or code numbers, and in the case of coloured parts, such as cabinets, knobs, etc., the colour plus the part number.