



Model 4-F-227 (5408 Chassis)

Diag No	Part No	DESCRIPTION	Diag No	Part No	DESCRIPTION
C1	22-200	TWO GANG VARIABLE	1	5 5100	INT. COIL & SHIELD ASSEMBLY
C2	250	.05 MFD	2	5 4662	OSCILLATOR COIL ASSEMBLY
C3	199	.05 MFD	3	95-219	1ST. I.F. TRANSFORMER
C4	248	.005 MFD	4	95-220	2ND. I.F. TRANSFORMER
C5	212	.05 MFD	5		SPEAKER TRANS. (ON SPEAKER)
C6	162	.001 MFD			
C7	227	.05 MFD			
C8	147	.0005 MFD			
C9	185	.05 MFD			
C10	492	.002 MFD			
R1	65-593	47 M OHM	A		1ST. I.F. TRANSFORMER PRIMARY
R2	638	5600 OHM	B		1ST. I.F. TRANSFORMER SECONDARY
R3	647	59 M OHM	C		2ND. I.F. TRANSFORMER PRIMARY
R4	271	1 MEG OHM	D		2ND. I.F. TRANSFORMER SECONDARY
R5	650	500 M OHM	E		BROADCAST OSCILLATOR (ON GANG)
R6	545	1 MEG OHM VOLUME CONTROL	F		BROADCAST OSCILLATOR (ON GANG)
R7	441	1 MEG OHM	G		22-519 OSCILLATOR PADDER.
R8	637	330 M OHM			
R9	604	.04 OHM (WIREWOUND)			
			MODEL		SPEAKER
			4F227		10-209-6"

I.F. FREQUENCY 456 K.C.  
 4 TUBE BATTERY SUPERHETERODYNE  
 CHASSIS NO 5408  
 ZENITH RADIO CORPORATION